

AIR CONDITIONER INDOOR UNIT Cassette type

⚠ CAUTION

R410A REFRIGERANT


This Air Conditioner contains and operates with refrigerant R410A.

THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL.

Refer to Commonwealth, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.

INSTALLATION MANUAL

For authorized service personnel only.



Contents

| | | | |
|--|---|--|----|
| 1. SAFETY PRECAUTIONS..... | 2 | 7. REMOTE CONTROLLER SETTING | 10 |
| 2. ABOUT THE UNIT | 2 | 7.1. Installing the remote controller | |
| 2.1. Precautions for using R410A refrigerant | | 7.2. Setting the dip switches | |
| 2.2. Special tools for R410A | | 8. DECORATION PANEL INSTALLATION | 11 |
| 2.3. Accessories | | 9. FUNCTION SETTING | 11 |
| 2.4. Optional parts | | 9.1. Turning on the power | |
| 3. INSTALLATION WORK | 3 | 9.2. Function setting | |
| 3.1. Selecting an installation location | | 9.3. Setting the room temperature detection location | |
| 3.2. Installation dimension | | 10. SELECTING THE REMOTE CONTROL UNIT | |
| 3.3. Installation the unit | | SIGNAL CODE | 14 |
| 4. PIPE INSTALLATION | 5 | 11. TEST RUN | 14 |
| 4.1. Selecting the pipe material | | 12. CHECK LIST | 14 |
| 4.2. Pipe requirement | | 13. ERROR CODES | 15 |
| 4.3. Flare connection (pipe connection) | | 14. SPECIAL INSTALLATION METHODS | 16 |
| 4.4. Installing heat insulation | | 14.1. Group control system | |
| 5. INSTALLING DRAIN PIPES | 7 | 14.2. Dual remote controllers | |
| 6. ELECTRICAL WIRING | 8 | 15. CUSTOMER GUIDANCE | 16 |
| 6.1. Electrical requirement | | | |
| 6.2. Wiring method | | | |

1. SAFETY PRECAUTIONS

- Be sure to read this Manual thoroughly before installation.
- The warnings and precautions indicated in this Manual contain important information pertaining to your safety. Be sure to observe them.
- Hand this Manual, together with the Operating Manual, to the customer. Request the customer to keep them on hand for future use, such as for relocating or repairing the unit.

WARNING

This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.

- Request your dealer or a professional installer to install the indoor unit in accordance with this Installation Manual. An improperly installed unit can cause serious accidents such as water leakage, electric shock, or fire. If the indoor unit is installed in disregard of the instructions in the Installation Manual, it will void the manufacturer's warranty.
- Do not turn ON the power until all work has been completed. Turning ON the power before the work is completed can cause serious accidents such as electric shock or fire.
- If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Installation work must be performed in accordance with national wiring standards by authorized personnel only.

CAUTION

This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

2. ABOUT THE UNIT

2.1. Precautions for using R410A refrigerant

WARNING

- Do not introduce any substance other than the prescribed refrigerant into the refrigeration cycle. If air enters the refrigeration cycle, the pressure in the refrigeration cycle will become abnormally high and cause the piping to rupture.
- If there is a refrigerant leak, make sure that it does not exceed the concentration limit. If a refrigerant leak exceeds the concentration limit, it can lead to accidents such as oxygen starvation.
- Do not touch refrigerant that has leaked from the refrigerant pipe connections or other area. Touching the refrigerant directly can cause frostbite.
- If a refrigerant leak occurs during operation, immediately vacate the premises and thoroughly ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.

2.2. Special tools for R410A

WARNING



- To install a unit that uses R410A refrigerant, use dedicated tools and piping materials that have been manufactured specifically for R410A use. Because the pressure of R410A refrigerant is approximately 1.6 times higher than the R22, failure to use dedicated piping material or improper installation can cause rupture or injury. Furthermore, it can cause serious accidents such as water leakage, electric shock, or fire.












| Tool name | Changes |
|----------------------|--|
| Gauge manifold | The pressure in the refrigerant system is extremely high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended to use a gauge manifold with a high pressure display range of -0.1 to 5.3 MPa and a low pressure display range of -0.1 to 3.8 MPa. |
| Charging hose | To increase pressure resistance, the hose material and base size were changed. (The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.) |
| Vacuum pump | A conventional vacuum pump can be used by installing a vacuum pump adapter. Be sure that the pump oil does not backflow into the system. Use one capable for vacuum suction of -100.7 kPa (5 torr, -755 mmHg). |
| Gas leakage detector | Special gas leakage detector for R410A refrigerant. |

2.3. Accessories

WARNING





- For installation purposes, be sure to use the parts supplied by the manufacturer or other prescribed parts. The use of non-prescribed parts can cause serious accidents such as the unit falling, water leakage, electric shock, or fire.
- The following installation parts are furnished. Use them as required.
- Keep the Installation Manual in a safe place and do not discard any other accessories until the installation work has been completed.



| Name and Shape | Q'ty | Description |
|---|------|----------------------------|
| Template (Carton top)  | 1 | For installing indoor unit |
| Washer  | 8 | For installing indoor unit |

| | | |
|--|---|---|
| Coupler heat insulation (Large)  | 1 | For indoor side pipe joint |
| Coupler heat insulation (Small)  | 1 | For indoor side pipe joint |
| Insulation  | 1 | For installing drain pipe |
| Drain hose  | 1 | For installing drain pipe |
| Hose band  | 1 | For installing drain pipe |
| Drain hose heat insulation  | 1 | For installing drain pipe |
| Binder (Large)  | 3 | For electrical wiring |
| Binder (Small)  | 1 | For electrical wiring (Wired remote controller) |
| Wired remote controller  | 1 | |
| Remote controller cable(*1)  | 1 | For connecting the remote controller |
| Screw (M4 × 16)  | 2 | For installing the remote controller |

(*1) This part is not furnished for AUT* series

2.4. Optional parts

| Exterior | Parts name | Model No. | Summary |
|---|--|------------|---|
|  | Wired remote controller | UTB-*UD | Unit control is performed by wired remote controller |
|  | Air outlet shutter plate | UTR-YDZC | Install the plate at outlet when carrying out 3-way direction operation |
|  | Wireless remote controller and I, R, receiver unit | UTY-LRH*A1 | Unit control is performed by wireless remote controller |
|  | Wide panel | UTG-AGYA-W | Wide panel hides the gap between the ceiling hole and the Decoration panel. |

| | | | |
|---|----------------------------------|---|--|
|  | Panel spacer | UTG-BGYA-W | Installation in a space of 56 mm or greater is possible by using panel spacer when the height behind the ceiling is low. |
|  | Insulation kit for high humidity | UTZ-KXGA (MODEL : 30 ~ 54) UTZ-KXGB (MODEL : 24) | Install when the under roof condition is expected to be the humidity of over 80 % and the temperature of over 30 °C. |

3. INSTALLATION WORK

Especially, the installation place is very important for the split type air conditioner because it is very difficult to move from place to place after the first installation.

3.1. Selecting an installation location

Decide the mounting position together with the customer as follows.

WARNING

- Select installation locations that can properly support the weight of the indoor unit. Install the units securely so that they do not topple or fall.


CAUTION


- Do not install the indoor unit in the following areas:
 - Area with high salt content, such as at the seaside. It will deteriorate metal parts, causing the parts to fall or the unit to leak water.
 - Area filled with mineral oil or containing a large amount of splashed oil or steam, such as a kitchen. It will deteriorate plastic parts, causing the parts to fall or the unit to leak water.
 - Area that generates substances that adversely affect the equipment, such as sulfuric gas, chlorine gas, acid, or alkali. It will cause the copper pipes and brazed joints to corrode, which can cause refrigerant leakage.
 - Area that can cause combustible gas to leak, contains suspended carbon fibers or flammable dust, or volatile inflammables such as paint thinner or gasoline. If gas leaks and settles around the unit, it can cause a fire.
 - Area where animals may urinate on the unit or ammonia may be generated.
- Do not install where there is the danger of combustible gas leakage.
- Do not install the unit near a source of heat, steam, or flammable gas.
- Install the indoor unit, outdoor unit, power supply cable, transmission cable, and remote control cable at least 1 m away from a television or radio receivers. The purpose of this is to prevent TV reception interference or radio noise. (Even if they are installed more than 1 m apart, you could still receive noise under some signal conditions.)
- If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

- (2) Setting the positions of hanging bolt and ceiling opening.
 - Use an installation template (packaging top surface) to set the positions of the hanging bolt and ceiling opening and drill holes.
- (3) Hanging structure.
 - Select a strong structure for the hanging location.
 - If necessary, reinforce the hanging bolt with quake proof columnar support material to prevent shaking.
 - Use hanging bolts of M8-M10.

3.3.2. Body installation


- (1) Install the attached washer and nut (prepared on site) onto the hanging bolt.
- (2) Hook the body onto the hanging bolt.
- (3) Adjust the dimensions of the ceiling surface from the body. After installing the decorative panel, you can make fine adjustment of the height of the body. For details, refer to the Installation Manual of the decorative panel.

|  WARNING |
|---|
| <ul style="list-style-type: none"> • Perform final tightening by tightening the double nut firmly. |
| <ul style="list-style-type: none"> • Be sure to install the body horizontally and adjust the height below the body and the ceiling surface properly. |



3.3.3. Leveling

Using a level, or vinyl hose filled with water, fine adjust so that the body is level.



4. PIPE INSTALLATION

CAUTION

- Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant R410A models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.
- While welding the pipes, be sure to blow dry nitrogen gas through them.

4.1. Selecting the pipe material

CAUTION

- Do not use existing pipes.
- Use pipes that have clean external and internal sides without any contamination which may cause trouble during use, such as sulfur, oxide, dust, cutting waste, oil, or water.
- It is necessary to use seamless copper pipes. Material : Phosphor deoxidized seamless copper pipes. It is desirable that the amount of residual oil is less than 40 mg/10 m.
- Do not use copper pipes that have a collapsed, deformed, or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants.
- Improper pipe selection will degrade performance. As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials.

- Thicknesses of copper pipes used with R410A are as shown in the table.
- Never use copper pipes thinner than those indicated in the table even if they are available on the market.

Thicknesses of Annealed Copper Pipes (R410A)

| Pipe outside diameter [mm (in.)] | Thickness [mm] |
|----------------------------------|----------------|
| 6.35 (1/4) | 0.80 |
| 9.52 (3/8) | 0.80 |
| 12.70 (1/2) | 0.80 |
| 15.88 (5/8) | 1.00 |
| 19.05 (3/4) | 1.20 |

4.2. Pipe requirement

⚠ CAUTION

- Refer to the Installation Manual of the outdoor unit for description of the length of connecting pipe or for difference of its elevation.

| Diameter [mm (in.)] | Liquid | 9.52 (3/8) |
|---------------------|--------|-------------|
| | Gas | 15.88 (5/8) |

- Use pipe with water-resistant heat insulation.


⚠ CAUTION

- Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks. Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only)
- In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70 %, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80 %, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80 %, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

4.3. Flare connection (pipe connection)


4.3.1. Flaring

- Use special pipe cutter and flare tool exclusive for R410A.
- Cut the connection pipe to the necessary length with a pipe cutter.
 - Hold the pipe downward so that cuttings will not enter the pipe and remove any burrs.
 - Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional flare tool. Leakage of refrigerant may result if other flare nuts are used.
 - Protect the pipes by pinching them or with tape to prevent dust, dirt, or water from entering the pipes.



| Pipe outside diameter [mm (in.)] | Dimension A [mm] Flare tool for R410A, clutch type | Dimension B _{0.4} [mm] |
|----------------------------------|---|---------------------------------|
| | 0 to 0.5 | |
| 6.35 (1/4) | | 9.1 |
| 9.52 (3/8) | | 13.2 |
| 12.70 (1/2) | | 16.6 |
| 15.88 (5/8) | | 19.7 |
| 19.05 (3/4) | | 24.0 |

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.



| Pipe outside diameter [mm (in.)] | Width across flats of Flare nut [mm] |
|----------------------------------|--------------------------------------|
| 6.35 (1/4) | 17 |
| 9.52 (3/8) | 22 |
| 12.70 (1/2) | 26 |
| 15.88 (5/8) | 29 |
| 19.05 (3/4) | 36 |

4.3.2 Bending pipes

- If pipes are shaped by hand, be careful not to collapse them.
- Do not bend the pipes in an angle more than 90°.
- When pipes are repeatedly bend or stretched, the material will harden, making it difficult to bend or stretch them any more.
- Do not bend or stretch the pipes more than three times.

⚠ CAUTION


- To prevent breaking of the pipe, avoid sharp bends.
- If the pipe is bent repeatedly at the same place, it will break.

4.3.3. Pipe connection

⚠ CAUTION

- Be sure to apply the pipe against the port on the indoor unit and the outdoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.
- Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.
- Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.


- Detach the caps and plugs from the pipes.
- Center the pipe against the port on the indoor unit, and then turn the flare nut by hand.



- (3) When the flare nut is tightened properly by your hand, hold the body side coupling with a separate spanner, then tighten with a torque wrench. (See the table below for the flare nut tightening torques.)

CAUTION

- Hold the torque wrench at its grip, keeping it in the right angle with the pipe, in order to tighten the flare nut correctly.
- Tighten the flare nuts with a torque wrench using the specified tightening method. Otherwise, the flare nuts could break after a prolonged period, causing refrigerant to leak and generate a hazardous gas if the refrigerant comes into contact with a flame.




| Flare nut [mm (in.)] | Tightening torque [N·m (kgf·cm)] |
|----------------------|----------------------------------|
| 6.35 (1/4) dia. | 16 to 18 (160 to 180) |
| 9.52 (3/8) dia. | 32 to 42 (320 to 420) |
| 12.70 (1/2) dia. | 49 to 61 (490 to 610) |
| 15.88 (5/8) dia. | 63 to 75 (630 to 750) |
| 19.05 (3/4) dia. | 90 to 110 (900 to 1,100) |

4.4. Installing heat insulation

CAUTION

- After checking for gas leaks (refer to the Installation Manual of the outdoor unit), perform this section.
- Install heat insulation around both the large (gas) and small (liquid) pipes. Failure to do so may cause water leaks.

After checking for gas leaks, insulate by wrapping insulation around the two parts (gas and liquid) of the indoor unit coupling, using the Coupler heat insulation. After installing the Coupler heat insulation, wrap both ends with vinyl tape so that there is no gap.



CAUTION


- Must fit tightly against body without any gap.

5. INSTALLING DRAIN PIPES

Note

Install the drain pipe.

- Install the drain pipe with downward gradient (1/50 to 1/100) and so there are no rises or traps in the pipe.
- Use general hard polyvinyl chloride pipe (VP25) [outside diameter 32 mm (1-1/4")] and connect it with adhesive (polyvinyl chloride) so that there is no leakage.
- When the pipe is long, install supporters.
- Do not perform air bleeding.
- Always heat insulate the indoor side of the drain pipe.
- When desiring a high drain pipe height, raise it up to 850 mm or less from the ceiling within a range of 150 mm from the body. A rise dimension over this range will cause leakage.
- Set up the entire piping lines at the position 100 mm lower than the main body drain port, and use the piping lines VP30 or more with the descending inclination to 1/100 or more.



WARNING



- Do not insert the drain piping into the sewer where sulfurous gas occurs. (Heat exchange erosion may occur.)
- Insulate the parts properly so that water will not drip from the connection parts.
- Check for proper drainage after the construction by using the visible portion of transparent drain port and the drain piping final outlet on the body.

CAUTION

- Do not apply adhesive agent on the drain port of the body. (Use the attached drain hose and connect the drain piping.)

Working procedure


- (1) Install the attached drain hose to the drain port of the body.
Attach hose band on top of the drain hose. Tighten the band for about 5mm to 10mm.
- (2) Use vinyl adhesive agent to glue the drain piping (PVC pipe VP25) which is prepared on site or elbow socket.
(Apply color adhesive agent evenly until the gauge line and seal.)
- (3) Check the drainage. (See Note)
- (4) Install the heat insulation.
- (5) Use the attached heat insulation to insulate the drain port and band parts of the body.



Note

Check for drainage

Pour about 1 liter of water from the position shown in the diagram or from the airflow outlet to the dew tray. Check for any abnormalities such as strange noises and whether the drain pump functions normally.



6. ELECTRICAL WIRING

⚠ WARNING

- Electrical work must be performed in accordance with this Manual by a person certified under the national or regional regulations. Be sure to use a dedicated circuit for the unit.
An insufficient power supply circuit or improperly performed electrical work can cause serious accidents such as electric shock or fire.
- Before starting work, check that power is not being supplied to the indoor unit and outdoor unit.
- Use the included connection cables and power cables or ones specified by the manufacturer. Improper connections, insufficient insulation, or exceeding the allowable current can cause electric shock or fire.
- For wiring, use the prescribed type of wires, connect them securely, making sure that there are no external forces of the wires applied to the terminal connections. Improperly connected or secured wires can cause serious accidents such as overheating the terminals, electric shock, or fire.
- Do not modify the power cables, use extension cables, or use any branches in the wiring. Improper connections, insufficient insulation, or exceeding the allowable current can cause electric shock or fire.
- Match the terminal block numbers and connection cable colors with those of the outdoor unit. Erroneous wiring may cause burning of the electric parts.
- Securely connect the connection cables to the terminal blocks. In addition, secure the cables with wiring holders. Improper connections, either in the wiring or at the ends of the wiring, can cause a malfunction, electric shock, or fire.
- Always fasten the outside covering of the connection cable with the cable clamp. (If the insulator is chafed, electric leakage may occur.)
- Securely install the electrical box cover on the unit.
An improperly installed electrical box cover can cause serious accidents such as electric shock or fire through exposure to dust or water.
- Install sleeves into any holes made in the walls for wiring. Otherwise, a short circuit could result.
- Install a ground leakage breaker. In addition, install the ground leakage breaker so that the entire AC main power supply is cut off at the same time. Otherwise, electric shock or fire could result.
- Install a ground leakage breaker.
If a ground leakage breaker is not installed, it may cause electric shock or fire.
- Always connect the ground wire.
Improper grounding work can cause electric shocks.
- Install the remote controller wires so as not to be direct touched with your hand.

6.1. Electrical requirement

| Connection cable (mm ²) | |
|-------------------------------------|------|
| MAX. | MIN. |
| 2.5 | 1.5 |

- Use conformed cable with Type 245 IEC57.
- Perform all electrical work according to the standard.
- Install circuit breakers, which have the terminal spacing of more than 3 mm, in a place of near the indoor unit and outdoor unit.


⚠ CAUTION

- Be sure to execute the electrical work according to the Laws of each country and the Installation Instructions. In addition, be sure to set as exclusive line and use the rated voltage and circuit breaker.


6.2. Wiring method

6.2.1. Connection diagrams

- Connection cable (to outdoor unit)




- Wired remote controller cable



*Ground the remote controller if it has a ground wire.

6.2.2. Connection cable preparation


- Keep the earth wire longer than the other wires.



- Use a 4-core wire cable.

How to connect wiring to the terminals. (For strand wiring)

- (1) Use crimp-type terminals with insulating sleeves as shown in the figure below to connect to the terminal block.
- (2) Securely crimp the crimp-type terminals to the wires using an appropriate tool so that the wires do not come loose.




- (3) Use the specified wires, connect them securely, and fasten them so that there is no stress placed on the terminals.
- (4) Use an appropriate screwdriver to tighten the terminal screws. Do not use a screwdriver that is too small, otherwise, the screw heads may be damaged and prevent the screws from being properly tightened.
- (5) Do not tighten the terminal screws too much, otherwise, the screws may break.
- (6) See the table below for the terminal screw tightening torques.

⚠ WARNING

- Use crimp-type terminals and tighten the terminal screws to the specified torques, otherwise, abnormal overheating may be produced and possibly cause serious damage inside the unit.


Tightening torque [N·m (kgf·cm)]

| | |
|----------|-----------------------|
| M4 screw | 1.2 to 1.8 (12 to 18) |
| M5 screw | 2.0 to 3.0 (20 to 30) |




6.2.3. Wiring procedure

- (1) Remove the control box cover and install each connection wire. Please firmly tighten connection cable and remote control cable with the attached binder.




- ※ Remove the control box cover and install each connection wire. Please firmly tighten connection cable and remote control cable with the attached binder.
- ※ Cure the wiring connecting port and remote control connecting port with paste or heat insulation so that insects or dust will not enter the unit




Detail (a)

Thread the binder through the hole and tighten securely



Detail (b)

(2) Please fix the connection cable with cable clamp. And then install the wire cover with screws.



(3) Install control box cover.

CAUTION


- Do not bundle the remote controller cable, or wire the remote controller cable in parallel, with the indoor unit connection wire (to the outdoor unit) and the power supply cable. It may cause erroneous operation.

7. REMOTE CONTROLLER SETTING

CAUTION

- In order to detect the room temperature correctly when using the temperature sensor of the remote controller, do not install the remote controller in a place where it will be exposed to direct sunlight or directly below the air outlet of the indoor unit.
- Do not touch the remote controller PC board and PC board parts directly with your hands.
- Install the remote controller wires so as not to be direct touched with your hand.
- Do not wire the remote controller cable and the bus wire together with or parallel to the connection cables, transmission cables, and power supply cables of the indoor and outdoor units. It may cause erroneous operation.
- When installing the bus wire near a source of electromagnetic waves, use shielded wire.
- Do not set the DIP switches, either on the air conditioner or the remote controller, in any way other than indicated in this manual or the manual that is supplied with the air conditioner. Doing so may result in an accident.

Temperature sensor




7.1. Installing the remote controller

Open the operation panel on the front of the remote controller, remove the two screws indicated in the following figure, and then remove the front case of the remote controller.


When installing the remote controller, remove the connector from the front case. The wires may break if the connector is not removed and the front case hangs down.

When installing the front case, connect the connector to the front case.



When remote controller cable is embedded



- Embed the remote controller cable and box.
- Pass the remote controller cable through the hole in the rear case and connect the remote controller cable to the remote controller terminal blocks specified in figure.
- Clamp the remote controller cable sheath with the binder as shown in figure.
- Cut off the excess binder.
- Install the rear case to the wall, box, etc., with two screws figure.



CAUTION

- When connecting the remote controller wires, do not overtighten the screws.


[Example]



7.2. Setting the dip switches

Set the remote controller DIP switches.

[Example]



| | NO. | SW state | | Detail |
|--------------|-----|--|------------|---|
| | | OFF | ON | |
| DIP switch 1 | 1 | ◆ | | Cannot be used. (Do not change) |
| | 2 | ◆ | | Dual remote controller setting * Refer to 14.2. Dual remote controllers |
| | 3 | Follow the selection in FUNCTION SETTING | Invalidity | Filter reset operation and filter display |
| | 4 | ◆ | | Cannot be used. (Do not change) |
| | 5 | ◆ | | Cannot be used. (Do not change) |
| | 6 | ◆ Invalidity | Validity | Memory backup setting * Set to ON to use batteries for the memory backup. If batteries are not used, all of the settings stored in memory will be deleted if there is a power failure. |

(◆ : Factory setting)

8. DECORATION PANEL INSTALLATION

- Installation according to the Installation instruction sheet Decoration panel.
- Be sure to confirm there is no gap between the panel and main unit after installing the Decoration panel.

9. FUNCTION SETTING

CAUTION

- Confirm whether the wiring work for outdoor unit has been finished.
- Confirm whether the cover for electric control box on the outdoor unit is close.

9.1. Turning on the power

- (1) Check the remote controller wiring and DIP switch settings.
- (2) Install the front case.
When installing the front case, connect the connector to the front case.
- (3) Check the indoor and outdoor unit wiring and circuit board switch settings, and then turn on the indoor and outdoor units. After "BL" has flashed on the set temperature display for several seconds, the clock display will appear in the center of the remote controller display.
The clock display will appear in the center of the remote controller display.




9.2. Function setting


- This procedure changes to the function settings used to control the indoor unit according to the installation conditions. Incorrect settings can cause the indoor unit malfunction.
- After the power is turned on, perform the "FUNCTION SETTING" according to the installation conditions using the remote controller.
- The settings may be selected between the following two: Function Number or Setting Value.
- Settings will not be changed if invalid numbers or setting values are selected.

Operation Method


- (1) Press the set temperature buttons (V) (A) and fan control button simultaneously for more than 5 seconds to enter the function setting mode.




- (2) Press the SET BACK button to select the indoor unit number.



- (3) Press the set time buttons to select the function number.



- (4) Press the set temperature buttons (▼) (▲) to select the setting value.
The display flashes as shown to the right during setting value selection.



- (5) Press the TIMER SET button to confirm the setting. Press the TIMER SET button for a few seconds until the setting value stops flashing.
If the setting value display changes or if “-” is displayed when the flashing stops, the setting value has not been set correctly. (An invalid setting value may have been selected for the indoor unit.)



Setting value

- (6) Repeat steps 2 to 5 to perform additional settings. Press the set temperature buttons (▼) (▲) and fan control button simultaneously again for more than 5 seconds to cancel the function setting mode. In addition, the function setting mode will be automatically canceled after 1 minute if no operation is performed.

- (7) After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.

Setting the Ceiling Height

- Select the setting values in the table below according to the height of the ceiling. (The unit is factory-set to “00”.)


| Setting Description [m] | Function Number | Setting Value |
|----------------------------------|-----------------|---------------|
| Standard 3.2 (2.7 to 4.0) | 20 | 00 |
| Low ceiling 2.5 (2.5 to 2.7) | | 01 |
| High ceiling 5.0 (4.0 to 5.0) | | 02 |

The ceiling height values are for the 4-way outlet.
Do not change this setting in the 3-way outlet mode.

Setting the vertical direction adjusting scope

- To prevent from draft, we recommend using “upward mode”. (The unit is factory-set to “00”.)

| Setting Description | Function Number | Setting Value |
|---------------------|-----------------|---------------|
| Standard | 23 | 00 |
| Upward | | 01 |



Setting the Outlet Directions

- Select the setting values in the table below for using a 3-way outlet. (The unit is factory-set to “00”.)

| Setting Description | Function Number | Setting Value |
|---------------------|-----------------|---------------|
| 4-way | 22 | 00 |
| 3-way | | 01 |

Setting the Filter Sign

- The indoor unit has a sign to inform the user that it is time to clean the filter.
- Select the time setting for the filter sign display interval in the table below according to the amount of dust or debris in the room. (The unit is factory-set to “00”.)
- If you do not wish the filter sign to be displayed, select the setting value for “No indication”.

| Setting Description | Function Number | Setting Value |
|---------------------------------|-----------------|---------------|
| Standard (2,500 hours) | 11 | 00 |
| Long interval (4,400 hours) | | 01 |
| Short interval (1,250 hours) | | 02 |
| No indication | | 03 |

Setting the Cooler Room Temperature Correction

- Depending on the installed environment, the room temperature sensor may require a correction. The settings may be selected as shown in the table below. (The unit is factory-set to “00”.)

| Setting Description | Function Number | Setting Value |
|---------------------|-----------------|---------------|
| Standard | 30 | 00 |
| Lower control | | 01 |

Setting the Heater Room Temperature Correction

- Depending on the installed environment, the room temperature sensor may require a correction. The settings may be changed as shown in the table below. (The unit is factory-set to “00”.)

| Setting Description | Function Number | Setting Value |
|-------------------------|-----------------|---------------|
| Standard | 31 | 00 |
| Lower control | | 01 |
| Slightly warmer control | | 02 |
| Warmer control | | 03 |

Setting Other Functions

- The following settings are also possible, depending on the operating conditions. (The unit is factory-set to “00”.)

Auto Restart

| Setting Description | Function Number | Setting Value |
|---------------------|-----------------|---------------|
| Yes | 40 | 00 |
| No | | 01 |

Indoor Room Temperature Sensor Switching Function (Wired remote controller only)

| Setting Description | Function Number | Setting Value |
|---------------------|-----------------|---------------|
| No | 42 | 00 |
| Yes | | 01 |

- If setting value is “00”, room temperature is controlled by the indoor unit temperature sensor.
- If setting value is “01”, room temperature is controlled by either indoor unit temperature sensor or remote control unit sensor.

Setting record

- Record any changes to the settings in the following table.

| Setting | Setting Value |
|---|---------------|
| Ceiling height | |
| Vertical direction adjusting scope | |
| Outlet directions | |
| Filter sign | |
| Cooler room temperature correction | |
| Heater room temperature correction | |
| Auto restart | |
| Indoor room temperature sensor switching function | |

After completing the FUNCTION SETTING, be sure to turn off the power and turn it on again.


9.3. Setting the room temperature detection location

The detection location of the room temperature can be selected from the following two examples. Choose the detection location that is best for the installation location.

A. Indoor unit setting (factory setting)

The room temperature is detected by the indoor unit temperature sensor.


- When the THERMO SENSOR button is pressed, the lock display flashes because the function is locked at the factory.



B. Indoor unit/remote controller setting (room temperature sensor selection)

The temperature sensor of the indoor unit or the remote controller can be used to detect the room temperature.

- Enable the room temperature sensor selection in FUNCTION SETTING, which will be described later.
- Press the THERMO SENSOR button for 5 seconds or more to select the temperature sensor of the indoor unit or the remote controller.



NOTE

If the function to change the temperature sensor is used as shown in examples A (other than example B), be sure to lock the detection location.


If the function is locked, the lock display **C₀** will flash when the THERMO SENSOR button is pressed.

10. SELECTING THE REMOTE CONTROL UNIT SIGNAL CODE

[When using the wireless remote controller] (Option) Switching remote control unit signal codes

- Confirm the setting of the remote control unit signal code and the printed circuit board setting.
If these are not confirmed, the remote control unit cannot be used to operate for the air conditioner.

| Jumper wire | | Remote control unit signal code |
|-------------|------------|---------------------------------|
| JM1 | JM2 | |
| Connect | Connect | A (Primary setting) |
| Disconnect | Connect | B |
| Connect | Disconnect | C |
| Disconnect | Disconnect | D |



11. TEST RUN


CHECK ITEMS

- Is operation of each button on the remote control unit normal?
 - Does each lamp light normally?
 - Do not air flow direction louvers operate normally?
 - Is the drain normal?
 - Is there any abnormal noise and vibration during operation?
- Do not operate the air conditioner in the running state for a long time.

[Operation method]

- For the operation method, refer to the operating manual.

- Stop the air conditioner operation.
- Press the master control button and the fan control button simultaneously for 2 seconds or more to start the test run.




- Press the start/stop button to stop the test run.

If "C0" appears in the unit number display, there is a remote controller error.

| Unit number | Error code | Content |
|-------------|------------|---|
| C0 | 1d | Incompatible indoor unit is connected |
| C0 | 1c | Indoor unit ↔ remote controller communication error |

[Using the wireless remote control] (Option)

- For the operation method, refer to the operating manual.
 - The outdoor unit may not operate depending on the room temperature.
- In this case, press the test run button on the remote control unit while the air conditioner is running. (Point the transmitter section of the remote control unit toward the air conditioner and press the test run button with the tip of a ball-point pen, etc.)



- To end test operation, press the remote control unit START/STOP button.
- (When the air conditioner is run by pressing the test run button, the OPERATION Lamp and TIMER Lamp will simultaneously flash slowly.)

12. CHECK LIST

Pay special attention to the check items below when installing the indoor unit(s). After installation is complete, be sure to check the following check items again.

| CHECK ITEMS | If not performed correctly | CHECK BOX |
|--|--|-----------|
| Has the indoor unit been installed correctly? | Vibration, noise, indoor unit may drop | |
| Has there been a check for gas leaks (refrigerant pipes)? | No cooling, No heating | |
| Has heat insulation work been completed? | Water leakage | |
| Does water drain easily from the indoor units? | Water leakage | |
| Are the wires and pipes all connected completely? | No operation, heat or burn damage | |
| Is the connection cable the specified thickness? | No operation, heat or burn damage | |
| Are the inlets and outlets free of any obstacles? | No cooling, No heating | |
| After installation is completed, has the proper operation and handling been explained to the user? | | |

13. ERROR CODES


If you use a wired type remote control, error codes will appear on the remote control display. If you use a wireless remote control, the lamp on the photo detector unit will output error codes by way of blinking patterns. See the lamp blinking patterns and error codes in the table below.

[Troubleshooting at the remote control LCD]

This is possible only on the wired remote control.

Self-diagnosis

If an error occurs, the following display will be shown. ("EE" will appear in the set room temperature display.)




Ex. Self-diagnosis

| Error code | Error contents |
|----------------------|--|
| 01 13 26 27 | Indoor signal error |
| 00 | Wired remote controller abnormal |
| 02 | Indoor room temperature sensor error |
| 04 | Indoor heat exchanger temperature sensor (middle) error |
| 28 | Indoor heat exchanger temperature sensor (inlet) error |
| 09 | Float switch operated |
| 0c | Outdoor discharge pipe temperature sensor error |
| 06 | Outdoor heat exchanger temperature sensor (outlet) error |
| 0A | Outdoor temperature sensor error |
| 0E | Heat sink thermistor (Inverter) error |
| 15 | Compressor temperature sensor error |
| 1d | 2-way valve temperature sensor error |
| 1E | 3-way valve temperature sensor error |
| 29 | Outdoor heat exchanger temperature sensor (middle) error |
| 2d | Heat sink thermistor (P.F.C) error |
| 20 | Indoor manual auto switch abnormal |
| 2A | Power supply frequency detection error |
| 17 | IPM protection |
| 18 | CT error |
| 1A | Compressor location error |
| 1b | Outdoor fan error |
| 1F | Connected indoor unit abnormal |
| 1c | Outdoor unit computer communication error |
| 2E | Inverter error |
| 12 | Indoor fan abnormal |
| 0F | Discharge temperature error |
| 24 | Excessive high pressure protection on cooling |
| 2c | 4-way valve abnormal |
| 16 | Pressure switch abnormal, Pressure sensor abnormal |
| 2b | Compressor temperature error |
| 2F | Low pressure error |
| 19 | Active filter abnormal |
| 25 | PFC circuit error |
| 30 | Refrigerant circuit address set-up error |
| 31 | Master unit, Slave unit set-up error |
| 32 | Connected the indoor number set-up error |
| 33 | P.F.C. printed circuit board error |

Troubleshooting (Option)

[Troubleshooting with the indoor display]

Troubleshooting at the display is possible either on the wired or wireless remote control.



The OPERATION, TIMER and FILTER Lamp operate as follows table according to the error contents.

| OPERATION Lamp | TIMER Lamp | FILTER Lamp | Error contents |
|----------------|-----------------|-------------|--|
| × | (2 times)○ | × | Indoor signal error |
| × | (3 times)○ | × | |
| × | (4 times)○ | × | |
| × | (5 times)○ | × | |
| × | (8 times)○ | × | Wired remote controller abnormal |
| (2 times)○ | (2 times)○ | × | Indoor room temperature sensor error |
| (2 times)○ | (3 times)○ | × | Indoor heat exchanger temperature sensor (middle) error |
| (2 times)○ | (4 times)○ | × | Indoor heat exchanger temperature sensor (inlet) error |
| (2 times)○ | (6 times)○ | × | Float switch operated |
| (3 times)○ | (2 times)○ | × | Outdoor discharge pipe temperature sensor error |
| (3 times)○ | (3 times)○ | × | Outdoor heat exchanger temperature sensor (outlet) error |
| (3 times)○ | (4 times)○ | × | Outdoor temperature sensor error |
| (3 times)○ | (7 times)○ | × | Heat sink thermistor (Inverter) error |
| (3 times)○ | (8 times)○ | × | Compressor temperature sensor error |
| (3 times)○ | × | (2 times)○ | 2-way valve temperature sensor error |
| (3 times)○ | × | (3 times)○ | 3-way valve temperature sensor error |
| (3 times)○ | × | (4 times)○ | Outdoor heat exchanger temperature sensor (middle) error |
| (3 times)○ | × | (5 times)○ | Heat sink thermistor (P.F.C) error |
| (4 times)○ | (2 times)○ | × | Indoor manual auto switch abnormal |
| (4 times)○ | (4 times)○ | × | Power supply frequency detection error |
| (5 times)○ | (2 times)○ | × | IPM protection |
| (5 times)○ | (3 times)○ | × | CT error |
| (5 times)○ | (5 times)○ | × | Compressor location error |
| (5 times)○ | (6 times)○ | × | Outdoor fan error |
| (5 times)○ | (7 times)○ | × | Connected indoor unit abnormal |
| (5 times)○ | (8 times)○ | × | Outdoor unit computer communication error |
| (5 times)○ | × | (2 times)○ | Inverter error |
| (6 times)○ | (2 or 3 times)○ | × | Indoor fan abnormal |
| (7 times)○ | (2 times)○ | × | Discharge temperature error |
| (7 times)○ | (3 times)○ | × | Excessive high pressure protection on cooling |
| (7 times)○ | (4 times)○ | × | 4-way valve abnormal |
| (7 times)○ | (5 times)○ | × | Pressure switch abnormal, Pressure sensor abnormal |
| (7 times)○ | (6 times)○ | × | Compressor temperature error |
| (7 times)○ | (7 times)○ | × | Low pressure error |
| (8 times)○ | (2 or 3 times)○ | × | Active filter abnormal |
| (8 times)○ | (4 times)○ | × | P.F.C circuit error |
| (8 times)○ | (6 times)○ | × | P.F.C. printed circuit board error |
| (9 times)○ | (2 times)○ | × | Refrigerant circuit address set-up error |
| (9 times)○ | (3 times)○ | × | Master unit, Slave unit set-up error |
| (9 times)○ | (4 times)○ | × | Connected the indoor number set-up error |

○ : 0.5s ON/0.5s OFF (Flash) × : OFF

14. SPECIAL INSTALLATION METHODS


⚠ CAUTION

- When setting DIP switches, do not touch any other parts on the circuit board directly with your bare hands.
- Be sure to turn off the main power.

14.1. Group control system

A number of indoor units can be operated at the same time using a single remote controller.

(1) Wiring method (indoor unit to remote controller)



When ground wire is necessary

(2) DIP switch setting (Indoor unit)


Set the unit number of each indoor unit using the DIP switches on the indoor unit circuit board. (See the following table and figure.)

The DIP switches are normally set to make the unit number 0.

Indoor unit

| Unit number | DIP SWITCH No. | | | |
|-------------|----------------|-----|-----|-----|
| | 1 | 2 | 3 | 4 |
| 0 | OFF | OFF | OFF | OFF |
| 1 | ON | OFF | OFF | OFF |
| 2 | OFF | ON | OFF | OFF |
| 3 | ON | ON | OFF | OFF |
| 4 | OFF | OFF | ON | OFF |
| 5 | ON | OFF | ON | OFF |
| 6 | OFF | ON | ON | OFF |
| 7 | ON | ON | ON | OFF |
| 8 | OFF | OFF | OFF | ON |
| 9 | ON | OFF | OFF | ON |
| 10 | OFF | ON | OFF | ON |
| 11 | ON | ON | OFF | ON |
| 12 | OFF | OFF | ON | ON |
| 13 | ON | OFF | ON | ON |
| 14 | OFF | ON | ON | ON |
| 15 | ON | ON | ON | ON |

Example : No. 3



NOTE

Be sure to set the unit numbers sequentially.

(3) Remote controller setting

- Turn on all of the indoor units.
 - *1 Turn on the indoor unit with the unit number 0 last. (Within 1 minute)
 - *2 When the indoor units are turned on, error codes 01 and 31 will be displayed; however, these error codes will be deleted by setting the remote controller. Therefore, continue with the setting procedure.
- Set the refrigerant circuit address. (Assign the same number to all of the indoor units connected to an outdoor unit.)

| Refrigerant circuit address | Function Number | Setting Value |
|-----------------------------|-----------------|---------------|
| | 02 | 00~15 |

- Set the "master" and "slave" settings. (Set the indoor unit that is connected to the outdoor unit using a transmission cable as the "master".)

| | Function Number | Setting Value |
|--------|-----------------|---------------|
| Master | 51 | 00 |
| Slave | | 01 |


- After completing the function settings, turn off all of the indoor units, and then turn them back on.

* If error code 01, 1F, 30, 31, or 32 is displayed, there may be an incorrect setting. Perform the remote controller setting again.

NOTE

When different indoor unit models are connected using the group control system, some functions may no longer be available.

If the group control system contains multiple units that are operated simultaneously, connect and set the units as shown below.




*Make sure that the indoor unit with the unit number 0 is connected to the outdoor unit using a transmission cable.

14.2. Dual remote controllers

- Two separate remote controllers can be used to operate the indoor units.
- The timer and self-diagnosis functions cannot be used on the slave units.

(1) Wiring method (indoor unit to remote controller)



(2) Remote controller DIP switch 1 setting

Set the remote controller DIP switch 1 No. 2 according to the following table.

| Number of remote controllers | Master unit | Slave unit |
|------------------------------|----------------|----------------|
| | DIP SW 1 No. 2 | DIP SW 1 No. 2 |
| 1 (Normal) | OFF | — |
| 2 (Dual) | OFF | ON |

15. CUSTOMER GUIDANCE

Explain the following to the customer in accordance with the operating manual:

- Starting and stopping method, operation switching, temperature adjustment, timer, air flow switching, and other remote control unit operations.
- Air filter removal and cleaning, and how to use the air louvers.
- Give the Operating and Installation manuals to the customer.
- If the signal code is changed, explain to the customer how it changed (the system returns to signal code A when the batteries in the remote control unit are replaced).

*(4) is applicable to using wireless remote control.