


# AIRSTAGE™ J-III L

## SERVICE MANUAL



FUJITSU GENERAL LIMITED

# CONTENTS

## 1. TEST RUN

<b>1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS.....</b>	<b>01-01</b>
<b>1-2 TEST RUN METHOD.....</b>	<b>01-03</b>
1-2-1 Check Items Before Power ON.....	01-03
1-2-2 Check Items After Power ON.....	01-04
1-2-3 Automatic address setting procedure for Signal amplifiers.....	01-06
1-2-4 Automatic address setting procedure for indoor units.....	01-07
1-2-5 Indoor unit connection check procedure .....	01-08
1-2-6 Test run from the outdoor Main PCB .....	01-09
1-2-7 Test run from the Remote controller .....	01-10
<b>1-3 TEST RUN CONTROL.....</b>	<b>01-15</b>
<b>1-4 FIELD SETTING AND MONITOR MODE LIST FOR OUTDOOR UNIT.....</b>	<b>01-16</b>
<b>1-5 FIELD SETTING / FUNCTION SETTING FOR INDOOR UNIT.....</b>	<b>01-19</b>
<b>1-6 FIELD SETTING / FUNCTION SETTING FOR OUTDOOR AIR UNIT.....</b>	<b>01-21</b>

## 2. OUTDOOR UNIT OPERATION CONTROL

<b>2-1 INPUT / OUTPUT LIST.....</b>	<b>02-01</b>
<b>2-2 COMPRESSOR OPERATION.....</b>	<b>02-02</b>
2-2-1 Operation / Stop Condition.....	02-02
2-2-2 Capacity Control.....	02-02
2-2-3 Speed Range of Start,Stop,and Operation.....	02-03
<b>2-3 FAN CONTROL.....</b>	<b>02-04</b>
2-3-1 Cooling Operation.....	02-04
2-3-2 Heating Operation.....	02-05
2-3-3 Low noise mode.....	02-06
2-3-4 Other Control.....	02-07
<b>2-4 EXPANSION VALVE CONTROL.....</b>	<b>02-07</b>
<b>2-5 SPECIAL OPERATION.....</b>	<b>02-08</b>
2-5-1 Oil Recovery Operation.....	02-08
2-5-2 Pre-Heat Operation.....	02-09
2-5-3 Defrost Operation Control.....	02-09
<b>2-6 PROTECTIVE FUNCTION.....</b>	<b>02-10</b>
2-6-1 Protective Function List.....	02-10

# CONTENTS

## 3. INDOOR UNIT OPERATION

<b>3-1 FAN CONTROL</b>	03-01
3-1-1 Fan Speed Setting	03-01
3-1-2 "AUTO" Position	03-01
<b>3-2 MASTER CONTROL</b>	03-02
3-2-1,2 Operation Mode Control	03-02
3-2-3,4 Auto Changeover	03-05
3-2-5,6,7,8 "COOL"/"HEAT"Position	03-08
<b>3-3 LOUVER CONTROL</b>	03-10
<b>3-4 ELECTRONIC EXPANSION VALVE CONTROL</b>	03-14
<b>3-5 DRAIN PUMP OPERATION</b>	03-14
<b>3-6 FUNCTION</b>	03-15
3-6-1 Auto Restart	03-15
3-6-2 Icing Protection Control	03-15
3-6-3 Oil Recovery Operation	03-15
3-6-4 Outdoor temperature protected operation for outdoor	03-16
<b>3-7 TIMER CONTROL</b>	03-17
3-7-1 Wireless Remote Controller	03-17
3-7-2 Group Remote Controller	03-19
3-7-3 Wired Remote Controller	03-21
<b>3-8 DX-KIT</b>	03-25
3-8-1 System configuration	03-25
3-8-2,3 Fundamental functions	03-26
3-8-4 Electrical expansion valve control for DX-KIT	03-28
3-8-5 Drain pump operation for DX-KIT	03-28
3-8-6 Function	03-29

# CONTENTS

## 4. TROUBLE SHOOTING

<b>4-1 NORMAL OPERATION</b> .....	04-01
4-1-1 Indoor Unit Display.....	04-01
4-1-2 Outdoor Unit Display.....	04-02
<b>4-2 ABNORMAL OPERATION</b> .....	04-03
4-2-1 Indoor Unit Display.....	04-03
4-2-2 Outdoor Unit Display.....	04-04
4-2-3 Error Code List for Outdoor Unit.....	04-05
4-2-4 Remote Controller Display.....	04-06
4-2-5 Error Code List for Simple and Wired Remote Controller.....	04-07
4-2-6 Error Code List for Group Remote Controller.....	04-07
4-2-7 Troubleshooting - No Error code - .....	04-08
4-2-8 Error Code List for External Switch Controller.....	04-08
4-2-9 Error Code List for Signal Amplifier.....	04-08
4-2-10 Error Code List for Network Convertor .....	04-08
<b>4-3 TROUBLE SHOOTING</b> .....	04-09
4-3-1 Trouble Shooting With Error Code (Indoor unit) .....	04-09
4-3-2 Trouble Shooting With Error Code (Outdoor unit) .....	04-39
4-3-3 Trouble Shooting With No Error Code .....	04-76
4-3-4 Trouble Shooting for Option Parts .....	04-82
<b>4-4 SERVICE PARTS INFORMATION</b> .....	04-106

## 5. APPENDING DATA

<b>5-1 REFRIGERANT CIRCUIT</b> .....	05-01
<b>5-2 WIRING DIAGRAM</b> .....	05-03
5-2-1 Indoor Unit.....	05-03
5-2-2 Outdoor Unit.....	05-18
5-2-3 DX-KIT .....	05-20
<b>5-3 CHARACTERISTICS OF SENSORS</b> .....	05-22
5-3-1 Pressure sensor.....	05-22
5-3-2 Thermistor resistance.....	05-23
5-3-3 Saturation temperature and saturation pressure tables (R410A).....	05-24
5-3-4 Temperature and pressure of refrigerant (Graph).....	05-25

## 6. DISASSEMBLY PROCESS





# **AIRSTAGE™ J-III L**

*Variable Refrigerant Flow System*

## **1. TEST RUN**

# 1. TEST RUN

## 1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS

### Before execution

	Execution procedure and precautions	Reason
Location decision	Do not install the units in the place not recommended in the installation manual.	• The performance may drop significantly due to the protection controlling
Confirmation of Refrigerant used	Check the characteristics of the refrigerant used and grasp the special features of the refrigerant. If refrigerant must be charged, always charge the refrigerant specified for the product. *Confirm the product design pressure. < R410A 4.2MPa >	• Use of a refrigerant other than the specified refrigerant will invite equipment trouble
Preparation of execution drawings	Prepare the design for the system	
Confirmation of installation site	① Use new refrigerant piping of the thickness specified by the D&T manual. ② Since R410A dedicated tools are necessary, prepare them in advance.	• Secure the necessary pressure resistance.
Preparation before execution	③ Absolutely avoid use of existing piping. If use of existing piping is unavoidable, the piping must be cleaned.	

### Execution 1/2

Sleeve and insert work	Always use a level and keep the indoor unit level. If the equipment is tilted toward the drain port, install it so that the tilt is within 13/32in.(10mm). Excessive tilt will cause water leakage.	• Prevention of water leakage
Indoor unit installation	When performing piping work, observe the following items so that the inside of the piping is clean and air tight.	• Foreign matter, water, etc. in the piping will cause faulty cooling and compressor trouble.
Refrigerant piping work	① Use pipe that is not dirty inside. ② Confirm the design for the piping ( Diameter, Thickness ) ③ When the pipe is left standing, protect it. ④ Confirm the angle of separation tube and header correctly. ⑤ Finish flaring exactly.	• Incorrect pipe diameter will cause faulty cooling • Incorrect angle of separation tube or header will be cause poor cooling or refrigerant noise problem
Drain piping work	⑥ Confirm the width across flats dimension and shape of flare nuts. ⑦ Always blow nitrogen while brazing. ⑧ Perform flushing before connecting the equipment.	• Refrigerant leakage will cause low performance and abnormal stopping
Duct work	① Always make the downward slope of the drain pipe 1/100 or greater and make the horizontal length within 20m. ② Use hard polyvinyl chloride pipe as the drain pipe. ③ Support the drain pipe between 1.5m to 2.0m. ④ Use pipe of 1 rank up (VP30 or greater) as central piping.	• Prevention of water leakage
Heat insulation work	Select the size of the heat insulating material according to the ambient temperature and relative humidity of the refrigerant. Use a heat insulating material having a heat conductivity of 0.043W/(m.k) or less.	• Prevention of water leakage
Electrical work		
Outdoor unit foundation work		
Outdoor unit installation	When making flare connections always use a torque wrench and tighten the flare nut positively to the specified torque.	• Refrigerant leakage will cause low performance and abnormal stopping.
Refrigerant piping connection work	Pressurize the product with nitrogen gas up to the design pressure and conduct a 24Hr air tightness test.	• Refrigerant leakage will cause low performance and abnormal stopping.
Air tightness test	① Install a vacuum pump with reverse flow check mechanism or a reverse flow check adapter to a conventional vacuum pump and use. ② Pump down sufficiently. Approximately 1 hour or longer after -14.5psi (-0.10MPa) reached. Allow to stand for approximately 1 hour after stopping the vacuum pump and confirm that the needle does not return.	• Mixing in of vacuum pump oil by reverse flow will cause equipment trouble. • recommend the vacuuming mode
Vacuum drying	③ Air purging using refrigerant is strictly prohibited.	

#### \*Vacuuming mode

This function is used for vacuuming the indoor unit and the connection piping.  
Note: For starting Vacuuming mode, the refrigerant address setting has to be finished.

When the [vacuuming mode] is set, <Push switch setting, F3:21>  
EEV of connected all indoor units opens.  
So, the vacuuming indoor unit and piping becomes easier.

When the vacuuming ends, please turn off the power supply for all of the indoor units and the outdoor unit, [vacuuming mode] is released.

## Execution 2/2

	Execution procedure and precautions	Reason
Addition refrigerant charging	<ol style="list-style-type: none"> <li>① Confirm the additional refrigerant amount with the installation manual, etc.</li> <li>② Always take the R410A refrigerant from the cylinder liquid phase and charge it using the gas phase. (Do not lay a cylinder with siphon pipe on its side.)</li> <li>③ Use an R410A dedicated gauge manifold and charging hose.</li> <li>④ Charge refrigerant using the liquid pipe.</li> <li>⑤ When the defined amount of refrigerant cannot charge using the liquid pipe, charge refrigerant using the gas pipe while operating the cooling test run. Charge refrigerant bit by bit with cautious operation of valve for the liquid refrigerant back prevention.</li> </ol>	<ul style="list-style-type: none"> <li>• If taken from the air phase, since the composition of the refrigerant which is charged will change, low performance and abnormal stop will occur easily.</li> <li>• Prevent erroneous sealing in of refrigerant.</li> </ul>
Gas leak test	Use an R410A dedicated leak tester to check for gas leaks.	• A leak tester for other than R410A cannot detect leaks.
Initial setting	<ol style="list-style-type: none"> <li>① Set the refrigerant circuit address. ROTARY SW: REF ADX10, X1</li> <li>② Confirm the DIP SW setting SET 1: Factory setting, SET 2: All OFF</li> <li>③ Confirm the Terminal resistor setting SET 5-4 OFF: Disable, ON: Enable</li> </ol> <p>[Note] Perform in the power OFF state.</p>	<ul style="list-style-type: none"> <li>• Dual address setting No. is not allowed in one network.</li> <li>• If the DIP SW setting is wrong, the system may not work correctly</li> <li>• If the Terminal resistor setting is wrong, the system may detect transmission error</li> </ul>
Piping length setting	<p>Set according to the length of the connection piping. Set to "Standard 40 to 65m" at the factory. Set using the push button SW on the outdoor unit main PCB. &lt; Refer to the Page 01-17 Setting mode F2-00 &gt; Set the pipe length to be the nearest indoor unit from the outdoor unit</p> <p>[Note] Perform in the power ON state after all indoor units have stopped operation</p>	<ul style="list-style-type: none"> <li>• When the setting is not same as the real piping length, the system may not work correctly.</li> <li>• If the pipe length is set as the farthest indoor unit, the nearest operating indoor unit may be stopped the operation by the icing up protection as by over cooling.</li> </ul>
Address setting for Signal Amp - When using signal Amps -	<p>When setting the address of Signal amplifier, please refer to the installation manual of the signal amplifier.</p> <p>The address setting can be set by automatically from 1 outdoor unit on the network. &lt; Refer to the Page 01-06 Setting mode F3-10 &gt;</p> <p>[Note] Manual setting: Set the rotary SW on the PCB in the power OFF state. Automatic address setting: Perform setting by push button SW on the outdoor unit Main PCB in the power ON state after all indoor units have stopped operation.</p>	<ul style="list-style-type: none"> <li>• Dual address setting No. is not allowed in one network.</li> </ul>
Address setting for Indoor unit	<p>Set the refrigerant circuit address and indoor unit address. Can be set by rotary SW on the indoor unit PCB ( Main PCB or Switch PCB) or from a remote controller or from a push button SW on the outdoor unit Main PCB &lt; Automatic address setting, Refer to the Page 01-07 Setting mode F3-11&gt;</p> <p>[Note] Manual setting: Set the rotary SW on the PCB in the power OFF state. Automatic address setting: Perform setting by push button SW on the outdoor unit Main PCB in the power ON state after all indoor units have stopped operation.</p>	<ul style="list-style-type: none"> <li>• Dual address setting No. is not allowed in one network.</li> </ul>
Indoor unit connection check	<p>Before starting the system, check on the number of indoor units and the total capacity. &lt; Refer to the Page 01-08 Setting mode F3-12 &gt;</p> <p>[Note] Perform setting by push button SW on the outdoor unit Main PCB in the power ON state after all indoor units have stopped operation.</p>	<ul style="list-style-type: none"> <li>• Normal operation will not be possible without performing the indoor unit connection check.</li> </ul>
Test run & adjustment		
Turnover & explanation of operation		

## 1-2 TEST RUN METHOD

### 1-2-1 Check Items Before Power ON

Procedure	Check contents	Judgement standard	Check
Power source	Circuit breaker capacity	Outdoor unit: AJ*072/090LELAH: 20A / AJ*108LELAH: 25A	
		Indoor unit: 20A	
		Leakage current: 100mA 0.1sec or less	
		Install a breaker (Included with Earth Leakage Circuit Breaker) in accordance with the related laws and regulations.	
	Type of power source wiring	Outdoor unit: Power cable: 6.0mm <sup>2</sup> / Earth cable: 6.0mm <sup>2</sup> Limited wiring length : 62 m	
		Indoor unit: 2.5mm <sup>2</sup> 2 wires + Ground	
	Supply power source	Outdoor unit side: 400V 3 $\phi$ 50Hz	
		Indoor unit side: 230V 1 $\phi$ 50Hz	
	Wiring on terminal blocks	Use crimp-type terminals with insulating sleeves for stranded conductor cable	

Outdoor unit	Appearance	Shall be no scratches, deformation, etc. (Be careful of deformation of the front panel)	
	Serial No.	Shall be checked and entered in the check sheet.	
	Outside air temperature	Shall be checked and entered in the check sheet.	
	Power source wiring connection	Connection points check & loose terminal block screws check	
	Type of communication line	0.33mm <sup>2</sup> , shielded wire used (22AWG)	
	Communication line connection	Connection points check & loose terminal panel screws check	
	Connection piping	Check whether or not the heat insulation material is installed without a gap.	
	DIP-SW setting	DIP SW : SET1 (1 ~4), Factory setting SET2, SET3, SET5-1,2,3: ALL OFF	
		Terminal resistor setting SET5 - 4 OFF: Disable, ON: Enable Refer to the Installation manual 7.2.2	
	Rotary SW setting	Refrigerant circuit address setting (SET : REF AD x10 and REF AD x1)	
	Additional refrigerant amount	Comparison of calculated value and value written on electrics box. Entered in check sheet. Refer to the installation manual 8.3.2	
	3-way valve	Gas pipe: fully open	
		Liquid pipe: fully open	

[Note] If operated with the 3-way valve closed, the oil discharged from the compressor will not be returned and will lead to trouble.

Indoor unit	Appearance	There shall be no scratches, deformation, tilting, etc.	
	Serial No.	Shall be checked and entered in the check sheet.	
	Drain cap installation	Shall be installed positively.	
	Power source wiring connection	Connection points check & loose terminal panel screws check	
	Type of communication line	0.33mm <sup>2</sup> , shielded wire used (22AWG)	
	Communication line connection	Connection points check & loose terminal panel screws check	
	Type of remote controller wiring	2 wire type : 16 to 22AWG (0.33 to 1.25mm <sup>2</sup> ) 3 wire type : 22AWG (0.33mm <sup>2</sup> )	
	Remote controller wiring connection	Connection points check & loose terminal panel screws check	
	Connection piping	Check whether or not the heat insulation material is installed without a gap.	
	Rotary SW setting	Refrigerant circuit address (REF AD)	
		Indoor unit address (IU AD)	
		At automatic address setting, IU AD/REF AD shall be [0].	
		Remote controller address (RC AD)	
	DIP-SW setting	Function setting (Remote controller custom code/ external input switching/ auxiliary heater ON-OFF)	

## 1-2-2 Check Items After Power ON

[Note]

Cooling test run for each refrigerant circuit.

If multiple refrigerant circuits are test run at the same time, refrigerant circuit address setting errors cannot be detected.

Procedure	Check contents	Judgement standard	Check
Power ON	Outdoor unit circuit breaker ON	Check lighting of Main PCB LED101 and 7-segment display.	
	Indoor unit circuit breaker ON	Check whether or not indoor unit OPERATION and TIMER lamps flash alternately.	

[Note] Turn on all indoor units power in the same refrigerant circuit address.

When the system operates with the indoor units remaining no power, it is cause of malfunction.

Outdoor unit Main PCB push button SW setting/check	Function setting	Are the necessary functions set ? < For the setting, Refer to the page 01-16 ~ 19 >	
--	------------------	--	--

Address setting/ check	Automatic address setting	Addresses shall be assigned to all indoor units / Signal amps. Check for unset or duplicated addresses. < For the setting, Refer to the page 01-06, 07 >	
	Address read	All the indoor units and outdoor units of the same refrigerant circuit can be checked on the service tool.	
	Address record	Enter the set addresses in the check sheet.	
	Address hold check	Check whether or not the address setting is held by the service tool after indoor/outdoor circuit breakers were turned OFF to ON.	
Indoor unit connection check	Indoor unit connection check	Are the number of connecting indoor units correct ? Is the total capacity of indoor units correct ? < For the checking, Refer to the page 01-08 >	

[Note] Before connecting service tool, the address setting has to be completed.

Cooling test run	Outdoor unit push button SW operation	All the indoor units in the same refrigerant circuit shall enter the cooling test run state. The outdoor units corresponding to the operation capacity of the indoor units shall operate. < Test operation procedure, Refer to the page 01-09,10 >	
All of the indoor units operation (after 30 mins)	<On service tool>		
	High pressure	HPS: 2.7 ~ 3.0 MPa *	
	Low pressure	LPS: 0.9 ~ 1.0 MPa *	
	Discharge pipe temperature (outdoor unit)	TH1: 81°C *	
	Suction pipe temperature (outdoor unit)	TH4: 15°C *	
	Inlet air temperature (indoor unit)	TH21: 27°C *	
	Heat exchange inlet temperature (indoor unit)	TH22: 11°C *	
	Heat exchange outlet temperature (indoor unit)	TH24: 13°C *	
	Compressor operation	Shall operate corresponding to the operation capacity of the indoor units.	
	Data output	Service tool used, output (CSV ⇒ Excel)	
	<Outdoor unit>		
	Outdoor Main PCB 7-seg. display	There shall be no Error information on the 7-segment display on the Main PCB.	
	Operation voltage	3 Phase: 342 to 456V	
	Abnormal sound/ abnormal vibration	These shall be no abnormal sound or abnormal vibration.	
		The outdoor fan shall not make a moaning sound.	
		There shall be no discharge air leaking from the outdoor duct.	
		There shall be no pipe chattering sound or flute sound generated.	
	<Indoor unit service tool + actual measurement>		
	Outlet air temperature	Inlet air temperature and outlet air temperature difference shall be 10°C or greater.	
	Abnormal sound/abnormal vibration	There shall be no abnormal sound or abnormal vibration.	
	Water leakage check	There shall be no water leakage. There shall be no condensation on the drain, cabinet, piping, and discharge port.	
	Remote controller operation	Shall operate according to the settings. (ON-OFF, set temperature change)	

Procedure	Check contents	Judgement standard	Check
Indoor unit individual operation	<Indoor unit service tool + actual measurement>		
	Fan operation	Shall be switched to all fan speeds in the cooling mode.	
	Louver operation (except duct)	Louver shall be switched to all positions. Shall also swing.	
	Outlet air temperature	Inlet air temperature and outlet air temperature difference shall be 10°C or greater.	
	Abnormal sound/abnormal vibration	There shall be no abnormal sound or abnormal vibration.	
	Water leakage check	There shall be no water leakage. There shall be no condensation on the drain, cabinet, piping, and discharge port.	
	Remote controller operation	Shall operate according to the settings. (ON-OFF, set temperature change)	

\*  
These are representative figures of AJ\*108LELAH at the standard condition. ( Indoor : 27°C, Outdoor : 35°C )  
If conditions are different from those above mentioned, the figures will be changed slightly.  
It depends on following conditions.

- Outdoor unit capacity
- Indoor and outdoor temperature
- Indoor unit capacity
- Pipe length
- etc

## Trouble shooting on Test run operation

### 1. Error occurred

- Check on the Error code on the Remote controller or Indoor unit or Outdoor unit or Service tool and check the description of the Error code.  
< Refer to the Trouble shooting in the Service manual.>  
< Refer to the Execution of precautions 1-1 and Check item Before power ON 1-2-1>

### 2. No good performance without error code

- Check if the protection controlling is operating or not  
Evaporator Icing up protection, High discharge temperature protection, etc.  
< Refer to the part of protection controlling in the Service manual >
- Check on the refrigerant circuit  
Refrigerant amount, Pipe blockage, Wrong position of separation pipes etc.  
< Refer to the Execution of precautions 1-1 and Check item Before power ON 1-2-1>  
< Refer to the regulation of installation in the Installation manual>



## 1-2-3 Automatic address setting for signal amplifiers when using signal amplifiers




When setting the address of the signal amplifier, please use the factory setting.  
(See the installation manual of the signal amplifier)

When the system is normal, nothing will be displayed on the 7 segment display.

When ERROR is displayed, inspect the units.

Use the "MODE/EXIT", "SELECT", and "ENTER" buttons on the outdoor unit Main PCB to configure settings according to the procedures below.

### ● SWITCH POSITION



## 1-2-4 Automatic address setting for Indoor units

Check that the rotary switch IU AD on the indoor unit Main PCB is set to "00". If it is not set to "00", it means the address of that device is not set. (Factory default is "00").




Turn on the power of the indoor and outdoor units.

When the system is normal, nothing will be displayed on the 7 segment display.

When ERROR is displayed, inspect the units.


Use the "MODE/EXIT", "SELECT", and "ENTER" buttons on the outdoor unit Main PCB to configure settings according to the procedures below.

### ● SWITCH POSITION




## 1-2-5 Indoor unit connection check

### ● SWITCH POSITION



Please perform the indoor unit connection check according to following procedures.



- Turn on the power of indoor unit and outdoor unit.



## 1-2-6 Test Run From Outdoor Main PCB

All the indoor units connected to the outdoor unit can be test-operated by push button setting.


### ● SWITCH POSITION




### ● TEST RUN SETTING

For a detailed description of push button operation, refer to the [D&T manual Chapter 6. SYSTEM DESIGN]


#### < Monitoring condition >




#### < Mode select condition >



#### < Function select condition >




#### < Pursuance completion >



#### < Return to mode select condition >



#### < Return to monitoring condition >







### Note

There are the following 2 methods of resetting test operation.


- (1) Automatic reset when 60 minutes has elapsed.
- (2) Reset when operation stop was performed.

## 1-2-7 Test Run From Remote Controller

### 1. Standard wired remote controller

Stop the indoor unit. Push the  button and  button simultaneously for more than two seconds. The air conditioner will start to conduct a test run and "a i" will display on the remote controller display. However, the ,  setting button does not have function, but all other buttons, displays, and protection functions will operate.


- Perform the test operation for 60 minutes.
- To stop test run, push the START / STOP button of the standard wired remote controller.
- For the operation method, refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.







### 2. Standard wireless remote controller


- Press the TEST RUN button on the remote controller, while the air conditioner is running.
- To end test run operation, press the remote controller START / STOP button.


When the air conditioner is being test run, the OPERATION and TIMER lamps of indoor unit flash slowly at the same time.



### 3. Simple remote controller

Stop the indoor and outdoor units. Push the remote controller  button and  button simultaneously for more than three seconds. The air conditioner will start to conduct a test run and "a i" will display on the temperature display. However the ,  setting button does not have function but all other buttons, displays and protection functions will operate.


- To stop test running press the  button of the simple remote controller.
- For the operation method refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.




#### 4. Central remote controller


##### Test run operating procedure

< Monitor screen : 9 units display >

- 1) Press  Button
- 2) Press the [ Setup Menu (F2) ] button






UTY-DCG \*




< Password verification >


- 3) Shift Indoor unit special setting by pressing the [] button and [] button



- 4) Shift the Test Operation by pressing the [] button and [] button



- 5) Press the [ Select All (F2) ] button or [ Identify Unit (F3) ] button




[ Select All (F2) ] : All of R.C.Group (Indoor units)  
[ Identify Unit (F3) ] : Specific R.C.Group (Indoor unit)

- 6) Press the [ Start (F5) ] button



## 5. Touch panel controller

### Test run operating procedure



<Monitor screen (icon)>

**Monitor Mode** 10/11.2008.Mar. 02:20 PM **Status: On**

All  
↳ Lange Group

Top Up Down List

<b>Office A</b> On Cool 21.5°C	<b>Office B</b> On Heat 21.0°C	<b>PC Room</b> On Cool 26.0°C
<b>Room 101</b> Off	<b>Restrant</b> On Auto 24.0°C	<b>Entrance</b> On Auto 24.0°C
<b>Meeting 1</b> On Heat 21.5°C	<b>Meeting 2</b> Off	<b>Meeting 3</b> On Heat 21.0°C
<b>Conference A</b> On Heat 21.5°C	<b>Conference B</b> On Auto 22.0°C	<b>Parking lot</b> Off

Setting  
Schedule

Select All (1)  
Clear All

Operation (2)

On  
Off (\*)

Group Schedule Op.Controlled Mode  
Error Filter Sign Op.Restricted Set Temp.

<Monitor screen (list)>

**Monitor Mode** 10/11.2008.Mar. 02:20 PM **Status: On**

All  
↳ Lange Group

Top Up Down List

Name	Expand	Status	Mode	Set Temp	Fan	R/C Prohibit
Office A		On	Heat	21.5°C	High	
Office B		Mixed	Mixed	Mixed	Mixed	Mixed
PC Room		On	Auto	24.0°C	Low	
Room 101		Off				
Restrant		On	Cool	26.0°C	Auto	
Entrance		Off				
Meeting 1		Off				

Setting  
Schedule

Select All (1)  
Clear All

Operation (2)

On  
Off (\*)

Group Schedule RC Prohibition  
Error Filter Sign All Mode Filter  
Op. Controlled On/Off Temp.  
Op. Restricted On Timer


- (1) Select the objective you want to test run.  
Select the objective icon or list at the monitor screen. (Multiple selections is possible)  
Select all the devices registered as objectives by pressing "Select All" on the monitor screen.
- (2) After objective selection at (1), switch to the <Setting screen> by pressing "Operation".

<Setting screen>



(3) Switch to the <Details setting screen> by pressing "Optional Setting" on the setting screen.


<Details setting screen>



(4) Send (start) test run by pressing "Start" and then pressing "OK" on the details setting screen.

Test run continues for 60 minutes.

During sending, the slave screen shown below is displayed. When sending is completed, the sending slave screen and details setting screen are closed.



To interrupt test run, select the device being test run and execute an operation stop command.

(\*) At the monitor screen, test run is reset by stopping operation of the objective devices by pressing "OFF".


(\*) Or test operation is reset by stopping operation of the objective devices by pressing "Off" of Operation and then pressing "OK" on the setting screen.

6. 2-Wire type wired remote controller

- (1) Press "Menu" on the monitor screen. the < Main Menu screen > is displayed.
- (2) Press "Next Page" and press "Maintenance"
- (3) Press "Next Page" and press "Test Run". the <Test run screen > is displayed.
- (4) Press "OK"

The test run continues for 60 minutes.  
To interrupt test run before it is complet, return to the "Monitor Mode Screen",  
and press ON/ OFF.

UTY - RNR\*



## 1-3 TEST RUN CONTROL

### 1. When the test run signal is transmitted from standard wired, wireless remote controller, simple remote controller, transmitted network, and outdoor unit.


- (1) The test run operation starts and the electric expansion valve is controlled to a maximum flow, regardless of the temperature condition.
- (2) Frost prevention operation has priority over item(1).
- (3) Whether state of the indoor unit operates or stops, All units in the same refrigerant circuit will start to conduct a test run in accordance with the operation mode set by push switch of outdoor unit ( see 1 - 2 - 3 ).
- (4) After 60 minutes passes, the test run stops.
- (5) Test running initialization is shown below.

Operating Mode	EXCEPT FOR THE DUCT MODEL		DUCT TYPE	
	Cooling	Heating	Cooling	Heating
Fan speed	Hi	Hi	Hi	Hi
Room Temperature Indication	18	30	18	30
Vertical Air Direction Panel	Position ①	Position ④	_____	_____
Swing	OFF	OFF	_____	_____


\*Example




■ COMPACT CASSETTE TYPE





■ CEILING TYPE




■ COMPACT WALL MOUNTED TYPE



Set the air outlet selection switch to



Set the air outlet selection switch to



■ COMPACT FLOOR

## 1-4 FIELD SETTING AND MONITOR MODE LIST FOR OUTDOOR UNIT

	Classification	ITEM CODE No.	Setting Mode	Information contents
Push switch on outdoor unit PCB  Monitor mode <b>[ F1 ]</b>	Device and system	00	Connected number of indoor unit	The number of the communicating unit is displayed
		01	Software version of outdoor unit	Software version : E●●●V○○☆■□L△△-◎
		02	Software version of INV PCB	[E●●●][V○○][☆■□][L△△][-◎] displays by five items
		03	Software version of communication PCB	It skips when there is no suffix「-◎」
	Operation of each part	10	Rotational speed of outdoor unit fan motor	The rotational speed of the outdoor unit fan motor is displayed [ rpm ]
		11	Rotational speed of INV compressor	The rotational speed of the compressor is displayed [ rps ]
		12	Current value of INV compressor	Current value of INV compressor is displayed [ A ]
		13	Forbidden	
		14	Pulse of EEV1	Pulse of EEV1 is displayed [ pls ]
		15	Pulse of EEV2	Pulse of EEV2 is displayed [ pls ]
	Time guard	20	Accumulated current time	Accumulated current time is displayed [ ×10 hour ]
		21	INV compressor accumulated time [ Cooling ]	Accumulated time is displayed in the cooling operation of the INV compressor [ ×10 hour ]
		22	INV compressor accumulated time [ Heating ]	Accumulated time is displayed in the heating operation of the INV compressor [ ×10 hour ]
		23	Forbidden	
	Refrigerant cycle data 1	30	Information on Thermistor 1 ( INV compressor discharge temperature sensor )	The value of the Thermistor 1 is displayed [ °C ] or [ °F ]
		31	Forbidden	
		32	Information on Thermistor 3 ( Outdoor temperature sensor )	The value of the Thermistor 3 is displayed [ °C ] or [ °F ]
		33	Information on Thermistor 4 ( Suction temperature sensor )	The value of the Thermistor 4 is displayed [ °C ] or [ °F ]
		34	Information on Thermistor 5 ( Heat-exchanger (outlet) temperature sensor )	The value of the Thermistor 5 is displayed [ °C ] or [ °F ]
		35	Forbidden	
	Refrigerant cycle data 2	36	Information on Thermistor 7 ( Liquid temperature sensor 2 )	The value of the Thermistor 7 is displayed [ °C ] or [ °F ]
		37	Forbidden	
		38	Information on Thermistor 9 ( Sub-cool heat-exchanger (outlet) temperature sensor )	The value of the Thermistor 9 is displayed [ °C ] or [ °F ]
		39	Information on Thermistor 10 ( INV compressor temperature sensor )	The value of the Thermistor 10 is displayed [ °C ] or [ °F ]
	Refrigerant cycle data 3	40	Forbidden	
	Refrigerant cycle data 4	50	Information on pressure sensor 1 ( High pressure sensor )	The value of the pressure sensor 1 is displayed [ MPa ] or [ psi ]
		51	Information on pressure sensor 2 ( Low pressure sensor )	The value of the pressure sensor 2 is displayed [ MPa ] or [ psi ]



	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Information contents	Default
Push switch on outdoor unit PCB  Monitor mode [ F2 ]	Install	00	Pipe length setting	00	40-65m	○
				01	0-40m	
				02	65-90m	
				03	90-120m	
	Correction	10	Forbidden	00	Factory default	○
				01	Normal mode	○
		11	Cooling capacity shift	01	Save energy mode +2°C	
				02	High power mode 1 -2°C	
				03	High power mode 2 -4°C	
				04	Forbidden	
		12	Heating capacity shift	00	Normal mode	○
				01	Save energy mode -2°C	
				02	High power mode 1 +2°C	
				03	High power mode 2 +4°C	
		13,14	Forbidden	00	Factory default	○
		16,17	Forbidden	00	Factory default	○
	Change of function 1	20	Switching between forced stop or emergency stop	00	Forced stop	○
				01	Emergency stop	
		21	Operation mode selecting method	00	Priority given to the first command	○
				01	Priority given to the external input of outdoor unit	
				02	Priority given to the master indoor unit	
		22,23,24	Forbidden	00	Factory default	○
		25,26,27	Forbidden	00	Factory default	○
		28	Change of unit (Temperature)	00	Celsius (°C)	○
				01	Disable (°F)	
		29	Change of unit (Pressure)	00	MPa	○
				01	psi	
	Change of function 2	30	Energy saving level setting	00	Level 1 (stop)	○
				01	Level 2 (operated at 40% capacity)	
				02	Level 3 (operated at 60% capacity)	
				03	Level 4 (operated at 80% capacity)	
				04	Level 5 (operated at 100% capacity)	
		31,34,35 35,36,37 38,39	Forbidden	00	Factory default	○
	Low noise setting 1	40	Capacity priority setting	00	Off (quiet priority)	○
				01	On (capacity priority)	
		41	Low noise mode setting	00	Off (Normal)	○
				01	On (Low noise mode operation is always done)	
		42	Low noise level setting	00	Level 1	○
				01	Level 2	
	Change of function 3	50,51,60, 61,64	Forbidden	00	Factory default	○
	Change of function 4	70	Electricity meter No. setting 1 ( Set the ones digit and tens digit of the No. of the electricity meter connected to CN135 ) *1	00~99	Setting number x00~x99 ( Refer to Design & Technical Manual for details.)	00
		71	Electricity meter No. setting 2 ( Set the ones digit and tens digit of the No. of the electricity meter connected to CN135 ) *1	00~02	Setting number 0xx~2xx ( Refer to Design & Technical Manual for details.)	00
		72	Electricity meter pulse setting 1 ( Set the ones digit and tens digit of the No. of the electricity meter pulse setting connected to CN135 ) *2	00~99	Setting number xx00~xx99 ( Refer to Design & Technical Manual for details.)	00
		73	Electricity meter pulse setting 2 ( Set the ones digit and tens digit of the No. of the electricity meter pulse setting connected to CN135 ) *2	00~99	Setting number 00xx~99xx ( Refer to Design & Technical Manual for details.)	00

\*1 : When electricity meter No. is set to "000" and "201 to 299", the pulses input to CN135 become ineffective.  
Available setting number is "001" to "200"

\*2 : When the electricity meter pulse setting is set to "0000", the pulses input to CN135 become ineffective.  
Available setting number is "0001" to "9999"



	Classification	ITEM CODE No.	Setting Mode	Setting Function
Push switch on outdoor unit PCB  Monitor mode [ F3 ]	Forced operation	00	Cooling test run	Forced thermostat-ON in Cooling.
		01	Heating test run	Forced thermostat-ON in Heating.
		02	Test run stop	Test run is stopped.
		03.04	Forbidden	
	Install and maintenance 1	10	Signal amplifier automatic address	Automatic address setting operates for signal amplifier.
		11	Indoor unit automatic address	Automatic address setting operates for indoor unit of same refrigerant circuit.
		12	Indoor unit connection check	The number of indoor units and the total capacity of indoor units of same refrigerant circuit.
	Install and maintenance 2	20	Forbidden	
		21	Vacuuming mode	Vacuuming mode operates Refer to page 01-01 for the function.
	Clear	30	Error history clear	All the abnormal code histories are cleared.
		31	Forbidden	
		32	Current time clear	Accumulated current time becomes [ 0 ]
		33	INV compressor accumulated time clear	Accumulated time of the INV compressor becomes [ 0 ]
		35	Field setting all clear	Return to default the all set items.
		36	Clear memorized information of "F3 - 12" ( Indoor unit connection check )	The information of the number of indoor units and the total capacity of indoor units are cleared.
		37	Forbidden	
		40	Abnormal reset	It was displayed when abnormality occurs, and the total code is reset.  This is a function that uses to clear abnormal display after the repair is completed.  Please operate the switch after power off or power on the outdoor unit.
	Reset	41	Maximum memorized indoor unit number reset	Maximum memorized indoor unit number is reset "E14.5 : Indoor unit number shortage " error is cleared.
	Specialty function	90	Forbidden	
		91	Forced Central control function release	When the centralized control device failure, and the centralized control setting cannot be released, this function is used.  All the limitations set with the centralized control device are released.

	Classification	ITEM CODE No.	Meaning of Error History Number	Information contents
Push switch on outdoor unit PCB  Monitor mode [ F9 ]	Error history	00	1 time ago (Newest)	When the error occurred, the error code is memorized up to 10 on Main PCB.
		01	2 time ago	
		02	3 time ago	
		03	4 time ago	If the memorized error code becomes over 10, the oldest one will be erased.
		04	5 time ago	
		05	6 time ago	
		06	7 time ago	
		07	8 time ago	
		08	9 time ago	
		09	10 time ago	

Refer to Chapter 4.TROUBLE SHOOTING

4-3-2 Error Code List for Outdoor unit

\* < Reset Error Item List By Abnormal Reset Setting >

- Compressor Motor Loss of Synchronization
- Compressor 1 Temperature Abnormal
- Inverter Compressor Start Up Error
- Discharge Temperature 1 Abnormal
- Low Pressure Abnormal
- Current Sensor 1 Error
- Trip Detection
- Rush Current Limiting Resistor Temp Rise Protection
- Outdoor Unit FAN motor 1 Lock Error
- Outdoor Unit FAN motor 2 Lock Error

# 1-5 FIELD SETTING / FUNCTION SETTING FOR INDOOR UNIT

Function	Function number	Setting number		Default	Details																																																							
Address	01	00~63	Indoor unit address	00																																																								
	02	00~99	Ref. circuit address	00																																																								
Filter indicator interval	11	00	Standard		Adjust the filter cleaning interval notification. If the notification is too early, change to setting 01. If the notification is too late, change to setting 02.																																																							
		01	Longer																																																									
		02	Shorter																																																									
Filter indicator action	13	00	Enable	●	Enable or disable the filter indicator. Setting 02 is for use with a central remote control.																																																							
		01	Disable																																																									
		02	Display only on central remote control																																																									
Ceiling airflow	20	00	Standard	●	Regulate the airfl ow according to the needs of the installation location. When set to 01, the air flow will be stronger. (Cassette type only)																																																							
		01	High Ceiling																																																									
Vertical airflow direction	23	00	Standard	●	Adjust the vertical airflow direction. All airflow direction louvers are adjusted together. (Cassette type only)																																																							
		01	Raise																																																									
Horizontal swing airflow direction	24	00	Standard	●	Adjust the horizontal swing airflow direction. (For horizontal swing equipped models)																																																							
		01	Left half																																																									
		02	Right half																																																									
Static pressure	26	00	SP mode 00		<table><tr><th>Model name</th><th>Range of static pressure</th><th>Normal static pressure</th></tr><tr><td>ARXK07GCLH</td><td rowspan="3">SP mode 00 to 03</td><td rowspan="3">10 Pa</td></tr><tr><td>ARXK09GCLH</td></tr><tr><td>ARXK12GCLH</td></tr><tr><td>ARXK14GCLH</td><td rowspan="3">SP mode 00 to 05</td><td rowspan="3">15 Pa</td></tr><tr><td>ARXK18GCLH</td></tr><tr><td>ARXK24GCLH</td></tr><tr><td>ARXD04GALH</td><td rowspan="6">SP mode 00 to 09 (0 to 90 Pa)</td><td rowspan="6">25Pa</td></tr><tr><td>ARXD07GALH</td></tr><tr><td>ARXD09GALH</td></tr><tr><td>ARXD12GALH</td></tr><tr><td>ARXD14GALH</td></tr><tr><td>ARXD18GALH</td></tr><tr><td>ARXD24GALH</td><td>SP mode 00 to 05 (0 to 50 Pa)</td><td rowspan="3">40Pa</td></tr><tr><td>ARXA24GBLH</td><td rowspan="2">SP mode 00 to 14</td></tr><tr><td>ARXA30GBLH</td></tr><tr><td>ARXA36GBLH</td><td>SP mode 00 to 12</td><td>50Pa</td></tr><tr><td>ARXA45GBLH</td><td>SP mode 00 to 11</td><td>60Pa</td></tr><tr><td>ARXC36GBTH</td><td>SP mode 02 to 16</td><td>100Pa</td></tr><tr><td>ARXC72GBTH</td><td>SP mode 04 to 27</td><td rowspan="3">150Pa</td></tr><tr><td>ARXC90GBTH</td><td>SP mode 05 to 24</td></tr><tr><td>ARXC96GATH</td><td>SP mode 05 to 29</td></tr><tr><td>ARXN18GATH</td><td>SP mode 05 to 10</td><td rowspan="3">50Pa</td></tr><tr><td>ARXN24GATH</td><td>SP mode 05 to 15</td></tr><tr><td>ARXN30GATH</td><td rowspan="4">SP mode 05 to 25</td></tr><tr><td>ARXN34GATH</td></tr><tr><td>ARXN36GATH</td></tr><tr><td>ARXN45GATH</td></tr></table>			Model name	Range of static pressure	Normal static pressure	ARXK07GCLH	SP mode 00 to 03	10 Pa	ARXK09GCLH	ARXK12GCLH	ARXK14GCLH	SP mode 00 to 05	15 Pa	ARXK18GCLH	ARXK24GCLH	ARXD04GALH	SP mode 00 to 09 (0 to 90 Pa)	25Pa	ARXD07GALH	ARXD09GALH	ARXD12GALH	ARXD14GALH	ARXD18GALH	ARXD24GALH	SP mode 00 to 05 (0 to 50 Pa)	40Pa	ARXA24GBLH	SP mode 00 to 14	ARXA30GBLH	ARXA36GBLH	SP mode 00 to 12	50Pa	ARXA45GBLH	SP mode 00 to 11	60Pa	ARXC36GBTH	SP mode 02 to 16	100Pa	ARXC72GBTH	SP mode 04 to 27	150Pa	ARXC90GBTH	SP mode 05 to 24	ARXC96GATH	SP mode 05 to 29	ARXN18GATH	SP mode 05 to 10	50Pa	ARXN24GATH	SP mode 05 to 15	ARXN30GATH	SP mode 05 to 25	ARXN34GATH	ARXN36GATH	ARXN45GATH
		Model name	Range of static pressure	Normal static pressure																																																								
		ARXK07GCLH	SP mode 00 to 03	10 Pa																																																								
		ARXK09GCLH																																																										
		ARXK12GCLH																																																										
		ARXK14GCLH	SP mode 00 to 05	15 Pa																																																								
		ARXK18GCLH																																																										
		ARXK24GCLH																																																										
		ARXD04GALH	SP mode 00 to 09 (0 to 90 Pa)	25Pa																																																								
		ARXD07GALH																																																										
		ARXD09GALH																																																										
		ARXD12GALH																																																										
		ARXD14GALH																																																										
		ARXD18GALH																																																										
		ARXD24GALH	SP mode 00 to 05 (0 to 50 Pa)	40Pa																																																								
		ARXA24GBLH	SP mode 00 to 14																																																									
		ARXA30GBLH																																																										
		ARXA36GBLH	SP mode 00 to 12	50Pa																																																								
		ARXA45GBLH	SP mode 00 to 11	60Pa																																																								
		ARXC36GBTH	SP mode 02 to 16	100Pa																																																								
		ARXC72GBTH	SP mode 04 to 27	150Pa																																																								
		ARXC90GBTH	SP mode 05 to 24																																																									
		ARXC96GATH	SP mode 05 to 29																																																									
		ARXN18GATH	SP mode 05 to 10	50Pa																																																								
		ARXN24GATH	SP mode 05 to 15																																																									
		ARXN30GATH	SP mode 05 to 25																																																									
		ARXN34GATH																																																										
		ARXN36GATH																																																										
		ARXN45GATH																																																										
		01	SP mode 01																																																									
		02	SP mode 02																																																									
		03	SP mode 03																																																									
		04	SP mode 04																																																									
		05	SP mode 05																																																									
		06	SP mode 06																																																									
		07	SP mode 07																																																									
08	SP mode 08																																																											
09	SP mode 09																																																											
10	SP mode 10																																																											
11	SP mode 11																																																											
12	SP mode 12																																																											
13	SP mode 13																																																											
14	SP mode 14																																																											
15	SP mode 15																																																											
16	SP mode 16																																																											
17	SP mode 17																																																											
18	SP mode 18																																																											
19	SP mode 19																																																											
20	SP mode 20																																																											
21	SP mode 21																																																											
22	SP mode 22																																																											
23	SP mode 23																																																											
24	SP mode 24																																																											
25	SP mode 25																																																											
26	SP mode 26																																																											
27	SP mode 27																																																											
28	SP mode 28																																																											
29	SP mode 29																																																											
31	Normal SP	●																																																										
Cool air temperature trigger	30	00	Standard	●	Adjust the cool air trigger temperature. To lower the trigger temperature, use setting 01. To raise the trigger temperature, use setting 02.																																																							
		01	Adjust (1)																																																									
		02	Adjust (2)																																																									
Heat air temperature trigger	31	00	Standard	●	Adjust the heat air trigger temperature. To lower the trigger temperature by 6 degrees C, use setting 01. To lower the trigger temperature by 4 degrees C, use setting 02. To raise the trigger temperature, use setting 03.																																																							
		01	Adjust (1)																																																									
		02	Adjust (2)																																																									
		03	Adjust (3)																																																									

Function	Function number	Setting number		Default	Details
*1 Auto restart	40	00	Enable		Enable or disable automatic system restart after a power outage.
		01	Disable	●	
Cool Air Prevention	43	00	Super low	●	Restrain the cold airflow with making the airflow lower when starting heating operation. To correspond to the ventilation, set to 01.
		01	Follow the setting on the remote controller		
External control	46	00	Start/Stop	●	Allow an external controller to start or stop the system, or to perform an emergency stop, or to perform a forced stop. * If an emergency stop is performed from an external controller, same refrigerant system will be disabled. *If forced stop is set,indoor unit stops by the input to the external input terminals,and Start/Stop by a remote controller is restricted.
		01	Emergency stop		
		02	Forced stop		
Error report target	47	00	All	●	Change the target for reporting errors. Errors can either be reported in all locations, or only on the wired remote.
		01	Display only on central remote control		
Fan setting when cooling thermostat OFF	49	00	Follow the setting on the remote controller	●	When set 00, Indoor unit is continued operation based upon Central remote controller or individual controller set. Once indoor unit received signal from External controller, Indoor unit changed Fan mode forcibly. When set 01, Indoor unit is continued operation based upon Central remote controller or individual controller set. Once indoor unit received signal from External controller, Indoor unit stop forcibly. Connection of the wired remote controller (2-wire type or 3-wire type) and switching its thermistor are necessary.
		01	Stop		

\*1 : Auto restart is an emergency function such as for power failure etc.  
Do not start and stop the indoor unit by this function in normal operation.  
Be sure to operate by the control unit, converter or external input device.

## 1-6 FIELD SETTING / FUNCTION SETTING FOR OUTDOOR AIR UNIT

Function	Function number	Setting number		Default	Details														
Filter indicator interval	11	00	Standard	●	Adjust the filter cleaning interval notification. If the notification is too early, change to setting 01. If the notification is too late, change to setting 02.														
		01	Longer																
		02	Shorter																
Filter indicator action	13	00	Enable		Enable or disable the filter indicator. Setting 02 is for use with a central remote control.														
		01	Disable	●															
		02	Display only on central remote control																
Static pressure	26	05	SP mode 05		<table><tr><th>Model name</th><th>Range of static pressure</th><th>Normal static pressure</th></tr><tr><td>ARXH054GTAH</td><td>SP mode 05 to 19 (50 to 185 Pa)</td><td>185Pa</td></tr><tr><td>ARXH072GTAH</td><td>SP mode 05 to 20 (50 to 200 Pa)</td><td>200Pa</td></tr><tr><td>ARXH096GTAH</td><td>SP mode 05 to 22 (50 to 220 Pa)</td><td>200Pa</td></tr></table>			Model name	Range of static pressure	Normal static pressure	ARXH054GTAH	SP mode 05 to 19 (50 to 185 Pa)	185Pa	ARXH072GTAH	SP mode 05 to 20 (50 to 200 Pa)	200Pa	ARXH096GTAH	SP mode 05 to 22 (50 to 220 Pa)	200Pa
		Model name	Range of static pressure	Normal static pressure															
		ARXH054GTAH	SP mode 05 to 19 (50 to 185 Pa)	185Pa															
		ARXH072GTAH	SP mode 05 to 20 (50 to 200 Pa)	200Pa															
		ARXH096GTAH	SP mode 05 to 22 (50 to 220 Pa)	200Pa															
		06	SP mode 06																
		07	SP mode 07																
		08	SP mode 08																
		09	SP mode 09																
		10	SP mode 10																
		11	SP mode 11																
		12	SP mode 12																
		13	SP mode 13																
		14	SP mode 14																
		15	SP mode 15																
		16	SP mode 16																
		17	SP mode 17																
		18	SP mode 18																
		19	SP mode 19																
		20	SP mode 20																
21	SP mode 21																		
22	SP mode 22																		
31	Normal SP	●																	
*1 Auto restart	40	00	Enable		Enable or disable automatic system restart after a power outage.														
		01	Disable	●															
Cool Air Prevention	43	00	Prohibited		Setting change prohibited.														
		01	Follow the setting on the remote controller	●															
External control	46	00	Start/Stop	●	Allow an external controller to start or stop the system, or to perform an emergency stop, or to perform a forced stop.  * If an emergency stop is performed from an external controller, same refrigerant system will be disabled.  *If forced stop is set,indoor unit stops by the input to the external input terminals,and Start/Stop by a remote controller is restricted.														
		01	Emergency stop																
		02	Forced stop																
Error report target	47	00	All	●	Change the target for reporting errors. Errors can either be reported in all locations, or only on the wired remote.														
		01	Display only on central remote control																
Humidifier control	63	00	mode 00	●	Select control conditions of external output. "Mode 00" is output when heating thermostat is ON, "Mode 01" is output in heating operation, "Mode 02" is output in heating operation and in fan operation.														
		01	mode 01																
		02	mode 02																



# **AIRSTAGE™ J-III L**

*Variable Refrigerant Flow System*

## **2. OUTDOOR UNIT OPERATION CONTROL**

## 2. OUTDOOR UNIT

### 2-1 INPUT / OUTPUT LIST

		Input / output or kind of detail	Control range
I N P U T	Discharge pressure sensor <HIGH> Suction pressure sensor <LOW> Discharge temperature sensor <TH1> Outdoor temperature sensor <TH3> Suction temperature sensor <TH4> Heat exchanger temperature sensor <TH5> Liquid temperature sensor <TH7> Sub-cool heat exchanger (outlet) sensor <TH9> Compressor temperature sensor <TH10> Operation current sensor Pressure switch	Pressure sensor Pressure sensor Themistor <Blue> Themistor < - > Themistor <Red> Themistor <Brown> Themistor <Green> Themistor < White> Themistor < - > Current sensor Pressure switch	Measure range 0.0 to 5.0MPa Measure range 0.0 to 1.7MPa Measure range 10 to 130°C Measure range -25 to 58°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range 10 to 130°C Open 4.2MPa Short 3.2MPa
	Rotary SW & DIP-SW & Push SW	Address and function setting	
O U T P U T	Compressor Electronic expansion valve 1 (Main) Electronic expansion valve 2 (SC-Hex) Fan motor 1 (Upper) Fan motor 2 (Lower) 4-way valve Crank case heater Base heater	DC Inverter compressor EEV coil EEV coil DC Brushless motor DC Brushless motor 4-way valve coil For Inverter Compressor Field supply	Operating voltage DC12V Operating voltage DC12V AC220-240V, 50/60Hz 6/5 W AC240V, 35W AC220-240V, 35W
Communication Input / Output	LON WORKS Inverter communication	Indoor unit ↔ Outdoor unit	
External Input / Output	External input 1 (CN131) (Low noise mode operation) External input 2 (CN132) (Cooling / Heating priority) External input 3 (CN133) (Outdoor unit operation peak control) External input 4 (CN134) (Emergency stop operation)	Dry contact input	
	External output 1 (CN136) (Error display) External output 2 (CN137) (Operation display)	ON (Error) / OFF (Normal) ON (Operation) / OFF (Stop)	Control output: DC 0/12-24V, Max.30mA Control output: DC 0/12-24V, Max.30mA
LED display	Single LED 101 Single LED 102 7 Segment LED	Display the information on operation, error and setting with single LED and 7 segment LED.	



## 2-2 COMPRESSOR OPERATION

### 2-2-1 Operation / Stop Condition

When cooling requirement capacity or heating requirement capacity from either of the indoor units in the same refrigerant circuit is input, the compressor operates.

When all the indoor units in no "cooling requirement capacity" or "heating requirement capacity", the compressor is stopped.

But in the following case, the compressor operates in accordance with operation of each mode.


- During 3 minute restart prevention operation
- Icing protection
- Failure (Refer to chapter 4, TROUBLE SHOOTING )
- Under expansion valve initialization
- At protective operation
- Emergency stop
- Defrost operation
- Peak cut stop operation

### 2-2-2 Capacity Control

#### (1) Capacity of compressor operation

By the operation of DC inverter rotary compressor, the amount of required refrigerant circulation according to cooling and heating load can be supplied from compressor efficiently.

DC inverter rotary compressor is able to control the amount of required refrigerant circulation in details.



## (2) Target low-pressure and high-pressure control

### <Cooling>

In order to make the evaporation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by low-pressure sensor of the outdoor unit.

### <Heating>

In order to make the condensation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by high-pressure sensor of the outdoor unit.

Target low-pressure and high pressure temperature depends on system capacity, capacity of compressor operation, pipe length, and capacity shift switch settings.


## 2-2-3 Speed Range of Start, Stop, And Operation

- On stop mode : 0 rps
- On operating mode : 15 - 120 rps

### (1) Heating starting process

\*The compressor starting process in cool mode does not have the limited hold controlling.

- For Heating operation only, the upper limit speed at starting is made 40rps and is raised in +10rps increments every 60 seconds.
- The compressor operates at the upper limit speed if the target speed is higher than the upper limit speed.
- The compressor operates at the target speed if the target speed is lower than the upper limit speed.



## 2-3 FAN CONTROL

### 2-3-1 Cooling Operation

Fan step	Fan speed (rpm)		
	AJ*072LELAH	AJ*090LELAH	AJ*108LELAH
13	-	-	960
	-	-	880
12	-	-	870
	-	-	790
11	680	780	790
	680	740	710
10	660	660	700
	660	660	620
9	590	590	590
	510	510	510
8	520	520	520
	400	400	400
7	440	440	440
	330	330	330
6	380	380	380
	300	300	300
5	300	300	300
	300	300	300
4	450	450	450
	0	0	0
3	300	300	300
	0	0	0
2	Intermittent 1	Intermittent 1	Intermittent 1
	0	0	0
1	Intermittent 2	Intermittent 2	Intermittent 2
	0	0	0
0	0	0	0
	0	0	0

Step	Upper FAN
	Lower FAN

Intermittent 1 : 14 sec. ON (300rpm), 17 sec. OFF

Intermittent 2 : 19 sec. ON (300rpm), 17 sec. OFF

#### ● Switching conditions of step

The initial speed of the outdoor unit is detected by out door temperature sensor.

Outside air temperature sensor detected value	Fan step
TAOUT > 30°C	9
30°C ≥ TAOUT > 20°C	7
20°C ≥ TAOUT > 10°C	4
10°C ≥ TAOUT	0

Thereafter, the high-pressure is monitoring at a set time interval and the fan speed is changed by the following conditions.

(Conditions which lower the fan speed)


High-pressure saturation < low limit of target high-pressure saturation range and heat sink temperature ≤ 55°C: 8&10HP  
60°C: 12HP

(Conditions which raise the fan speed)

High-pressure saturation > upper limit of target high-pressure saturation or heat sink temperature ≥ 60°C: 8&10HP  
65°C: 12HP

The fan is controlled to keep high puressure saturation temperature within the target range as follows

High-pressure saturation temperature



## 2-3-2 Heating Operation

Fan step	Fan speed (rpm)		
	AJ*072LELAH	AJ*090LELAH	AJ*108LELAH
13	-	-	960
	-	-	880
12	-	-	870
	-	-	790
11	680	780	790
	680	740	710
10	660	660	700
	660	660	620
9	590	590	590
	510	510	510
8	520	520	520
	400	400	400
7	440	440	440
	330	330	330
6	380	380	380
	300	300	300
5	300	300	300
	300	300	300
4	450	450	450
	0	0	0
3	300	300	300
	0	0	0
2	Intermittent 1	Intermittent 1	Intermittent 1
	0	0	0
1	Intermittent 2	Intermittent 2	Intermittent 2
	0	0	0
0	0	0	0
	0	0	0

Step	Upper FAN
	Lower FAN

Intermittent 1 : 14 sec. ON (300rpm), 17 sec. OFF

Intermittent 2 : 19 sec. ON (300rpm), 17 sec. OFF

### ● Switching conditions of step

The initial speed of the first boot outdoor unit is detected by outdoor air temperature sensor value (TAOUT).

Outside air temperature sensor detected value	Fan step
TAOUT < 0°C	8HP&10HP: 11 / 12HP: 13
0°C ≤ TAOUT < 5°C	6
5°C ≤ TAOUT	0

Thereafter, the high-pressure is monitoring at a set time interval and the fan speed is changed by the following conditions.

(Condition which lowers the fan speed)

Low-pressure ≥ 0.85MPa and heat sink temperature ≤ 55°C: 8&10HP  
60°C: 12HP

(Condition which raises the fan speed)

Low-pressure saturation ≤ 0.74MPa or heat sink temperature ≥ 60°C: 8&10HP  
65°C: 12HP

## 2-3-3 Low noise mode

When the low noise mode setting ON from PUSH SW or EXTERNAL INPUT, the outdoor unit operates in the low noise mode as follows.

«Settings and corresponding operations»

Capacity priority setting ( PUSH SW )	Low noise level setting ( PUSH SW )	Operation mode
OFF	ON	LOW NOISE MODE
ON	ON	* Automatic switching


«Low noise mode and operation contents»

			AJ*072LELAH	AJ*090LELAH	AJ*108LELAH
Low Noise Mode Level 1	COOL	Max FAN Step	8	9	10
		Upper FAN Lower FAN	520 400	590 510	700 620
		Max Compressor Speed	48	63	80
	HEAT	Max FAN Step	8	9	10
		Upper FAN Lower FAN	520 400	590 510	700 620
		Max Compressor Speed	55	65	85
Low Noise Mode Level 2	COOL	Max FAN Step	7	8	8
		Upper FAN Lower FAN	440 330	520 400	520 400
		Max Compressor Speed	35	47	54
	HEAT	Max FAN Step	7	8	8
		Upper FAN Lower FAN	440 330	520 400	520 400
		Max Compressor Speed	37	48	58

The operating noise is reduced by limiting the rotational speed of the compressor and fan motor

LOW NOISE MODE    • • • The operating sound lowers from about 3 to 5 dB more than the rated value

\* Automatic switching



## 2-3-4 Other Control

To accurately detect the outside air temperature, the fan is operated while the outdoor unit is stopped.

## 2-4 EXPANSION VALVE CONTROL

	Initialization conditions	Operation mode	Control range	
			operation	stop
EEV 1	① When power turned on ② When operation stopped	Cooling	3000 Pulses	40 pulses
		Heating	160 - 3000 pulses	
EEV 2		Cooling	55 - 500 pulses	0 pulses
		Heating		

< Cooling mode >  
3000 pulses basically.

< Heating mode >  
EEV is controlled so that the system reaches closer to the target discharge temperature that is calculated from high and low pressure.

## 2-5 SPECIAL OPERATION

### 2-5-1 Oil Recovery Operation

#### Purpose of the operation

The amount of refrigerant lubricant oil which has been transported to the indoor units and the connection pipe with the refrigerant will become large as the operation time of compressor increases. It is necessary to recover the oil back into the outdoor unit for a certain time interval in order to prevent compressors from damaging due to lack of lubrication oil.

#### 1. Oil Recovery in Cooling operation

##### < Start condition >

Compressor accumulated operation time since last cooling oil recovery operation exceeds 3 hours (first time : 1hour)

##### < End condition >

30 seconds have elapsed since the start and "suction temperature - low pressure saturation temperature  $\leq 5\text{deg}$ " or 6 minutes have elapsed since the start.

##### < Operation >

COMPRESSOR: The rotation speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit): Controlled pulse (as normal operation mode).

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode).

#### 2. Oil Recovery in Cooling start-up operation

##### < Start condition >

LP < 0.13Mpa

##### < End condition >

HP- LP  $\geq 0.7\text{Mpa}$  and LP  $\geq 0.18\text{Mpa}$  or LP  $\geq 0.52\text{Mpa}$  or 15 minutes have elapsed since the start.

##### < Operation >

COMPRESSOR: The rotation speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit): Controlled pulse (as normal operation mode).

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode).

#### 3. Oil Recovery in Heating operation

##### < Start condition >

Compressor accumulated operation time since the last heating oil recovery exceeds 8 hours (first time : 1hour)

##### < End condition >

After 4 minutes have elapsed



##### < Operation >

COMPRESSOR: The rotation speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit) : Controlled pulse (as normal operation mode)

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode)

#### Others

During the oil recovery operation,  appears on the display of wired and central remote controller, and  appears on the simple remote controller.

The operation indicators (LED) of the indoor units flash slowly.

## 2-5-2 Pre-heat Operation

This pre-heat operation protects the start up failure by preventing the refrigerant from soaking into the oil in compressor.

Crankcase heater ON: 30 minutes elapsed since installed compressors stopped (However, ON when power turned on)

OFF: Compressor starts

\*It doesn't control according to the temperature.

## 2-5-3 Defrost Operation Control

### Defrost Operation Start Condition 1

Outdoor temperature  $< 2^{\circ}\text{C}$  and Compressor stop count exceed 20 times at less than 10 minutes of accumulated heating operation time

### Defrost Operation Start Condition 2

Accumulated heating operation time is 40 minutes or longer

[Accumulated heating operation time is reset at the end of cooling operation or defrosting operation.]

and

an outdoor unit satisfies condition ① or ② below

Condition ①: "Heat exchange temperature  $\leq -2^{\circ}\text{C}$ " accumulated operating time is 180 minutes or longer

Condition ②: After the following all condition satisfied, "heat exchange temperature  $\leq$  defrosting start judgment temperature and during heat exchange liquid temperature drop" accumulated time: 10 minutes

(a) accumulated heating operation time  $\geq 30$  minutes

(b) 10 minutes have elapsed after outdoor unit starting

(c) 5 minutes have elapsed since oil recovery

\* Defrosting start and end judgment temperature are determined by the outdoor temperature.

⇒ **Defrosting start judgment temperature =  $0.8 \times \text{outdoor temperature} - 11.6$  (However,  $-27.6^{\circ}\text{C}$  to  $-6^{\circ}\text{C}$ )**

If the calculated result is lower than  $-27.6^{\circ}\text{C}$ , the judgment temperature is defined as  $-27.6^{\circ}\text{C}$

If the calculated result is higher than  $-6^{\circ}\text{C}$ , the judgment temperature is defined as  $-6^{\circ}\text{C}$

### Defrost Operation End Condition

① At all outdoor units, heat exchange liquid temperature  $\geq$  end judgment temperature  
or

② when 15 minutes have elapsed from the start

⇒ **Defrosting end judgment temperature =  $0.39 \times \text{outdoor temperature} + 12.7$  (However, 5 to  $12^{\circ}\text{C}$  range)**

If the calculated result is lower than  $5^{\circ}\text{C}$ , the judgment temperature is defined as  $5^{\circ}\text{C}$

If the calculated result is higher than  $12^{\circ}\text{C}$ , the judgment temperature is defined as  $12^{\circ}\text{C}$



## 2-6 PROTECTIVE FUNCTION

### 2-6-1 Protective Function List

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
Discharge Temp Protection 1	Discharge Temp Thermistor	○		—	<p>&lt;Starting conditions&gt; 3 minutes have elapsed since the start of operation and (discharge temperature <math>\geq 105^{\circ}\text{C}</math> or suction SH <math>\geq 10^{\circ}\text{C}</math> accumulated time 30 minutes)</p> <p>&lt;Reset conditions&gt; Discharge temperature <math>\leq 100^{\circ}\text{C}</math> and suction SH <math>\leq 7^{\circ}\text{C}</math></p>	EEV of operating indoor unit gradually opened
Discharge Temp Protection 2	Discharge Temp Thermistor	○	○	—	<p>&lt;Starting conditions&gt; Cooling: Discharge temperature <math>\geq 100^{\circ}\text{C}</math></p> <p>&lt;Reset conditions&gt; Discharge temperature <math>&lt; 95^{\circ}\text{C}</math></p>	EEV2 + 30pls/30 secs
Discharge Temp Protection 4	Discharge Temp Thermistor	○	○	—	<p>&lt; starting condition&gt; Discharge temperature <math>\geq 110^{\circ}\text{C}</math></p> <p>&lt;Pattern reset condition&gt; Discharge temperature <math>&lt; 105^{\circ}\text{C}</math> and Compressor temperature <math>&lt; 110^{\circ}\text{C}</math></p>	Compressor speed -6rps every 30 secs Speed rise prohibited, when discharge temperature becomes lower than $105^{\circ}\text{C}$ , prohibit the rotational speed rise of the compressor.
Discharge Temp Protection 5	Discharge Temp Thermistor		○	—	<p>&lt;Starting conditions&gt; Discharge temperature <math>\geq 95^{\circ}\text{C}</math> and EEV1=3000 pls</p> <p>&lt;Reset conditions&gt; 2 minutes have elapsed and (discharge temperature <math>\leq 90^{\circ}\text{C}</math> or EEV1 <math>\leq 400</math>pls)</p>	Expansion valve of stopped indoor unit gradually opened (upper limit 200pls)
Discharge Temp Protection Stop	Discharge Temp Thermistor	○	○	P1	<p>&lt;Pattern ① starting condition&gt; Discharge temperature <math>\geq</math> fixed value (<math>120^{\circ}\text{C}</math>)</p> <p>&lt;Pattern ① reset condition&gt; 3 minutes have elapsed and discharge temperature <math>\leq 85^{\circ}\text{C}</math></p>	Compressor stopped
				EA11	<p>&lt;Pattern ② starting condition&gt; Pattern ① generated 2 times within 40 minutes</p> <p>&lt;Pattern ② reset condition&gt; Error reset (push button SW) executed after power turned on again</p>	Compressor stopped (permanent stop) Error display
High Pressure Protection 3	High Pressure Sensor	○		—	<p>&lt;Starting conditions&gt; Fixed time has elapsed and high-pressure <math>\geq 3.50\text{MPa}</math> (* Fixed time at start of operation: 10 secs, after operation execution: 20 secs)</p> <p>&lt;Reset conditions&gt; Operation (fan speed 1 step increase) complete</p>	Fan speed 1 step increase
High Pressure Protection 4	High Pressure Sensor		○	—	<p>&lt;Starting conditions&gt; High-pressure <math>\geq 3.50\text{MPa}</math></p> <p>&lt;Reset conditions&gt; High-pressure <math>&lt; 3.50\text{MPa}</math></p>	Fan lowest speed Upper 300 rpm Lower 0 rpm
High Pressure Protection 5	High Pressure Sensor		○	—	<p>&lt;Starting conditions&gt; High-pressure <math>\geq 3.20\text{MPa}</math></p> <p>&lt;Reset conditions&gt; High-pressure <math>&lt; 3.20\text{MPa}</math></p>	Compressor capacity lowered/every 15 secs
Abnormal High Pressure protection Control	High Pressure Sensor	○		—	<p>&lt;Starting conditions&gt; HP <math>\geq 3.68\text{MPa}</math></p> <p>&lt;Reset conditions&gt; After 25 seconds have elapsed and, HP <math>&lt; 3.60\text{MPa}</math></p>	Compressor capacity rise prohibited
				—	<p>&lt;Starting conditions&gt; HP <math>\geq 3.8\text{MPa}</math></p> <p>&lt;Reset conditions&gt; After 25 seconds have elapsed and, HP <math>&lt; 3.68\text{MPa}</math></p>	Compressor capacity lowered every 30 secs

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
High Pressure Protection Stop 1	High Pressure Sensor	○	○	P2	<Pattern ① starting condition> High-pressure $\geq 4.00\text{MPa}$  <Pattern ① reset condition> 5 minutes have elapsed and high-pressure $\leq 3.50\text{MPa}$	Compressor stopped
				EA41	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and high-pressure $\leq 3.50\text{MPa}$	Compressor stopped
High Pressure Protection Stop 2	Pressure Switch	○	○	P2	<Pattern ① starting condition> Pressure SW operated (Operated by high-pressure $\geq 4.20\text{MPa}$ )  <Pattern ① reset condition> 5 minutes have elapsed and pressure SW operation reset (Reset by high-pressure $\leq 3.2\text{MPa}$ )	Compressor stopped
				EA42	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and pressure SW operation reset (Reset by high-pressure $\leq 3.2\text{MPa}$ )	Compressor stopped Error display
Low Pressure Protection 1	Low Pressure Sensor		○	—	<Starting conditions> 3 minutes have elapsed and low-pressure $\leq 0.18\text{MPa}$  <Reset conditions> 3 minutes have elapsed and low-pressure $\geq 0.22\text{MPa}$	EEV of stopped indoor unit opened quickly (450pls)
Abnormal Low Pressure Protection Control	Low Pressure Sensor		○	—	<Starting condition> Low-pressure $\leq 0.16\text{MPa}$ <Reset condition> 3 minutes have elapsed and low-pressure $\geq 0.18\text{MPa}$	Compressor capacity lowered every 180 secs, when the Low-pressure becomes more than 0.17MPa, prohibit compressor capacity rise
Low Pressure Protection Stop	Low Pressure Sensor	○	○	P3	<Pattern ① starting condition> Low-pressure $\leq 0.05\text{MPa}$ or low-pressure $\leq 0.10\text{MPa}$ continues for 10 mins  <Pattern ① reset condition> 3 minutes have elapsed and low-pressure $\geq 0.17\text{MPa}$	Compressor stopped
				EA51	<Pattern ② starting condition> Pattern ① generated 5 times within 180 minutes.  <Pattern ② reset condition> Error reset (push button SW) executed after power turned on again.	Compressor stopped (permanent stop) Error display
Compressor Temp Protection	Compressor Temp Thermistor	○	○	—	<Starting condition> Compressor temperature $\geq$ fixed value (115°C)  <Reset condition> Compressor temperature < fixed value (110°C) and Discharge temperature < fixed value (105°C)	Compressor stopped
Compressor Temp Protection Stop	Compressor Temp Thermistor	○	○	P4	<Pattern ① starting condition> Compressor temperature $\geq$ fixed value (130°C)  <Pattern ① reset condition> 3 minutes have elapsed and discharge temperature $\leq 90^\circ\text{C}$	Compressor stopped
				EA31	<Pattern ② starting condition> Pattern ① generated 2 times within 40 minutes  <Pattern ② reset condition> Error reset (push button SW) executed after power turned on again	Compressor stopped (permanent stop) Error display

Protective Function	Detect Parts	COOL	HEAT	DISPLAY	Operating Condition	Operation
Overcurrent Break Stop (Compressor)	Overcurrent Protection Circuit	○	○	E941 (permanent stop)	Compressor is stopped when the over current protection circuit in the inverter PCB detects an abnormal current during the operation. If it repeated 5 times, the compressor becomes permanent stop.	Compressor stopped
				E931 (permanent stop)	Compressor is stopped when the over current protection circuit in the inverter PC Board detects an abnormal current at the time of start up. Compressor becomes permanent stop if it repeated over the number of set time.	
				—	<Reset condition> Error reset (push button SW) executed after power turned on again.	
Heatsink Temp Protection Stop	Heatsink Temp Thermistor	○	○	—	<Pattern ① starting condition> Heat sink temperature $\geq 95^{\circ}\text{C}$  <Pattern ① reset condition> 3 minutes have elapsed and heat sink temperature $\leq 74^{\circ}\text{C}$	Compressor stopped
				EAC4	<Pattern ② starting condition> Pattern ① generated 3 times within 60 minutes.  <Pattern ② reset condition> 10 minutes have elapsed and heat sink temperature $\leq 74^{\circ}\text{C}$	Compressor stopped Error display
Frequency Maximum Setting Protection (Compressor)	Current Detector Circuit	○	○	—	<Pattern ① starting condition> Current value $\geq$ Cooling: 14.8A (8,10HP) / 17.7A (12HP) Heating: 23.5A  <Pattern ① reset condition> Current value < Cooling: 22.5A / Heating: 23.5A	Compressor speed rise prohibited
				—	<Pattern ② starting condition> Current value $\geq$ Cooling: 15.8A (8,10HP) / 18.7A (12HP)  <Pattern ② reset condition> Current value < Cooling: 23.0A / Heating: 24.0A  <div>           • Pattern ① and ② start current value changed by outside temperature         </div>	Compressor speed lowered

Protective function	Detect device	Cool	Heat	Display	Operating condition	Operation
Outdoor Unit Reverse phase, Missing phase Wire Error	Main PCB Reverse phase prevention circuit	○	○	E6 15	< Starting condition> 1 Reverse phase prevention circuit detected reversed phase input or input was not normal at the time of power ON. 2 Reverse phase prevention circuit detected open-phase after power ON.  < Reset condition> Reverse phase prevention circuit detects normal condition	System Stop Error indication

# **AIRSTAGE™ J-III L**

*Variable Refrigerant Flow System*

## **3. INDOOR UNIT OPERATION**

# 3. INDOOR UNIT OPERATION

## 3-1 FAN CONTROL

### 3-1-1 Fan Speed Setting

Fan speed setting



Press the FAN CONTROL button to set the fan speed.




### 3-1-2 "AUTO" Position

#### 1. COOLING OPERATION


The fan speed is determined automatically in accordance with the condition " $T_R$ (corrected room temperature) -  $T_s$  (corrected set temperature)" as shown on the right. However, the fan speed zone is determined in the manner as the room temperature increases for the following cases.

- (1) When the  $T_s$  is changed.
- (2) When the operation mode is changed from other mode to "COOL".
- (3) When the fan control is changed from other position to "AUTO".



#### 2. HEAT OPERATION

Same as Cooling operation, fan speed is decided by the difference between the room temperature and the set temperature.



#### 3. DRY OPERATION

The indoor fan always rotates at "Lo" speed.



- (1) The indoor fan starts operation 5 seconds after the electric expansion valve opens. However, when the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is not stopped, the fan will rotate immediately without a delay time of 5 seconds.
- (2) The indoor fan will stop in 30 seconds when the refrigerant circulation stops.
- (3) The indoor fan will stop immediately when the indoor unit is stopped by pushing the stop button or by a setting of ON timer.
- (4) When the refrigerant circulation is stopped due to a lower room temperature for more than 3 minutes, the fan will rotate 2 minutes at intervals of 3 minutes.
- (5) When the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is stopped, the fan will rotate for 1 minute and then it will operate according to the statement (4).

## 3-2 MASTER CONTROL

### 3-2-1 Operation Mode Control

Each operation mode is controlled as below.

(1) Stop mode

Indoor fan motor	: OFF
Electric expansion valve	: Stop pulse
Drain pump	: Turns ON-OFF by the drain pump control function

(2) Cool, Dry and Heat Mode

	Cool	Dry	Heat
Indoor fan motor	Operates according to the AIR FLOW-MODE setting.	See the fan control page.	Operates according to the AIR FLOW-MODE setting, and besides cold air prevention operation
Drain pump	Turns ON-OFF by the drain pump control function		
Electrical expansion valve	Pulse controlled by the temperature difference calculation and frost prevent fuction	Pulse controlled by the temperature difference calculation and frost prevent function	Pulse controlled by the temperature difference.

(3) Priority mode


The purpose of the priority mode is to restrict operation commands (heating, cooling, dry) from the connected indoor units. There are 3 priority modes of Neutral, Cooling Priority, and Heating Priority. The operation modes restricted by each of these modes are as follows:

Priority mode	Restricted operation mode
Neutral	No restrictions
Cooling priority	Heating
Heating priority	Cooling, dry

1. Priority mode decision methods

Method 1. (Default value)


The initial priority mode is made Neutral and is shifted to Cooling Priority when cooling and to Heating Priority when heating depending on which operation mode (cooling, heating) was input first. After shifting to Cooling Priority or Heating Priority, the priority mode shifts to Neutral only when there was a Stop input from all the indoor units.



Method 2. (Management by outdoor unit)

Operation mode management is made "Management by outdoor unit" by outdoor unit PUSH-SW (field setting).

The priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the outdoor unit regardless of the current mode.



### Method 3. (Management by indoor unit)


Operation mode management is made "Management by indoor unit" by outdoor unit PUSH-SW (field setting).

Then the master indoor unit is set by wired remote controller.

Thereupon the priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the master indoor unit regardless of the current priority mode.

The priority mode is fixed at either cooling or heating even if the master indoor unit stops

Cooling/heating switching can be performed by the master indoor unit only.



### (4) Opposite operation mode

When the operation mode commanded from an indoor unit (remote controller) and the operation mode allowed by the system (cooling and dry operation for cooling only type and operation mode allowed by priority mode for heat pump type) do not match, it is indicated by blinking of an LED.

Timer lamp: 3 secs ON/1 sec OFF repeated

### 3-2-1 Operation Mode Control for Outdoor air unit

Each operation mode is controlled as below.

#### (1) Stop mode

Outdoor air unit fan motor : OFF  
Electric expansion valve : Stop pulse  
Drain pump : Turns ON-OFF by the drain pump control function  
Solenoid valve : Closed

#### (2) Cool and Heat Mode

Each operation mode is controlled as below.

	Cool	Heat	Fan
Outdoor air unit fan motor	Operates according to the HIGH MODE setting.	Operates according to the HIGH MODE setting.	Operates according to the HIGH MODE setting.
Drain pump	Turns ON-OFF by the drain pump control function		
Electrical expansion valve	Pulse controlled by the temperature difference calculation and freeze prevention control	Pulse controlled by the temperature difference.	Stop pulse
Solenoid valve	Closed at all times	Opened at thermostat off and compressor on. Closed at other operation.	Closed at all times



### (3) Priority mode


The purpose of the priority mode is to restrict operation commands (heating, cooling) from the connected outdoor air units. There are 3 priority modes of Neutral, Cooling Priority, and Heating Priority. The operation modes restricted by each of these modes are as follows:

Priority mode	Restricted operation mode
Neutral	No restrictions
Cooling priority	Heating
Heating priority	Cooling

#### 1. Priority mode decision methods

##### Method 1. (Default value)


The initial priority mode is made Neutral and is shifted to Cooling Priority when cooling and to Heating Priority when heating depending on which operation mode (cooling, heating) was input first. After shifting to Cooling Priority or Heating Priority, the priority mode shifts to Neutral only when there was a Stop input from all the indoor units.



##### Method 2. (Management by Outdoor unit)

Operation mode management is made "Management by Outdoor unit" by Outdoor unit PUSH-SW (field setting).

The priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the Outdoor unit regardless of the current mode.




##### Method 3. (Management by indoor unit)

Operation mode management is made "Management by indoor unit" by Outdoor unit PUSH-SW (field setting).

Then the master indoor unit is set by wired remote controller.

Thereupon the priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the master indoor unit regardless of the current priority mode.

The priority mode is fixed at either cooling or heating even if the master indoor unit stops Cooling/Heating switching can be performed by the master indoor unit only.



### (4) Opposite operation mode

When the operation mode commanded from an indoor unit (remote controller) and the operation mode allowed by the system (cooling and dry operation for cooling only type and operation mode allowed by priority mode for heat pump type) do not match, it is indicated by blinking of an LED.

Timer lamp: 3 secs ON/1 sec OFF repeated


## 3-2-2 Auto Changeover

[Method]

1. Switch operation mode management to "Management by indoor unit" by outdoor unit DIP-SW.
2. Set the master indoor unit by wired remote controller.
3. Judge cooling/heating by the difference between the master indoor unit's setting temperature and the room temperature.

### ■ AUTO CHANGEOVER operation

Operation flow chart



### 3-2-2 Auto Changeover Heating / Cooling Operation for Outdoor air unit


Function is available when an outdoor air unit set as the administrative indoor unit (Management Outdoor air unit).  
Refer to the setting Method

#### Setting Method

1. Switch operation mode management to "Management by outdoor air unit" by Outdoor unit PUSH-SW.
2. Set the master outdoor air unit by wired remote controller.
3. Judge cooling/heating by the difference between the master outdoor air unit's setting temperature and the suction airflow temperature

#### ■ AUTO CHANGEOVER operation


Operation flow chart



### 3-2-3 "COOL" Position

When using the cooling mode, set the temperature to a value lower than the current room temperature, otherwise the indoor unit will not start the cooling operation and only the fan will rotate.


An example for COOLING TEMPERATURE CONTROL time chart (Manual setting)



### 3-2-4 "HEAT" Position

- (1) When using the heating mode, set the temperature to a value higher than the current room temperature, otherwise the indoor unit will not start the heating operation.
- (2) After the start of heating operation, the fan of indoor unit will not rotate until the heater exchange is warmed up to blow out warm air.
- (3) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.


An example for HEATING TEMPERATURE CONTROL time chart (Manual setting)



### 3-2-4 "COOL" Position for Outdoor air unit

When using the cooling mode, set the temperature to a value lower than the discharge airflow temperature, otherwise the outdoor air unit will not start the cooling operation and only the fan will rotate.


An example for COOLING TEMPERATURE CONTROL time chart (Manual setting)



### 3-2-5 "HEAT" Position for Outdoor air unit

- (1) When using the heating mode, set the temperature to a value higher than the discharge airflow temperature, otherwise the outdoor air unit will not start the heating operation.
- (2) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.

An example for HEATING TEMPERATURE CONTROL time chart (Manual setting)




## 3-3 LOUVER CONTROL

### (1) ADJUSTING THE DIRECTION OF AIR CIRCULATION

Instructions relating to heating (\*) are applicable only to heat pump type outdoor unit.  
Begin air conditioner operation before performing this procedure.

#### Vertical Air Direction Adjustment

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE", "COMPACT WALL MOUNTED TYPE" and "COMPACT FLOOR TYPE".



Press the **VERTICAL AIR FLOW DIRECTION SET** button.

**Example :** When set to vertical air direction.

- Press the VERTICAL AIRFLOW DIRECTION button.


The temperature display will change to the vertical airflow direction setting display.

- Press the VERTICAL AIRFLOW DIRECTION button to change the vertical louvre position.  
The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④

Heating : ①, ②, ③, ④


#### ■ LARGE CEILING TYPE




#### ■ UNIVERSAL FLOOR/CEILING TYPE




#### ■ CASSETTE TYPE




#### ■ WALL MOUNTED TYPE



#### ■ COMPACT WALL MOUNTED TYPE



#### ■ COMPACT FLOOR TYPE



#### ⚠ DANGER!

Never place fingers or foreign objects inside the outlet ports, since the internal fan operates at high speed and could cause personal injury.

- Always use the remote control unit's AIR FLOW DIRECTION button to adjust the UP/DOWN air direction flaps or RIGHT/LEFT air direction louvers. At tempting to move them manually could result in improper operation; in this case, stop operation and restart.  
The louvers should begin to operate properly again.
- When used in a room with infants, children, elderly or sick persons, the air direction and room temperature should be considered carefully when making settings.

- Use the air direction adjustments within the ranges shown above.
- The vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.  
During Cooling mode : Horizontal flow ①  
\* During Heating mode : Downward flow ④
- During AUTO mode operation, for the first minute after beginning operation, airflow will be horizontal ①, the air direction cannot be adjusted during this period.

## Horizontal Air Direction Adjustment


This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE" and "WALL MOUNTED TYPE".

**Press the HORIZONTAL AIR FLOW DIRECTION SET button.**

- Press the HORIZONTAL AIRFLOW DIRECTION button. The temperature display will change to the horizontal airflow direction setting display.
- Press the HORIZONTAL AIRFLOW DIRECTION button to change the horizontal louvre position. The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④, ⑤

Heating : ①, ②, ③, ④, ⑤




**Example :** When set to horizontal air direction.


### ■ LARGE CEILING TYPE



### ■ WALL MOUNTED TYPE



### ■ UNIVERSAL FLOOR/CEILING TYPE



## (2) SWING OPERATION

Instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE", "COMPACT WALL MOUNTED TYPE" and "COMPACT FLOOR TYPE".


Begin air conditioner operation before performing this procedure.

### To select Vertical airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE", "COMPACT WALL MOUNTED TYPE" and "COMPACT FLOOR TYPE".

**Press the VERTICAL SWING button for more than two seconds.**

The remote controller's Vertical Swing Display will light up.  
In this mode, the UP/DOWN air direction flaps will swing automatically to direct the air flow both up and down.



**Example :** When set to vertical swing.

### To Stop Vertical airflow SWING Operation

**Press the VERTICAL SWING button for more than two seconds once and again.**

The remote controller's Vertical Swing Display will go out.  
Airflow direction will return to the setting before swing was begun.

Instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE", "COMPACT WALL MOUNTED TYPE", and "COMPACT FLOOR TYPE".

### About Vertical Airflow SWING Operation

- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Air swing range


Air flow direction set	Range of swing
①	① to ④ (All range)
②	
③	
④	

### To select Horizontal Airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR / CEILING TYPE", "WALL MOUNTED TYPE".

**Press the HORIZONTAL SWING button for more than two seconds.**

The remote controller's Horizontal Swing Display will light up. In this mode, the RIGHT/LEFT air direction louvers will swing automatically to direct the airflow both right and left.



**Example :** When set to horizontal swing.

### To stop Horizontal airflow SWING Operation

**Press the HORIZONTAL SWING button for more than two seconds once and again.**

The remote controller's Horizontal Swing Display will go out. Airflow direction will return to the setting before swing was begun.

### About Horizontal Airflow Swing Operation

- Left and right swing range can be changed in 3 steps by field setting.
- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Left and right swing range (◆ ... Factory setting)

Range of swing	Function Number	Setting Value
◆ ① to ⑤ (All range)	24	00
① to ③		01
③ to ⑤		02



## 3-4 ELECTRONIC EXPANSION VALVE CONTROL

### 1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

### 2. Operation Control

- When indoor unit stopping

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Slightly open

- When starting up  
(Cooling) Move to the cooling control base pulse in steps.  
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control  
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Room temperature control  
The room temperature is controlled so that it reaches to the set-up temperature based on the difference between the room temperature and the set-up temperature, and the change of indoor unit temperature. if the room temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.

### 3. Special Control

- Oil recovery operation : Controlled pulse.
- Test run operation : Controlled pulse.
- Icing protection control : Fully closed.
- Pump down operation : Fully open.
- Defrost operation : Controlled pulse

## 3-5 DRAIN PUMP OPERATION

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigent circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
  - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
  - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.  
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

## 3-4 ELECTRONIC EXPANSION VALVE CONTROL for Outdoor air unit

### 1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

### 2. Operation Control

- When indoor unit stopping by Thermo-OFF condition.

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Fully closed

- When starting up  
(Cooling) Move to the cooling control base pulse in steps.  
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control  
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Discharge airflow temperature control  
The discharge airflow temperature is controlled so that it reaches to the set-up temperature based on the difference between the discharge airflow temperature and the set-up temperature.  
Cooling operation: 1) If the discharge airflow temperature becomes 5°C lower than the set-up temperature, EEV is fully closed.  
2) If the suction airflow temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.  
Heating operation: 1) If the discharge airflow temperature becomes 5°C higher than the set-up temperature for 5 minutes or more, EEV is fully closed.  
2) If the suction airflow temperature becomes 0.5°C higher than the set-up temperature, EEV is fully closed.

### 3. Special Control

- Oil recovery operation : Controlled pulse(Maximum 1400 puls)
- Test run operation : Controlled pulse.
- Freeze prevention control : Fully closed.
- Vacuuming operation : Fully open.
- Defrost operation : Controlled pulse(Maximum 1400 puls)

## 3-5 DRAIN PUMP OPERATION for Outdoor air unit

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigent circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
  - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
  - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.  
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

## 3-6 FUNCTION

### 3-6-1 Auto Restart

The air conditioner restarts with the previous setting operation.

### 3-6-2 Icing Protection Control

The icing of the indoor heat exchanger is prevented during the cooling and dry mode operation.

(1) Starting Condition

- Compressor is operation more than 3 minutes.  
When "Heat exchanger inlet temperature  $\leq T_A$ " continues \*4 minutes or more.
- Compressor is operation more than 3 minutes.  
When "Heat exchanger outlet temperature  $\leq T_A$ " continues 4 minutes or more.

(2) Operation

EEV is closed.  
Fan is at the setting amount.

(3) Completing Condition

Heat exchanger inlet and middle temperature  $\geq T_B$   
After more than 5 minutes


\* Drain pump turns off at 60 minutes past the completion of the icing protection operation.

$T_A$	$T_B$
1°C	7°C

### 3-6-3 Oil Recovery Operation

[Oil recovery operation] : It periodically returns the residual refrigerant ion oil in the indoor unit and the connection piping back to the outdoor unit , and prevents the compressor oil level from decreasing.

Indoor unit LED : Operation LED



Indoor fan : Same operation before oil recovery operation.

Indoor EEV : Control pulse


\* During the above operation, a refrigerant noise may be from the indoor unit.

### 3-6-4 Outdoor temperature protected operation for Outdoor air unit


#### 1. COOL OPERATION

The contents of operation is controlled as following based on the suction airflow temperature.

- a) Operation mode management is made  
"Management by indoor unit", and  
outdoor air unit is master indoor unit.




- b) Cases Other than (a)



#### 2. HEAT OPERATION


The contents of operation is controlled as following based on the suction airflow temperature.




#### 3. FAN OPERATION

The contents of operation is controlled as following based on the suction airflow temperature.

- a) Operation mode management is made  
"Management by indoor unit", and  
outdoor air unit is master indoor unit.



- b) Cases Other than (a)



## 3-7 TIMER CONTROL

### 3-7-1 Wireless Remote Controller

UTY - LNH\*

There are following 4 kinds of timer modes are available.




- ON Timer
- OFF Timer
- PROGRAM Timer
- SLEEP Timer

#### 1. ON / OFF TIMER

The timer functions cannot be used when this controller is used together with the remote controller (Wired type).  
A beeping sound is made when a signal is received.

##### To set the ON / OFF timer







Press the START/ STOP button to start the air conditioner, and then proceed as follows.

<b>1</b>  Press the <b>TIMER MODE</b> button to select "OFF TIMER" or "ON TIMER" — CANCEL → OFF TIMER → ON TIMER — — PROGRAM TIMER (OFF ← ON, OFF → ON) —	<b>2</b>   Adjust the OFF or ON time. (About 5 seconds later, the entire display will reappear.)
--	---

#### 2. PROGRAM TIMER

##### To set the PROGRAM timer

Press the START/ STOP button to start the air conditioner, and then proceed as follows.

<b>1</b>  Select "OFF TIMER"	<b>2</b>  Adjust the OFF time.	<b>3</b>  Select "ON TIMER"
<b>4</b> Adjust the ON time. (About 5 seconds later, the entire display will reappear.) 	<b>5</b>   Select "PROGRAM TIMER" (Either OFF → ON or OFF ← ON will display.) (If the ON timer has been selected to operate first, the unit will stop operating at this point.)	

##### To cancel the TIMER

 Select "CANCEL".  
The air conditioner will return to normal operation.

##### \*To change operating conditions

If you wish to change the operating conditions (ON/OFF, Mode, Fan Speed, Temperature Setting), after making the time setting, wait until the entire display reappears, then press the appropriate buttons to change to the desired operating condition.

\* Even ON/OFF and Sleep timer are valid.

#### 3. SLEEP TIMER

##### To set the SLEEP timer


Unlike other timer functions, the SLEEP timer is designed to set the duration of time in which the unit does not operate. The SLEEP timer can be set regardless of whether the indoor unit is operating or stopped.

<b>1</b>  (Both the indoor unit's OPERATION indicator lamp (green) and the TIMER indicator lamp (orange) will light.)	<b>2</b>   Adjust the OFF time. (About 5 seconds later, the entire display will reappear.)
--	---

##### To change the timer settings

<b>1</b>  Press the SLEEP button once again.	<b>2</b>  Set the time using the TIMER SET buttons.
---	--

##### \*To cancel the TIMER

 Select "CANCEL".  
The air conditioner will return to normal operation.

##### \*To stop air conditioner operation during timer operating




\* Even ON/OFF and Program timer are valid.

- Sleep timer

The sleep timer function automatically corrects the temperature thermostat setting according to the time setting to prevent excessive cooling and heating while sleeping.


#### Cooling operation / dry operation

When the sleep timer is set, the set temperature automatically rises  $1^{\circ}\text{C}$  every hour. The set temperature can rise up to a maximum of  $2^{\circ}\text{C}$



#### Heating operation

When the sleep timer is set, the set temperature automatically drops  $1^{\circ}\text{C}$  every 30 minutes. The set temperature can drop to a maximum of  $4^{\circ}\text{C}$



## 3-7-2 Group Remote Controller

UTY - CGG \*

Different schedules can be set for each day of the week.

• WEEKLY TIMER

Four timers can be set for each day

### 1. WEEKLY TIMER

The timer function is not available depending on the initial setting.


- Different schedules can be set for each day of the week.
- Four timers can be set for each day.
- Operation on/off time, operation mode, and temperature can be specified for each timer.

#### To start / cancel the WEEKLY timer operation


The timer does not start if the time is not set.

ALL


Press the ALL TIMER button to start or cancel the WEEKLY timers for all indoor units.





- If any of the indoor units are in the timer mode, pressing this button cancels the timers for all indoor units.
- If none of the indoor units are in the timer mode, pressing this button starts the timers for all indoor units.



Press the Select button to select the indoor unit.




Press the Timer Mode (DELETE) button to start or cancel the WEEKLY timers.




Note: When a time is not set, the weekly timer cannot be started.

#### To set the WEEKLY timer




Press the PROGRAM (CLOCK ADJUST) button.

\* Do not press this button for two seconds or more, otherwise you will enter the time setting mode.




Press the Select button to select the indoor unit.

\* If all indoor units are selected, the times for all of the registered indoor unit timers are set at once.





### 3 ● Day of the week setting




Press the DAY button to select the day of the week.

\* For ALL, all of the days can be set together when a appears around each day.



### 4 ● Timer setting

Decrement Increment





Press the Set Time buttons to set the time in 10-minute increments.

\* Hold down a Set Time button to adjust the time quickly.

\* The time already set at another timer is skipped at the relevant indoor unit.

# 5


## ● Operating setting



Press the Start/Stop button or the Mode button or the Set Temperature button to set the operation.

\* For the operations that can be set, refer to "Operation mode setting", "Room temperature setting", and "To start /stop operation", in "OPERATION".


\* Only the current operation settings are displayed.



ex. TIMER-1 will start operation at 8:00 on COOL.

# 6

## ● Setting the next timer for the same day:



Then press the ENTER button to proceed to the time setting, and repeat steps from **4** to **5**.

● Repeat steps **3** to **5** to set the timer for another day of the week.

※ Be careful for pressing the ENTER button without any operation setting because the time that is set will be cancelled.

# 7

## ● Setting the timer for the other indoor units:



Before setting the timer for other indoor units, press the ENTER button to confirm the settings.

\* The display switches to the next timer.

● Repeat steps **2** to **6** to set the timer for other indoor units.


# 8



1. Press the ENTER button to confirm the set timer.
2. Press again the PROGRAM (CLOCK ADJUST) button to complete the weekly timer setting.



\* flashes for two seconds.

When the operating time is set, the mark appears.



ex. TIMER-1 will start operation at 8:00 on COOL with a setting of 20°C

## ● To delete the operating time



1. If the Timer Mode (DELETE) button is pressed during steps **3** to **7**, the operating time for the selected day will be deleted.

\* If all the days are selected, the operating times for all of the days of the selected timer will be deleted.

2. Press the ENTER button to confirm the deletion.

## 1 NOTES

- (1) The WEEKLY timer does not operate when the HEAT timer is set if a HEAT PUMP MODEL in the air conditioning system is operating in the cooling mode. In addition, the WEEKLY timer does not operate when the COOL or DRY timer is set if a HEAT PUMP MODEL in the air conditioning system is operating in the heating mode.
- (2) Even if the timer operation is set, the timer lamp of the indoor unit does not light up. (The timer lamp is used for wireless remote controller only.)
- (3) If the same time is set in Timer-1 to Timer-4 of an indoor unit, the timer setting of the smallest number will be effective.



### 3-7-3 Wired Remote Controller


UTY - RNK \*


- ON / OFF TIMER
- WEEKLY TIMER
- TEMPERATURE SET BACK TIMER


#### 1. ON / OFF TIMER


The timer function is not available depending on the model.

**To set the ON/OFF timer**

**1**  
  
CLOCK ADJUS  
Press the timer mode button to select the ON timer or OFF timer. It is switched every time as shown in the below diagram when the button is pressed.

  
No display → OFF TIMER → ON TIMER → WEEKLY TIMER

**2**  
  
From 1 to 24 hours  
Press the set time buttons to set the time. After the time is set, the timer will start automatically. The amount of time until the OFF timer operates that is displayed on the timer display decreases as time passes.

  
ex. OFF timer set for 6 hours

● To cancel


  
TIMER DELETE

- Press the DELETE button to cancel the timer mode.
- The timer mode can also be canceled by changing the timer mode using the timer mode button.



## 2. WEEKLY TIMER

The timer function is not available depending on the model.

### Weekly timer setting




Press the timer mode button to select the weekly timer.






Press the SET button for 2 seconds or more.

### 3 • Day of the week setting






Press the DAY button to select the day of the week, and then press the TIMER SET button to confirm the setting.


\* For ALL, all of the days can be set together when a  appears around each day.



### 4 • Time setting (ON / OFF timer)



When the operating time is set, the  mark appears.




ex. The timer is set for 7:00-18:00.

Press the SET TIME buttons to set the ON time in 30-minute increments, then press the TIMER SET button to proceed to the OFF time setting. Set the OFF time in the same way.



If necessary, set the second weekly timer settings in the same way.

### • Time setting (Independent OFF timer)

Switching from ON/OFF timer to independent OFF timer



The independent timer will flash on the display.



Press the TIMER MODE button to change to the independent OFF timer setting.


\* The time setting process is the same as the ON/OFF timer.

Press the TIMER MODE button to return to the ON/OFF timer setting.

**5**

Repeat steps **3** and **4** to set the weekly timer for another day of the week.

**6**



Press the TIMER SET button for 2 seconds or more to complete the weekly timer settings.


### • To delete the operating time




If the TIMER DELETE button is pressed during steps **3** or **4**, the operating time for the selected day will be deleted. If all the days are selected, the operating times for all of the days will be deleted.

## To start /cancel the WEEKLY timer operation

### ● To start



The independent timer will flash on the display.




ex. Operating time 7:00-18:00  
Indpnd. OFF time 21:00

When the weekly timer is selected, the timer starts automatically.

The operating time for the current day is displayed.

### ● To cancel

TIMER DELETE



- Press the TIMER DELETE button to cancel the timer mode.
- The timer mode can also be canceled by changing the timer mode using the TIMER MODE button.

## i NOTES

### (1) PRECAUTIONS DURING WEEKLY TIMER SETUP

Setup is not possible in the following cases, so amend the time.

- Be sure to set the ON time first, then the OFF time. If either the ON time or the OFF time is not set correctly, the timer will not operate properly.
- The WEEKLY 2 settings cannot be set earlier than the WEEKLY 1 settings.
- The WEEKLY 1 and WEEKLY 2 time spans cannot overlap.

(2) The earliest OFF time you can set is 30 minutes after the ON time.

(3) The OFF time can be carried over to the next day.

(4) The earliest independent OFF time you can set is 30 minutes after the last OFF time.


(5) An independent OFF time can be set up to 0:00 hours of the next day.

(6) Even if the timer operation is set, the timer indicator lamp of the indoor unit does not light up. (The timer indicator lamp is used for wireless remote controllers only.)

## To set the DAY OFF (for a holiday)

1

TIMER SET



During the weekly timer, press the TIMER SET button for 2 seconds or more to set the day.

2

DAY

DAY OFF



Select the day to set the DAY OFF.

3

DAY


DAY OFF





Press the DAY (DAY OFF) button for 2 seconds or more to set the DAY OFF.

4

TIMER SET



Press the TIMER SET button for 2 seconds or more to complete the DAY OFF setting.



Flashing mark: indicates the DAY OFF.

ex. The DAY OFF is set for Monday.


### ● To cancel

Follow the same procedures as those for setup.


## i NOTES

- The DAY OFF setting is only available for days for which weekly settings already exist.
- If the operating time carries over to the next day (during a next day setting), the effective DAY OFF range will be set as shown below.

### ● Normal



### ● Next day setting





- The DAY OFF setting can only be set one time.  
The DAY OFF setting is cancelled automatically after the set day has passed.

### 3. TEMPERATURE SET BACK TIMER

The timer function is not available depending on the model.

#### Temperature SET BACK timer setting

**1** SET BACK



If there is no existing SET BACK temperature setting, " - - " will be displayed for the temperature.

**2** TIMER SET



Press the SET BACK button to change to the SET BACK confirmation display.




The SET BACK operating time and the set temperature will be displayed.

Press the SET button for 2 seconds or more.

**3** • Day setting




• Operating time setting




ex. When setting all days together

Follow step **3** and **4** in "To set the WEEKLY timer". The DELETE button is also used as described in the procedures for the weekly timer.


**4** • Temperature setting




Press the set temperature buttons to set the temperature. (The temperature setting range is the same as the range for the operation mode.)



ex. Operating time 15:00 - 22:00




**5** TIMER SET



Repeat steps **3** and **4**. Press the SET button for 2 seconds or more to complete the temperature SET BACK timer settings.

#### To start /cancel the temperature SET BACK timer operation


• To start



ex. Display during SET BACK timer operation  
(The operating time will not be displayed.)

Press the SET BACK button. The SET BACK confirmation display appears for 5 seconds, and then the timer starts automatically.

• To cancel



Press the SET BACK button, and then press the DELETE button while the SET BACK confirmation display is displayed. Even if the SET BACK button is pressed again, the SET BACK timer will be cancelled.

#### NOTES

- The SET BACK timer only changes the set temperature, it cannot be used to start or stop air conditioner operation.
- The SET BACK timer can be set to operate up to two times per day but only one temperature setting can be used.
- The SET BACK timer can be used together with the ON, OFF, and weekly timer functions.
- The SET BACK operating time is displayed only in the SET BACK confirmation display.  
(Refer to step 1 for the SET BACK confirmation display.)
- During the COOL/DRY mode, the air conditioner will operate at a minimum of 18°C even if the SET BACK temperature is set to 17°C or lower.
- Room temperatures as low as 10, 12, and 14°C cannot be set depending on the model.


## 3-8 DX-KIT

### 3-8-1 SYSTEM CONFIGURATION

#### 1. FGL remote/controller connection

The DX kit is controlled by a VRF operation device and use the external output of the DX kit to perform the AHU operation indirectly.

Control devices can be unified with FGL devices.




Interface	Contents
External input	Fan abnormal input
External output	Fan ON/OFF
	Thermostat ON/OFF

#### 2. External controller connection

Air conditioning control (thermostat-control) can be designed on-site.

(Air conditioning control by DX is also possible.)

Control equipment suited to the application can be connected.



Interface	Contents	Remarks
External input	Operation ON/OFF	
	Operation mode Cool/Heat	Typical indoor unit is required for mode changing.
	Set temperature or capacity request (Analog input)	Temperature setting: When thermo-control is performed by DX kit. Capacity request: When the thermo-control is performed by external controller.
	Error	Information on error occurred at external controller
External output	Operation ON/OFF	
	Error	Information on error occurred at VRF system
	Special operation (defrost)	The Fan operation can be stopped with the communication signal of special operation

## 3-8-2 FUNDAMENTAL FUNCTIONS

### 1. FGL remote/controller connection

Air conditioning control system (SET3-3)	Intake temperature control	Discharge temperature control
Set temperature objective	Intake temperature (Room temperature) Cooling: 18 to 30°C Heating: 10 to 30°C	Discharge temperature Cooling: 14 to 25°C Heating: 17 to 28°C
Thermostat OFF conditions	Cooling Intake temperature < Setting temperature -0.5°C Heating Intake temperature > Setting temperature +0.5°C	Cooling Discharge temperature < Setting temperature -5.0°C Heating Discharge temperature > Setting temperature +5.0°C for 5 minutes
Operation (ON/OFF/Mode/ Set temperature)	FGL controller	
Fan control	Fan control commands are output from the DX kit external output terminal	

### 2. External controller connection


Air conditioning control system (SET3-3)		Intake temperature control	Outlet temperature control
Analog input system (SET3-2)		Set temperature input / Capacity input Selection	Set temperature input / Capacity input Selection
Temperature setting	Temperature Setting range	Intake temperature (Room temperature) Cooling: 18 to 30 °C Heating: 10 to 30 °C	Discharge temperature Cooling: 14 to 25 °C Heating: 17 to 28 °C
	Thermostat OFF conditions	Cooling Intake temperature < Setting temperature -0.5 °C Heating Intake temperature > Setting temperature +0.5 °C	Cooling Discharge temperature < Setting temperature -5.0 °C Heating Discharge temperature > Setting temperature +5.0 °C for 5 minutes
Capacity input	Capacity input range	0%, 5 % to 100%	
	Thermostat OFF conditions	Controlled by external controller and EEV closed by making the capacity input 0% in cooling mode.  EEV slightly opened when the Compressor operating in heating mode	
Operation (ON/OFFMode/ Set temperature)		Controlled by external controller, input to DX Kit external input terminal *Operation from FGL controller is disabled. (Only monitoring is possible)	
When error generated at external equipment		When fanmotor locked or another error was generated at the external equipment, the refrigerant cycle is stopped by inputting an error signal to the DX Kit external input terminal. (EEV is Closed)	
Fan control		Control is performed by external equipment, but when you want to stop the fan during defrosting, use the defrost signal that is output from the DX Kit external output terminal.	

### 3-8-3 FUNDAMENTAL FUNCTIONS

#### Cooling operation

When using the cooling mode, set the temperature to a value lower than the target controlling temperature, otherwise the External refrigeration cycle equipment will not start the cooling operation.

An example for **COOLING TEMPERATURE CONTROL** time chart



$T_R$ : Target controlling temperature (Air intake temperature or Air discharge temperature)  
 $T_s$ : Corrected Setting temperature

Air intake temp controlling

$T_s + 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of start of refrigerant flow

$T_s - 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of stop of refrigerant flow

Air discharge temp controlling


$T_s + 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of start of refrigerant flow

$T_s - 5.0\text{ }^{\circ}\text{C}$ : The threshold temperature of stop of refrigerant flow

#### Heating operation

- (1) When using the heating mode, set the temperature to a value higher than the current room temperature, otherwise the indoor unit will not start the heating operation.
- (2) After the start of heating operation, the fan of indoor unit will not rotate until the heater exchange is warmed up to blow out warm air.
- (3) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.

An example for **HEATING TEMPERATURE CONTROL** time chart



$T_s$ : Corrected Setting temperature      \* : Duration of cold air prevention

$T_R$ : Target controlling temperature (Air intake temperature or Air discharge temperature)

Air intake temp controlling

$T_s - 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of start of refrigerant flow

$T_s + 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of stop of refrigerant flow

Air discharge temp controlling

$T_s - 0.5\text{ }^{\circ}\text{C}$ : The threshold temperature of start of refrigerant flow

$T_s + 5.0\text{ }^{\circ}\text{C}$ : The threshold temperature of stop of refrigerant flow

\*When the EEV operates with the minimum pulse, and it keeps for 5 minutes.

## 3-8-4 ELECTRICAL EXPANSION VALVE CONTROL for DX-KIT

### 1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

### 2. Operation Control

- When indoor unit stopping by Thermo-OFF condition.

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Fully closed

- When starting up  
(Cooling) Move to the cooling control base pulse in steps.  
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control  
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Discharge airflow temperature control  
The discharge airflow temperature is controlled so that it reaches to the set-up temperature based on the difference between the discharge airflow temperature and the set-up temperature.  
Cooling operation: 1) If the discharge airflow temperature becomes 5°C lower than the set-up temperature, EEV is fully closed.  
2) If the suction airflow temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.  
Heating operation: If the suction airflow temperature becomes 0.5°C higher than the set-up temperature, EEV is fully closed.

### 3. Special Control

- Oil recovery operation : Controlled pulse(Maximum 1400 puls)
- Test run operation : Controlled pulse.
- Freeze prevention control : Fully closed.
- Vacuuming operation : Fully open.
- Defrost operation : Controlled pulse(Maximum 1400 puls)

## 3-8-5 DARIN PUMP OPERATION for DX-KIT

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigent circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
  - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
  - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.  
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.



## 3-8-6 FUNCTION

### Auto Restart

The air conditioner restarts with the previous setting operation.

### Freeze Prevention Control

The icing of the indoor heat exchanger is prevented during the cooling and dry mode operation.

(1) Starting Condition

- Compressor is operation more than 3 minutes.  
When "Heat exchanger inlet temperature  $\leq T_A$ " continues \*4 minutes or more.
- Compressor is operation more than 3 minutes.  
When "Heat exchanger outlet temperature  $\leq T_A$ " continues 4 minutes or more.

(2) Operation

EEV is closed.  
Fan is at the setting amount.

(3) Completing Condition

Heat exchanger inlet and middle temperature  $\geq T_B$   
After more than 5 minutes

\* Drain pump turns off at 60 minutes past the completion of the icing protection operation.


$T_A$	$T_B$
1°C	7°C

### Oil Recovery Operation / Defrost Operation

[Oil recovery operation / Defrost operation] :

It periodically returns the residual refrigeration oil in the indoor unit and the connection piping back to the outdoor unit, and prevents the compressor oil level from decreasing.

IR Receiver Unit LED: Operation LED



FAN output: Same operation before oil recovery operation in cooling operation or dry operation. (Heating operation: Stop)

DX-KIT EEV: Control pulse

\* During the above operation, a refrigerant noise might hear from the EEV Kit.

# **AIRSTAGE™ J-III L**








*Variable Refrigerant Flow System*

## **4. TROUBLE SHOOTING**














## 4. TROUBLESHOOTING



### 4-1 NORMAL OPERATION

#### 4-1-1 Indoor Unit Display

Indication type	Indication Lamp	Flashing Pattern
Operation	Operation LED	Continuous lighting
Anti Freeze		Continuous lighting(lowered light)
Timer	Timer LED	Continuous lighting(lowered light)
Filter	Filter LED	Continuous lighting
Power Failure	Operation LED	ON  OFF
	Timer LED	ON  OFF
Test Operation	Operation LED	ON  OFF
	Timer LED	ON  OFF
Defrosting	Operation LED	ON  OFF
Oil Recovery		
Opposite Operation Mode	Timer LED	ON  OFF
Maintenance Mode	Operation LED	ON  OFF
	Timer LED	
	Filter LED	

## 4-1-2 OUTDOOR UNIT DISPLAY

Indication type	7 Segment LED Pattern	Description
Idling(stop)	 Blank	
Cooling Mode	 "C" OO "L"	
Heating Mode	 "H" EA "T"	
Oil Recovery Operation	 "O" IL "R" ECOVERY	Refer to 02-08 page for operation.
Defrost Operation	 "D" E "F" ROST	Refer to 02-09 page for operation.
Discharge Temp. Protection is stopped	 "P" ROTECT "1"	<Starting condition> Discharge temp $\geq$ fixed value 120°C <Release condition> 3 minutes have elapsed and discharge temperature $\leq$ 85°C
High Pressure Protection is stopped	 "P" ROTECT "2"	<Starting condition> High pressure $\geq$ 4.20MPa <Release condition> 5 minutes have elapsed and high pressure $\leq$ 3.20MPa
Low Pressure Protection is stopped	 "P" ROTECT "3"	<Starting condition> Low pressure $\leq$ 0.05MPa or low pressure $\leq$ 0.10MPa continues for 10 mins <Release condition> 3 minutes have elapsed and low pressure $\geq$ 0.17MPa
Compressor Temperature Protection is stopped	 "P" ROTECT "4"	<Starting condition> Compressor temp $\geq$ fixed value 130°C <Release condition> 3 minutes have elapsed and discharge temperature $\leq$ 90°C
Peak Cut Mode	 "P" eak "C" ut	
Low Noise Mode	 "L" OW "N" OISE	Refer to 02-06 page for operation.
Inverter Compressor Operation Indication	 Blinking	ON  OFF




## 4-2 ABNORMAL OPERATION

### 4-2-1 Indoor Unit Display

Please refer the flashing pattern as follows.

Error Contents	Operation LED	Timer LED	Filter LED	Trouble shooting
Wired Remote Controller Communication Error	1 times flash	2 times flash	Continuous flash	1, 2, 3
Network Communication Error	1 times flash	4 times flash	Continuous flash	4, 5, 6
Peripheral device Communication Error	1 times flash	6 times flash	Continuous flash	7, 8
Address setting Error	2 times flash	6 times flash	Continuous flash	9, 10
Connection Unit Number Error in Wired Remote Controller System	2 times flash	9 times flash	Continuous flash	11, 12
Indoor Unit Power Frequency Abnormal	3 times flash	1 times flash	Continuous flash	13
Indoor Unit Main PCB Error	3 times flash	2 times flash	Continuous flash	14, 15, 16
Indoor Unit Power Supply Error For Fan Motor 1(2)	3 times flash	9 times flash	Continuous flash	17, 18, 19
Indoor Unit Communication circuit (Wired Remote Controller) Error	3 times flash	10 times flash	Continuous flash	20
Room Temperature Sensor Error	4 times flash	1 times flash	Continuous flash	21
Indoor Unit Heat Ex. Sensor Error	4 times flash	2 times flash	Continuous flash	22, 23
Outdoor Air Unit Temperature Sensor Error	4 times flash	10 times flash	Continuous flash	24, 25
Indoor Unit Fan Motor 1 Error	5 times flash	1 times flash	Continuous flash	26
Indoor Unit EEV coil 1 Error	5 times flash	2 times flash	Continuous flash	27
Indoor Unit Water Drain Abnormal	5 times flash	3 times flash	Continuous flash	28
Indoor Unit Fan Motor 2 Error	5 times flash	9 times flash	Continuous flash	29
Outdoor Unit Error	9 times flash	15 times flash	Continuous flash	4, 6, 30~66


Depending on contents of Outdoor unit, it may not indicate. (Refer to "TROUBLE LEVEL OF SYSTEM")




\* LED Display when Option receiver unit installed.

## 4-2-2 Outdoor Unit Display


### LED display



POWER MODE LED : on  
ERROR LED : blink




### Operation button



### ERROR transition

Short press : less than 3 seconds  
Long press : more than 3 seconds



If some error is newly occurred or resolved during transition, it is reflected after going back to "Annunciation".

\* Only in the case of "indoor unit abnormal (E.5U.1)", indoor unit address is shown by ENTER long press.

## 4-2-3 Error Code List for Outdoor Unit

Error Code	Error Contents	Trouble shooting
- - - -	Initial Setting Error	30
1 4 . 2	Outdoor unit Network communication abnormal 2	4
1 4 . 5	The number of Indoor unit shortage	6
2 8 . 1	Auto Address Setting Error	31
2 8 . 4	Signal Amplifier Auto Address Setting Error	32
5 U . 1	Indoor Unit Error	1~29
6 1 . 5	Outdoor Unit Reverse phase missing, phase wire Error	33
6 2 . 3	Outdoor Unit EEPROM Access Error	34
6 2 . 6	Inverter Communication Error	35
6 2 . 8	EEPROM Data corrupted Error	36
6 3 . 1	Inverter Error	37
6 7 . 2	Inverter PCB short interruption detection	38
6 8 . 2	Rush current limiting resistor temp rise protection	39
6 9 . 1	Outdoor Unit transmission PCB Parallel Communication Error	40
7 1 . 1	Discharge Temp. Sensor Error < TH1 >	41
7 2 . 1	Compressor Temp. Sensor Error < TH10 >	42
7 3 . 3	Heat Ex. Liquid pipe Temp. Sensor Error < TH5 >	43
7 4 . 1	Outdoor Temp. Sensor Error < TH3 >	44
7 5 . 1	Suction Gas Temp. Sensor Error < TH4 >	45
7 7 . 1	Heat Sink Temp. Sensor Error	46
8 2 . 2	SC HE. Gas Outlet Temp. Sensor Error < TH9 >	47
8 3 . 2	SC HE. Liquid Outlet Temp Sensor Error < TH7 >	48
8 4 . 1	Current Sensor Error	49
8 6 . 1	Discharge Pressure Sensor Error	50


Error Code	Error Contents	Trouble shooting
8 6 . 3	Suction Pressure Sensor Error	51
8 6 . 4	High Pressure Switch Error	52
9 3 . 1	Inverter Compressor Start Up Error	53
9 4 . 1	Trip Detection	54
9 5 . 5	Compressor Motor Loss of Synchronization	55
9 7 . 1	Outdoor unit Fan Motor 1 Lock Error (Start up Error)	56
9 7 . 4	Outdoor unit FAN Motor 1 Under voltage	57
9 7 . 5	Outdoor unit Fan Motor 1 Temperature Abnormal	58
9 7 . 9	Outdoor unit FAN Motor Driver Abnormal	59
9 8 . 1	Outdoor unit Fan Motor 2 Lock Error (Start up Error)	56
9 8 . 5	Outdoor unit Fan Motor 2 Temperature Abnormal	58
9 8 . 9	Outdoor unit FAN Motor Driver Abnormal	59
9 A . 1	Coil ( Expansion Valve 1 ) Error	60
9 A . 2	Coil ( Expansion Valve 2 ) Error	60
A 1 . 1	Discharge Temperature Abnormal	61
A 3 . 1	Compressor Temperature Abnormal	62
A 4 . 1	High Pressure Abnormal	63
A 4 . 2	High Pressure Protection 1	64
A 5 . 1	Low Pressure Abnormal	65
A C . 4	Outdoor unit Heat Sink temp. Abnormal	66

## 4-2-4 Remote Controller Display

### << SIMPLE REMOTE CONTROLLER >> UTY-RSKU , UTY-RHKU

#### ERROR CODE DISPLAY

If an error occurs, the following display will be shown.  
("Er" will appear in the set room temperature display.)  
If "Er" is displayed, immediately contact authorized service personnel.




Faulty unit No.  
(Remote controller address)  
Ex. Error code display

### << WIRED REMOTE CONTROLLER 3 wire type >> UTY-RNKU

#### ERROR CODE DISPLAY

If an error occurs, the following display will be shown.  
("Er" will appear in the set room temperature display.)  
If "Er" is displayed, immediately contact authorized service personnel.


Unit number (usually 0) Error code




Ex. Error code display

### << WIRED REMOTE CONTROLLER 2 wire type >> UTY-RNRU


If an error occurred, an error icon appears on the Monitor mode screen.



1. Touch the [Status] on the Monitor mode screen.



2. Touch the [Error Information] on the Status screen.




2-digit numbers are corresponding to the error code

### << WIRED REMOTE CONTROLLER 2 wire type >> UTY-RNRU

This appears automatically on the display if an error occurs.

If an error occurs, the following display will be shown. ("⚠" will appear in the "Monitor Mode Screen")




Ex. Error code display

### << GROUP REMOTE CONTROLLER >> UTY-CGGY

#### ERROR CODE DISPLAY

The air conditioning system must be inspected if "E" : " (error code) appears on the timer and Clock Display, or the operation lamp is flashing.

\*1 ; Model code  
 O : Outdoor unit  
 I : Indoor unit  
 G : Group remote controller  
 R : Convertor



Ex. Error code display



## 4-2-5 Error Code List for Simple and Wired Remote Controller

Error Code	Error Contents	Trouble shooting	Error Code	Error Contents	Trouble shooting
1 2	Remote Controller Communication Error	1, 2, 3	3 A	Indoor unit Communication circuit (WRC) Error	20
1 4	Network Communication Error	4, 5, 6	4 1	Room Temperature Sensor Error	21
1 5	Incompatible Indoor units connected	95	4 2	Indoor Unit Heat Ex. Sensor Error	22, 23
1 6	Peripheral device Communication Error	7, 8	4 A	Outdoor Air Unit Temperature sensor Error	24, 25
2 6	Address Setting Error	9, 10	5 1	Indoor Unit Fan Motor Error	26
2 9	Connection Unit Number Error in Wired Remote Controller System	11, 12	5 2	Indoor Unit EEV Coil 1 (2) Error	27
3 1	Indoor Unit Power Frequency Abnormal	13	5 3	Water Drain Abnormal	28
3 2	Indoor Unit Main PCB Error	14, 15, 16	5 9	Indoor Unit Fan Motor 2 Error	29
3 9	Indoor Unit Power Supply Error for Fan Motor 1(2)	17, 18, 19	9 U	Outdoor Unit Error	4, 6, 30~ 66

Thermo sensor Icon on the display is brinking: The integrated room temperature sensor Error --> Refer to the Trouble shooting No. 96

## 4-2-6 Error Code List for Group Remote Controller

Error Code	Error Contents	Trouble shooting	Error Code	Error Contents	Trouble shooting
- -	Initial Setting Error	30	7 1	Discharge Temperature Sensor Error	41
1 2	Remote Controller Communication Error	1, 2, 3, 91	7 2	Compressor Temperature Sensor Error	42
1 4	Network Communication Error	4, 5, 6, 7, 94	7 3	Heat Ex. liquid pipe Temperature Sensor Error	43
1 5	Scan Error	93	7 4	Outdoor Temperature Sensor Error	44
1 6	Peripheral device Communication Error	7, 8, 87	7 5	Suction Gas Temperature Sensor Error	45
2 6	Address Setting Error	9, 10, 92	7 7	Heat Sink Temperature Sensor Error	46
2 9	Connection Unit Number Error in Wired Remote Controller System	11, 12	8 2	Sub-cool Heat Ex. Gas Temperature Sensor Error	47
3 1	Indoor Unit Power Frequency Abnormal	13	8 3	Liquid Pipe Temperature Sensor Error	48
3 2	Indoor Unit Main PCB Error	14, 15, 16	8 4	Current Sensor Error	49
3 9	Indoor Unit Power Supply Error for Fan Motor 1(2)	17, 18, 19	8 6	Pressure Sensor Error	50, 51, 52
3 A	Indoor Unit Communication circuit (WRC) Error	20	9 3	Inverter Compressor Start Up Error	53
4 1	Room Temperature Sensor Error	21	9 4	Trip Detection	54
4 2	Indoor Unit Heat Ex. Sensor Error	22, 23	9 5	Compressor Motor loss of Synchronization	55
4 A	Outdoor Air Unit Temperature Sensor Error	24, 25	9 7	Outdoor Unit Fan Motor 1 Error	56 ~ 59
5 1	Indoor Unit Fan Motor Error	26	9 8	Outdoor Unit Fan Motor 2 Error	56 ~ 59
5 2	Indoor Unit EEV coil 1 (2) Error	27	9 A	Coil ( Expansion Valve ) Error	60
5 3	Water Drain Abnormal	28	A 1	Discharge Temperature Abnormal	61
5 9	Indoor Unit Fan Motor 2 Error	29	A 3	Compressor Temperature Abnormal	62
6 1	Outdoor Unit Reverse phase missing, phase wire Error	33	A 4	High Pressure Abnormal	63, 64
6 2	Outdoor Unit Main PCB Error	34, 36	A 5	Low Pressure Abnormal	65
6 3	Inverter Error	37	A C	Outdoor unit Heat Sink temp. Abnormal	66
6 7	Inverter PCB short interruption detection	38	C 1	Main PCB Error	80, 84
6 8	Rush current limiting resistor temp rise protection	39	C 4	Group Remote controller Hardware Error	90
6 9	Outdoor Unit transmission PCB Parallel Communication Error	40	C A	Software Error	88

#### 4-2-7 Trouble shooting - No Error code -

No Error Code	Error condition	Trouble shooting
System Abnormal	Indoor Unit - No Power	67
	Outdoor unit - No Power	68
	No operation (Power is ON )	69
	No Cooling	70
	Abnormal Noise	71
	Indoor Unit - No Power(Outdoor air unit)	72

#### 4-2-8 Error Code List for External Switch Controller (UTY-TEKX)

Error indication LED1	Error Contents	Trouble shooting
OFF	Power Supply Error	73
0.5sec ON / 0.5sec OFF	The abnormality in connection of remote controller cable	74
0.5sec ON / 1.0sec OFF	Transmission Error	75
ON, but SW1 or SW2 not operate	Switch Operation Error	76

#### 4-2-9 Error Code List for Signal Amplifier (UTY-VSGXZ1)

Error indication of converter	Error Contents	Trouble shooting
- -	Power Supply Error	77
- -	Communication Error	78
2 6	Address Setting Error	79
C 1	Main PCB Error	80
LED "D9" Flashing or Lighting	Communication Error B	81
LED "D14" Flashing or Lighting	Communication Error A	82

#### 4-2-10 Error Code List for Network Converter (UTY-VGGXZ1)

Error indication of converter	Error Contents	Trouble shooting
- -	Power Supply Error	83
C 1	Main PCB Error	84
1 2	Communication Error with Remote Controller	85, 86
1 6	Peripheral device Communication abnormal	87
C A	Software Error	88
2 6	Refrigerant circuit address setting error	89

#### 4-2-11 Error Code List for Wireless LAN Adaptor

LED1	LED2	Error Contents	Trouble shooting
Flashing Fast	Flashing Fast	Wireless LAN adaptor Error OR Communication Error between Indoor Unit and Wireless LAN Router	97, 98
Flashing Fast	ON	Communication Error between Indoor unit and Wireless LAN adaptor	99
ON	Flashing Fast	Communication Error between Wireless LAN Router and Wireless LAN adaptor	100
OFF	OFF	Wireless LAN adapter Non-Energized OR Wireless LAN adaptor Sleep mode	101, 102

## 4-2-12 TROUBLE SHOOTING WITH ERROR CODE

<b>Trouble shooting 1</b> <b>INDOOR UNIT Error Method:</b> <b>Wired Remote Controller</b> <b>Communication Error</b>	<b>E12.1</b> <b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash,</b> <b>Filter LED Continuous Flash. &lt; 1 2 &gt;</b> <b>Error Code : 1 2</b>
---	--


<b>Detective Actuators:</b> Indoor unit controller PCB circuit Wired Remote Control (3 wire / 2 Wire type)	<b>Detective details:</b> Upon receiving the signal more than 1 time from Wired Remote or other Indoor unit, but the same signal has not been received more than 1 minute (3 Wire type). 2.5 minute (2 Wire type)
--	--

<b>Forecast of Cause :</b> 1. Terminal connection abnormal    2. Wired Remote Control failure    3. Controller PCB failure
---

<b>Check Point 1 : Check the connection of terminal</b>
<u>After turning off the power, check &amp; correct the followings.</u> <input type="checkbox"/> Indoor Unit - Check the connection of terminal between remote control and Indoor unit, or between Indoor units, and check if there is a disconnection or short of the cable.



<b>Check Point 2 : Check Remote and Controller PCB</b>
<input type="checkbox"/> Check terminal voltage of controller PCB Connector CNC01. (Power supply for Remote) If DC12V, Remote Control failure (Controller PCB is OK) >>> Replace Remote controller If DC0V, Controller PCB failure (Remote is OK) >>> Replace Controller PCB <b>▶ In case of re-installation is done due to removed connector or incorrect wiring, turn on the power again.</b>



<b>Trouble shooting 2</b> <b>E12.2</b> <b>INDOOR UNIT Error Method:</b> <b>Wired Remote Controller signal Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1,</b> <b>Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Remote Controller : 1 2</b>
--	--


<b>Detective Actuators:</b> Indoor unit Controller PCB circuit Wired Remote Control (3 wire type)	<b>Detective details:</b> More than 1 time of Token (Communication between wired remote controllers) is received, but it was not received more than 1 minute.
---	--

<b>Forecast of Cause :</b> 1. Terminal connection abnormal    2. Mis-setting    3. Wired Remote Control failure    4. Controller PCB failure
---

<b>Check Point 1 : Check the connection of terminal</b>
<u>After turning off the power, check &amp; correct the followings.</u> <input type="checkbox"/> Indoor Unit - Check the connection of terminal between remote control and Indoor unit, or between Indoor units, and check if there is a disconnection or short of the cable.



<b>Check Point 2 : Check Remote and Controller PCB</b>
<input type="checkbox"/> Check terminal voltage of Controller PCB Connector CNC01. (Power supply for Remote) If DC12V, Remote Control failure (Controller PCB is OK) >>> Replace Remote If DC0V, Controller PCB failure (Remote is OK) >>> Replace Controller PCB <b>► In case of re-installation is done due to removed connector or incorrect wiring, turn on the power again.</b>



<b>Trouble shooting 3</b> <b>E12.3</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Number excess of device in Wired remote controller system (2 Wires RC)</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 1 2</b>
--	---

<b><u>Detective Actuators:</u></b> Wired remote controller ( 2-Wire ) Indoor unit Controller PCB circuit	<b><u>Detective details:</u></b> When the number of connecting Indoor unit and Remote controller in one RCgroup exceeds more than 32 units.
--	--

<b>Forecast of Cause :</b> 1. Wrong wiring of RCgroup    2. Indoor unit controller PCB failure
---

<b>Check Point 1 : Wire installation Wrong RCgroup setting</b>
<input type="checkbox"/> Wrong wire connection in RCgroup (Please refer to the installation manual) <input type="checkbox"/> The number of connecting indoor unit and Remote controller in one RCgroup were less than 32 units.




<b>Check Point 2 : Check Indoor unit controller PCB</b>
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

<b>Trouble shooting 4</b> <b>E14. 2</b> <b><u>OUTDOOR UNIT Error Method :</u></b> <b>Outdoor Unit Network</b> <b>Communication 2 Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 1 4. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. /</b> <b>Operation LED 1 times Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. *</b> <b>Error Code : 9 U / 1 4 / 1 6 / 1 4. 2</b>
---	--

\* Indoor unit indicates 9 U or 1 4  
Peripheral device indicates 1 4 or 1 6

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>•No communication for 180 seconds or more from an indoor unit which received communication once.</li> <li>•No communication for 180 seconds or more from all indoor units that once received communication.</li> </ul>
---	---

<b><u>Forecast of Cause :</u></b>	1. Noise, momentary open, voltage drop                      2. Indoor unit power off 3. Communication line connection defective                      4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Control PCB defective
-----------------------------------	--



<b>Trouble shooting 5</b> <b>E14. 3</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor unit Network communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit</b> : E.1 4. 1 / 1 4. 2 * <b>Indoor Unit</b> : Operation LED 1 times Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. <b>Error Code</b> : 1 4 / 1 6 / 9 U / 14.1 / 14.2 / 14.3 *
---	---

\* Outdoor unit indicates 1 4.1 or 1 4.2 (No communication from 14.3 Error Indoor unit)  
Peripheral device indicates 1 4 or 1 6

<b>Detective Actuators:</b> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<b>Detective details:</b> When the cut-off of network communication is detected (more than 90 seconds passed since the last receipt of Outdoor unit signal).
--	---

**Forecast of Cause :**

1. Outside cause    2.Connection failure    3. Communication PCB failure    4. Controller PCB failure

Check Point 1 : Check if any outside cause such as voltage drop or noise

- ⚙ Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit.
- ⚙ Momentary power failure ----- Check contact failure or leak current in power supply circuit  
**>>Check power supply for Outdoor Unit as well.**
- ⚙ Check if there is any equipment that causes harmonic wave near the power cable  
(Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.  
**>>If the same symptom does not reappear after resetting the power, possibility of noise is high.**



Check Point 2 : Check the connection

After turning off the power, check and correct followings.

- ☐ Is Indoor Communication PCB loose?
- ☐ Check loose or removed connection of communication line Indoor unit => Outdoor unit.  
Refer to SERVICE INFORMATION Network communication Abnormal
- ☐ When the signal amplifier is connected , Check the error indication of signal amplifier. ( Refer to the installation manual)



Check Point 3 : Check Communication PCB

- ☐ Replace Communication PCB of the Indoor units that have the error.



Check Point 4 : Check Controller PCB

- ☐ Replace controller PCB of the Indoor units that have the error.

<b>Trouble shooting 6</b> <b>E14. 5</b> <b>OUTDOOR UNIT Error Method:</b> <b>The number of Indoor unit shortage Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.1 4. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. /</b>  <b>Error Code : 9 U / 1 4 / 1 6 / 1 4. 5 / 1 4. 3 *</b>
---	--

**\*Peripheral device indicates 14,16**

<b>Detective Actuators:</b>  Outdoor unit Main PCB	<b>Detective details:</b>  When the indoor unit number decreases for 180 seconds from the memorized maximum indoor units number after power(Breaker) ON.
--	--

<b>Forecast of Cause :</b>	1. Indoor unit power off 2. Noise, momentary open, voltage drop 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Controller PCB defective
----------------------------	---

Check Point 1 : Find the indoor unit that the communication is lost.
<input type="checkbox"/> Check system drawing and service tool.



Check Point 2 : Check the indoor unit power supply
<input type="checkbox"/> Main power ON check <input type="checkbox"/> Power cable connection and open check



Check Point 2 : Noise, momentary open, voltage drop
<input type="checkbox"/> Check if temporary voltage drop was not generated. <input type="checkbox"/> Check if momentary open was not generated. <input type="checkbox"/> Check if ground is connection correctly or there are no related cables near the power line.



Check Point 3 : Check the communication line connection
<input type="checkbox"/> Communication line connection, open check Refer to SERVICE INFORMATION Network communication Abnormal



Check Point 4 : Check the Terminal resistor setting
<input type="checkbox"/> Terminal resistor setting check



Check Point 5 : Check the communication PCB (indoor unit/ outdoor unit)
<input type="checkbox"/> Communication PCB connection check <input type="checkbox"/> Communication PCB check



Check Point 6 : Replace Main PCB and Communication PCB (indoor unit/ outdoor unit)
<input type="checkbox"/> Change Main PCB and Communication PCB, and set up the original address.

#### **Attention!!**

If the failure indoor unit is pinpointed and it needs to erase the error indication, it can be reset by function setting (F3-41: Maximum memorized indoor unit number reset).

#### **Caution!!**

Even if normal, this error occurs temporarily by the timing of the power ON of outdoor unit, indoor unit, and signal amplifier.

In this case, please wait for 5 minutes after turning on all the equipments.




<b>Trouble shooting 7</b> <b>E16. 1</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Transmission PCB Connection Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.1 4.1, 1 4.2 *</b> <b>Indoor Unit : Operation LED 1 times Flash, Timer LED 6 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 1 6 *</b>
--	--


\* Outdoor unit indicates 1 4.1 or 14.2 (No communication from Indoor unit)  
Peripheral device indicates 1 6 ( 1 6.4 Error)  
Service Tool indicates 14.3 ( Missing Error Indoor unit)

<b><u>Detective Actuators:</u></b> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<b><u>Detective details:</u></b> When Parallel communication error (Communication reset occurs continuously more than specified times) is detected.
---	--


<b><u>Forecast of Cause :</u></b> 1. Connection failure    2. Outside cause    3. Communication PCB failure    4. Controller PCB failure
---



<b>Trouble shooting 8                      E16. 4</b> <b>INDOOR UNIT Error Method:</b> <b>Communication Error Between</b> <b>Controller and Indoor unit</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : No Display</b> <b>Indoor Unit : No Display</b>  <b>Error Code : 1 6 (Peripheral Unit )</b>
<b><u>Detective Actuators:</u></b> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<b><u>Detective details:</u></b> When the cut-off of network communication is detected (more than 90 seconds passed since the last receipt of Outdoor unit signal).
<b><u>Forecast of Cause :</u></b> 1. Outside cause    2. Connection failure    3. Communication PCB failure    4. Controller PCB failure	



<b>Trouble shooting 9                      E26. 4</b> <b>INDOOR UNIT Error Method:</b> <b>Address Duplication in Wired remote</b> <b>contorller system</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 2 times Flash, Timer LED 6 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 2 6</b>
<b>Detective Actuators:</b> Wired remote controller ( 2-Wire ) Indoor unit Controller PCB circuit	<b>Detective details:</b> When the duplicated address number exists in one RCgroup
<b>Forecast of Cause :</b> 1. Wrong wiring of RCgroup   2. Wrong remote address setting   3. Indoor unit controller PCB failure 4. Remote controller failure	



<b>Trouble shooting 10</b> <b>INDOOR UNIT Error Method:</b> <b>Address setting Error in Wired remote controller system</b>	<b>E26. 5</b>  <b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 2 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 2 6</b>
--	---

<b>Detective Actuators:</b> Wired remote controller ( 2-Wire ) Indoor unit Controller PCB circuit	<b>Detective details:</b> When the address number set by auto setting and manual setting are mixed in one RC group
---	---

<b>Forecast of Cause :</b> 1. Wrong wiring of RCgroup 2. Wrong remote address setting 3. Indoor unit controller PCB failure 4. Remote controller failure
---

<b>Check Point 1 : Wire installation</b>
<input type="checkbox"/> Wrong wire connection in RCgroup (Please refer to the installation manual)



<b>Check Point 2 : Wrong RCgroup setting</b>
<input type="checkbox"/> The given address number by auto setting (00) and the manual set number (Except 00) were not existing in one RCG. <input type="checkbox"/> The remote controller address setting by U.I. were not existing same address.



<b>Check Point 3 : Check Indoor unit controller PCB</b>
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

<b>Trouble shooting 11</b> <b>E29. 1</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Connection unit number error (Indoor unit in Wired remote controller system)</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 2 times Flash, Timer LED 9 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 2 9</b>
--	--

<b>Detective Actuators:</b> Wired remote controller ( 2-Wire ) Indoor unit Controller PCB circuit	<b>Detective details:</b> When the number of connecting indoor units are out of specified rule.
---	--

<b>Forecast of Cause :</b> 1. Wrong wiring/ Number of I.U, RC in RCgroup    2. Indoor unit controller PCB defective
--

Check Point 1 : Wire installation
<input type="checkbox"/> Wrong number of connecting indoor unit



Check Point 2 : Check Indoor unit controller PCB
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

<b>Trouble shooting 12</b> <b>INDOOR UNIT Error Method:</b> <b>Connection unit number error</b> <b>(Remote controller)</b>	<b>E29. 2</b>  <b>Indicate or Display:</b> <b>Outdoor Unit : No Display</b> <b>Indoor Unit : No Display</b>  <b>Error Code : 2 9</b>
---	--

<b>Detective Actuators:</b> Wired remote controller ( 2-Wire )	<b>Detective details:</b> When the number of connecting remote controller are out of specified rule.
---	---

<b>Forecast of Cause :</b> 1. Wrong wiring / Wrong number of connecting RC in RCgroup      2. Remote controller PCB defective
--


<b>Check Point 1 : Wire installation</b>
<input type="checkbox"/> Wrong number of connecting remote controller



<b>Check Point 2 : Check Indoor unit controller PCB</b>
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address



<b>Trouble shooting 14</b> <b>E32. 1</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Indoor unit PCB Model Information Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 3 2</b>
<b><u>Detective Actuators:</u></b>  Indoor Unit Controller PCB Circuit	<b><u>Detective details:</u></b> 3 continuous failure of lead test of EEPROM at Power ON, or Apparent Model information error from EEPROM. Also, Error on Model information upon model information test of EEPROM, or Model information of EEPROM not possible to recover.
<b><u>Forecast of Cause :</u></b> 1. Outside cause    2. Connection failure of electric components    3. Controller PCB defective	




#### **Note : EEPROM**


EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.



<b>Trouble shooting 15 E32. 3</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor unit EEPROM Access Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 3 2</b>
<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit	<b>Detective details:</b> When 3 continuous failure occurred on lead test of EEPROM.
<b>Forecast of Cause :</b> 1. Outside cause    2. Defective connection of electric component    3. Controller PCB defective	



<b>Trouble shooting 16 E32. 7</b> <b>INDOOR UNIT Error Method:</b> Indoor unit microcomputer self-check error	<b>Indicate or Display:</b> Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 3 2
<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit	<b>Detective details:</b> When the error is detected by the self-diagnosis of a microcomputer
<b>Forecast of Cause :</b> 1. Outside cause    2. Defective connection of electric component    3. Controller PCB defective	



<b>Trouble shooting 17</b> <b>E.39.1</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Indoor Unit power supply error for</b> <b>FAN motor 1 (Outdoor Air unit)</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Error Code : 39.1</b>
---	---

<b><u>Detective Actuators:</u></b> Indoor Unit Controller PCB Circuit Indoor Unit filter PCB Circuit	<b><u>Detective details:</u></b> When the DC power input for Fan motor < W500 - W501 on the Filter PCB> becomes lower voltage than the specified voltage.
--	--

<b><u>Forecast of Cause :</u></b> 1. Noise momentary open, voltage drop    2. Wire connection    3. Fan motor 4. Peripheral electric devices    5. Filter PCB    6. Controller PCB
---

<b>Check Point 1 : Check if any outside cause such as voltage drop or noise</b>
<ul style="list-style-type: none"> <li>❏ Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit.</li> <li>❏ Momentary power failure ----- Check contact failure or leak current in power supply circuit</li> <li>❏ Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.</li> </ul> <p><b>&gt;&gt;If the same symptom does not reappear after resetting the power, possibility of noise is high.</b></p>



<b>Check Point 2 : Check wire connection</b>
<ul style="list-style-type: none"> <li>❏ Wire lose connection / damage between the CN21on the Controller PCB and CN250 on the Filter PCB In case of Model 72, between W530 (W531) on the filter PCB and capacitor.</li> </ul> <p><b><u>&gt;&gt;If there is abnormal on the wire, replace it</u></b></p>



<b>Check Point 3 : Check rotation of Fan / wire resistance</b>
<ul style="list-style-type: none"> <li>❏ Rotate the applicable fan by hand when operation is off.</li> <li>❏ Disconnect the connector from the controller PCB and Check resistance value of Motor connector</li> </ul>



<b>Check Point 4 : Check peripheral devices, Posistor, Capacitor, Diode bridge</b>
<ul style="list-style-type: none"> <li>❏ Check resistance value, short circuit, visible damage</li> </ul> <p><b><u>&gt;&gt;If there is abnormal , replace it</u></b></p>



<b>Check Point 5 : Replace Filter PCB</b>
<ul style="list-style-type: none"> <li>❏ Change filter PCB</li> </ul>



<b>Check Point 6 : Replace Controller PCB</b>
<ul style="list-style-type: none"> <li>❏ Change Controller PCB and set up the original address.</li> </ul>

<b>Trouble shooting 18</b> <b>E.39.2</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Indoor Unit power supply error for</b> <b>FAN motor 2 (Outdoor Air unit)</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Error Code : 39.2</b>
---	---

<b><u>Detective Actuators:</u></b> Indoor Unit Controller PCB Circuit Indoor Unit filter PCB Circuit	<b><u>Detective details:</u></b> When the DC power input for Fan motor < W530 - W531 on the Filter PCB> becomes lower voltage than the specified voltage.
--	--

<b><u>Forecast of Cause :</u></b> 1. Noise momentary open, voltage drop    2. Wire connection    3. Fan motor 4. Peripheral electric devices    5. Filter PCB    6. Controller PCB
---

<b>Check Point 1 : Check if any outside cause such as voltage drop or noise</b>
<ul style="list-style-type: none"> <li>⚙ Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit.</li> <li>⚙ Momentary power failure ----- Check contact failure or leak current in power supply circuit</li> <li>⚙ Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.</li> </ul> <b>&gt;&gt;If the same symptom does not reappear after resetting the power, possibility of noise is high.</b>



<b>Check Point 2 : Check wire connection</b>
<input type="checkbox"/> Wire lose connection / damage between the CN21on the Controller PCB and CN250 on the Filter PCB In case of Model 72, between W530 (W531) on the filter PCB and capacitor. <b><u>&gt;&gt;If there is abnormal on the wire, replace it</u></b>



<b>Check Point 3 : Check rotation of Fan / wire resistance</b>
<input type="checkbox"/> Rotate the applicable fan by hand when operation is off. <input type="checkbox"/> Disconnect the connector from the controller PCB and Check resistance value of Motor connector



<b>Check Point 4 : Check peripheral devices, Posistor, Capacitor, Diode bridge</b>
<input type="checkbox"/> Check resistance value, short circuit, visible damage <b><u>&gt;&gt;If there is abnormal , replace it</u></b>



<b>Check Point 5 : Replace Filter PCB</b>
<input type="checkbox"/> Change filter PCB



<b>Check Point 6 : Replace Controller PCB</b>
<input type="checkbox"/> Change Controller PCB and set up the original address.

<b>Trouble shooting 19</b> <b>E39. 3</b> <b><u>INDOOR UNIT Error Method:</u></b> <b>Indoor Unit Power Supply Error of AC24V System</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E.5 U.1</b> <b>Error Code : 3 9</b>
--	--

<b><u>Detective Actuators:</u></b> Indoor Unit Power Supply PCB Circuit Indoor Unit Power Trans Indoor Unit Controller PCB	<b><u>Detective details:</u></b> When the AC voltage of the Power Trans output , Is lower than 24V.
---	--

<b><u>Forecast of Cause :</u></b>	1. Terminal Connection Abnormal    2. Power Supply Abnormal    3. Power Trans 4. Power Supply PCB    5. Controller PCB    6. Cable Connection failure
-----------------------------------	--


Check Point 1 : Check the Power Supply PCB and Controller PCB
<input type="checkbox"/> Check the connection of connection terminal between Power Supply PCB(CN24) and Controller PCB(CN114) and check if there is a disconnection or short of the cable.



Check Point 2 : Check the connection of terminal
<input type="checkbox"/> After turning off the power, check & correct of followings. >>Check the connection of terminal between Power Trans and Power Supply PCB(CN113), and Check if there is a disconnection or short of the cable.



Check Point 3 : Check the Power Trans and Power Supply PCB
<input type="checkbox"/> Check terminal voltage of Power Trans and Power Supply PCB connector CN113 (AC24V IN). If AC 0V, Power Trans is failure >> <b><u>Replace Power Trans</u></b> If AC24V, To the Check Point 4.



Check Point 4 : Replace the Power Supply PCB
▶ Replace Power Supply PCB.



Check Point 5 : Replace the Controller PCB
▶ Replace Controller PCB and set up the original address.















<b>Trouble shooting 26</b> <b>E51. 2</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor Unit Fan Motor 1 rotation speed Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 5 times Flash, Timer LED 1 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 5 1</b>
---	--

<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit Indoor Fan Motor	<b>Detective details:</b> When the FAN motor feed back rotation value which is detecting on the controller PCB becomes 0 and lasts for more than 1 minute at motor operation condition. Or, when the feed back rotation value continues at 1/ 3 of target value for more than 1 minute.
---	---

<b>Forecast of Cause :</b>	1. Fan rotation failure    2. Fan motor winding open    3. Motor protection by ambient temp. increase 4. Capacitor failure      5. Controller PCB failure
----------------------------	--

Check Point 1 : Check rotation of Fan
<input type="checkbox"/> Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor) <u>&gt;&gt;If Fan or Bearing is abnormal, replace it.</u>




Check Point 2 : Check Motor winding / Internal PCB circuit
<input type="checkbox"/> Check Indoor Fan motor ( Refer to the PARTS INFORMATION 13,14) <u>&gt;&gt;If Fan motor is abnormal, replace it.</u>



Check Point 3 : Check ambient temp. around motor
<input type="checkbox"/> Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat) <u>&gt;&gt;Upon the temperature coming down, restart operation.</u>



Check Point 4 : Check Motor Capacitor (*)
<input type="checkbox"/> Check continuity of motor capacitor <u>&gt;&gt;If it is shorted, replace the capacitor.</u>




\* Applicable indoor unit:  
- ARXA, ARXB, ARXC type



Check Point 5 : Replace Controller PCB
<input type="checkbox"/> Change Controller PCB and set up the original address.

<b>Trouble shooting 27</b> <b>INDOOR UNIT Error Method:</b> <b>Coil 1 (2)* Expansion valve Error</b>	<b>E52. 1</b> <b>(E52. 2)*</b> <b>Indicate or Display:</b> <b>Outdoor Unit : E.5U.1</b> <b>Indoor Unit : Operation LED 5 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 5 2</b>
<b>Detective Actuators:</b> Indoor unit controller PCB	<b>Detective details:</b> When the EEV1 (2)* drive circuit is open circuit
<b>Forecast of Cause :</b> 1. EEV1 coil lose connection 2. EEV1 (2)* wire(s) cut or pinched 3. Defective EEV1 (2)* coil 4. Controller PCB (DC 12V) output abnormal 5. Noise momentary open, voltage drop	



<b>Trouble shooting 28</b> <b>INDOOR UNIT Error Method:</b> <b>Indoor unit Drain pump Error</b>	<b>E53. 1</b> <b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Indoor Unit : Operation LED 5 times Flash, Timer LED 3 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 5 3</b>
---	---

<b><u>Detective Actuators:</u></b> Indoor Unit Controller PCB Circuit Float Switch	<b><u>Detective details:</u></b> When Float switch is ON for more than 3 minutes.
--	--

<b><u>Forecast of Cause :</u></b>	1. Drain Installation 2. Drain pipe line blockage 3. Float switch defective 4. Shorted connector/wire 5. Controller PCB defective / Drain pump defective
-----------------------------------	--

Check Point 1 : Check Drain pipe installation

- ❑ Check Drain pipe installation (Refer to the installaion manual)  
 The Height limit for Drain pump, The angle of drain pipe, The angle of indoor unit




Check Point 2 : Check Drain pipe blockage

- ❑ Check Drain pipe line blockage  
 The drain pump inlet and outlet, The connecting pipe, The drain pipe outlet



Check Point 3, 4 : Check Float Switch operation, connecting wire shorted.

- ❑ Check operation of float switch.  
 Remove Float switch and check ON/OFF switching operationby using a meter.  
**>>If Float switch is defective, replace it.**



Check Point 5 : Check controller PCB defective / Drain pump defective

- ❑ Measure power supply (AC198 - 264V) for the drain pump on the Power supply PCB (CN106) at the Float SW ON states.  
**>>If No voltage on the connector, replace the power supply PCB**  
**>>If AC198- 264V on the connector, replace the Drain pump**

<b>Trouble shooting 29</b> E.59.2 <b>INDOOR UNIT Error Method:</b> <b>Indoor Unit Fan Motor 2 rotation speed Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E.5 U.1</b> <b>Error Code : 5 9, 5 9. 2</b>
--	---

<b>Detective Actuators:</b> Indoor Unit Controller PCB Circuit Indoor Fan Motor	<b>Detective details:</b> When the FAN motor feed back rotation value which is detecting on the controller PCB becomes 0 and lasts for more than 1 minute at motor operation condition. Or, when the feed back rotation value continues at 1/ 3 of target value for more than 1 minute.
---	---

<b>Forecast of Cause :</b> 1. Fan rotation failure 2. Fan motor winding open 3. Motor protection by ambient temp. increase 4. Capacitor failure 5. Controller PCB failure
--

Check Point 1 : Check rotation of Fan
<input type="checkbox"/> Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor) <u>&gt;&gt;If Fan or Bearing is abnormal, replace it.</u>




Check Point 2 : Check Motor winding / Internal PCB circuit
<input type="checkbox"/> Check Indoor Fan motor ( Refer to the PARTS INFORMATION 14 ) <u>&gt;&gt;If Fan motor is abnormal, replace it.</u>



Check Point 3 : Check ambient temp. around motor
<input type="checkbox"/> Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat) <u>&gt;&gt;Upon the temperature coming down, restart operation..</u>



Check Point 4 : Check Motor Capacitor	
<input type="checkbox"/> Check continuity of motor capacitor <u>&gt;&gt;If it is shorted, replace the capacitor.</u>	



Check Point 5 : Replace Controller PCB
<input type="checkbox"/> Change Controller PCB and set up the original address.

## 4-3-2 Trouble Shooting With Error Code (OUTDOOR UNIT)

<b>Trouble shooting 30</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Initial Setting Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : - - - - ( Flashing 0.5 sec. ON and OFF )</b> <b>Indoor Unit : No Display</b> <b>Error Code : No Display</b>
--	---

<b><u>Detective Actuators:</u></b> Outdoor unit main PCB	<b><u>Detective details:</u></b> When the DIP SW setting was wrong, after turned on the power supply
---	---

<b><u>Forecast of Cause :</u></b>	1. Wrong DIP SW setting 2. Power supply defective 3. Main PCB defective
-----------------------------------	---

<b>Check Point 1 : Check the power supply</b>
<input type="checkbox"/> Main power ON/OFF state check <input type="checkbox"/> Power cable connection, open check




<b>Check Point 2 : Replace Main PCB</b>
<input type="checkbox"/> Change Main PCB and set up the original address.



<b>Trouble shooting 31</b> <b>E. 28. 1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Auto Address Setting Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 28. 1</b> <b>Indoor Unit : No Display</b> <b>Error Code : 28</b>
--	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> ▪ When none of the connected indoor units answers during auto address And when abnormal answer signal is input.
--	---

<b>Forecast of Cause :</b>	1. Indoor unit power supply defective 2 Indoor unit overconnected 3.Communication line incorrect connection 4. Noise, momentary open
----------------------------	---



<b>Trouble shooting 32</b> <b>E. 28. 4</b> <b>OUTDOOR UNIT Error Method:</b> <b>Signal Amplifier Auto Address Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 28. 4</b> <b>Indoor Unit : No Display</b> <b>Error Code : 28</b>
---	--

<b>Detective Actuators:</b> Outdoor unit Main PCB	<b>Detective details:</b> ▪ When abnormal answer signal is input during signal amplifier auto address
--	--

<b>Forecast of Cause :</b>	1. Signal amplifier power supply defective 2. Signal amplifier overconnected 3. Signal amplifier auto address wrong setting 4. Noise, momentary open.
----------------------------	--

Check Point 1 : Check signal amplifier unit power supply
<input type="checkbox"/> Check signal amplifier unit power supply



Check Point 2 : Check the signal amplifier number connection
<input type="checkbox"/> Check if more than 8 signal amplifiers are connected in a network



Check Point 3 : Check the operation of signal amplifier auto address setting
<input type="checkbox"/> Check if signal amplifier auto address is set at the same time from multiple outdoor units (master unit)




Check Point 4 : Check noise, momentary open, voltage drop
<input type="checkbox"/> Check if power supply temporarily stops by outages or if strong noise is generated from surrounding environment during signal amplifier auto address

<b>Trouble shooting 33      E61. 5</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Reverse Phase, Missing Phase Wire Error</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 6 1. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 9 U / 6 1</b>
---	--

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ Reverse phase prevention circuit detected reversed phase input or input was not normal at the time of power ON.</li> <li>▪ Reverse phase prevention circuit detected open-phase after power ON.</li> </ul>
---	--


<b><u>Forecast of Cause :</u></b>	1. Noise, momentary open, voltage drop 2. Power supply defective 3. Filter PCB (Main) defective 4. Main PCB defective
-----------------------------------	--



<b>Trouble shooting 34</b> <b>E. 62. 3</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit EEPROM Access Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
--	---

<b><u>Detective Actuators:</u></b> Outdoor unit Main PCB	<b><u>Detective details:</u></b> •Access to EEPROM failed due to some cause after outdoor unit started.
---	--


<b><u>Forecast of Cause :</u></b> 1. Noise, momentary open, voltage drop    2. Main PCB defective
---



<b>Trouble shooting 35</b> <b>E. 62. 6</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 6</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
--	---

<b>Detective Actuators:</b> Outdoor unit Main PCB Outdoor unit Inverter PCB	<b>Detective details:</b> •Communication not received from Inverter PCB for 10 seconds or more
---	---


<b>Forecast of Cause :</b> 1. Noise   2. Main to Inverter PCBs wiring connection defective 3. Main PCB defective   4. Inverter PCB defective
---



<b>Trouble shooting 36</b> <b>E. 62. 8</b> <b>OUTDOOR UNIT Error Method:</b> <b>EEPROM Data corrupted Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 62. 8</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 62</b>
---	---

<b><u>Detective Actuators:</u></b>  Outdoor unit Main PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ Set contents sum value memorized in EEPROM and sum value calculated based on the set contents read from EEPROM do not match</li> <li>* Regarding the sum value, only the contents set in the push button SW setting mode (F2) shall be the objective.</li> </ul>
---	---


<b><u>Forecast of Cause :</u></b> 1. Noise, momentary open, voltage drop   2. Main PCB defective
--



<b>Trouble shooting 37</b> <b>E. 63.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 63. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 63</b>
---	---

<b>Detective Actuators:</b> Inverter PCB	<b>Detective details:</b> •Error information received from Inverter PCB
---	--


<b>Forecast of Cause :</b> 1. Noise, momentary open, voltage drop. 2. Power supply to Inverter PCB wiring disconnection, open 3. Inverter PCB defective
---



<b>Trouble shooting 38</b> <b>E. 67.2</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Inverter PCB short interruption detection</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 67. 2</b> <b>Indoor Unit : No Display</b> <b>Error Code : 67</b>
---	---

<b><u>Detective Actuators:</u></b> Inverter PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>• "Momentary power failure" received from Inverter PCB</li> </ul>
--	--

<b><u>Forecast of Cause :</u></b>	1. Noise, momentary power failure, voltage drop 2. Power supply to Inverter PCB wiring disconnection, open 3. Main PCB defective   4. Inverter PCB defective
-----------------------------------	--





<b>Trouble shooting 39</b> <b>E68. 2</b> <b>OUTDOOR UNIT Error Method:</b> <b>Rush Current Limiting Resistor</b> <b>Temp Rise Protection</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 6 8. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 9 U / 6 8</b>
---	---

<b><u>Detective Actuators:</u></b>  Inverter PCB	<b><u>Detective details:</u></b>  ▪ "Protection stop by "Rush current limiting resistor temperature rise detection" of inverter PCB" was generated 2 times.
--	---

<b><u>Forecast of Cause :</u></b>  1. The wire between the Power PCB (CN804) and the Inverter PCB (CN330) unplugged. 2. The Relay (K801) defected. 3. Resistance (R806) open circuit. 4. Inverter PCB defected.
--

<b>Check Point 1 : Check the wiring Power PCB (CN804) and the Inverter PCB (CN330)</b>
<input type="checkbox"/> Connector and wiring connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check Relay (K801) operation</b>
<input type="checkbox"/> Check click sound of Relay (K801) When the Relay (K801) did not operate, replace the Power PCB.



<b>Check Point 3 : Check Resistance (R806)</b>
<input type="checkbox"/> Check the Resistance is not open circuit When the Resistance is open circuit, replace the the Power PCB.




<b>Check Point 3 : Check Inverter PCB, Filter PCB, Power PCB</b>
<input type="checkbox"/> Refer to the Service parts information 4

After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset
--

<b>Trouble shooting 40</b> <b>E. 69.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit transmission PCB</b> <b>Parallel Communication Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 69. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 69</b>
---	---

<b>Detective Actuators:</b>  Outdoor unit Main PCB Communication PCB	<b>Detective details:</b>  •Parallel communication (communication between main CPU and communication PCB ) failed 5 times.
---	--

<b>Forecast of Cause :</b> 1. Noise      2. Communication PCB connection defective 3. Communication PCB defective      4. Main PCB defective
---



<b>Trouble shooting 41</b> <b>E. 71.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Temp Sensor Error&lt;TH1&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 71. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 71</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor 1	<b>Detective details:</b> <ul style="list-style-type: none"> <li>Discharge temperature thermistor 1 short detected</li> <li>Discharge thermistor 1 open detected after compressor 1 operated continuously for 5 minutes or more</li> </ul>
---	---



<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN146:1-2) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  </div>	
Discharge temperature sensor 1 (CN146:1-2) <b>► If the voltage does not appear, replace Main PCB and set up original address.</b>	

<b>Trouble shooting 42</b> <b>E. 72.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor Temp Sensor Error</b> <b>&lt;TH10&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 72. 1</b>  <b>Filter LED Continuous Flash.</b> <b>Error Code : 72</b>
--	--

<b>Detective Actuators:</b>  Compressor temperature thermistor 1	<b>Detective details:</b> <ul style="list-style-type: none"> <li>Compressor temperature thermistor 1 short detected</li> <li>Compressor thermistor 1 open detected after compressor 1 operated continuously for 5 minutes or more</li> </ul>
--	--



<b>Forecast of Cause :</b> <ul style="list-style-type: none"> <li>1. Connector connection defective, open</li> <li>2. Thermistor defective</li> <li>3. Main PCB defective</li> </ul>
--

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN146:3-4) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>Compressor temperature sensor 1 (CN146:3-4)</p> <p>► <b><u>If the voltage does not appear, replace Main PCB and set up original address.</u></b></p> </div>	

<b>Trouble shooting 43</b> <b>E. 73.3</b> <b>OUTDOOR UNIT Error Method:</b> <b>Heat Ex. Liquid pipe Temp.</b> <b>Sensor Error&lt;TH5&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 73. 3</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 73</b>
---	---

<b>Detective Actuators:</b>  Heat exchanger liquid temperature thermistor	<b>Detective details:</b>  • Heat exchanger liquid temperature thermistor short or open detected
---	--



<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the connector connection and cable open  <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check
---



Check Point 2 : Check the thermistor  <input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".
---



Check Point 3 : Check voltage of Main PCB (DC5.0V)  <input type="checkbox"/> Main PCB (CN147:3-4) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p>CN147</p> </div> <p>Heat exchanger liquid temperature sensor (CN147:3-4)</p> <p>► <u>If the voltage does not appear, replace Main PCB and set up original address.</u></p>	

<b>Trouble shooting 44</b> <b>E. 74.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Temp Sensor Error&lt;TH3&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 74. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 74</b>
---	---

<b>Detective Actuators:</b>  Outdoor temperature thermistor	<b>Detective details:</b>  • Outdoor temperature thermistor short or open detected
---	--



<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2: Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN144:1-3) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  </div>	
Outdoor temperature sensor (CN144:1-3)	
<b>► If the voltage does not appear, replace Main PCB and set up original address.</b>	

<b>Trouble shooting 45</b> <b>E. 75.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Suction Gas Temp Sensor Error</b> <b>&lt;TH4&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 75. 1</b>  <b>Filter LED Continuous Flash.</b> <b>Error Code : 75</b>
--	--

<b>Detective Actuators:</b>  Suction gas temperature thermistor	<b>Detective details:</b>  • Suction gas temperature thermistor short or open detected
---	--



<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b>   </div>
<input type="checkbox"/> Main PCB (CN147:1-2) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;">  <p><b>CN147</b></p> </div> <p>Suction gas temperature sensor (CN147:1-2)</p> <p>► <u>If the voltage does not appear, replace Main PCB and set up original address.</u></p>	

<b>Trouble shooting 46      E. 77.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Heat Sink Temp Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 77. 1</b>  <b>Filter LED Continuous Flash.</b> <b>Error Code : 77</b>
<b>Detective Actuators:</b>  Inverter PCB	<b>Detective details:</b>  • Heat sink temperature thermistor open/short circuit detected
<b>Forecast of Cause :</b> 1. Heat sink Thermistor open / short circuit	

Check Point 1 : Check connection of Connector
<input type="checkbox"/> Check if connector is loose or removed <input type="checkbox"/> Check erroneous connection <input type="checkbox"/> Check if thermistor cable is open <u>&gt;&gt; Reset Power when reinstalling due to removed connector or incorrect wiring.</u>



Check Point 2 : Check voltage of Inverter PCB (DC5.0V)	<b>DC</b>				
<input type="checkbox"/> Inverter PCB (CN360:1-2) voltage value = 5V <u>Remove the thermistor from the inverter PCB and check the voltage</u>					
<div data-bbox="156 1093 421 1529" data-label="Diagram"> <p><b>CN360</b></p> <table border="1"> <tr> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>2</td> </tr> </table> <p>BLACK    BLACK</p> <p><b>THERMISTOR (HEAT SINK)</b></p> </div> <p>► <u>If the voltage does not appear, replace Inverter PCB .</u></p>		1	2	1	2
1	2				
1	2				





<b>Trouble shooting 48</b> <b>E. 83.2</b> <b>OUTDOOR UNIT Error Method:</b> <b>SC.HE. Liquid Outlet Sensor Error</b> <b>&lt;TH7&gt;</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 83. 2</b>  <b>Filter LED Continuous Flash.</b> <b>Error Code : 83</b>
--	--

<b>Detective Actuators:</b>  Liquid pipe temperature thermistor	<b>Detective details:</b>  • SC.HE.Liquid Outlet temperature thermistor 2 short or open detected
---	--

<b>Forecast of Cause :</b>	1. Connector connection defective, open 2. Thermistor defective 3. Main PCB defective
----------------------------	---

<b>Check Point 1 : Check the connector connection and cable open</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the thermistor</b>
<input type="checkbox"/> Thermistor characteristics check (Disconnect the thermistor from the PCB and check.) * For the thermistor characteristics, refer to the "Service Parts Information 17".




<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>DC</b> </div>
<input type="checkbox"/> Main PCB (CN142:1-2) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>Diagram showing the connection of two thermistors to the CN142 connector. The left thermistor (SC.EXT.LIQ) &lt; TH 7 &gt; is connected to pins 1 and 2. The right thermistor (SC.EXT.GAS) is connected to pins 3 and 4. The connector is labeled CN142.</p> </div>	
Liquid pipe temperature sensor 2 (CN142:1-2)	

<b>Trouble shooting 49</b> <b>E. 84.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Current Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit :</b> E. 84. 1 <b>Indoor Unit :</b> Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. <b>Error Code :</b> 84
---	--

<b>Detective Actuators:</b> Judgment from value sensed by current sensor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>• "Protection stop by "inverter speed <math>\geq 20</math>rps and sensor value 0.5A continued for 1 min"" was generated 2 times</li> <li>• Sensor value while inverter stopped = maximum was detected</li> </ul>
---	---

<b>Forecast of Cause :</b>	1. Filter PCB to Inverter PCB current sensor wiring connector disconnection, open 2. Power supply to Filter PCB to Inverter PC wiring disconnection, open 3. Filter PCB defective (Power supply section, current sensor section) 4. Inverter PCB defective
----------------------------	---



<b>Trouble shooting 50</b> <b>E. 86.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Pressure Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
--	---

<b>Detective Actuators:</b>  Discharge pressure sensor	<b>Detective details:</b>  • When any of the following conditions is satisfied, a discharge pressure sensor error is generated. 1. 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value < 0.3V continued for 30 seconds or more 2. 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value ≥ 5.0V was detected.
--	--

<b>Forecast of Cause :</b>	1. Discharge pressure sensor connector disconnection, open 2. Discharge pressure sensor defective 3. Main PCB defective
----------------------------	---

<b>Check Point 1 : Check the discharge pressure sensor connection state</b>
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



<b>Check Point 2 : Check the discharge pressure sensor</b>
<input type="checkbox"/> Sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to the "Service Parts Information 15".



<b>Check Point 3 : Check voltage of Main PCB (DC5.0V)</b>	<div>DC</div>
<input type="checkbox"/> Main PCB (CN118:1-3) voltage value = 5V <u>Remove the thermistor from Main PCB, check the voltage.</u>	
<div> <div> <div> PRESSURE SENSOR (HIGH) </div> <div> PS </div> <div> <div>RED</div> <div>WHITE</div> <div>BLACK</div> </div> <div> <div>1</div> <div>2</div> <div>3</div> </div> <div> <div>1</div> <div>2</div> <div>3</div> </div> </div> <div>CN118</div> </div> <div>Discharge pressure sensor (CN118:1-3)</div>	

<b>Trouble shooting 51</b> <b>E. 86.3</b> <b>OUTDOOR UNIT Error Method:</b> <b>Suction Pressure Sensor Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit</b> : E. 86. 3 <b>Indoor Unit</b> : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. <b>Error Code</b> : 86
--	--

<b>Detective Actuators:</b> Suction pressure sensor	<b>Detective details:</b> <ul style="list-style-type: none"> <li>When any of the following conditions is satisfied, a suction pressure sensor error is generated. <ol style="list-style-type: none"> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value &lt; 0.06V continued for 30 seconds or more.</li> <li>30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value ≥ 5.0V was detected.</li> </ol> </li> </ul>
--	--

<b>Forecast of Cause :</b>	1. Suction pressure sensor connector disconnection, open 2. Suction pressure sensor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the suction pressure sensor connection state
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the suction pressure sensor
<input type="checkbox"/> Sensor characteristics check * For the characteristics of the suction pressure sensor, refer to the "Service Parts Information 15".




Check Point 3 : Check voltage of Main PCB (DC5.0V)	<div> <div>DC</div> </div>
<input type="checkbox"/> Main PCB (CN119:1-3) voltage value = 5V Remove the thermistor from Main PCB, check the voltage.	
<div> <div> <div> PRESSURE SENSOR (LOW) </div> <div>PS</div> <div> <div>RED</div> <div>WHITE</div> <div>BLACK</div> </div> <div> <div>1</div> <div>2</div> <div>3</div> </div> <div> <div>1</div> <div>2</div> <div>3</div> </div> <div>CN119</div> </div> <div> Suction pressure sensor (CN119:1-3) </div> </div>	

<b>Trouble shooting 52</b> <b>E. 86.4</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Switch Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 86. 4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 86</b>
---	---

<b><u>Detective Actuators:</u></b>  High pressure switch	<b><u>Detective details:</u></b>  • When the power was turned on, "high pressure switch : open" was detected.
--	---


<b><u>Forecast of Cause :</u></b>	1. High pressure switch connector disconnection, open 2. High pressure switch characteristics defective 3. Main PCB defective
-----------------------------------	---



<b>Trouble shooting 53</b> <b>E. 93.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Inverter Compressor Start UP Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 93. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 93</b>
---	---

<b><u>Detective Actuators:</u></b> Inverter PCB Inverter Compressor	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "overcurrent generation at inverter compressor starting" ⇒ restart" generated consecutively 60 times x 2 sets (total 120 times)</li> <li>* The shortest time up to error generation is about 100 minutes</li> <li>* Restart is not performed if an indoor unit in the same refrigerant system is not turned ON by thermostat.</li> <li>* After the end of the 1st set, the 2nd set is not started if all the compressors in the same refrigerant system are not temporarily stopped.</li> </ul>
---	--


<b><u>Forecast of Cause :</u></b>	1. Inverter PCB to inverter compressor wiring disconnection, open 2. Inverter PCB defective 3. Inverter compressor defective (lock, winding short)
-----------------------------------	--



<b>Trouble shooting 54</b> <b>E. 94.1</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Trip Detection</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 94. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 94</b>
--	--

<b><u>Detective Actuators:</u></b> Inverter PCB Inverter Compressor SV 2 coil	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "overcurrent generation after inverter compressor start processing completed"" generated consecutively 5 times.</li> <li>* The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.</li> </ul>
--	---

<b><u>Forecast of Cause :</u></b>	1. Outdoor unit fan operation defective, foreign matter on hear exchanger, excessive rise of ambient temperature 2. Inverter PCB defective 3. Inverter compressor defective (lock, winding short)
-----------------------------------	---






<b>Trouble shooting 55</b> <b>E. 95.5</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Compressor Motor Loss of Synchronization</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 95. 5</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 95</b>
--	--

<b><u>Detective Actuators:</u></b> Inverter PCB Inverter Compressor	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "loss of synchronization detection"" generated consecutively 5 times</li> <li>* The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.</li> </ul>
---	--


<b><u>Forecast of Cause :</u></b>	1. Inverter PCB defective 2. Inverter compressor defective (lock)
-----------------------------------	--

Check Point 1 : Check the Inverter PCB
<input type="checkbox"/> Inverter PCB check (Refer to "Service Parts Information 4" )
<div style="text-align: center;">  <b>OK</b> </div>
Check Point 2 : Check the Inverter compressor
<input type="checkbox"/> Inverter compressor check (Refer to "Service Parts Information 1,2")

<b>Trouble shooting 56</b> E. 97.1 (E 98.1) <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor Unit Fan Motor 1(2)</b> <b>Lock Error - Start up Error -</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit :</b> E. 97. 1 ( FAN 1 ) , E. 98. 1 ( FAN 2 ) <b>Indoor Unit :</b> Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. <b>Error Code :</b> 97 ( FAN 1 ) , 98 ( FAN 2 )
---	---

<b><u>Detective Actuators:</u></b> Outdoor unit fan	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "fan speed <math>\leq</math> 100rpm" 20 seconds after fan operation command issued" was generated consecutively 15 times</li> <li>* The compressor is protection stopped every time fan protection stop has been generated 3 times.</li> </ul>
--	---


<b><u>Forecast of Cause :</u></b>	1. Rotation obstruction by foreign matter 2. Motor wiring, connector disconnection, open 3. Fan motor defective (winding open, lock) 4. Main PCB defective (drive circuit, speed detection circuit)
-----------------------------------	--



<b>Trouble shooting 57 E. 97.4 ( E. 98.4)</b> <b><u>OUTDOOR UNIT Error Method:</u></b> <b>Outdoor unit Fan motor 1(2)</b> <b>undervoltage - Lack of DC Voltage -</b>	<b><u>Indicate or Display:</u></b> <b>Outdoor Unit : E. 97. 4 E.98.4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 97</b>
---	---

<b><u>Detective Actuators:</u></b> Outdoor unit main PCB	<b><u>Detective details:</u></b> ▪ Low DC power supply (DC voltage 180V or less) detected
---	--


<b><u>Forecast of Cause :</u></b> <ol style="list-style-type: none"> <li>1. Power OFF, voltage drop, momentary open</li> <li>2. Power supply wiring connection defective, open</li> <li>3. Main PCB defective (electrolytic capacitor, DC voltage detection circuit)</li> </ol>
---



<b>Trouble shooting 58</b> <b>E. 97.5 (E.98.5)</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Fan Motor 1 Temp. Abnormal</b> <b>Outdoor Unit Fan Motor 2 Temp. Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 97. 5 (FAN1), E. 98. 5 (FAN2)</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 97 (FAN1), 98 (FAN2)</b>
---	---

<b><u>Detective Actuators:</u></b>  Outdoor unit fan	<b><u>Detective details:</u></b>  ▪ Protection stop by speed $\leq 220\text{rpm}$ after 60 seconds have elapsed after fan operation command issued generated 3 times within 3 hours.
--	--


<b><u>Forecast of Cause :</u></b>	1. Rotation obstructed by foreign matter 2. Ventilation obstructed by heat exchange foreign matter 3. Excessive ambient temperature rise 4. Static pressure setting incorrect, specified static pressure value exceeded 5. Fan motor defective (internal PCB defective)
-----------------------------------	---



<b>Troubleshooting 59</b> <b>E. 97.9 (E. 98.9)</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor Unit Fan Motor Driver 1(2)</b> <b>Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 9 7. 9 ( E. 9 8. 9 )</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : 9 U / 9 7 ( 98 )</b>
---	--

<b><u>Detective Actuators:</u></b>  Driver PCB Fan motor Main PCB	<b><u>Detective details:</u></b> When Driver PCB detects the following abnormalities, the error signal is output. ▪ Driver PCB defective ▪ Fan motor defective (Layer short) ▪ Main PCB defective (DC output abnormal) ▪ Lose connection or disconnecting wire
---	---


<b><u>Forecast of Cause :</u></b> 1. Driver PCB defective      2. Fan motor defective      3. Main PCB defective 4. Lose connection or disconnecting wire
--



<b>Trouble shooting 60 E.9A.1( E.9A.2)</b> <b>OUTDOOR UNIT Error Method:</b> <b>Coil (Expansion Valve 1 ) Error</b> <b>Coil (Expansion Valve 2 ) Error</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. 9A. 1 ( EEV1), E. 9A. 2 ( EEV2)</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : 9A</b>
---	---

<b><u>Detective Actuators:</u></b>  Main PCB	<b><u>Detective details:</u></b>  ▪ When the EEV input on the Main PCB (CN116, CN117) was open circuit or short circuit.
--	--

<b><u>Forecast of Cause :</u></b> 1. EEV coil lose connection 2. EEV wire(s) cut or pinched 4. Defective EEV coil 3. Main PCB (DC 12V) output abnormal
--



<b>Trouble shooting 61 E.A1.1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Discharge Tempreature Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A1. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A1</b>
---	---

<b>Detective Actuators:</b>  Discharge temperature thermistor	<b>Detective details:</b>  <ul style="list-style-type: none"> <li>"Protection stop by "discharge temperature1 <math>\geq</math> 115°C during compressor 1 operation" generated 2 times within 40 minutes</li> </ul>
---	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Discharge temperature thermistor 1 defective 5. Insufficient refrigerant
----------------------------	--

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1,EEV2, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before EEV, 3Way Valve, oil return) Refer to "Service Parts Information 8,9,10".



Check Point 3 : Check the outdoor unit fan,heat exchanger
<input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check



Check Point 4 : Check the discharge thermistor 1
<input type="checkbox"/> Discharger thermistor 1 characteristics check (Check by disconnecting thermistor from PCB.) * For the characteristics of the thermistor, refer to the "Service Parts Information 17".




Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.




Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2) open? <input type="checkbox"/> Strainer clogging check (before EEV, 3Way Valve, oil return) Refer to "Service Parts Information 9,10".



<b>Trouble shooting 62</b> <b>E. A3. 1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Compressor Tempreature Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A3. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A3</b>
---	---

<b><u>Detective Actuators:</u></b>  Compressor temperature thermistor	<b><u>Detective details:</u></b>  •"Protection stop by "compressor tempreature" $\geq 230^{\circ}\text{F}(110^{\circ}\text{C})$ during compressor operation""generated 2 times within 40 minutes
---	--

<b><u>Forecast of Cause :</u></b>	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Compressor 1 temperature thermistor defective 5. Insufficient refrigerant
-----------------------------------	---





<b>Trouble shooting 63</b> <b>E. A4. 1</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A4. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A4</b>
--	---

<b><u>Detective Actuators:</u></b>  Judgment from value sensed by discharge pressure sensor	<b><u>Detective details:</u></b>  ▪ "Protection stop by "discharge pressure $\geq$ 4.00MPa during operation of any compressor"" generated 3 times within 60 minutes
---	---

<b><u>Forecast of Cause :</u></b>	1. 3-way valve not opened   2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise   3. Check valve clogged 4. EEV defective, strainer clogged   5. Solenoid valve defective 6. Discharge pressure sensor defective   7. Refrigerant overcharged
-----------------------------------	---

<Cooling operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3 : Check the EEV, strainer
<input type="checkbox"/> EEV(EEV 1) open? <input type="checkbox"/> Strainer clogging check. (before EEV) Refer to "Service Parts Information 9".



Check Point 4 :Check the discharge pressure sensor
<input type="checkbox"/> Discharge pressure sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to "Service Parts Information 15".



Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Refrigerant charged amount check

<Heating operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the EEV, strainer (indoor unit)
<input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 8".



<b>Trouble shooting 64</b> <b>E. A4. 2</b> <b>OUTDOOR UNIT Error Method:</b> <b>High Pressure Protection 1</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A4. 2</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A4</b>
--	---

<b>Detective Actuators:</b>  High pressure switch 1	<b>Detective details:</b>  ▪ "Protection stop by "high pressure switch 1 operated during compressor 1 operation"" generated 3 times within 60 minutes
---	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened   2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise   3. Check valve clogged 4. EEV defective, strainer clogged   5. Solenoid valve defective 6. High pressure switch 1 defective   7. Refrigerant overcharged
----------------------------	--

<Cooling operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.  <input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.
---



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature  <input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?
---



Check Point 3-1 : Check the EEV, strainer  <input type="checkbox"/> EEV(EEV 1) open? <input type="checkbox"/> Strainer clogging check. (before EEV) Refer to "Service Parts Information 9".
---



Check Point 3-2 : Check the check valve  <input type="checkbox"/> Check if check valve (oilseparator (out) of compressor 1) is not clogged.
---



Check Point 4 : Check high pressure switch 1  <input type="checkbox"/> High pressure switch 1 characteristics check * For the characteristics of the high pressure switch 1, refer to "Service Parts Information 16".
--



Check Point 5: Check the refrigerant amount  <input type="checkbox"/> Refrigerant charged amount check
--

<Heating operation>

Check Point 1 : Check if 3-way valve(gas side) is open.  <input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.
--



Check Point 2 : Check the EEV, strainer (indoor unit)  <input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 8".
--



<b>Trouble shooting 65</b> <b>E. A5. 1</b> <b>OUTDOOR UNIT Error Method:</b> <b>Low Pressure Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. A5. 1</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash.</b> <b>Error Code : A5</b>
---	---

<b>Detective Actuators:</b> Suction pressure sensor	<b>Detective details:</b> ▪ "Protection stop by "suction pressure $\leq 0.10\text{MPa}$ continued for 10 minutes" or "suction pressure $\leq 0.05\text{MPa}$ during operation of any compressor"" was generated 5 times within 3 hours
--	---

<b>Forecast of Cause :</b>	1. 3-way valve not opened   2. Outdoor unit ambient temperature too low 3. Outdoor unit fan operation defective, foreign matter at heat exchanger 4. EEV defective, strainer clogged   5. Solenoid valve defective 6. Low pressure sensor characteristics defective   7. Insufficient refrigerant
----------------------------	--

#### <Cooling operation>

Check Point 1 : Check if 3-way valve(gas side) is open.
<input type="checkbox"/> If the 3-way valve(gas side) was closed, open the 3-way valve(gas side) and check operation.



Check Point 2 : Check the indoor unit EEV, strainer clogging
<input type="checkbox"/> Indoor unit EEV operation check <input type="checkbox"/> Strainer not clogged?



Check Point 3: Check the suction pressure sensor
<input type="checkbox"/> Suction pressure sensor characteristics check * For the characteristics of the suction pressure sensor, refer to "Service Parts Information 15".



Check Point 4 : Check the refrigerant amount
<input type="checkbox"/> Leak check

#### <Heating operation>

Check Point 1 : Check if 3-way valve(liquid side) is open.
<input type="checkbox"/> If the 3-way valve(liquid side) was closed, open the 3-way valve(liquid side) and check operation.



Check Point 2 : Check the outdoor unit ambient temperature
<input type="checkbox"/> Outdoor ambient temperature lower than operating range?



Check Point 3 : Check the outdoor unit fan operation, heat exchanger
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Fan rotates? <input type="checkbox"/> Outdoor unit fan motor check



Check Point 4 : Check the outdoor unit EEV, strainer clogging
<input type="checkbox"/> Outdoor unit EEV1 operation check <input type="checkbox"/> Strainer not clogged? Refer to "Service Parts Information 9".



<b>Trouble shooting 66</b> <b>E. AC. 4</b> <b>OUTDOOR UNIT Error Method:</b> <b>Outdoor unit Heat Sink Temperature</b> <b>Abnormal</b>	<b>Indicate or Display:</b> <b>Outdoor Unit : E. AC. 4</b> <b>Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,</b> <b>Filter LED Continuous Flash.</b> <b>Error Code : AC</b>
---	---

<b><u>Detective Actuators:</u></b> Inverter PCB	<b><u>Detective details:</u></b> <ul style="list-style-type: none"> <li>▪ "Protection stop by "heat sink temp. <math>\geq 105^{\circ}\text{C}</math> generated 3 times within 60 minutes.</li> </ul>
--	---

<b><u>Forecast of Cause :</u></b>	1. Foreign matter on heat sink, heat sink dirty 2. Foreign matter on heat exchanger, excessive ambient temperature rise 3. Heat sink temp. sensor (Inside IPM) defective
-----------------------------------	--

Check Point 1 : Check the heat sink state
<input type="checkbox"/> Heat sink foreign matter, soiling check



Check Point 2 : Check the foreign matter and ambient temperature of heat exchanger
<input type="checkbox"/> Heat exchange foreign matter check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3 : Replace Inverter PCB
<input type="checkbox"/> Replace Inverter PCB


### 4-3-3 TROUBLE SHOOTING WITH NO ERROR CODE

#### Trouble shooting 67

#### Indoor Unit - No Power

#### Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Component defective



## Trouble shooting 68

### Outdoor Unit - No Power

#### Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Components defective

#### Check Point 1 : Check Installation Condition

- ☐ Isn't the breaker down?
- ☐ Check loose or removed connection cable.
- >>If abnormal condition is found, correct it by referring to Installation Manual or Data & Technical Manual.**


↓ OK

#### Check Point 2 : Check Outside Cause such as Voltage drop or Noise

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).  
Check the complete insulation of grounding.

↓ OK

#### Check Point 3 : Check Electrical Components



- ☐ Check the voltage of power supply.
- >> Check if the reted voltage appears at Outdoor Unit Terminal L1, L3 - N.**

NO

↓ OK

- ☐ Check the fuse on the Filter PCB.

↓ NG

- ☐ Replace the fuse.
- ☐ Recheck if the power supply terminals section is shorted.
- (Note) Always check in the power off state.

↓ NG

- ☐ Disconnect connecting cable of the Filter PCB and Main PCB and recheck. if the power supply terminals section is not shorted.
- (Note) Always check in the power off state.

↓ OK

↓ NG

- ☐ Check If the FAN motor PCB has a damage or not. ( Check short circuit )

↓ OK

↓ NG

- ☐ Replace the FAN Motor

- ☐ Check if the circuit between pin No. 1 and pin No.4 of CN104/ CN122 on the Main PCB (8, 10HP) / between pin No. 1 and pin No.3 of CN 701 on the FAN Driver PCB(12HP) are not short-circuit (Short - NG)  
\* Disconnect FAN motor when check the circuit

↓ NG

↓ NG

- ☐ If the symptom does not change by above Check 3, replace Main PCB or Filter PCB

## Trouble shooting 69

### No Operation (Power is ON)

#### Forecast of Cause :

1. Setting/Connection failure
2. Outside cause
3. Electrical Component defective

#### Check Point 1 : Check indoor and outdoor installation condition

- ❑ Indoor Unit - Check incorrect wiring between Indoor Unit- Remote Control, or terminals between Indoor Units.  
Or, check if there is an open cable connection.
  - ❑ Check address setting (Are all the address of Indoor and Outdoor correct?)
  - ❑ Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?
- >> If there is some abnormal condition, correct it by referring to Installation manual and Data & Technical Manual.**



Turn off Power and check/correct followings.

- ❑ Isn't Communication PCB of Indoor Unit removed?
- ❑ Is there loose or removed communication line of Indoor Unit and Outdoor Unit?
- ❑ Check Terminator (DIP-SW SET 5) is installed on Outdoor Main PCB.
- ❑ Check loose or removed communication line between each Outdoor Unit.
- ❑ Check loose Communication PCB of each Outdoor Unit.




#### Check Point 2 : Check outside cause at Indoor and Outdoor (Voltage drop or Noise)

- ⚙ Instant drop -----Check if there is a large load electric apparatus in the same circuit.
- ⚙ Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- ⚙ Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).  
Check the complete insulation of grounding.



#### Check Point 3 : Check Electrical Components at Indoor and Outdoor



- ❑ Indoor Unit - Check the voltage between pins 1-3 of the connector (on the control PCB) for connection with the remote controller.  
**>> If it is DC12V, Remote Control is defective (Controller PCB is normal) >> Replace Remote Control**  
**>> If it is DC 0V, Controller PCB is defective (Check Remote Control once again) >> Replace Controller PCB**
- ❑ If some of Indoor unit does not operate, replace the Communication PCB of the non-operative Indoor Unit.  
**>> If the symptom does not change, replace Controller PCB of Indoor Unit.**
- ❑ If all of Indoor Units do not operate, check the connection between Main PCB and Communication PCB of Outdoor Unit (Main Unit).  
**>> If the symptom does not change, replace Communication PCB of Outdoor Unit (Main Unit).**  
**(If it did not work, replace Main PCB.)**

## Trouble shooting 70

### No Cooling

#### Forecast of Cause :

1. Indoor Unit error
2. Outdoor Unit error
3. Effect by Surrounding environment
4. Connection Pipe / Connection Wire failure
5. Refrigeration cycle failure

#### Check Point 1 : Check Indoor Unit

- ☐ Does Indoor Unit FAN run on HIGH FAN?
- ☐ Is Air Filter dirty?
- ☐ Is Heat Exchanger clogged?



#### Check Point 2 : Check Outdoor Unit Operation

- ☐ Check if Outdoor Unit is operating
- ☐ Check any objects that obstruct the air flow route.
- ☐ Check clogged Heat Exchanger.
- ☐ Is the pipe length setting (Push Switch "MODE/EXIT", "SELECT", "ENTER") suitable?
- ☐ Is the Valve open?



#### Check Point 3 : Check Site Condition

- ☐ Is capacity of Indoor Unit fitted to Room size?
- ☐ Any windows open? Or direct sunlight ?




#### Check Point 4 : Check Indoor/Outdoor Installation Condition

- ☐ Check connection pipe (specified pipe length & Pipe diameter?)
  - ☐ Check any loose or removed communication line.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Data & Technical Manual.**





#### Check Point 5 : Check Refrigeration Cycle

- ☐ Check if Strainer is clogged (Refer to the figure at right).
  - ☐ Measure Gas Pressure and if there is a leakage, correct it.
- >> When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- ▶ Check EEV (Refer to Service Parts Information)
  - ▶ Check Solenoid Valve (Refer to Service Parts Information)
  - ▶ Check Compressor (Refer to Service Parts Information)



#### Attention!!

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference like shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.





## Trouble shooting 71

### Abnormal Noise

#### Forecast of Cause :

1. Abnormal installation (Indoor/Outdoor)
2. Fan failure(Indoor/Outdoor)
3. EEV failure (Indoor)
4. Compressor failure (Outdoor)

#### Diagnosis method when Abnormal Noise is occurred

Abnormal noise is coming from Indoor Unit  
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is the installation of Air suction grille and front panel normal?
- ☐ In case of Duct type : Is Static Pressure range normal?  
(Refer to Data & Technical Manual)

↓ **OK**

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

#### **Attention!!**

- If Refrigerant Noise is occurring, Check if the Indoor and Outdoor Thermistor is wrongly installed. Check and correct the thermistor.
- Check the refrigerant additional charging amount. When the refrigerant is not enough, add the refrigerant. However, the total refrigerant amount is prevented from more than 15.7kg.

Abnormal noise is coming from Outdoor Unit  
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is Bell Mouth installed normally?

↓ **OK**

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

↓ **OK**

- ☐ Check if vibration noise by loose bolt or contact noise of piping is happening.

↓ **OK**

- ☐ Is Compressor locked?  
>> Check Compressor (Refer to Service Parts Information)

## Trouble shooting 72

### Outdoor air unit - No Power

#### Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Component defective

#### Check Point 1 : Power supply

- Is not the breaker down?
  - Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
  - Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
  - Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).Check the complete insulation of grounding.

OK

#### Check Point 2 : Check Protector (20A)

- Check protector open / short  
If the protector is open circuit, replace it.

OK (No short circuit)

#### Check Point 3 : Check AC line

- Check AC line open / short

NG (Short circuit)

#### Check Point 4 : Check short circuit Filter PCB

- Disconnect the wire between Filter PCB and reactor, check short circuit of AC line.  
If there is short circuit, replace the Filter PCB.

OK (No short circuit)

#### Check Point 5 : Check short circuit Diode bridge

- Connect the disconnected wire(s) on the check point 4, disconnect the wire between Diode bridge and Capacitor, check short circuit of AC line.  
If there is short circuit, replace the Diode bridge.

OK (No short circuit)

#### Check Point 6 : Check short circuit Capacitor

- Connect the disconnected wire(s) on the check point 5, disconnect the wire between Capacitor and Filter PCB, check short circuit of AC line.  
If there is short circuit, replace the Capacitor.

OK (No short circuit)

#### Check Point 7 : Check short circuit Power supply PCB

- Connect the disconnected wire(s) on the check point 6, disconnect the wire of Fan motor, check short circuit of AC line.  
If there is short circuit, replace the Power supply PCB.

OK (No short circuit)

#### Check Point 8 : Check Fan Motor

- Check open / short of FAN motor  
Refer to the Service Parts Information 14-1  
If there is short circuit, replace FAN motor.

OK (No short circuit)

#### Check Point 9 : Short circuit check on DC circuit

- Disconnect the connector (CN200) on the Power supply PCB and check the short circuit
1. DC12V line ( CN200 Pin 1 - 5 )
  2. DC 5V Line ( CN200 Pin 1 - 3 )
  3. DC 15V-1 Line ( CN500 Pin 3 - 4 )
  4. DC 15V-2 Line ( CN530 Pin 3 - 4 )
- If one of them is short circuit, replace the Power supply PCB

OK (No short circuit)

#### Check Point 10 : Check short circuit of actuators (for DC12V)

- Disconnect the CN10 (EEV1) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.  
If the short circuit disappears, replace the EEV coil.
- Disconnect the CNC01 (WRC) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.  
If the short circuit disappears, check the WRC wire, WRC.
- Disconnect the CNB01 (Ext.Out) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.  
If the short circuit disappears, check the Ext. device or wiring.
- Disconnect the CN2 (TransmissionPCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.  
If the short circuit disappears, replace the Transmission PCB.
- Disconnect the CN22 (Interconnecting wire) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.  
If the short circuit disappears, replace the Filter PCB.
- If the short circuit appears after disconnecting actuators, replace the Main PCB.

OK (No short circuit)

#### Check Point 11 : Check short circuit of actuators (for DC5V)

- Disconnect the CN14 (SW PCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.  
If the short circuit disappears, replace the SW PCB.
- Disconnect the CN18 (Receiver unit \*Option) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.  
If the short circuit disappears, check the wire, Receiver unit.
- Disconnect the CN2 (Transmission PCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.  
If the short circuit disappears, replace the Transmission PCB.
- Disconnect the CN21 (Interconnecting wire) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.  
If the short circuit disappears, replace the Power supply PCB.
- If the short circuit appears after disconnecting actuators, replace the Main PCB.

## 4-3-4 Trouble Shooting for Optional Parts

### 1. External Switch Controller (UTY-TEKX)


#### Trouble shooting 73

**Error Contents :**  
**Power Supply Error**

**Symptom :**  
**No operation & LED does not light up.**

**Condition :**

1. No power supply.  
Voltage error between red and black terminals of External Switch Controller. (Normal voltage: 12V plus minus 10%)
2. Electric circuit error.  
Voltage is normal between red and black terminals of External Switch Controller (Normal voltage: 12V plus minus 10%)



## Trouble shooting 74

### Error Contents :


The abnormality in connection of remote controller cable

### Symptom :

LED repeats flashing 0.5sec ON & 0.5sec OFF.

### Condition :

Communication with Indoor unit has been cut off for longer than 1 minute.



## Trouble shooting 75

**Error Contents :**  
**Transmission Error**

**Symptom :**  
**LED repeats flashing 0.5sec ON & 1.0sec OFF.**

**Condition :**

Normal communication with Indoor unit has been suspended for longer than 1 minute.

Cause 1 : DIP switch setting defective

❑ Check setting of DIP-SW1-4, 1-5, 1-6.



OK

Cause 2 : External noise


❑ Remove or shut out external noise source.

OK


Cause 3 : Ext. Switch Controller is defective.

► **Replace External Switch Controller.**

Trouble shooting 76	
<b>Error Contents :</b> <b>Switch Operation Error</b>	<b>Symptom :</b> <b>LED is lighting but Switch (SW1 or SW2) does not operate.</b>
<b>Condition :</b> Switch input can not be detected.	



## Signal Amplifier (UTY-VSGXZ1)

Trouble shooting 77	
<u>Error Contents :</u> Power Supply Error	<u>Symptom :</u> No display
<u>Details :</u> Condition of occurrence : Normal power is not supplied. 7 segment indicator is defective. Release condition : Normal power is supplied. 7 segment indicator is normal.	
Cause 1 : Power supply cable installation is defective or open.	
<input type="checkbox"/> Check following installation and reset the power supply. (1) Installation of power cable on power supply terminal. (2) Connection between Power PCB and Terminal. (3) Connector condition between power PCB and Main PCB.	<div>OK</div> <div>  </div>
	Cause 2 : Signal Amplifier is defective.
	If normal voltage (Rated Voltage) is applied to power supply terminal of Signal Amplifier, there is a possibility of defective PCB. Proceed as follows. ► <b><u>Replace Signal Amplifier.</u></b>

## Signal Amplifier (UTY-VSGXZ1)

### Trouble shooting 78

#### Error Contents :

Communication Error

#### Symptom :

Error code does not appear [ \_ ]

Communication error occurs at connected equipment side.

#### Details :

Condition of occurrence : Network cable defective. External noise is applied.

Overlapping of Signal Amplifier address setting. System design mistake.

Release condition : Network cable is connected. External noise is removed.

Overlapping of Signal Amplifier has been corrected. System design is normal.

#### Cause 1 :

Network cable installation is defective or open.

- ❑ Check Network cable installation.



OK

#### Cause 2 : External noise

- ❑ Remove external noise around Signal Amplifier or Network cable. (Keep enough distance)



OK

#### Cause 3 :

Overlapped address of Signal Amplifier.

- ❑ Set up address again which does not overlap on system. After set up again, reset the power supply.

OK

#### Cause 4 : System Design mistake


- ❑ Check following items.(Refer to Installation Manual)

- (1) Installation location of Terminal Resistor.  
(Only 1 location on NS\*)
- (2) Cable length. (Within 500m maximum on NS\*)
- (3) Number of units connected  
(Up to 64 units maximum on NS\*)
- (4) Communication cable specification.  
(Use specified type.)
- (5) Number of Signal Amplifier installed.  
(Up to 8 units max. on system)
- (6) Network cable shall not be connected in loop.

\*NS : Network Segment



Signal Amplifier (UTY-VSGXZ1)



## Signal Amplifier (UTY-VSGXZ1)

### Trouble shooting 80

#### Error Contents :

Main PCB Error

#### Symptom :

Error display [ C 1 ]

No operation.

#### Details :

Condition of occurrence : Communication error between CPU and Network Driver IC

Release condition : Communication is normal between CPU and Network Driver IC

#### Cause 1 : External noise

❑ Upon pressing RESET button (SW7) or turning on power, proceed as follows.

(1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.

(2) If error occurs again, check followings other than removing surrounding noise source.

OK

Cause 2 : Signal Amplifier is defective.

► Replace Signal Amplifier.

## Signal Amplifier (UTY-VSGXZ1)

### Trouble shooting 81

#### **Error Contents : Communication Error B**

**Symptom :**  
**Error display [ D9 (Flashing or Lighting) ]**  
**No operation.**

#### **Details :**

Condition of occurrence : Communication error between CPU and Network Driver IC (CH\_B side).

Network Driver IC is defective.

Release condition : Communication is normal between CPU and Network Driver IC (CH\_B side).

Network Driver IC operation is normal.

#### **Cause 1 : External noise**

- ☐ Upon pressing RESET button (SW7) or turning on power, proceed as follows.
- (1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

**OK**

Cause 2 :Signal Amplifier is defective.

► **Replace Signal Amplifier.**

## Signal Amplifier (UTY-VSGXZ1)

### Trouble shooting 82

#### **Error Contents :** **Communication Error A**

**Symptom :**  
**Error display [ D14 (Flashing or Lighting) ]**  
**No operation.**

#### **Details :**

Condition of occurrence : Communication error between CPU and Network Driver IC (CH\_A side).

Network Driver IC is defective.

Release condition : Communication is normal between CPU and Network Driver IC (CH\_A side).

Network Driver IC operation is normal.

#### **Cause 1 : External noise**


- ☐ Upon pressing RESET button (SW7) or turning on power, proceed as follows.
- (1) If error did not appear, it is not a defect of PCB. Remove the surrounding noise source.
- (2) If error occurs again, check followings other than removing surrounding noise source.

**OK**


**Cause 2 : Signal Amplifier is defective.**

► **Replace Signal Amplifier.**

## Network Converter (UTY-VGGXZ1)

<b>Trouble shooting 83</b>	
<b><u>Error Contents :</u></b> Power Supply Error	<b><u>Symptom :</u></b> No display
<b><u>Details :</u></b> Condition of occurrence : Normal power is not supplied. 7 segment indicator is defective. Release condition : Normal power is supplied. 7 segment indicator is normal.	
<div>           Cause 1 :            Power supply cable installation is defective or open.         </div> <div> <input type="checkbox"/> Check following installation and reset the power supply.            (1) Installation of power cable on power supply terminal.            (2) Connection between Power PCB and Terminal.            (3) Connector condition between power PCB and Main PCB.         </div>	
<div> <div>OK</div> <div>  </div> </div> <div>           Cause 2 : Network Converter is defective.             If normal voltage (Rated Voltage) is applied to power supply terminal of Network Converter, there is a possibility of defective PCB. Proceed as follows.            ► <b><u>Replace Network Converter.</u></b> </div>	

## Network Convertor (UTY-VGGXZ1)



## Network Convertor (UTY-VGGXZ1) Group Remote controller Setting

### Trouble shooting 85

#### Error Contents :

**Communication Error  
with Group Remote Controller**

#### Symptom :

**Error Code display [ 1 2 ] Control/Display from Group Remote is  
not available.**

#### Details :

Condition of occurrence : The communication between Group Remote and Network Convertor was not normally performed.  
Release condition : When the communication between Group Remote and Network Convertor resumes normal operation.

#### Cause 1 : External noise

☐ After pressing SW104 of Network Convertor PCB for 5 seconds or turning on power.  
Does error code display reappear?

**YES**

- Remove the surrounding noise source.

**NO**

- It is not a defect of PCB. Remove the surrounding noise source.

**OK**

#### Cause 2 :

**Defective or open connection of cable wire between Network Convertor and Connected Remote Controller.**

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Convertor and Connected Remote Controller.
- ☐ Check connection between Control PCB and Terminal.

**OK**

#### Cause 3 : Incorrect setting of Network Convertor's DIP-SW103[1 to 4]

- ☐ Check Network Convertor PCB DIP-SW103[1 to 4] ON.

**OK**

#### Cause 4 : Defective Remote Controller or Network Convertor.

► **Replace Remote Controller or Network Convertor.**

## Network Converter (UTY-VGGXZ1) Single Split system setting

### Trouble shooting 86

#### Error Contents :

**Communication Error  
with Standard Remote Controller**

#### Symptom :

**Error Code display [ 1 2 ] Control/Display from Standard Remote s  
not available. Other controls are left as they are.**

#### Details :

Condition of occurrence : The communication between Standard Remote Controller and Network Converter was not normally performed.

Release condition : When the communication between Standard Remote Controller and Network Converter resumes normal operation.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

**YES**

- Remove the surrounding noise source.

**OK**

**NO**

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 :

**Defective or open connection of cable wire between Network Converter and Connected Remote Controller.**

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Converter and Connected Remote Controller.
- ☐ Check connection between Control PCB and Terminal.

**OK**

#### Cause 3 : Incorrect setting of Network Converter's DIP-SW107[2] (Wired RC Validity setting)

- ☐ Check Network Converter PCB DIP-SW107[2].

**OK**

#### Cause 4 : Incorrect selection of Remote Controller

- ☐ Check connection Remote Controller. (Is it specified with the Installation Manual of Network Converter?)

**OK**

#### Cause 5 :

**Incorrect setting of Remote Controller's DIP-SW (Number of connected remote controllers)**

- ☐ Check DIP-SW of Remote Controller.

**OK**

#### Cause 6 : Defective Remote Controller or Network Converter.

- **Replace Remote Controller or Network Converter.**



## Network Converter (UTY-VGGXZ1)

### Trouble shooting 87

#### Error Contents :

**Peripheral device Communication abnormal**

#### Symptom :

**Error Code display [ 1 6 ]**

**All the control items do not operate.**

#### Details :

Condition of occurrence : The communication between Indoor unit and Network Converter was not performed normally.

Release condition : When the communication with Indoor unit is resumed normally.

#### Cause 1 : External noise

- ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.  
Does error code display reappear?

**YES**

- Remove the surrounding noise source.

**OK**

**NO**

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 :

**Defective or open connection of Remote Control cable between Network Converter and Indoor Unit.**

After the following are checked, the power supply is reset.

- ☐ Check connection cable wire between Network Converter and Indoor unit.
- ☐ Check connection between Control PCB and Terminal.

**OK**

#### Cause 3 : Power to Indoor unit is shut down.

- ☐ Check the power to Indoor unit.

**OK**

#### Cause 4 : Incorrect setting of main unit address of Indoor unit.

- ☐ Check main unit address setting of Indoor unit.

**OK**

#### Cause 5 : Incorrect setting of DIP-SW of Network Converter. Mis-read of Indoor unit type and RC type.

- ☐ Check DIP-SW103[1 to 8] of Network Converter (Indoor unit type, RC type, number of Indoor units connected.)
- ☐ Check Indoor unit type and RC type of all Indoor units connected to Network Converter.

**OK**

#### Cause 6 : Defective PCB of Indoor unit or Network Converter.

- **Replace PCB of Controller PCB or Network Converter.**

## Network Converter (UTY-VGGXZ1)

### Trouble shooting 88

#### Error Contents :

#### Software Error

#### Symptom :

Error Code display [ C A ]

All the control items do not operate.

Other Controls are left they are.

#### Details :

Condition of occurrence : Micon program performed an abnormal control.

Error of inside information of EEPROM.

initial setting of Network Converter PCB was not normally performed.

Release condition : Micon has been reset, and the control of Network Converter became normal.

When error disappeared and Network Converter becomes available to control.

#### Cause 1 : External noise

##### ☐ Check continuation of error.

(1) If error is released automatically, it is not a defect of PCB. Remove the surrounding noise source around Network Converter.

(2) If error is not released automatically, check followings.

↓ OK

##### ☐ After pressing SW104 of Network Converter PCB for 5 seconds or turning on power.

Does error code display reappear?

↓ YES

- Remove the surrounding noise source.

↓ OK

↓ NO

- It is not a defect of PCB. Remove the surrounding noise source.

#### Cause 2 : Network Converter is defective.

► Replace Network Converter.

Network Convertor (UTY-VGGXZ1)

**Trouble shooting 89**

**Error Contents :**  
**Refrigerant circuit address setting error**

**Symptom :**  
**Error Code display [ 2 6 ]**

**Details :**

Condition of occurrence : Indoor unit registration is 3 refrigerant circuits or more.  
Release condition : Indoor unit registration is 2 refrigerant circuits or less.

**Cause 1 : Check of number of indoor unit registration refrigerant circuits**

☐ Check indoor unit registration.  
(1) Number of refrigerant circuits of indoor unit registered at Replace Group Remote Controller is 3 refrigerant circuits or more even though connected to one converter.

**YES**

☐ Make 2 refrigerant circuits or less and wait 2 minutes

**NO**

☐ Replace Network Convertor  
Replace Group Remote Controller

<b>Trouble shooting 90</b>	Group Remote Controller (UTY-CGGY / CGGG)
<b>Error Contents :</b> <b>Group remote controller hardware Error</b>	<b>Symptom :</b> <b>Error Code display [ C 4 ]</b> <b>OPERATION LED is flashing.</b>
<b>Details :</b> Condition of occurrence : When EEPROM can not be written, or the control port does not operate. Release condition : Power is reset.	

Cause 1 : Remote Controller is defective.
► <u>Replace Group Remote Controller.</u>

**Trouble shooting 91**

Group Remote Controller (UTY-CGGY / CGGG)

**Error Contents :****Remote controller Communication Error****Symptom :****Error Code display [ 1 2 ]****OPERATION LED is flashing.****Details :**

Condition of occurrence :

The valid signal has not been received from the convertor more than 90 seconds after the communication line became valid.

Release condition : Valid signal is received from Convertor.

**Cause 1 : Connection failure**

- ☐ Check power to the convertor.
- ☐ Check connection of remote control line between controller and convertor.

**OK****Cause 2 : Check outside cause (Voltage drop or noise, etc.)**

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).

**OK****Cause 3 : Remote Controller is defective.**

- ▶ **Replace Group Remote Controller.**

<b>Trouble shooting 92</b>	Group Remote Controller (UTY-CGGY / CGGG)
<b>Error Contents :</b> <b>Address Setting Error</b>	<b>Symptom :</b> <b>Error Code display [ 2 6 ]</b> <b>OPERATION LED is flashing.</b>
<b>Details :</b> Condition of occurrence : 1. No Indoor unit is registered. Release condition : 1. The key to enter the function selection process is pressed. TIME< key and TIME> key are simultaneously kept pressed. 2. It automatically initializes by itself. After that, it is released by pressing the key to enter the function selection process.	

<b>Cause 1 : Setting failure</b>
<input type="checkbox"/> Register Indoor units again by entering to the function selection mode. (Keep pressing TIME< key and TIME> key. <b>(Refer to the installation manual for the remote controller.)</b>

**Trouble shooting 93**

Group Remote Controller (UTY-CGGY / CGGG)

**Error Contents :  
Scan Error****Symptom :****Error Code display [ 1 5 ]  
OPERATION LED is flashing.****Details :**

Condition of occurrence :

1. Registration started within 4 minutes after power ON
2. Indoor unit refrigerant system registered at controller connected to converter reached 3 or more ([26] error generated at converter)
3. Only the slave unit is registered. (Main unit is not registered.)
4. Indoor unit which is not existing was registered.
5. Outdoor unit is not set in the same refrigerant circuit as the indoor unit.

Release condition : Registered contents have been changed by SELECT key, DAY key, Timer Mode key (DELETE key).

**Cause 1 : Conditions check**

- ☐ Check if 4 minutes or more after starting
- ☐ Clear when [26] error generated at converter.
- ☐ Check if refrigerant systems do not become 3 or more by this indoor unit registration.

**Cause 2 : Setting failure**

- ☐ Recheck the registered contents.(Register the main unit.)
- ☐ Check Indoor unit DIP-SW, R-SW
- ☐ Check outdoor unit R-SW.

**Cause 3 : Connection failure**

- ☐ Check transmission cable
- ☐ Check if Indoor or Outdoor unit power line is disconnected.
- ☐ Check if the convertor power line is disconnected.
- ☐ Check connection between controller and the convertor.

**Cause 4 : Check outside cause (Voltage drop or noise, etc.)**

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).

**Cause 5 : Remote Controller is defective.**

- **Replace Group Remote Controller.**

**Trouble shooting 94**

Group Remote Controller (UTY-CGGY / CGGG)

**Error Contents :****Network communication Error****Symptom :****Error Code display [ 1 4 ]****OPERATION LED is flashing.****Details :**

Condition of occurrence :

When the signal is cut off for more than 10 minutes from the registered Indoor unit (not including Slave unit).

Release condition : 1. The signal has been received from the Indoor units that was creating the error.

2. MPU has been booted up. (Release from the reset operation, the power failure stand-by operation.)

**Cause 1 : Connection failure**

- ☐ Check transmission cable
- ☐ Check disconnected power line for Indoor unit.
- ☐ Check if convertor power line is disconnected.

**OK****Cause 2 : Check outside cause (Voltage drop or noise, etc.)**

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).

**OK****Cause 3 : Remote Controller is defective.**

- **Replace Group Remote Controller.**



## Trouble shooting 95

**Error Contents :**  
**Incompatible Indoor Unit is Connected**

**Symptom :**  
**Error Code display [ 1 5 ]**

**Details :**

Condition of occurrence : When information was not obtained from indoor unit  
Release condition : When information was obtained from indoor unit

Cause 1 : Check remote controller master/slave setting.

- ☐ For the check and modification methods, refer to the remote controller (including external SW) installation manual.
- ☐ When there is 1 remote controller, check whether or not it is set as the master remote controller.
- ☐ When there are 2 remote controllers, check if one side is the master remote controller and the other side is the slave remote controller.
- ☐ When there are 1 remote controller and 1 external switch controller, check if the remote controller is master controller and the external switch controller is slave controller.



Cause 2 : Check connection

- ☐ Check cable
- ☐ Check indoor unit power supply



Cause 3 : Noise

- ☐ Source around cable



Cause 4 : Remote controller trouble

- ☐ Replace remote controller.



Cause 5 : Indoor unit PCB trouble

- ☐ Change Controller PCB and set up the original address.

<b>Trouble shooting 96</b>	
<b><u>Error Contents :</u></b> <b>Thermo Sensor Error</b>	<b><u>Symptom :</u></b> <b>Thermostat Sensor display is flashing.</b>
<b><u>Details :</u></b> Condition of occurrence : Thermistor in remote controller is open or shorted. Release condition : Thermistor in remote controller is not open or shorted.	
<b>Cause 1 : Remote controller internal thermistor trouble</b>	
<input type="checkbox"/> Replace remote controller.	

<b>Trouble shooting 97</b> <b><u>INDOOR UNIT Error Method:</u></b> Wireless LAN adapter Error	<b><u>Indicate of Display:</u></b> Indoor Unit : Operation lamp: No indication Timer lamp    : No indication <b>ERROR CODE : [ No indication ]</b>
---	--

Wireless LAN adapter :  
 LED 1 (Green) : Flashing Fast  
 LED 2 (Orange) : Flashing Fast

<b><u>Detective Actuators:</u></b> Wireless LAN adapter setting button Wireless LAN adapter PCB	<b><u>Detective details:</u></b> When the Setting button becomes ON for consecutive 60 or more seconds. <div data-bbox="1190 472 1461 658" data-label="Image"> </div>
---	---

**Forecast of Cause:**

1. Wireless LAN adapter setting button failure
2. Wireless LAN adapter PCB failure


**Check Point 1 : Check the setting button**

- Check if Setting button is kept pressed.  
 > If the Settings button is held down by the foreign matter,  
Please remove the foreign matter or remove the cause of the button press.



**Check Point 2 : Replace wireless LAN adapter**

- If Check Point 1 do not improve the symptom, replace Wireless LAN adapter and  
Please cancel the air conditioner of the registration on the Mobile App.  
After the replace adapter, Please perform the pairing on the app.
  - >> Refer to “ Air conditioning unregistration method”
  - >> Refer to “ Air conditioner registration Paring Method”

<p><b>Trouble shooting 98</b></p> <p><b><u>INDOOR UNIT Error Method:</u></b></p> <p>Communication Error between Indoor unit and Wireless LAN Router</p>	<p><b><u>Indicate of Display:</u></b></p> <table border="1"> <tr> <td>Indoor Unit :</td><td>Wireless LAN adapter :</td></tr> <tr> <td>Operation lamp : 1 time Flash</td><td>LED 1 (Green) : Flashing Fast</td></tr> <tr> <td>Timer lamp : 8 time Flash</td><td>LED 2 (Orange) : Flashing Fast</td></tr> <tr> <td colspan="2">ERROR CODE : [ 18 ]</td></tr> </table>	Indoor Unit :	Wireless LAN adapter :	Operation lamp : 1 time Flash	LED 1 (Green) : Flashing Fast	Timer lamp : 8 time Flash	LED 2 (Orange) : Flashing Fast	ERROR CODE : [ 18 ]	
Indoor Unit :	Wireless LAN adapter :								
Operation lamp : 1 time Flash	LED 1 (Green) : Flashing Fast								
Timer lamp : 8 time Flash	LED 2 (Orange) : Flashing Fast								
ERROR CODE : [ 18 ]									
<p><b><u>Detective Actuators:</u></b></p> <p>Wireless LAN router Wireless LAN adapter PCB Indoor unit Controller PCB</p>	<p><b><u>Detective details:</u></b></p> <p>When the "External Communication Error" and "Network Communication Error" has occurred at the same time.</p> 								

**Forecast of Cause:**

1. Connection cable failure of Wireless LAN router,
2. Wireless LAN router failure
3. Connection between A/C and Wireless LAN adapter failure
4. Connection between Wireless LAN adapter and Wireless LAN router failure
5. Wireless LAN adapter PCB failure,
6. Controller PCB failure

**Check Point 1 : Check the connection cable**


- Check the connection cable on the Wireless LAN router.  
>If there is loose connector, open cable or miswiring, correct it.



**Check Point 2 : Check the connection status and transmission state**

- Check the connection status to the Internet and Wireless LAN router.  
>If the Wireless LAN Router is not connected to the Internet,  
Please check the transmission between "Wi-Fi products of other than Air conditioner" and "Wireless LAN router".  
> When there is no problem with Wi-Fi products >> Refer to "Check Point 4".


Ex. ) Wi-Fi products



- Check the Wireless transmission state of Wireless LAN router.(LED status)  
>If the wireless transmission from the Wireless LAN Router has not been outgoing,  
Please the inquiry to "Wireless LAN router maker".

Did the display pattern will change?

Wireless LAN adapter : LED 1 (Green) : Flashing Fast , LED 2 (Orange) :ON



**Check Point 3-1 : Turn on power again of Air conditioner**

- If Check Point 1,2 do not improve the symptom,  
turn on power again of the Air conditioner,please wait 60 seconds.  
> When the flashing pattern of the LED 2(Orange) is "ON" >> Refer to "Check Point 3-2".  
> When the flashing pattern of the LED 2(Orange) is "Flashing Fast" >> Refer to "Check Point 4".

To NEXT PAGE

CONTINUATION

YES

Check Point 3-2 : Cheak the connection

- Check any loose or removed connection of between the Wireless LAN adapter PCB and Controller PCB  
>If there is abnormal condition, correct it.
- Check the connection condition on the Controller PCB  
>If there is loose connector, open cable or miswiring, correct it.

OK

Check Point 4 : Replace Wireless LAN adapter


- ▶ If Check Point 2,3 do not improve the symptom, replace Wireless LAN adapter and  
Please cancel the air conditioner of the registration on the Mobile App.  
After the replace adapter, Please perform the pairing on the app.
  - >> Refer to “ Air conditioning unregistration method”
  - >> Refer to “ Air conditioner registration Paring method”

OK

Check Point 5 : Replace Controller PCB

- ▶ If Check Point 4 do not improve the symptom, replace controller PCB.

<b>Trouble shooting 99</b> <b><u>INDOOR UNIT Error Method:</u></b> Communication Error between Indoor Unit and Wireless LAN adapter	<b><u>Indicate of Display:</u></b> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;">           Indoor Unit :            Operation lamp: 1 times Flash,            Timer lamp : 8 times Flash  <b>ERROR CODE : [ 18 ]</b> </div> <div style="width: 45%;"> <b>Wireless LAN adapter :</b>  <b>LED 1 (Green) : Flashing Fast</b>  <b>LED 2 (Orange) : ON</b> </div> </div>
---	---

<b><u>Detective Actuators:</u></b> Wireless LAN adapter PCB Controller PCB	<b><u>Detective details:</u></b> After receiving a signal from the wireless LAN adapter, the same a signal has not been received for 15sec. <div style="text-align: center; margin-top: 10px;">  </div>
--	---

<b><u>Forecast of Cause:</u></b> <ol style="list-style-type: none"> <li>1. Connection between A/C and Wireless LAN adapter failure</li> <li>2. Wireless LAN adapter PCB failure</li> <li>3. Controller PCB failure</li> </ol>
---

<b>Check Point 1 : Cheak the connection</b> <ul style="list-style-type: none"> <li>• Check any loose or removed connection of between the Wireless LAN adapter PCB and Controller PCB              &gt;If there is abnormal condition, correct it.</li> </ul> <p>Check the connection condition on the Controller PCB              &gt;If there is loose connector, open cable or miswiring, correct it.</p>
---




<b>Check Point 2 : Replace wireless LAN adapter</b> <ul style="list-style-type: none"> <li>▶ If Check Point 1 do not improve the symptom, replace Wireless LAN adapter and <u>Please cancel the air conditioner of the registration on the Mobile App.</u>  <u>After the replace adapter, Please perform the pairing on the app.</u></li> <li>&gt;&gt; Refer to “ Air conditioning unregistration method”</li> <li>&gt;&gt; Refer to “ Air conditioner registration Paring Method”</li> </ul>
--



<b>Check Point 3 : Replace Controller PCB</b> <ul style="list-style-type: none"> <li>▶ <u>If Check Point 2 do not improve the symptom, replace controller PCB.</u></li> </ul>
--

<b>Trouble shooting 100</b> <b>INDOOR UNIT Error Method:</b> Communication Error between Wireless LAN Router and Wireless LAN adapter	<b>Indicate of Display:</b> <table border="0"> <tr> <td data-bbox="662 238 1036 358"> <b>Indoor Unit :</b>  <b>Operation lamp:</b> No indication  <b>Timer lamp :</b> No indication  <b>ERROR CODE :</b> [ No indication ]         </td><td data-bbox="1068 238 1468 330"> <b>Wireless LAN adapter :</b>  <b>LED 1 (Green) :</b> ON  <b>LED 2 (Orange) :</b> Flashing Fast         </td></tr> </table>	<b>Indoor Unit :</b> <b>Operation lamp:</b> No indication <b>Timer lamp :</b> No indication <b>ERROR CODE :</b> [ No indication ]	<b>Wireless LAN adapter :</b> <b>LED 1 (Green) :</b> ON <b>LED 2 (Orange) :</b> Flashing Fast
<b>Indoor Unit :</b> <b>Operation lamp:</b> No indication <b>Timer lamp :</b> No indication <b>ERROR CODE :</b> [ No indication ]	<b>Wireless LAN adapter :</b> <b>LED 1 (Green) :</b> ON <b>LED 2 (Orange) :</b> Flashing Fast		


<b>Detective Actuators:</b> Wireless LAN router Wireless LAN adapter PCB	<b>Detective details:</b> When the Not connection between Wireless LAN adapter and Wireless LAN router. 
--	---

<b>Forecast of Cause:</b> <ol style="list-style-type: none"> <li>1. Connection cable failure of Wireless LAN ruter.</li> <li>2. Connection between Wireless LAN adapter and Wireless LAN router failure</li> <li>3. Wireless LAN router failure</li> <li>4. Wireless LAN adapter PCB failure</li> </ol>
---

<b>Check Point 1 : Check the connection cable</b> • Check the connection cable on the Wireless LAN router. >If there is loose connector, open cable or miswiring, correct it.
---



<b>Check Point 2-1 : Check the connection status</b> • Check the connection status to the Internet and Wireless LAN router. >If the Wireless LAN Router is not connected to the Internet, <u>Please check the transmission between</u> <u>"Wi-Fi products of other than Air conditioner" and "Wireless LAN ruter".</u> <div data-bbox="997 1288 1240 1322" data-label="Text">           Ex. ) Wi-Fi products         </div> <div data-bbox="1062 1352 1435 1501" data-label="Diagram"> </div>
---



<b>Check Point 2-2 : Check the transmission state</b> • Check the Wireless transmission state of Wireless LAN router.(LED status) >If the wireless transmission from the Wireless LAN router has not been outgoing, <u>Please the inquiry to "Wireless LAN router maker".</u>
--

<b>Check Point 3 : Turn on power again of Air conditioner</b> ► If Check Point 1,2 do not improve the symptom, <u>turn on power again</u> of the Air conditioner, please wait 60 seconds.
--



<b>Check Point 4 : Replace Wireless LAN adapter</b> ► If Check Point 3 do not improve the symptom, replace Wireless LAN adapter and <u>Please cancel the air conditioner of the registration on the Mobile App.</u> <u>After the replace adapter, Please perform the pairing on the app.</u> >> Refer to " Air conditioning unregistration method" >> Refer to " Air conditioner registration Paring Method"
---

<b>Trouble shooting 101</b> <b><u>INDOOR UNIT Error Method:</u></b> Wireless LAN adapter Non-Energized	<b><u>Indicate of Display:</u></b> <table border="0"> <tr> <td data-bbox="646 212 1029 320"> <b>Indoor Unit :</b>  <b>Operation lamp: 1 time Flash</b>  <b>Timer lamp : 8 time Flash</b>  <b>ERROR CODE : [ 18 ]</b> </td><td data-bbox="1029 212 1482 320"> <b>Wireless LAN adapter :</b>  <b>LED 1 (Green) : OFF</b>  <b>LED 2 (Orange) : OFF</b> </td></tr> </table>	<b>Indoor Unit :</b> <b>Operation lamp: 1 time Flash</b> <b>Timer lamp : 8 time Flash</b> <b>ERROR CODE : [ 18 ]</b>	<b>Wireless LAN adapter :</b> <b>LED 1 (Green) : OFF</b> <b>LED 2 (Orange) : OFF</b>
<b>Indoor Unit :</b> <b>Operation lamp: 1 time Flash</b> <b>Timer lamp : 8 time Flash</b> <b>ERROR CODE : [ 18 ]</b>	<b>Wireless LAN adapter :</b> <b>LED 1 (Green) : OFF</b> <b>LED 2 (Orange) : OFF</b>		

<b><u>Detective Actuators:</u></b> Indoor unit Controller PCB Wireless LAN adapter PCB	<b><u>Detective details:</u></b> When the does not output the DC12 voltage from Controller PCB.
--	--

<b><u>Forecast of Cause:</u></b> 1. Indoor unit Controller PCB failure 2. Wireless LAN adapter PCB failure 3. Wiring connection failure
--

<b>Check Point 1 : Cheak the Sleep mode</b> • Press the Wireless LAN adapter setting button the 3 seconds or more. Did the display pattern will change? <div data-bbox="159 1160 1217 1191" style="border: 1px solid black; padding: 2px;">           Wireless LAN adapter : LED 1 (Green) : Flashing Fast , LED 2 (Orange) : Flashing Fast         </div>
---

**NO**

**YES**

Refer To "Trouble shooting 98 "

<b>Check Point 2 : Cheak the connection</b> • Check any loose or removed connection of between the Wireless LAN adapter PCB and Controller PCB >If there is abnormal condition, <u>correct it.</u> Check the connection condition on the Controller PCB >If there is loose connector, open cable or miswiring, <u>correct it.</u>
---

**OK**

<b>Check Point 3 : Cheak the Wireless LAN adapter PCB and Controller PCB</b> • Check Voltage at CN12 (terminal 1-2) of Controller PCB. >If it is DC 0V, Controller PCB is <u>failure.</u> ► <u>Replace Controller PCB.</u> >If it is DC12V, Wireless LAN adapter PCB failure. ► <u>Replace Wireless LAN adapter and please cancel the air conditioner of the registration on the Mobile App.</u> <u>After the replace adapter, Please perform the pairing on the App.</u> >> Refer to " Air conditioning unregistration method" >> Refer to " Air conditioner registration Paring Method"
---






<b>Trouble shooting 102</b> <b><u>INDOOR UNIT Error Method:</u></b> Wireless LAN adapter Sleep mode	<b><u>Indicate of Display:</u></b> <div> Indoor Unit :  Operation lamp: No indication  Timer lamp : No indication  ERROR CODE : [ No indication ] </div> <div> Wireless LAN adapter :  LED 1 (Green) : OFF  LED 2 (Orange) : OFF </div>
---	--

<b><u>Detective Actuators:</u></b> Sleep mode	<b><u>Detective details:</u></b> When the state in which fly a wireless(SSID) have passed 1 hour.
--	--

<b><u>Forecast of Cause:</u></b> 1. Sleep mode
---




## 4-4 SERVICE PARTS INFORMATION

### SERVICE PARTS INFORMATION 1

#### Compressor

Diagnosis method of Compressor (If Outdoor Unit 7 segment LED displays Error, refer to Trouble shooting )




## SERVICE PARTS INFORMATION 2


### Inverter Compressor

#### Check Point 1 : Check Connection

❑ Check terminal connection of Compressor (loose or incorrect wiring)



❑ Check connection of Inverter PCB (Loose or incorrect wiring)




Compressor

#### Check Point 2 : Check Winding Resistance

❑ Check winding resistance of each terminal

► If the resistance value is  $0\Omega$  or infinite, replace Compressor.



#### **Attention!!**

If Check 1, 2 are normal, make sure the following points.

Check Voltage from Main PCB to Inverter PCB.

(DC16.0 - 20.0V between terminals of CN126 (1-2) connector of Main PCB).


► If it does not appear, replace Main PCB.

◆ If both of above voltages appear, it is considered to be Inverter PCB circuit failure. Replace Inverter PCB and check operation.



### SERVICE PARTS INFORMATION 3

Main PCB  
Filter PCB




## SERVICE PARTS INFORMATION 4

Inverter PCB

Filter PCB

Power PCB



## SERVICE PARTS INFORMATION 5

### IPM (Mounted on Inverter PCB)

#### Check Point 1

① Disconnect the connection wires between the Inverter PCB - ACTPM and Inverter PCB - Inverter Compressor.

② Set the tester to the "Resistance" mode, and measure the resistance between the following terminals.

P - Terminals U / V / W

N (TM482) - Terminals U / V / W

③ Judge the result of ② as follows:

All 6 points several MΩ or greater	: Normal
1 or more points several kΩ to short	: Defective




#### Check Point 2

④ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

Tester +side (red)	Tester - side (black)	Tester display [V]
Terminal U	(P)	
Terminal V		
Terminal W		
(N)	Terminal U	
	Terminal V	
	Terminal W	

⑤ Judge the result of ④ as follows:

All 6 points several 0.3V to 0.7V	: Normal
1 or more points under 0.1V or over load	: Defective



## **SERVICE PARTS INFORMATION 6**



**Choke Coil / Reactor assy (INV)**

**Reactor assy**

### **Check Point 1 : Appearance check**

- ☐ No fissures, breaks, damage, etc. at the body and winding section, terminals section?

### **Check Point 2 : Electric check**



① Set the tester to the "Resistance" mode, and check for open/short between both ends of the reactor wire (or connector).

② Judge the result of ① as follows:

Short	: Normal
Open	: Abnormal (open)

## **SERVICE PARTS INFORMATION 7**


### **Terminal**

#### **Check Point 1 : Appearance check**

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?
- ☐ Not clogged with foreign matter?
- ☐ Are there no abnormalities at threaded parts (Stripped threads, deformation, damage, etc.) ?

#### **Check Point 2 : Electric check**

- ☐ No short between adjacent terminals?
- ☐ Conducts before and after same terminal?






## SERVICE PARTS INFORMATION 8-1

### Indoor Unit Electronic Expansion Valve (EEV)

#### Check Point 1 : Check Connections

- Check Connectors (Loose connector or open cable.)

**Slim duct, High static pressure duct,  
Outdoor air unit, Cassette, Wall mount,  
Vertical air handler(it not have "BROWN wire").**



\* DX-Kit : CN11

**Floor/ Ceiling, Ceiling, Compact Wall mount**




#### Check Point 2 : Check Coil of EEV

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value 68°F(20°C)
White - Red	<b>200 ± 10% Ω</b>
Yellow - Brown	
Orange - Red	
Blue - Brown	

► **If Resistance value is abnormal, replace EEV.**



#### Check Point 3 : Check Noise at start up

Turn on Power and check operation noise.

>> **If an abnormal noise does not show, replace Controller PCB.**

#### Check Point 4 : Check Voltage from Controller PCB

- Remove Connector and check Voltage (DC12V).


>> **If it does not appear, replace Controller PCB.**



#### Check Point 5 : Check Opening and Closing Operation of Valve


When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

**CLOSE**  
Example : Hot Gas





If it is open,  
it has no temp. difference between Inlet and Outlet.

**OPEN**  
Example : Hot Gas



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 8-2

### Indoor Unit Electronic Expansion Valve (EEV)

#### Check Point 1 : Check Connections

❑ Check Connectors (Loose connector or open cable.)

**Cassette** (AUXK018 - 030GLAH, AUXM018 - 030GLAH)  
**Compact Floor** (AG\*A004 - 014GCAH)  
**Compact Wall mount** (AS\*A004 - 009GTAH)  
**Wall mount** (AS\*A030GTAH)




**Compact Slim Duct (ARXK04 - 24GCLH)**



#### Check Point 2 : Check Coil of EEV

❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	$46 \pm 10\% \Omega$
Yellow - Red	
Orange - Red	
Blue - Red	



► If Resistance value is abnormal, replace EEV.

#### Check Point 3 : Check Noise at start up

Turn on Power and check operation noise.

>> If an abnormal noise does not show, replace Controller PCB.

#### Check Point 4 : Check Voltage from Controller PCB

❑ Remove Connector and check Voltage (DC12V).


>> If it does not appear, replace Controller PCB.



#### Check Point 5 : Check Opening and Closing Operation of Valve


When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

**CLOSE**  
Example : Hot Gas





If it is open,  
it has no temp. difference between Inlet and Outlet.

**OPEN**  
Example : Hot Gas



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 8-3

### Indoor Unit Electronic Expansion Valve (EEV)

#### Check Point 1 : Check Connections

- ❑ Check Connectors (Loose connector or open cable.)


**Cassette (AUXK034 - 054GLAH)**  
**Wall mount (AS\*A034GTAH)**



#### Check Point 2 : Check Coil of EEV

- ❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	<b>150 ± 10% Ω</b>
Yellow - Red	
Orange - Red	
Blue - Red	



► **If Resistance value is abnormal, replace EEV.**

#### Check Point 3 : Check Noise at start up

Turn on Power and check operation noise.

>> **If an abnormal noise does not show, replace Controller PCB.**

#### Check Point 4 : Check Voltage from Controller PCB

- ❑ Remove Connector and check Voltage (DC12V).


>> **If it does not appear, replace Controller PCB.**



#### Check Point 5 : Check Opening and Closing Operation of Valve


When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

**CLOSE**  
**Example : Hot Gas**





If it is open,  
it has no temp. difference between Inlet and Outlet.

**OPEN**  
**Example : Hot Gas**



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 9

### Outdoor Unit Electronic Expansion Valve (EEV1)

#### Check Point 1 : Check Connections

- Check connection of connector (CN116)  
(Loose connector or open cable)



#### Check Point 2 : Check Coil of EEV1

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	$46 \pm 4 \Omega$
Yellow - Red	
Orange - Red	
Blue - Red	

► If Resistance value is abnormal, replace EEV.

#### Check Point 3 : Check Voltage from Controller PCB

- Remove Connector and check Voltage (DC12V).  
 >> If it does not appear, replace Controller PCB.



#### Check Point 4 : Check Noise at start up


- Turn on Power and check operation noise.  
 >> If an abnormal noise does not show, replace Controller PCB.

#### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

##### CLOSE


Example : Liquid Refrigerant  
Pipe (In)



If it is open, it has no temp. difference between Inlet and Outlet.



##### OPEN

Example : Liquid Refrigerant  
Pipe (In)



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




## SERVICE PARTS INFORMATION 10

### Outdoor Unit Electronic Expansion Valve (EEV2)

#### Check Point 1 : Check Connections

- Check connection of connector (CN117)  
(Loose connector or open cable)



#### Check Point 2 : Check Coil of EEV2

- Remove connector, check each winding resistance of Coil.

Read wire	Resistance value (20°C)
White - Red	$46 \pm 4 \Omega$
Yellow - Red	
Orange - Red	
Blue - Red	

► If Resistance value is abnormal, replace EEV.

#### Check Point 3 : Check Voltage from Controller PCB

- Remove Connector and check Voltage (DC12V).  
-> If it does not appear, replace Controller PCB.



#### Check Point 4 : Check Noise at start up


- Turn on Power and check operation noise.  
-> If an abnormal noise does not show, replace Controller PCB.

#### Check Point 5 : Check Opening and Closing Operation of Valve

When Valve is closed,  
it has a temp. difference between Inlet and Outlet.

##### CLOSE


Example : Liquid  
Refrigerant  
Pipe (In)



If it is open, it has no temp. difference between Inlet and Outlet.



##### OPEN

Example : Liquid  
Refrigerant  
Pipe (In)



#### Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.



## SERVICE PARTS INFORMATION 11

### 3-Phase Diode Bridge

#### Check Point 1 : Appearance check


- ☐ No fissures, breaks, damage, etc. at body and terminal section?
- ☐ Is the rear of the body coated with silicone grease?
- ☐ Are there no abnormalities at threaded parts (stripped threads, deformation, damage, etc.) ?

#### Check Point 2 : Electric check



- ① In the 3-phase diode bridge single part state, set the tester to the "Resistance" mode, and check for open/short between the following terminals.


Tester + side (red)	Tester - side (black)
Pin 1	Pin 4
Pin 2	
Pin 3	
Pin 5	Pin 1
	Pin 2
	Pin 3



Diode bridge

- ② Judge the result of ① as follows:

All 6 points shorted	: Normal
1 or more points open	: Defective



- ③ Set the tester to the "Resistance" mode, and check for open/short between the following terminals.

Tester + side (red)	Tester - side (black)
Pin 4	Pin 1
	Pin 2
	Pin 3
Pin 1	Pin 5
Pin 2	
Pin 3	

- ④ Judge the result of ③ as follows:


All 6 points open	: Normal
1 or more points shorted	: Defective

## SERVICE PARTS INFORMATION 12

### 4-WAY VALVE

#### Check Point 1 : Check Circuit connection

- Check the connection of connector CN 105




#### Check Point 2 : Check Solenoid Coil

- Remove CN6 from PCB and check the resistance value of coil




- ☆ If it is Open or abnormal resistance value, replace Solenoid Coil



#### Check Point 3: Check Operation of 4 Way Valve

- Check each piping temperature, and confirm the location of the valve by the temperature difference.



- ☆ If the valve location is not proper, replace 4 way valve.

#### Check Point 4: Check Voltage from Controller PCB

- Remove connector and check the voltage (Rated AC voltage).  
>> If the voltage does not appear, replace Controller PCB.


SERVICE PARTS INFORMATION 13

Indoor Unit AC Fan Motor



Check Point : ARXC45GATH (High Static Pressure Duct Type)

- Check each winding resistance of the motor
- ▶ If Resistance value is abnormal, replace motor.



Lead wire	Resistance value
White – Red	6.84 Ω ± 7%
Red – Black	9.78 Ω ± 7%
Red – Violet	6.10 Ω ± 7%
Violet – Blue	6.10 Ω ± 7%

(20°C)



## **SERVICE PARTS INFORMATION 14-1**

### **Indoor Unit Fan Motor <DC motor>**

⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.

#### **Check Point 1 : Check rotation of Fan**

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

#### **Check Point 2 : Check resistance of Indoor Fan Motor**

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)

**>>If they are short-circuited (below 300 k $\Omega$ ), replace Indoor fan motor and Controller PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Brown or Blue)	Feed back (FG)
2 (Yellow)	Speed command (Vsp)
3 (White)	Control voltage (Vcc)
4 (Black)	Earth terminal (GND)
5	No function
6 (Red)	DC voltage (Vm)



### SERVICE PARTS INFORMATION 14-2

Indoor Unit Fan Motor <DC motor>  
(Lower fan motor of Compact Floor model)

⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.

#### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

#### Check Point 2 : Check resistance of Indoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 kΩ), replace Indoor fan motor and Controller PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Blue)	Feed back (FG)
2 (Yellow)	Speed command (Vsp)
3 (White)	Control voltage (Vcc)
4 (Black)	Earth terminal (GND)
5	No function
6	No function
7 (Red)	DC voltage (Vm)



### SERVICE PARTS INFORMATION 14-3

Indoor Unit Fan Motor <DC motor>  
(For AS\*A030/ 034GTAH, AUXK018 - 054GLAH)

⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.


#### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

#### Check Point 2 : Check resistance of Indoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 kΩ), replace Indoor fan motor and Controller PCB.**

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Earth terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown or Blue)	Feed back (FG)



## SERVICE PARTS INFORMATION 15



### Discharge Pressure Sensor Suction Pressure Sensor

#### 1. Discharge Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN118:2-3 of the Main PCB.

- Characteristics of pressure sensor



psi	0.0	14.5	29.0	43.5	58.0	72.5	101.5	116.0	130.5	145.0	174.0	203.0	232.0	261.0	290.0
MPa	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.20	1.40	1.60	1.80	2.00
Output (V)	0.50	0.58	0.66	0.74	0.82	0.90	1.06	1.14	1.22	1.30	1.46	1.62	1.78	1.94	2.10



psi	319.0	348.0	377.0	406.0	435.0	464.0	493.0	522.0	551.0	580.0	609.0	638.0	667.0	696.0	725.0
MPa	2.20	2.40	2.60	2.80	3.00	3.20	3.40	3.60	3.80	4.00	4.20	4.40	4.60	4.80	5.00
Output (V)	2.26	2.42	2.58	2.74	2.90	3.06	3.22	3.38	3.54	3.70	3.86	4.02	4.18	4.34	4.50

#### 2. Suction Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN119:2-3 of the Main PCB.

- Characteristics of pressure sensor




psi	0.0	14.5	29.0	43.5	58.0	72.5	101.5	116.0	130.5	145.0	159.5	174.0	188.5	203.0	217.5
MPa	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.10	1.20	1.30	1.40	1.50
Output (V)	0.50	0.68	0.85	1.03	1.21	1.38	1.74	1.91	2.09	2.27	2.44	2.62	2.79	2.97	3.15

psi	232.0	246.5
Mpa	1.60	1.70
Output (V)	3.32	3.50

## SERVICE PARTS INFORMATION 16

### Pressure Switch

#### ▪ Type of contact



#### ▪ Characteristics of pressure switch

Contact : Short ⇒ Open	4.2 ~ 4.05MPa
Contact : Open ⇒ Short	3.2±0.15MPa


## SERVICE PARTS INFORMATION 17

### Thermistor

#### Check Point : Check Thermistor resistance value

▣ Remove connector and check Thermistor resistance value.

Temperature [°F]	Temperature [°C]	Resistance Value [ kΩ ] / Voltage Value [V]		
		Thermistor A	Thermistor B	Thermistor C
- 4	- 20	--- / ---	--- / ---	105.4 / 1.33
14	- 10	--- / ---	27.8 / 1.67	58.2 / 1.98
23	- 5	--- / ---	21.0 / 2.00	44.0 / 2.33
32	0	168.6 / 0.19	16.1 / 2.33	33.6 / 2.66
41	5	129.8 / 0.24	12.4 / 2.65	25.9 / 2.98
50	10	100.9 / 0.31	9.6 / 2.96	20.2 / 3.27
59	15	79.1 / 0.39	7.6 / 3.25	15.8 / 3.54
68	20	62.5 / 0.48	6.0 / 3.50	12.5 / 3.77
77	25	49.8 / 0.59	4.8 / 3.73	10.0 / 3.96
86	30	40.0 / 0.71	3.8 / 3.92	8.0 / 4.13
104	40	26.3 / 1.01	2.5 / 4.23	5.3 / 4.39
122	50	17.8 / 1.36	1.7 / 4.45	3.6 / 4.57
140	60	12.3 / 1.75	1.2 / 4.61	--- / ---
158	70	8.7 / 2.17	--- / ---	--- / ---
176	80	6.3 / 2.57	--- / ---	--- / ---
194	90	4.6 / 2.96	--- / ---	--- / ---
212	100	3.4 / 3.30	--- / ---	--- / ---
230	110	2.6 / 3.60	--- / ---	--- / ---
248	120	2.0 / 3.85	--- / ---	--- / ---
Applicable Thermistors		Discharge temp. TH : [TH1] Comp temp. TH : [TH10]	Heat exchanger. TH : [TH5] Suction temp. TH : [TH4] Sub-cool heat exchanger (inlet) TH : [TH8] Sub-cool heat exchanger (outlet) TH : [TH9] Liquid temp. TH : [TH7]	Outdoor temp. TH : [TH3]



## **SERVICE PARTS INFORMATION 18**

### **Outdoor Unit Fan Motor**

⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.


#### Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.  
(Check if fan is caught, dropped off or locked motor)  
**>>If Fan or Bearing is abnormal, replace it.**

#### Check Point 2 : Check resistance of Outdoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.  
(Vm: DC voltage, GND: Earth terminal)  
**>>If they are short-circuited (below 300 k $\Omega$ ), replace Outdoor fan motor.**

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Earth terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown)	Feed back (FG)



## SERVICE INFORMATION


### Network communication Abnormal

#### - Basic trouble shooting procedure -

1. Check Error code in one network segment separately, and check the Error code of (Outdoor unit, Indoor unit, Remotecontroller Service tool)  
< If the system has more than 2 Network segments, disconnect the other Network segment.>
2. Connect Service tool to the Outdoor unit, and try out **"Address checker"** Function by the Service tool.  
< Check missing indoor unit or outdoor unit by using Address checker function of Service tool>
3. Check terminal resistance value  $53\ \Omega \pm 5\%$  + Line Resistance on the terminal board one by one.  
< Terminal Resistance is located on the Outdoor unit PCB(activated SET 5-4 ON) >  
\*Refer to the wiring diagram of Network cable

#### Example

Terminal Resistance ① is located on the controller PCB of Outdoor unit as the Network for Indoor unit.




## Air Conditioning Unregistration Method

If you replace the Wireless LAN adapter, it needs the unregister of air conditioner information on the App.  
Unregister method is as follows.


- 1 Launch the mobile app(FGL air).




- 2 Please long-push the registered "Dvice name" of Air Conditioner.



- 3 Then will display the "Unregister" button. Please tap the "Unregister" button.



- 4 Please tap the "Yes" .



- 5 Air Conditiner Unregister is complete.

## Air conditioner registration Pairing Method

Choose from the following modes to connect your Air conditioner to your Wireless LAN router.

### Note:

- Before starting this setting, wait for **60 seconds** or more after the power supply is connected to the air conditioner (via breaker or plug).
- If both LED 1 and 2 are off, the WLAN adapter may be in Sleep mode. Be sure it is deactivated before setting up the wireless LAN. (Refer to "SETTING MANUAL")
- Check that the smartphone or tablet PC is linked to the wireless router you are connecting the air conditioner. The setting will not work if it is not connected to the same wireless router.
- The display screen design may differ depending on the version of the mobile app.
- To control 2 or more air conditioners with the same smartphone or tablet PC, repeat the setup of the chosen mode.


### Button Mode

\*Lighting pattern: ○ OFF ● ON ☼ Flashing

1 Launch the mobile app(FGL air).




2 Sign in with your Email address and password (as registered in "4.2. User registration") following the screen on the mobile app.



3 Press the [+] button to add a new air conditioner.



4 Confirm that LED 2 is flashing.(On/off at 2-second intervals.) Then select [Button mode] on the screen.  
If LED 1 and 2 are off, push the Setting button once.  
(Refer to "5. SLEEP MODE" SETTING MANUAL)



5 Press the WPS button on the wireless router that you are connecting to.


Refer to the operating manual of the wireless router for the location of the button and how to press it.




6 Confirm that LED 2 is flashing.  
(On/off at 2-second intervals.)  
Then press and hold the Setting button on the WLAN adapter for 3 seconds.

LED 2 lighting will change.  
(on/off: 2sec/2sec → 2sec/0.5sec)

Confirm that the LED 1 and 2 are both on to proceed.



7 Press [Register] to start the connection with the wireless router.



LED 1 and 2 will both flash 2 times, and a message will appear when setup is complete.


### Manual mode

\*Lighting pattern: ○ OFF ● ON ☼ Flashing

1~3 See steps 1 to 3 in "4.3.1. Button mode"


4 Select [Manual mode].

If LED 1 and 2 are off, push the Setting button once. (Refer to "5. SLEEP MODE" SETTING MANUAL)




### [For Android]

5 Select the SSID of the air conditioner you are connecting to.




6 Input the PIN code written on the WLAN label.

7 Select the SSID of the wireless router you are connecting to.  
Input the wireless router (WLAN access point) password then press [Connect device].




8 LED 1 and 2 will both flash 2 times, and a message will appear when setup is complete.




### [For iOS]


5 Select [Open W-LAN setting] or activate the wireless LAN by pressing the Home button -> [Setting] -> [Wi-fi].  
Select the SSID of the air conditioner you are connecting to.




6 Input the PIN code written on the WLAN label.



7 Select the SSID of the wireless router you are connecting to.  
Input the wireless router (WLAN Access Point) password then press [Connect device].



LED 1 and 2 will both flash 2 times, and a message will appear when setup is complete.






# **AIRSTAGE™ J-III L**

*Variable Refrigerant Flow System*

## **5. APPENDING DATA**

## 5-1 REFRIGERANT CIRCUIT

MODELS : AJ \* 072LELAH, AJ \* 090LELAH, AJ \* 108LELAH



## SYMBOL DESCRIPTION

### ● Outdoor unit

MARK	DESCRIPTION	
CMP	Compressor (Inverter type)	
HEX	Heat exchanger	
FAN 1	Fan 1	
FAN 2	Fan 2	
ACM	Accumulator	
OS	Oil separator	
SCHEX	Sub-cool heat exchanger	
HPS	High pressure sensor	
LPS	Low pressure sensor	
HPSW	High pressure sensor switch	
4WV	4-way valve	
EEV 1	Electric expansion valve 1	
EEV 2	Electric expansion valve 2	
SV 2	Solenoid valve	Marking (Tube)
TH 1	Discharge temperature thermistor	Blue
TH 3	Outdoor temperature thermistor	—
TH 4	Suction temperature thermistor	Red
TH 5	Heat exchanger (outlet) thermistor	Pink
TH 7	Liquid temperature thermistor	Green
TH 8	Sub-cool heat exchanger (inlet) thermistor	White
TH 9	Sub-cool heat exchanger (outlet) thermistor	Brown
TH 10	Compressor temperature thermistor	—

### ● Indoor unit


MARK	DESCRIPTION
HEX21	Heat exchanger
FAN21	Fan
EEV21	Electric expansion valve
TH21	Room temperature thermistor
TH22	Heat exchanger (inlet) thermistor
TH24	Heat exchanger (outlet) thermistor

## 5-2 WIRING DIAGRAM

### 5-2-1 Indoor Unit

#### COMPACT CASSETTE TYPE

MODELS : AUXB04GALH, AUXB07GA\* H, AUXB09GA\* H, AUXB12GA\* H, AUXB14GA\* H, AUXB18GA\* H, AUXB24GA\* H




**MODELS : AUXD18GA\* H, AUXD24GA\* H, AUXA18GALH, AUXA24GALH,  
AUXA30GA\* H, AUXA36GA\* H, AUXA45GA\* H, AUXA54GA\* H**



# CASSETTE TYPE

MODELS : AUXK018/ 024/ 030/ 034/ 036/ 045/ 054GLAH  
AUXM018/ 024/ 030GLAH




**MODELS : AUXB04GBLH,  
AUXB04/ 07/ 09/ 12/ 14/ 18/ 24GALH  
AUXB07/ 09/ 12/ 14/ 18/ 24GATH**



# LOW STATIC PRESSURE DUCT/ CONCEALED FLOOR TYPE


MODEL : ARXB07GALH, ARXB09GALH, ARXB12GALH  
ARXB14GALH, ARXB18GALH






# SLIM DUCT / SLIM CONCEALED FLOOR TYPE

MODELS : ARXD04GALH, ARXD07GA\* H, ARXD09GA\* H, ARXD12GA\* H, ARXD14GA\* H, ARXD18GA\* H, ARXD24GA\* H




# LOW STATIC PRESSURE DUCT TYPE

## MODEL : ARXB24GALH, ARXB30GALH, ARXB36GALH




## MODEL : ARXB45GALH




# MEDIUM STATIC PRESSURE DUCT TYPE

## MODELS : ARXA24GALH, ARXA30GALH, ARXA36GALH, ARXA45GALH




## MODELS : ARXA24GB\* H, ARXA30GB\* H, ARXA36GB\* H, ARXA45GB\* H




**MODELS : ARXC36GATH, ARXC45GATH, ARXC60GATH,**



**MODEL : ARXC36GBTH**




**MODELS : ARXC72GBTH, ARXC90GBTH**



# COMPACT SLIM DUCT TYPE


MODELS : ARXK04/ 07/ 09/ 12/ 14/ 18/ 24GCLH






# FLOOR / CEILING TYPE

**MODELS : AB\* A12GATH, AB\* A14GATH, AB\* A18GATH,  
AB\* A24GATH**



# CEILING TYPE


**MODELS : AB\* A30GATH, AB\* A36GATH, AB\* A45GATH,  
AB\* A54GATH**






# WALL MOUNTED TYPE (EEV external model)

MODELS : AS\* E04GACH, AS\* E07GACH, AS\* E09GACH,  
AS\* E12GACH, AS\* E14GACH




## WALL MOUNTED TYPE

MODELS : AS\* A04GACH, AS\* A07GA\* H, AS\* A09GA\* H,  
AS\* A12GA\* H, AS\* A14GA\* H




# **MODELS : AS\* A18GA\* H, AS\* A24GA\* H, AS\* A30GA\* H**




# COMPACT WALL MOUNTED TYPE (EEV internal)

**MODELS : ASYA004/ 007/ 009GTAH**  
**ASHA004/ 007/ 009GTAH**




# COMPACT WALL MOUNTED TYPE (EEV external)

**MODELS : ASYE004/ 007/ 009GTAH**  
**ASHE004/ 007/ 009GTAH**




## WALL MOUNTED TYPE


**MODELS : ASYA18/ 24/ 30GACH, ASHA18/ 24/ 30GACH  
ASYA18/ 24/ 30GBCH, ASHA18/ 24/ 30GBCH**



**MODELS : ASYA030/ 034GTAH  
ASHA030/ 034GTAH**




**MODELS : AGYA004/ 007/ 009/ 012/ 014GCAH**  
**AGHA004/ 007/ 009/ 012/ 014GCAH**






**MODELS : AGYE004/ 007/ 009/ 012/ 014GCAH  
AGHE004/ 007/ 009/ 012/ 014GCAH**




# OUTDOOR AIR UNIT


## MODEL : ARXH054GTAH



## MODEL : ARXH072GTAH




**MODEL : ARXH096GTAH**



## 5-2-2 Outdoor Unit

MODELS: AJ\*072LELAH, AJ\*090LELAH

### WIRING DIAGRAM




TH1	BLUE
TH10	-
TH3	-
TH7	GREEN
TH9	WHITE
TH5	BROWN
TH4	RED
MARK	MARKING (TUBE)

9378955295

# MODEL: AJ\*108LELAH

## WIRING DIAGRAM




9378955288

## 5-2-3 DX-KIT

### 1. REFRIGERANT CIRCUIT

MODELS: UTP-VX30A, UTP-VX60A, UTP-VX90A




#### SYMBOL DESCRIPTION

MARK	DESCRIPTION
HEX	Heat exchanger (Locally purchased)
FAN	Fan (Locally purchased)
EEV	Electric expansion valve
TH21	Suction airflow temperature thermistor
TH22	Heat exchanger (inlet) thermistor
TH24	Heat exchanger (outlet) thermistor
TH25	Discharge airflow temperature thermistor

### 2. WIRING DIAGRAMS

MODEL: UTY-VDGX



### 3. TERMINAL BLOCK LAYOUT

3rd row

				1	2	1	2	1	2	1	2	1	2
Thermistor (GAS)		Thermistor (LIQUID)		ON/OFF Signal (OUT PUT)		Error SIGNAL (OUT PUT)		FAN SIGNAL		DEFROST SIGNAL		THERMOSTAT ON/OFF SIGNAL	

2nd row

				1	2	3	1	2	1	2	1	2	
Thermistor (INLET AIR)		Thermistor (OUTLET AIR)		ON/OFF Signal (IN PUT)			ERROR SIGNAL (IN PUT)		COOL/HEAT SIGNAL		ANALOG SIGNAL		

1st row

1	2	1	2	3	4	5	6	1	2	3	4	5	6
FLOAT SW SIGNAL		EEV1						EEV2					


1	2	L	N	E
DRAIN PUMP OUTPUT		POWER SUPPLY		

X1	X2	E	Y1	Y2	Y3
TRANSMISSION TO OUTDOOR UNIT			TO REMOTE-CONTROL		


## 5-3 CHARACTERISTICS OF SENSORS

### 5-3-1 Pressure sensor

#### 1. Discharge Pressure Sensor - Pressure Sensor (HIGH): CN118 -




With the connector connected to the PCB, measure the voltage between CN118 : 2-3 of the Main PCB.




Pressure (MPa)	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.20	1.40	1.60	1.80	2.00
Output (V)	0.50	0.58	0.66	0.74	0.82	0.90	1.06	1.14	1.22	1.30	1.46	1.62	1.78	1.94	2.10

Pressure (MPa)	2.20	2.40	2.60	2.80	3.00	3.20	3.40	3.60	3.80	4.00	4.20	4.40	4.60	4.80	5.00
Output (V)	2.26	2.42	2.58	2.74	2.90	3.06	3.22	3.38	3.54	3.70	3.86	4.02	4.18	4.34	4.50

#### 2. Suction Pressure Sensor - Pressure Sensor (Low): CN119 -



With the connector connected to the PCB, measure the voltage between CN119 : 2-3 of the Main PCB.



Pressure (MPa)	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.10	1.20	1.30	1.40	1.50	1.60	1.70
Output (V)	0.50	0.68	0.85	1.03	1.21	1.38	1.74	1.91	2.09	2.27	2.44	2.62	2.79	2.97	3.15	3.32	3.50



## 5-3-2 Thermistor resistance

Thermistor resistance value <Outdoor unit side>

Temperature [°C]	Resistance Value [kΩ]		
	Thermistor A	Thermistor B	Thermistor C
- 20	---	---	105.4
- 10	---	27.8	58.2
- 5	---	21.0	44.0
0	168.6	16.1	33.6
5	129.8	12.4	25.9
10	100.9	9.6	20.2
15	79.1	7.6	15.8
20	62.6	6.0	12.5
25	49.8	4.8	10.0
30	40.0	3.8	8.0
40	26.3	2.5	5.3
50	17.8	1.7	3.6
60	12.3	1.2	---
70	8.7	---	---
80	6.3	---	---
90	4.6	---	---
100	3.4	---	---
110	2.6	---	---
120	2.0	---	---
Applicable Thermistors	Discharge temp. TH1 Comp.1 temp. TH10	Heat exchanger. TH5 Suction temp. TH4 Sub-cool heat exchanger Gas (inlet) TH8 Sub-cool heat exchanger Gas (outlet) TH9 Sub-cool heat exchanger Liquid temp TH7	Outdoor temp. TH3

Thermistor resistance value <Indoor unit side>

Indoor Temperature Thermistor (TH21)

Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	33.6	25.2	20.1	15.8	12.5	10.0	8.0	6.5

Temperature (°C)	40	45	50
Resistance Value (kΩ)	5.3	4.3	3.5

Heat Exchanger Thermistor (Inlet TH22 / Outlet TH23)

Temperature (°C)	0	5	10	15	20	25	30	35
Resistance Value (kΩ)	168.6	129.8	100.9	79.1	62.5	49.8	40.0	32.4

Temperature (°C)	40	45	50
Resistance Value (kΩ)	26.3	21.2	17.8

### 5-3-3 Saturation temperature and saturation pressure tables (°C / Mpa)


(Pressure: Gauge pressure)

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
-30	0.1722	0.1717
-29	0.1836	0.1830
-28	0.1953	0.1947
-27	0.2074	0.2067
-26	0.2199	0.2192
-25	0.2328	0.2320
-24	0.2460	0.2452
-23	0.2597	0.2588
-22	0.2737	0.2728
-21	0.2882	0.2872
-20	0.3031	0.3021
-19	0.3185	0.3174
-18	0.3343	0.3331
-17	0.3505	0.3493
-16	0.3672	0.3659
-15	0.3844	0.3830
-14	0.4021	0.4006
-13	0.4202	0.4187
-12	0.4389	0.4373
-11	0.4580	0.4563
-10	0.4776	0.4759
- 9	0.4978	0.4960
- 8	0.5185	0.5166
- 7	0.5398	0.5377
- 6	0.5616	0.5594
- 5	0.5839	0.5817
- 4	0.6069	0.6045
- 3	0.6304	0.6279
- 2	0.6545	0.6519
- 1	0.6791	0.6765
0	0.7044	0.7017
1	0.7303	0.7274
2	0.7569	0.7539
3	0.7840	0.7809
4	0.8119	0.8086
5	0.8403	0.8369
6	0.8695	0.8659
7	0.9000	0.8956
8	0.930	0.926
9	0.961	0.957
10	0.993	0.989
11	1.026	1.022
12	1.059	1.055
13	1.093	1.089
14	1.128	1.123
15	1.164	1.159
16	1.200	1.195
17	1.237	1.232

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
18	1.275	1.270
19	1.314	1.308
20	1.353	1.348
21	1.394	1.388
22	1.435	1.429
23	1.477	1.471
24	1.520	1.513
25	1.563	1.557
26	1.608	1.601
27	1.654	1.647
28	1.700	1.693
29	1.747	1.740
30	1.796	1.788
31	1.845	1.837
32	1.895	1.887
33	1.946	1.938
34	1.998	1.990
35	2.051	2.043
36	2.105	2.097
37	2.160	2.152
38	2.216	2.208
39	2.273	2.265
40	2.332	2.323
41	2.391	2.382
42	2.451	2.442
43	2.513	2.503
44	2.575	2.565
45	2.639	2.629
46	2.703	2.693
47	2.769	2.759
48	2.836	2.826
49	2.904	2.894
50	2.974	2.963
51	3.044	3.034
52	3.116	3.106
53	3.189	3.178
54	3.263	3.253
55	3.338	3.328
56	3.415	3.405
57	3.493	3.483
58	3.572	3.562
59	3.653	3.643
60	3.735	3.725
61	3.818	3.808
62	3.902	3.893
63	3.988	3.979
64	4.075	4.066
65	4.164	4.155

Saturation pressure (Mpa)	Saturation temperature (°C)	
	Saturated liquid	Saturated gas
0.0	-51.85	-51.83
0.1	-37.25	-37.21
0.2	-27.61	-27.55
0.3	-20.21	-20.14
0.4	-14.12	-14.04
0.5	- 8.89	- 8.80
0.6	- 4.30	- 4.20
0.7	- 0.17	- 0.06
0.8	3.58	3.69
0.9	7.02	7.15
1.0	10.22	10.35
1.1	13.21	13.34
1.2	16.01	16.15
1.3	18.66	18.80
1.4	21.17	21.31
1.5	23.55	23.70
1.6	25.83	25.98
1.7	28.01	28.16
1.8	30.10	30.25
1.9	32.11	32.26
2.0	34.04	34.20
2.1	35.91	36.06
2.2	37.72	37.87
2.3	39.46	39.62
2.4	41.16	41.31
2.5	42.80	42.95
2.6	44.40	44.55
2.7	45.95	46.10
2.8	47.47	47.62
2.9	48.94	49.09
3.0	50.38	50.53
3.1	51.78	51.93
3.2	53.16	53.30
3.3	54.50	54.63
3.4	55.81	55.94
3.5	57.09	57.22
3.6	58.35	58.48
3.7	59.58	59.70
3.8	60.79	60.91
3.9	61.98	62.09
4.0	63.14	63.25
4.1	63.99	64.38

5-3-4 Temperature and pressure of refrigerant (Graph)



# **AIRSTAGE™ J-III L**

*Variable Refrigerant Flow System*

## **6. DISASSEMBLY PROCESS**

## 6. DISASSEMBLY PROCESS


### ⚠ WARNING

Before servicing the unit, turn the power supply switch OFF,  
Then, do not touch electric parts for 10 minutes due to the risk of electric shock.


### 1. Appearance




### 2. SERVICE PANEL removal



### 3. MAIN PCB removal




### 4. COMMUNICATION PCB removal







5. INVERTER PCB, FILTER PCB, DIODE BRIDGE and POWER PCB removal




Remove the 6 mounting screws.




Open the CONTROL BOX (MAIN).



5-1. FILTER PCB removal




Remove the connectors and Earth screws.  
Note the tightening torque  
at the installation.  
Tightening torque is  $2.5 \pm 0.2\text{N}\cdot\text{m}$ .  
(except for the earth screw)



Remove the spacers.  
(6 places)

## 5-2. INVERTER PCB removal



Remove the 4 mounting screws.

For screws of IPM.

Note the tightening torque at the installation.


- Temporary tightening : 0.2 to 0.4N·m
- Final tightening : 0.98 to 1.47N·m

For screws of Comp. Wire.

Note the tightening torque at the installation.

- Tightening torque is as follows.
- Final tightening : 1.4 to 1.6 N·m

Remove the connectors and spacers.



Spread the heat transfer compound on IPM when you exchange INVERTER PCB by the repair.


Note at the installation.

1. Remove the old heat transfer compound as possible from IPM and Diode Bridges when you exchange INVERTER PCB by the repair.
2. Spread the heat transfer compound evenly on IPM and Diode Bridges.
3. Prevent foreign matter from attaching to the surface of IPM and Diode Bridges.

Specifications for the heat transfer compound

- Manufacturer : Shin-Etsu Chemical Co.,Ltd
- Grade : G746

## 5-3. DIODE BRIDGE removal



Remove the wires.

Remove the screws.

For screws of D.B. .

Note the tightening torque at the installation.

- Tightening torque is as follows.
- Temporary tightening : 0.6 +0.1N·m
  - Final tightening : 2.4 +0.1N·m

Spread the heat transfer compound on D.B. when you exchange D.B. by the repair.

Note at the installation.


1. Remove the old heat transfer compound as possible from D.B. when you exchange ACTPM by the repair.
2. Spread the heat transfer compound evenly on D.B. .
3. Prevent foreign matter from attaching to the surface of D.B. .

Specifications for the heat transfer compound


- Manufacturer : Shin-Etsu Chemical Co.,Ltd
- Grade : G746




#### 5-4. POWER PCB removal





Remove the 2 mounting screws.



Remove the Wires.





Remove the 2 Hooks.



Remove the POWER PCB.

6. FAN DRIVER PCB and INVERTER CT PCB removal ( For AJY108LELAH )


6-1. FAN DRIVER PCB removal




Remove the 2 mounting screws and spacers. (5 places)

Note the tightening torque at the installation.  
Tightening torque is as follows.  
- Temporary tightening : 0.2 to 0.4 N•m  
- Final tightening : 0.98 to 1.47 N•m


6-2. INVERTER CT PCB removal




Remove the 3 mounting screws.



Remove the mounting screw.




Note the tightening torque at the installation.  
Tightening torque is as follows.  
- Final tightening : 1.4 to 1.6 N•m



Remove the 3 spacers and connector.

7. PRESSURE SENSOR, SOLENOID COIL removal



7-1. PRESSURE SENSOR removal



**CAUTION**  
Wear gloves to prevent the frostbite,  
because a small amount of refrigerant leaks during work.

Remove the PRESSURE SENSOR with wrench.  
Note the tightening torque at the installation.  
Tightening torque is  $15 \pm 1.5 \text{ N}\cdot\text{m}$ .

7-2. SOLENOID COIL (4way valve) removal




Remove the mounting screw  
with wrench or short screwdriver.



Remove the SOLENOID COIL.




## 8. EEV COIL removal




Remove the EEV coil by hand.  
Be careful so as not to bend the pipe.


## 9. THERMISTOR removal



Cut the binders.(2 places)




Remove the THERMISTOR SPRING.




Remove the THERMISTOR.  
Careful not to disconnect  
the thermistor wire with a strong pull.

## 10. FAN MOTOR removal




Remove the 5 mounting screws.  
Remove the FAN GUARD  
by sliding upward.



Remove the nut.  
And remove the PROPELLER FAN


Note at the installation.  
Insert propeller Fan and Moter shaft reference  
D cutting position.  
And the tightening torque at the installation.  
Tightening torque is from 10 to 12N·m.



Cut the binders.(2 places)



Loose the wire clamp, and  
remove the lead wires.




Remove the 4 mounting screws.




Remove the FAN MOTOR.  
Note at the installation.  
Motor wire is underside of Fan motor.

## 11. TOP PANEL removal




## 12. REACTOR removal






### 13. PIPE COVER FRONT removal



### 14. RIGHT PANEL removal



## 15. COMPRESSOR removal

### Precautions for exchange of Compressor.


Do not allow moisture or debris to get inside refrigerant pipes during work.

### Procedure for compressor removal.

- (1) Turn off power.
- (2) Remove the SERVICE PANEL and PIPE COVER FRONT.
- (3) Fully open the 3WAY VALVE(Gas) and 3WAY VALVE(Liquid).
- (4) Open the EEVs of Outdoor units and Indoor units by vaccuming mode.
- (5) Collect the refrigerant from the 3WAY VALVE.

Start the following work after completely collecting the refrigerant.

Do not reuse the refrigerant that has been collected.





Screws

Screws

VALVE PLATE

Screws







Remove the 6 mounting screws.


Remove the VALVE PLATE.

---




TERMINAL COVER






Remove the TERMINAL COVER.




COMPRESSOR WIRES



Remove the COMPRESSOR WIRES.


---



COMPRESSOR COVER TOP


COMPRESSOR COVER A

COMPRESSOR COVER B



Remove the COMPRESSOR COVERS.





Thermistor (Discharge)



Cut the binders. (2 place)



Remove the Thermistor clip and Thermistor(Discharge).

Thermistor (Comp.temp.)



Remove the Thermistor (Comp.temp.)

HEATER (CRANK CASE)



Remove the HEATER. (CRANK CASE)




Remove the COMP BOLTS. (4 places)

Discharge side



Heat up the brazed part of the discharge side and disconnect.

Suction side



Heat up the brazed part of the suction side and disconnect. Remove the COMPRESSOR.

**Caution**

- There is a possibility of catching fire to oil when removing by the welding.

**Procedure for compressor installation.**

Reverse procedure to removing the compressor.

**Precautions for installation of Compressor.**

- (1) When brazing, do not apply the flame to the terminal.
- (2) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

## 16. Precautions for exchange of refrigerant-cycle-parts

- (1) During exchange the following parts shall be protected by wet rag and not make the allowable temperature or more.
- (2) Remove the heat insulation when there is the heat insulation near the welding place.  
Move and cool it when its detaching is difficult.
- (3) Cool the parts when there are parts where heat might be transmitted besides the replacement part.
- (4) Interrupt the flame with the fire-retardant board when the flame seems to hit the following parts directly.
- (5) Do not allow moisture or debris to get inside refrigerant pipes during work.
- (6) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.
- (7) Open the 3WAY VALVE because there is a possibility of squirting the refrigerant from the heated pipes at brazing.

Part name	Allowable temperature	Precautions in work
SOLENOID VALVE	120°C	Remove the coil before brazing. And install the coil after brazing.
EXPANSION VALVE	120°C	Remove the coil before brazing. And install the coil after brazing.
4WAY VALVE	120°C	Remove the coil before brazing. And install the coil after brazing.
3WAY VALVE (GAS)	100°C	
3WAY VALVE (LIQUID)		
UNION JOINT	100°C	Remove the pressure sensor before brazing. And install the pressure sensor after brazing.
PRESSURE SENSOR	100°C	Tighten the flare part gripping it. (Tightening torque :15±1.5N m) Do the static electricity measures.
PRESSURE SWITCH	100°C	Remove the wiring before brazing. And connect the wire after brazing.

# AIRSTAGE™ J-III L



## FUJITSU GENERAL LIMITED

3-3-17, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan

URL : <http://www.fujitsu-general.com>

"**AIRSTAGE™**" is a worldwide trademark of FUJITSU GENERAL LIMITED.

\* Microsoft®, Internet Explorer®, and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

\* Adobe® and Acrobat Reader® are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

\* Intel® is a trademark of Intel Corporation in the U.S. and/or other countries.

\* Echelon®, LonWorks®, and the Echelon logo are trademarks of Echelon Corporation registered in the United States and other countries.

\* BACnet® is a registered trademark of the American Society of Heating Refrigeration and Air Conditioning Engineers (ASHRAE).

Other company and product names mentioned herein may be registered trademarks, trademarks or trade names of their respective owners.

Copyright© 2017 FUJITSU GENERAL LIMITED. All rights reserved.

Product specifications are subject to change without notice.

Printed in Japan

2017.04.01