

SERVICE MANUAL

AIRSTAGE™ V-III

Variable Refrigerant Flow System

Multi Air Conditioning System for Buildings

Large Capacity Multi VRF System

DC Inverter Control Compressor

Long Piping System Design

High Efficiency Refrigerant R410A



FUJITSU GENERAL LIMITED

CONTENTS

1. TEST RUN

1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS	01-01
1-2 CHECK ITEMS BEFORE POWER ON	01-03
1-2-1 Power source Inspection.....	01-03
1-2-2 Outdoor unit field setting inspection.....	01-04
1-2-3 Indoor unit field setting inspection.....	01-04
1-2-4 Transmission wire installation inspection.....	01-05
1-2-5 Piping installation inspection.....	01-07
1-2-6 Refrigerant charge amount inspection.....	01-08
1-2-7 3-way valve opening inspection.....	01-08
1-3 CHECK ITEMS AFTER POWER ON	01-09
1-3-1 Power source check.....	01-09
1-3-2 Error indication check.....	01-09
1-3-3 Installed unit and their addresses check.....	01-10
1-3-4 Transmission line connection check.....	01-11
1-3-5 Operation check sheet.....	01-12
1-4 TEST RUN OPERATION	01-13
1-4-1 Test Run From Outdoor unit PC Board.....	01-13
1-4-2 Test Run From Remote Controller.....	01-14
1-5 TEST RUN CONTROL	01-17
1-6 FIELD SETTING / FUNCTION SETTING FOR OUTDOOR UNIT	01-18
1-7 FIELD SETTING / FUNCTION SETTING FOR INDOOR UNIT	01-21
1-8 FIELD SETTING / FUNCTION SETTING FOR OUTDOOR AIR UNIT	01-22

2. OUTDOOR UNIT OPERATION CONTROL

2-1 REFRIGERANT CIRCUIT	02-01
2-2 INPUT / OUTPUT LIST	02-03
2-3 COMPRESSOR OPERATION	02-04
2-3-1 Operation / Stop Condition.....	02-04
2-3-2 Compressor speed control.....	02-05
2-3-3 Capacity control.....	02-06
2-3-4 Compressor Sequence Operation.....	02-07
2-4 FAN CONTROL	02-08
2-4-1 Cooling operation.....	02-08
2-4-2 Heating operation.....	02-09
2-5 EXPANSION VALVE CONTROL	02-10
2-6 SPECIAL OPERATION	02-11
2-6-1 Oil Recovery Operation.....	02-11
2-6-2 Pre-Heat Operation.....	02-11
2-6-3 Defrost Operation Control.....	02-12
2-6-4 Low noise mode.....	02-14
2-6-5 Snow Falling Protection Fan Mode -Default Setting -.....	02-15

CONTENTS

2-7 PROTECTIVE FUNCTION	02-16
2-7-1 Discharge temperature protection	02-16
2-7-2 High pressure protection	02-18
2-7-3 Low pressure protection	02-20
2-7-4 Heatsink temperature protection	02-21
2-7-5 Compressor temperature protection	02-21
2-7-6 O.U Heat - Ex.1(2) Gas Temp. abnormal stop	02-21
2-7-7 Over current protection	02-22
2-7-8 Compressor Frequency Maximum setting protection	02-22
2-7-9 Compressor compress ratio protection	02-22
2-7-10 Fan Motor, Motor Driver abnormal stop protection	02-23
2-7-11 EEV Coil abnormal Stop	02-23

3. INDOOR UNIT AND RB UNIT OPERATION

3-1 FAN CONTROL	03-01
3-1-1 Fan Speed Setting	03-01
3-1-2 "AUTO" Position	03-01
3-2 MASTER CONTROL	03-02
3-2-1 Operation Mode Control	03-02
3-2-2 Operation Mode Control for Outdoor air unit	03-04
3-2-3 Auto Changeover	03-06
3-2-4 Auto Changeover Heating / Cooling Operation for Outdoor air unit	03-07
3-2-5 "COOL" Position	03-08
3-2-6 "HEAT" Position	03-08
3-2-7 "COOL" Position for Outdoor air unit	03-09
3-2-8 "HEAT" Position for Outdoor air unit	03-09
3-3 LOUVER CONTROL	03-10
3-4 ELECTRONIC EXPANSION VALVE CONTROL	03-13
3-5 DRAIN PUMP OPERATION	03-15
3-6 FUNCTION	03-16
3-6-1 Auto Restart	03-16
3-6-2 Icing Protection Control	03-16
3-6-3 Oil Recovery Operation	03-16
3-6-4 Outdoor temperature protected operation for Outdoor air unit	03-17
3-7 DX KIT	03-18
3-7-1 System Configuration	03-18
3-7-2 Fundamental Functions	03-19
3-7-3 Fundamental Functions	03-20
3-7-4 Electronic Expansion Valve Control for DX-KIT	03-21
3-7-5 Drain Pump Operation for DX-KIT	03-21
3-7-6 Functions	03-22

CONTENTS

4. TROUBLE SHOOTING

4-1 NORMAL OPERATION	04-01
4-1-1 Indoor Unit Display.....	04-01
4-1-2 Outdoor Unit Display.....	04-02
4-2 ABNORMAL OPERATION	04-03
4-2-1 Error code Display.....	04-03
4-2-2 Indoor Unit Display.....	04-04
4-2-3 Outdoor Unit Display.....	04-04
4-2-4 Remote Controller Display.....	04-05
4-2-5 Trouble shooting index - Error code List -	04-06
4-2-6 Trouble shooting index - No Error code -	04-07
4-2-7 Trouble level of system.....	04-08
4-2-8 Error History mode.....	04-09
4-2-9 Trouble shooting with Error code.....	04-10
4-2-10 Trouble shooting No Error code.....	04-82
4-3 SERVICE INFORMATION -Network communication abnormal -	04-100
4-4 SERVICE INFORMATION	04-101
4-4-1 Back up operation	04-101
4-2-2 Work procedure after the backup operation.....	04-103
4-5 SERVICE PARTS INFORMATION	04-105

5. APPENDING DATA

5-1 REFRIGERANT CIRCUIT	05-01
5-2 WIRING DIAGRAM	05-03
5-2-1 Indoor Unit.....	05-03
5-2-2 Outdoor Unit.....	05-18
5-3 SATURATION TABLE (R410A)	05-20
5-3-1 Saturation temperature and saturation pressure tables (R410A).....	05-20
5-3-2 Temperature and pressure of refrigerant (Graph).....	05-21

6. DISASSEMBLY PROCESS

AIRSTAGE™ V-III

Variable Refrigerant Flow System

1. TEST RUN

1. TEST RUN

1-1 EXECUTION PROCEDURE AND EXECUTION PRECAUTIONS

Before execution

Execution zone decision	Execution procedure and precautions	Reason
Confirmation of refrigerant used	① Check the characteristics of the refrigerant used and grasp the special features of the refrigerant. If refrigerant must be charged, always charge the refrigerant specified for the product. R410A 4.2 MPa	• Use of a refrigerant other than the specified refrigerant will invite equipment trouble.
Preparation of execution drawings	② Confirm the product design pressure.	
Confirmation of installation site	① Use new refrigerant piping of the thickness specified by the D&T manual.	• Secure the necessary pressure resistance.
Preparations before execution	② Since R410A dedicated tools are necessary, prepare them in advance. ③ Absolutely avoid use of existing piping. If use of existing piping is unavoidable, the piping must be cleaned.	

Execution

Sleeve and insert work	Always use a level and keep the indoor unit level. If the equipment is tilted toward the drain port, install it so that the tilt is within 10mm. Excessive tilt will cause water leakage.	• Prevention of water leakage
Indoor unit installation	When performing piping work, observe the following items so that the inside of the piping is clean and air tight.	• Foreign matter, water, etc. in the piping will cause faulty cooling and compressor trouble.
Refrigerant piping work	① Use pipe that is not dirty inside. ② When the pipe is left standing, protect it. ③ Finish flaring exactly.	• Refrigerant leakage will cause low performance and abnormal stopping.
Drain piping work	④ Confirm the width across flats dimension and shape of flare nuts. ⑤ Always blow nitrogen while brazing. ⑥ Perform flushing before connecting the equipment.	
Duct work	① Always make the downward slope of the drain pipe 1/100 or greater and make the horizontal length within 20m.	• Prevention of water leakage
Heat insulation work	② Use hard polyvinylchloride pipe as the drain pipe. ③ Support the drain pipe between 1.5 to 2.0m. ④ Use pipe of 1 rank up (VP30 or greater) as central piping.	
Electrical work	Select the size of the heat insulating material according to the ambient temperature and relative humidity of the refrigerant. Use a heat insulating material having a heat conductivity of 0.043W/(m·k) or less.	• Prevention of water leakage
Foundation work for products		
Products installation work <small>*Refer to warning or caution in the attached installation manual of each products</small>	When making flare connections always use a torque wrench and tighten the flare nut positively to the specified torque.	• Refrigerant leakage will cause low performance and abnormal stopping.
Refrigerant piping connection work	Pressurize the product with nitrogen gas up to the design pressure and conduct a 24Hr air tightness test.	• Refrigerant leakage will cause low performance and abnormal stopping.
Air tightness test	① Install a vacuum pump with reverse flow check mechanism or a reverse flow check adaptor to a conventional vacuum pump and use. ② Pump down sufficiently. Approximately 1 hour or longer after -0.10MPa reached. Allow to stand for approximately 1 hour after stopping the vacuum pump and confirm that the needle does not return.	• Mixing in of vacuum pump oil by reverse flow will cause equipment trouble. • Prevents degradation of the oil by completely removing water and air.
Vacuum drying	③ Air purging using refrigerant is strictly prohibited.	*recommend the vacuuming mode


* Vacuuming mode

This function is used for vacuuming the indoor unit and the connection piping.
Note: For starting Vacuuming mode, the refrigerant address setting has to be finished.

When the [vacuuming mode] is set, <Push switch setting, F3:21> EEV of connected all indoor units opens.
So, the vacuuming indoor unit and piping becomes easier.


When the vacuuming ends, please turn off the power supply for all of the indoor units, and outdoor unit, [vacuuming mode] is released.

Execution




1-2 Check Items Before Power ON

1-2-1 Power source Inspection sheet



Check Item	Check contents	Judgement	Present Status	
Ref. circuit name: _____				
Power Source	Outdoor Unit	Power supply	3 ϕ / 4W / (342 - 456V) / 50Hz <input type="checkbox"/> Yes / <input type="checkbox"/> No	
		Circuit Breaker Size (A)	• For AJ* 072L : 20A • For AJ* 090/ 108L : 25A • For AJ* 126/ 144/ 162L : 40A	Master (AJ* ____L) : ____ (A) Slave-1(AJ* ____L) : ____ (A) Slave-2(AJ* ____L) : ____ (A)
			Leakage current : 100mA, 0.1 sec or less	<input type="checkbox"/> Yes / <input type="checkbox"/> No
		Power Line Wire Size (mm ²)	Check the breaker capacity vs. wire size 20A=4mm ² , 25A=6mm ² , 40A=10mm ² , 60A=16mm ² , 80A=22mm ² , 100A=38mm ² * Japanese Standard	Master : ____ (mm ²) Slave-1: ____ (mm ²) Slave-2: ____ (mm ²)
		Power line Wiring Note: One Outdoor Unit must have one individual Circuit Breaker	Example : 	<input type="checkbox"/> Complied <input type="checkbox"/> Not complied

* Note: Regulation of wire size and circuit breaker differs from each locality, please refers in accordance with local rule

Check Item	Check contents	Judgement	Present Status	
Ref. circuit name: _____				
Power Source	Indoor Unit	Power supply	1 ϕ / (198 - 264V) / 50Hz <input type="checkbox"/> Yes / <input type="checkbox"/> No	
		Circuit Breaker Size (A) (Check, Leakage current vs. number of IUs)	• 20A breaker for one circuit • Leakage current as follows: No. of units vs. leakage current: • 30mA for 12 nos. (IUs) • 100mA for 40 nos. (IUs) • 200mA for 81 nos. (IUs) • 300mA for 122 nos. (IUs) Note: MCA for total connected units (IU) less than 15A for 20A breaker capacity MCA means, minimum circuit ampere	Circuit number -1 Breaker capacity: ____ (A) Nos. of Connected units: ____ (IU) Circuit number -2 Breaker capacity: ____ (A) Nos. of connected units: ____ (IU) Circuit number -3 Breaker capacity: ____ (A) Nos. of Connected units: ____ (IU)
		Power line wire size (mm ²)	Wire size 2.5mm ² (for 20A breaker)	____ (mm ²)
		Power line wiring	Example for one circuit 	<input type="checkbox"/> Complied <input type="checkbox"/> Not complied

* Note: Regulation of wire size and circuit breaker differs from each locality, please refers in accordance with local rule

1-2-2 Outdoor unit field setting inspection sheet

Check Item		Check contents	Judgement	Present Status	
No. of outdoor unit for one ref. circuit: _____, Ref. circuit name: _____					
Outdoor Unit	Outlook	Appearance	Shall be no deformation	<input type="checkbox"/> OK / <input type="checkbox"/> NG	
		Serial No.	Master: _____ Slave -1: _____ Slave -2: _____		
		Power source & transmission wiring	Connection points & loose screws check	<input type="checkbox"/> OK / <input type="checkbox"/> NG	
		Connection piping	Is it insulated properly without gap?	<input type="checkbox"/> OK / <input type="checkbox"/> NG	
		Outdoor air temperature	Checked & entered the value _____	(°C)	
	Setting	• DIP-SW setting  SET-3 SET-5  REF-AD x 10 x 1 • RotarySW setting	OU Address (SET 31 & SET 3 -2) Note: setting for Master & Slave units (Default : OFF - OFF)	Master (OFF - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
			No. of Slave Unit (SET 3-3 & SET 3-4) Note: setting for Master unit only (Default : OFF - OFF)	Slave1 (OFF - ON)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				Slave2 (ON - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				NO Slave (OFF - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
			No. of OU (SET 5 -1 & SET 5-2) Note: setting for Master & Slave units (Default : OFF - OFF)	1 x Slave (OFF - ON)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				2 x Slave (ON - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				1 x OU (OFF - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
			Terminal Register (SET 5 -4) Note : setting for Master units	2 x OU (OFF - ON)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				3 x OU (ON - OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
				OFF or ON (Default : OFF)	<input type="checkbox"/> Y / <input type="checkbox"/> N
Ref. Add. (among Master & Slave units)	Ref ADx10 & Ref ADx1	<input type="checkbox"/> Y / <input type="checkbox"/> N			

1-2-3 Indoor unit field setting inspection sheet

Check contents														
Ref. circuit name: _____, Ref. address: ____ (00 ~ 99)														
Model Name & Serial No.	Outlook				Function setting by DIP-SW (Off / On)					Add. Setting (by Rotary-SW)				
	Access hole for maintenance (For Duct type & Cassette type units)	RC wiring connection points: (loose / deform)	Refrigerant pipes insulation	Drain pipes installation	Wired RC setting (DIP SW 1-1) 1 wire / 2 wire (default: 2 wire)	External Input (edge/pulse) SET 2-2 (default: OFF)	Wireless RC custom code SW 1-1 SET 3-1 (default: OFF)	Wireless RC custom code SW 2-2 SET 3-2 (default: OFF)	Drain Pump SW (for Slim duct) SET 4-1 (default: OFF)	Ref. Add. (REF AD x 0)	Ref. Add. (REF AD x 1)	Ref. Add. (REF AD x 2)	Ref. Add. (REF AD x 3)	Ref. Add. (REF AD x 4)
	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N					
	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N					
	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N					
	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N	<input type="checkbox"/> Y / <input type="checkbox"/> N					

1-2-4 Transmission wire installation inspection sheet 1/3

Check Item	Check contents	Judgement	Present Status	
Number of ref. circuit connected in the network system: _____, Ref. addresses: _____(00 - 99)				
VRF Network System	Transmission wire	Outlook	Is it LonWorks compatible? <input type="checkbox"/> Yes / <input type="checkbox"/> No	
			Maker name?	
		Wire specification	0.33mm ² , shield wire	(mm ²)
	Transmission line connection points	Between Master OUs	Must be properly connected (Between Master OUs) Master OUs 【Terminal: Z1 & Z2】	<input type="checkbox"/> Yes / <input type="checkbox"/> No
		Between Master OU & Slave OU or In between Slave OUs	Must be properly connected (Between Master OU and Slave OU / Slave OU and Slave OU) 【Terminal: H1 & H2】	<input type="checkbox"/> Yes / <input type="checkbox"/> No
		Shield wire connection	Both ends of shield wire must be grounded	<input type="checkbox"/> Yes / <input type="checkbox"/> No
		Wiring connection	Wiring connection per terminal (≤2)	<input type="checkbox"/> Yes / <input type="checkbox"/> No

1-2-4 Transmission wire installation inspection sheet 2/3

Check Item	Check contents	Judgement	Present Status
Number of ref. circuit connected in the network system: _____, Ref. addresses: _____(00 ~ 99)			
VRF Network System	Network wiring	Total transmission line length	Wiring length ≤ 3600m (Value taken from Network Design Drawing) (m)
		Network wiring layout	Do not make a loop configuration <input type="checkbox"/> Looped / <input type="checkbox"/> Not looped
		No. of network segment (*1)	No. of network segment ≤ 41

(*1) Create one Network Segment based on the following conditions,


Condition -1: if the transmission line length ≤ 500m

Condition -2: if a total number of connected units ≤ 64 connected units (*2)

(*2) connected units mean a total of (Indoor Units + Master Outdoor Units + TPC Units + System Controller Units
+ Network Converter for LonWorks Unit + Central RC Units + Network Converter Units
+ BACnet Gateway Unit + Signal Amplifier Units + Service Tool Unit + Web Monitoring Tool Unit)

1-2-4 Transmission wire installation inspection sheet 3/3

Check Item		Check contents	Judgement		Present Status
Number of ref. circuit connected in the network system : _____, Ref. addresses : _____ (00 ~ 99)					
VRF Network System	Network Configuration	No. of IUs & OUs	For one VRF Network System (IU ≤ 400 & OU ≤ 100)		IU number : _____ OU number: _____
		No. of System Controller	One System Controller per VRF Network System		
		No. of Touch panel controller (TPC)	Connectable Nos. 16	Total 16 Nos. Per VRF Network System (including one Network Converter for LonWorks)	TPC: _____
		No. of Central RC (CRC)	Connectable Nos. 16		CRC: _____
		No. of Network Convert for Group RC	Connectable Nos. 64		Group RC: _____
		No. of Signal Amplifier (SA) ≤ 40 Detail contents • No. of SA (filter mode OFF) ≤ 8 • No. of SA (filter mode ON) ≤ 32	• One per 500m transmission line length OR, • One per 400m transmission line length between units OR, • One per every 64 number of connected units OR, • One per every master OU if total number of connected Indoor Units > 320		Number of Signal Amplifier : _____
		No. of Network Convertor (≤ 100)	One for each separate Room-Airconditioning system		Total: _____
		No. of BACnet Gateway	One BACnet Gateway per VRF Network System		Total: _____
		Terminal Register	One per Network Segment (refer to table -9)		Total: _____
		No. of Network Convertor for LonWorks	One per VRF Network System (IU ≤ 128 & OU ≤ 100) 【 NOTE: Special VRF Network system configuration】		IU number : _____ OU number: _____

Check Item		Check contents	Judgement	Present Status
Number of ref. circuit connected in the network system : _____, Ref. addresses : _____ (00~99)				
VRF Network System	Terminal Resistance of transmission line	Terminal resistance of transmission line: From device with connected terminal resistance (OU or SA) to the most distance device	50 ohm ≤ (Resistance value) ≤ 180 ohm	<input type="checkbox"/> OK / <input type="checkbox"/> Not OK In- between OU (add____) & SA (add____)
				<input type="checkbox"/> OK / <input type="checkbox"/> Not OK In- between SA (add____)
				<input type="checkbox"/> OK / <input type="checkbox"/> Not OK In- between OU (add____) & SA (add____)

1-2-5 Piping installation inspection sheet

Check Item		Check contents		Judgement		Present Status	
Ref. circuit name : _____, Ref. address: _____ (00~99)							
Refrigerant system piping	Outlook	Insulation & Fastening		Insulated without gap & properly fastened (Yes / No)		<input type="checkbox"/> Yes / <input type="checkbox"/> No	
		Suction line filter		Is there any external filter in the suction line		<input type="checkbox"/> Yes / <input type="checkbox"/> No	
		Oil Trap		If Distance between OUs 2m , Place oil trap both at suction & at Discharge line		<input type="checkbox"/> Yes / <input type="checkbox"/> No <input type="checkbox"/> Not applicable	
	Piping	1 outdoor unit connected	Actual Pipe Length	Between Master OU and farthest IU ($\leq 165\text{m}$)		(m)	
				Between first separation tube and farthest IU ($\leq 90\text{m}$)		(m)	
				(farthest IU) - (closest IU) ($\leq 60\text{m}$)		(m)	
				Total Pipe Length ($\leq 700\text{m}$)		(m)	
		Height Difference	Between OU and IU (when OU is installed above) ($\leq 50\text{m}$)		(m)		
			Between OU and IU (when OU is installed below) ($\leq 40\text{m}$)		(m)		
			Between IUs ($\leq 15\text{m}$)		(m)		
		2 outdoor units connected	Actual Pipe Length	Between Master OU and farthest IU ($\leq 165\text{m}$)		(m)	
				Between first separation tube and farthest IU ($\leq 90\text{m}$)		(m)	
				(farthest IU) - (closest IU) ($\leq 60\text{m}$)		(m)	
				Total Pipe Length ($\leq 1000\text{m}$)		(m)	
				Between OU and OU branch kit ($\leq 3\text{m}$)		(m)	
			Height Difference	Between OU and IU (when OU is installed above) ($\leq 50\text{m}$)		(m)	
				Between OU and IU (when OU is installed below) ($\leq 40\text{m}$)		(m)	
				Between IUs ($\leq 15\text{m}$)		(m)	
				Between OUs ($\leq 0.5\text{m}$)		(m)	
		3 outdoor units connected	Actual Pipe Length	Between Master OU and farthest IU ($\leq 165\text{m}$)		(m)	
				Between first separation tube and farthest IU ($\leq 90\text{m}$)		(m)	
				(farthest IU) - (closest IU) ($\leq 60\text{m}$)		(m)	
Total Pipe Length ($\leq 1000\text{m}$)				(m)			
Between OU and OU branch kit ($\leq 3\text{m}$)				(m)			
Between farthest OU and first OU branch kit ($\leq 12\text{m}$)				(m)			
Height Difference	Between OU and IU (when OU is installed above) ($\leq 50\text{m}$)		(m)				
	Between OU and IU (when OU is installed below) ($\leq 40\text{m}$)		(m)				
	Between IUs ($\leq 15\text{m}$)		(m)				
	Between OUs ($\leq 0.5\text{m}$)		(m)				

1-2-6 Refrigerant charge amount inspection sheet

Check Item		Check contents		Judgement	Present Status
Ref. circuit name: _____, Ref. address : _____ (00~99)					
Additional Charged Refrigerant	Outdoor Unit	OU Model Name		Additional Refrigerant Amount for OU	
		AJ* 072L / AJ* 090L / AJ* 108L AJ* 126L / AJ* 144L / AJ* 162L		AJ* 072L / AJ* 090L : 0 (kg) AJ* 108L / AJ* 126L / AJ* 144L / AJ* 162L : 3.3 (kg)	
	Connecting Pipe	Liquid Pipe Length		Additional Refrigerant Amount based on the liquid pipe length	
		@ 6.35mm	(m)	For pipe diameter ϕ 6.35mm : 0.021 kg/m For pipe diameter ϕ 9.52mm : 0.058 kg/m For pipe diameter ϕ 12.7mm : 0.114 kg/m For pipe diameter ϕ 15.88mm : 0.178 kg/m For pipe diameter ϕ 19.05mm : 0.268 kg/m	(kg)
		@ 9.52mm	(m)		(kg)
		@ 12.7mm	(m)		(kg)
		@ 15.88mm	(m)		(kg)
		@ 19.05mm	(m)		(kg)
Total Additional Amount of Charged Refrigerant					(kg)

Note: In the refrigerant system, overall refrigerant amount \leq 31.5 kg (for 1 OU), 63.0 kg (for 2 OUs) and 94.5 kg (for 3 OUs)

Overall refrigerant amount (kg) in the refrigerant system = Factory charged refrigerant (kg) for OU* + Total additional amount of charged refrigerant (kg) [= Additional charged refrigerant for OU + Additional charged refrigerant for connecting pipe]

※ Factory charged refrigerant for outdoor unit :

AJ* 072L or AJ* 090L : 11.7 (kg)

AJ* 108L or AJ* 126L or AJ* 144L or AJ* 162L : 11.8(kg)

1-2-7 3-way valve opening inspection sheet

Check Item		Check contents		Judgement	Present Status
Ref. circuit name: _____, Ref. address : _____ (00~99)					
Outdoor Unit	3-way valves opening	3-way valve of each OU at - Discharge pipe side - Suction pipe side - Liquid pipe side		Master OU (all 3-way valve must be full open)	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				Slave1 OU (all 3-way valve must be full open)	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				Slave2 OU (all 3-way valve must be full open)	<input type="checkbox"/> Yes / <input type="checkbox"/> No

1-3 Check Items After Power ON

Overview of system operation check procedure

Step-1: Connect Service Tool PC to the VRF V-III system.

Do scanning of refrigerant system which should be commissioned.

Step-2: Compare the number of installed units (OU and IU) with the System List data obtained from the Service Tool.

Step-3: Operate all Indoor Units under Test Mode Cooling (Select Test mode either cool or heat based on ambient temperature.).

Step-3-1: During operation, check the IU thermistor value

Step-3-2: After 1-hour operation, check the Refrigerant System

Step-4: After 1-hour Test run operation (excluding special operation),

Step-4-1: Switching the operation mode of IU from cool to heat.

- Check the IU thermistor value

Step-4-2: When all IUs run under heating, continue operation minimum 15min. And check the Refrigerant system

1-3-1 Power source check sheet

Check Item		Check contents	Judgement	Present Status
Ref. circuit name _____,		Ref. address _____ (00 ~ 99)		
Power Source	Outdoor Unit	Actual Power Supply (V) Between R-S / S-T / T-R < 3, 4Wire + ground, 50Hz >	AC (380 - 415V) $\pm 10\%$ Incoming voltage per breaker	Master (V): R-S:____ / S-T:____ / T-R:____
				Slave -1 (V): R-S:____ / S-T:____ / T-R:____
				Slave -2 (V): R-S:____ / S-T:____ / T-R:____
	Indoor Unit	Actual Power Supply (V) < 1, 2Wire + ground, 50Hz >	AC (220 - 240V) $\pm 10\%$ Incoming voltage per breaker	Breaker-1 (V): _____
				Breaker-2 (V): _____
				Breaker-3 (V): _____

1-3-2 Error indication check sheet

Check Contents		Judgement	Present Status
Ref. circuit name _____,		Ref. address _____ (00 ~ 99)	
For each refrigerant system	Outdoor unit	Check PCB Lighting status	
	• Master	• LED101 (green light) Judgment : must be ON \Rightarrow Yes / No 【 Note : LED102 (Red) must not be flash & must not be ON 】 • 7-SEG LED Judgment : 'Sn' displayed \Rightarrow Yes / No	LED101: <input type="checkbox"/> Yes <input type="checkbox"/> No 7-SEG : <input type="checkbox"/> Yes <input type="checkbox"/> No
	• Slave-1		LED101: <input type="checkbox"/> Yes <input type="checkbox"/> No 7-SEG : <input type="checkbox"/> Yes <input type="checkbox"/> No
	• Slave-2		LED101: <input type="checkbox"/> Yes <input type="checkbox"/> No 7-SEG : <input type="checkbox"/> Yes <input type="checkbox"/> No
	Indoor unit	Check LED & RC display status	
	IU address _____	<u>Indoor Unit</u> ● For Wall mounted, Universal, Ceiling & Small Cassette Check IU operation LED & timer LED condition Judgment : must be flashing alternately \Rightarrow Yes / No ● For Large Cassette and Duct type IU Check Wired RC (3-wire) display screen Judgment : Clock display "AM 12:00" will appear \Rightarrow Yes / No Check Wired RC (2-wire) display screen Judgment : Language selection screen will appear \Rightarrow Yes / No	<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No
	IU address _____		<input type="checkbox"/> Yes <input type="checkbox"/> No

1-3-3 Installed unit and their addresses check sheet

Check Contents	Check items	Checking method	Judgement	Present Status	
Ref. circuit : Name _____,		Ref. address _____(select from 00 to 99)		Design value	Check status
Installed units and their addresses check	Number of IU IU address	Checked by Service Tool	Number of units and their address appeared in the System List must be same as the Actual Design value Judgment: (OK / Not OK)	Connected number of IU _____	<input type="checkbox"/> OK <input type="checkbox"/> Not OK
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	
				IU add _____	

1-3-4 Transmission line connection check sheet

Note: The following check method by using test-run is necessary for checking of incorrect transmission wire connection.

Check Contents	Check items	Checking method	Judgement	Present Status	
Ref. circuit : Name _____, Ref. address _____ (select from 00 to 99)				Design value	Check status
Transmission line connection confirmation check	Cooling status	Operate all Indoor Units under Test-run Cooling Mode by using Commissioning Function of Service Tool	Judgment Point during test-mode cooling : For Indoor Unit -Thermistor value 【 (TH21 - TH22) 8 °C 】 (Yes / No)	IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No

Check Contents	Check items	Checking method	Judgement	Present Status	
Ref. circuit : Name _____, Ref. address _____ (select from 00 to 99)				Design value	Check status
Transmission line connection confirmation	Heating status	Switching the operation of IU from cool to heat, Control function of Service Tool	Judgment Point after switching IU mode from cool to heat : For Indoor Unit - Thermistor value (TH24 > TH21) (Yes / No)	IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No
				IU add _____	<input type="checkbox"/> Yes / <input type="checkbox"/> No

1-3-5 Operation check sheet

Check Contents		Judgement	Present Status
Refrigerant Circuit : Name _____, Address _____(00 ~ 99)			
Test-run operation Cooling mode Conducted by Service Tool	▪ Degree of sub-cool at OU sub - cooler side should be, 5℃ ≤ ΔTsc ≤ 20℃ AND ▪ Pulse value EEV3 should be, EEV3 ≤ 400P	ΔTsc _____℃ EEV3 _____P	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Discharge refrigerant pressure should be, 2.5MPa ≤ Pd ≤ 3.3MPa	Pd _____MPa	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Suction refrigerant pressure should be, 0.7MPa ≤ Ps ≤ 1.2MPa	Ps _____MPa	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Discharge refrigerant temp. should be, Td ≤ 100℃ AND ▪ Discharge refrigerant superheat should be, ΔTshd > 10℃	Td _____℃ ΔTshd _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ IU refig. superheat should be, 2℃ ≤ ΔTshe ≤ 20℃ AND ▪ Pulse value IU EEV should be, EEV ≤ 1000P	ΔTshe _____℃ IU EEV _____P	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Ps between Master & Slave OUs should be, ΔPs ≤ 0.2 MPa	ΔPs _____MPa	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Air temperature of each IU should be, ΔTair cooling > 8℃	ΔTair cooling _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ No water fall from IU ▪ No abnormal noise from IU		<input type="checkbox"/> Yes / <input type="checkbox"/> No

Reference mark of Service tool
ΔTsc = Saturated liquid temperature of HPS - TH5 ΔTshe = TH24 - TH22 Td = TH1 Pd = HPS
ΔTshd = TH1- Saturated liquid temperature of HPS ΔTair cooling = TH21 - Outlet Air temperature Ps = LPS

Check Contents		Judgement	Present Status
Refrigerant Circuit : Name _____, Address _____(00 ~ 99)			
Test-run operation Heating mode Conducted by Service Tool	▪ Discharge refrigerant pressure should be, 2.5MPa ≤ Pd ≤ 3.3MPa	Pd _____MPa	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Suction refrigerant pressure should be, 0.3MPa ≤ Ps ≤ 1.2MPa	Ps _____MPa	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Discharge refrigerant temperature should be, Td ≤ 100℃ AND ▪ Discharge refrigerant superheat should be, ΔTshd > 10℃	Td _____℃ ΔTshd _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Degree of sub cool (at IU side) should be, 4℃ ≤ ΔTsc ≤ 7℃ AND	ΔTsc _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Refrigerant superheat (at OU side) should be, 2℃ ≤ ΔTshe1 & ΔTshe2 ≤ 5℃	ΔTshe _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Pd between Master & Slave OUs should be, ΔPs ≤ 0.2 MPa ▪ ΔTOUHE at each OU connected in series should be, ΔTOUHE* > 5℃	ΔPs _____MPa ΔTOUHE _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	▪ Air temperature of each IU should be, ΔTair heating > 15℃	ΔTair heating _____℃	<input type="checkbox"/> Yes / <input type="checkbox"/> No


Reference mark of Service tool
ΔTsc = Saturated liquid temperature of HPS - TH22 ΔTshe1 = TH7 - Saturated vapor temperature of LPS ΔTOUHE1 = TH4 - TH9
ΔTshd = TH1- Saturated liquid temperature of HPS ΔTshe2 = TH8 - Saturated vapor temperature of LPS ΔTOUHE2 = TH4 - TH10
ΔTair heating = TH21 - Outlet Air temperature

1-4 Test Run Operation

1-4-1 Test Run From Outdoor unit PC Board

All the indoor units connected to the outdoor unit can be test-operated by push button setting. (Only for master unit)


● SWITCH POSITION



● TEST RUN SETTING


For a detailed description of push button operation, refer to the [D&T manual Chapter 6. SYSTEM DESIGN]

< Monitoring condition >




(1) Press the MODE / EXIT button (SW107) once.


< Mode select condition >



< Fuction select condition >




< Pursuance completion >




(6) Press the ENTER button (SW109) or Time out (5 seconds)

< Return to mode select condition >



(7) Press the MODE / EXIT button





< Return to monitoring condition >




example,
Normal indicate : [Cooling mode]

1-4-2 Test Run From Remote Controller


1. Standard wired remote controller

Stop the indoor unit. Push the  button and  button simultaneously for more than two seconds. The air conditioner will start to conduct a test run and "a i" will display on the remote controller display. However, the ,  setting button does not have function, but all other buttons, displays, and protection functions will operate.


- Perform the test operation for 60 minutes.
- To stop test run, push the START / STOP button of the standard wired remote controller.
- For the operation method, refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.







2. Standard wireless remote controller


- Short two metal contacts under the battery compartment lid, while the air conditioner is running.
- To stop test run operation, push  button of the wireless remote controller.


When the air conditioner is being test run, the OPERATION and TIMER lamps of indoor unit flash slowly at the same time.



3. Simple remote controller

Stop the indoor and outdoor units. Push the remote controller  button and  button simultaneously for more than three seconds. The air conditioner will start to conduct a test run and "a i" will display on the temperature display. However the ,  setting button does not have function but all other buttons, displays and protection functions will operate.

- To stop test running press the  button of the simple remote controller.
- For the operation method refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test run operation.



4. Touch panel controller


- (1) Select the objective you want to test run.
Select the objective icon or list at the monitor screen. (Multiple selections is possible)
Select all the devices registered as objectives by pressing "Select All" on the monitor screen.
- (2) After objective selection at (1), switch to the <Setting screen> by pressing "Operation".
- (3) Switch to the <Detail setting screen > by pressing "Optional setting" on the setting screen,
- (4) Press "Start" button and OK on the details setting screen.

Test run continues for 60 minutes.

To interrupt test run, select the device being the test run and excute an operation stop.

At the monitor screen, test run can cancel by selecting objective device and press OFF.


UTY - DTG *



<Setting screen>



<Detail Setting screen>



5. Central remote controller



- (1) Press " " button.
- (2) Press "Set up Menu" and input password.
- (3) Select "Indoor unit special setting" by presing or button.
- (4) Select "Test operation by presing" or button
- (5) Press the "Select ALL button" or "Identify unit" button
[Select All]: All of R.C.Group (Indoor units)
[Identify Unit] : Specific R.C.Group (Indoor unit)

- (6) Press the " Start " button

The test run continues for 60 minutes.

To interrupt test run before it is complet, return to the "Monitor Mode Screen",
and press ON/ OFF.

UTY-DCG *





6. 2-wire type wired remote controller

- (1) Press "Menu" on the monitor screen. the < Main Menu screen > is displayed.
- (2) Press "Next Page" and press "Maintenance"
- (3) Press "Next Page" and press "Test Run". the <Test run screen > is displayed.
- (4) Press "OK"

The test run continues for 60 minutes.

To interrupt test run before it is complet, return to the "Monitor Mode Screen", and press ON/ OFF.

UTY - RNR*



1-5 TEST RUN CONTROL

1. When the test run signal is transmitted from standard wired, wireless remote controller, simple remote controller, transmitted network, and outdoor unit.

- (1) The test run operation starts and the electric expansion valve is controlled to a maximum flow, regardless of the temperature condition.
- (2) Frost prevention operation has priority over item(1).
- (3) Whether state of the indoor unit operates or stops, All units in the same refrigerant circuit will start to conduct a test run in accordance with the operation mode set by push switch of outdoor unit (see 1 - 2 - 3).
- (4) After 60 minutes passes, the test run stops.
- (5) Test running initialization is shown below.


* The temperature controlling on the test run operates regardless of setting temperature.

Operating Mode	EXCEPT FOR THE DUCT MODEL		DUCT TYPE	
	Cooling	Heating	Cooling	Heating
Fan speed	Hi	Hi	Hi	Hi
Vertical Air Direction Panel	Position ①	Position ④	_____	_____
Swing	OFF	OFF	_____	_____


*EXAMPLE



■ COMPACT CASSETTE TYPE



■ CEILING TYPE



■ COMPACT WALL MOUNTED TYPE

1-6 Field Setting And Monitor Mode List for Outdoor unit

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Information contents
Push switch on outdoor unit PCB Monitor mode [F1]	Device and system	00	Connected number of indoor unit		The number of the communicating unit is displayed
		01	Software version of outdoor unit		
		02	Software version of INV PCB		Software version : E●●●VO○☆■□L△△-◎
		03	Software version of communication PCB		[E●●●][VO○][☆■□][L△△][-◎] displays by five items
	Operation of each part	10	Rotational speed of outdoor unit fan motor		The rotational speed of the outdoor unit fan motor is displayed [0 ~ 999] rpm
		11	Rotational speed of INV compressor		The rotational speed of the compressor is displayed [0 ~ 999] rps
		12	Current value of INV compressor		Current value of INV compressor is displayed [0.00 ~ 99.99] A
		14	Pulse of EEV1		Pulse of EEV1 is displayed [0 ~ 9999] pls
		15	Pulse of EEV2		Pulse of EEV2 is displayed [0 ~ 9999] pls
		16	Pulse of EEV3		Pulse of EEV3 is displayed [0 ~ 9999] pls
	Time guard	20	Accumulated current time		Accumulated current time is displayed [0 ~ 9999] ×10hour
		21	INV compressor accumulated time [Cooling]		Accumulated time is displayed in the cooling operation of the INV compressor [0 ~ 9999] ×10hour
		22	INV compressor accumulated time [Heating]		Accumulated time is displayed in the heating operation of the INV compressor [0 ~ 9999] ×10hour
	Refrigerant cycle data 1	30	Information on Thermistor 1 (Discharge temperature sensor 1)		The value of the Thermistor 1 is displayed [-99.9 ~ 999.9] °C or °F
		31	Information on Thermistor 2 (Outdoor temperature sensor)		The value of the Thermistor 2 is displayed [-99.9 ~ 999.9] °C or °F
		32	Information on Thermistor 3 (Suction temperature sensor)		The value of the Thermistor 3 is displayed [-99.9 ~ 999.9] °C or °F
		33	Information on Thermistor 4 (Liquid temperature sensor 1)		The value of the Thermistor 4 is displayed [-99.9 ~ 999.9] °C or °F
		34	Information on Thermistor 5 (Liquid temperature sensor 2)		The value of the Thermistor 5 is displayed [-99.9 ~ 999.9] °C or °F
		35	Information on Thermistor 6 (Sub-cool H-Ex (outlet) sensor)		The value of the Thermistor 6 is displayed [-99.9 ~ 999.9] °C or °F
		36	Information on Thermistor 7 (Heat exchanger 1 gas sensor1)		The value of the Thermistor 7 is displayed [-99.9 ~ 999.9] °C or °F
		37	Information on Thermistor 8 (Heat exchanger 2 gas sensor2)		The value of the Thermistor 8 is displayed [-99.9 ~ 999.9] °C or °F
		38	Information on Thermistor 9 (Heat exchanger 1 liquid sensor)		The value of the Thermistor 9 is displayed [-99.9 ~ 999.9] °C or °F
		39	Information on Thermistor 10 (Heat exchanger 2 liquid sensor)		The value of the Thermistor 10 is displayed [-99.9 ~ 999.9] °C or °F
	Refrigerant cycle data 2	40	Information on Thermistor 11 (Compressor temperature sensor)		The value of the Thermistor 11 is displayed [-99.9 ~ 999.9] °C or °F
	Refrigerant cycle data 3	50	Information on pressure sensor 1 (High pressure sensor)		The value of the pressure sensor 1 is displayed If unit is [MPa], it is displayed as [0.00 ~ 9.99] [psi], it is displayed as [0.0 ~ 999.9]
		51	Information on pressure sensor 2 (Low pressure sensor)		The value of the pressure sensor 2 is displayed If unit is [MPa], it is displayed as [0.00 ~ 9.99] [psi], it is displayed as [0.0 ~ 999.9]

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Setting Function	Default	
Push switch on outdoor unit PCB Setting mode [F2]	Install	00	Pipe length setting	00	40-65m	○	
				01	0-40m		
				02	65-90m		
				03	90-120m		
				04	120-165m		
		Correction	10	Sequential start shift	00	Normal	○
					01	21sec. Delay	
					02	42sec. Delay	
					03	63sec. Delay	
			11	Cooling capacity shift	00	Normal mode	○
					01	Save energy mode (+2°C)	
					02	High power mode 1 (-2°C)	
					03	High power mode 2 (-4°C)	
					04	(Forbidden)	
			12	Heating capacity shift	00	Normal mode	○
					01	Save energy mode (-2°C)	
					02	High power mode 1 (+2°C)	
					03	High power mode 2 (+4°C)	
			13,14,15	(Forbidden)	00		○
	01						
	17		Height difference between indoor units	00	Standard	○	
				01	(Forbidden)		
				02	Height difference		
				03	(Forbidden)		
				04	(Forbidden)		
				If installing the indoor units (even only one set) to a lower floor than the outdoor unit, and the height difference between the indoor units is 3m or greater (i.e., if installing the indoor units on separate floors), set "02 (height difference)".			
	Change of function 1		20	Switching between batch stop or emergency stop	00	Batch stop	○
					01	Emergency stop	
			21	Operation mode selecting method	00	Priority given to the first command	○
		01			Priority given to the external input of outdoor unit		
		02			Priority given to the master indoor unit		
		22	Snow falling protection fan mode	00	Valid	○	
				01	Invalid		
		23	Interval setting for snow falling protection fan mode	00	Standard (30min)	○	
				01	Short 1 (5min)		
				02	Short 2 (10min)		
				03	Short 3 (20min)		
		24	High static pressure mode	00	Standard	○	
				01	High static pressure 1 (equivalent to 30Pa)		
				02	High static pressure 2 (equivalent to 82Pa)		
				03	(Forbidden)		
		25	(Forbidden)	00		○	
				01			
		26	(Forbidden)	00		○	
				01			
		27	(Forbidden)	00		○	
				01			
		28	(Forbidden)	00		○	
				01			
		29	(Forbidden)	00		○	
				01			
	Change of function 2	30	Energy saving level setting	00	Level 1 (stop)	○	
				01	Level 2 (operated at 40% capacity)		
				02	Level 3 (operated at 60% capacity)		
				03	Level 4 (operated at 80% capacity)		
				04	Level 5 (operated at 100% capacity)		
		32	(Forbidden)	00		○	
				01			
		33	(Forbidden)	00		○	
				01			
	Low noise setting 1	40	Capacity priority setting (in low noise mode)	00	Off (quiet priority)	○	
				01	On (capacity priority)		
		41	Low noise mode setting	00	Off (Normal)	○	
				01	On (Low noise mode operation is always done)		
		42	Low noise mode operation level setting	00	Level 1 (55dB)	○	
				01	Level 2 (50dB)		
	Change of function 3	70	Electricity meter No. setting 1 (Set the ones digit and tens digit of the No. of the electricity meter connected to CN135.)	00~99 *3	Setting number x00~x99 (Refer to Design & Technical Manual for details.)	00	
		71	Electricity meter No. setting 2 (Set the hundreds digit of the No. of the electricity meter connected to CN135.)	00~02 *3	Setting number 0xx~2xx (Refer to Design & Technical Manual for details.)	00	
72	Electricity meter pulse setting 1 (Set the ones digit and tens digit of the No. of the electricity meter pulse setting connected to CN135.)	00~99 *4	Setting number xx00~xx99 (Refer to Design & Technical Manual for details.)	00			
73	Electricity meter pulse setting 2 (Set the hundreds digit and thousands digit of the electricity meter pulse setting connected to CN135.)	00~99 *4	Setting number 00xx~99xx (Refer to Design & Technical Manual for details.)	00			

*1 : If one of compressor fails, backup operation will be performed by the remaining compressors.(For starting the system SET4-2 switching is required)

*2 : If one of compressor fails, all units will be abnormal stop.

*3 : When electricity meter No. is set to "000" and "201 to 299", the pulses input to CN135 become ineffective.
Available setting number is "001" to "200"

*4 : When the electricity meter pulse setting is set to "0000", the pulses input to CN135 become ineffective.
Available setting number is "0001" to "9999"

		ITEM CODE No.	Setting Mode	ITEM CODE No.	Setting Function	Default
Push switch on outdoor unit PCB Function mode [F3]	Forced operation	00	Cooling test run		Forced thermostat-ON in Cooling	
		01	Heating test run		Forced thermostat-ON in Heating	
		02	Test run stop		Test run is stopped	
	03,04	(Forbidden)				
	Install and maintenance 1	10	Signal amplifier automatic address		Automatic address setting operates for signal amplifier	
		11	Indoor unit automatic address		Automatic address setting operates for indoor unit of same refrigerant circuit	
	Install and maintenance 2	21	Vacuuming mode		Vacuuming mode operates	
	Clear	30	Error history clear		Refer to page 01-01 for the function All the abnormal code histories are cleared	
		31	(Forbidden)			
		32	Current time clear		Accumulated current time becomes [0]	
		33	INV compressor accumulated time clear		Accumulated time of the INV compressor becomes [0]	
		35	Field setting all clear		Return to default the all set items	
	Abnormal	40	*Abnormal reset		It was displayed when abnormality occurs, and abnormal code is reset	
					This is a function that uses to clear abnormal display after the repair is completed Please operate the switch after power off or power on the outdoor unit	
	Specialty function	91	Foreced Central control function forced release		When the centralized control device failure, and the centralized control setting cannot be released, this function is used	
					All the limitations set with the centralized control device are released	

		ITEM CODE No.	Meaning of Error History Number	Information contents
Push switch on outdoor unit PCB Error History Mode [F9]	Error history	00	1 time ago (Newest)	When the error occurred, the error code is memorized up to 10 on Main PCB.
		01	2 times ago	
		02	3 times ago	If the memorized error code becomes over 10, the oldest one will be erased.
		03	4 times ago	Refer to Chapter TROUBLE SHOOTING Error Code List of Outdoor unit
		04	5 times ago	
		05	6 times ago	
		06	7 times ago	
		07	8 times ago	
		08	9 times ago	
		09	10 times ago (Oldest)	

<< Error code which manual error release will be required >>

A5.1 Low pressure abnormal
 84.1 Current sensor 1 error
 93.1 Inverter compressor start up error
 94.1 Trip detection
 A1.1 Discharge temperature 1 abnormal
 A3.1 Compressor 1 temperature abnormal
 97.1 Outdoor unit fan motor lock error
 97.5 Fan motor temperature abnormal
 97.9 Fan motor driver abnormal
 68.2 Rush current limiting resister temp rise protection
 95.5 Compressor motor loss of synchronization
 A6.3 Outdoor heat exchanger 1 gas temperature abnormal
 A6.4 Outdoor heat exchanger 2 gas temperature abnormal
 A4.1 High pressure Abnormal
 86.4 High pressure SW 1 Error

1-7 Field Setting / Function Setting for Indoor unit

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Setting Function	Default
Indoor unit field setting setting by remote controller	Address	01	Indoor unit address	00~63	00~63	00
		02	Refrigerant circuit address	00~99	00~99	00
	Filter	11	Filter indicator Interval	00	Default	○
				01	Longer	
				02	Shorter	
		13	Filter sign display	00	Enable	○
				01	Disable	
				02	Display only on central remote control	
	Airflow	20	Ceiling airflow (Cassette type only)	00	Default	○
				01	High ceiling	
		23	Vertical airflow direction	00	Default	○
				01	Raise	
		24	Horizontal swing airflow direction	00	Default	○
				01	Left half	
				02	Right half	
		26	Static Pressure setting - Slim Duct Only - The Range of static pressure is different from one model to other.	00	0 Pa	
				01	10 Pa	
				02	20 Pa	
				03	30 Pa	
				04	40 Pa	
				05	50 Pa	
				06	60 Pa	
				07	70 Pa	
				08	80 Pa	
				09	90 Pa	
				31	25 Pa (Standard)	○
	Correction	30	Cool air temperature trigger	00	Default (0°C)	○
				01	Temperature overshoot setting (+2°C)	
				02	Temperature undershoot setting (-2°C)	
		31	Heat air temperature trigger	00	Default (0°C)	○
				01	Temperature undershoot setting (-6°C)	
				02	Temperature slightly undershoot setting (-4°C)	
				03	Temperature overshoot setting (+4°C)	
		32	Temperature correction in Auto	00	Disable	○
				01	Enable (Nonfunctional on J2 Series)	
	Change of Function 1	40	Auto restart *1	00	Enable	
				01	Disable	○
		43	Cool air prevention	00	Super low	○
				01	Follow the setting on the remote controller	
		46	External control	00	Start / Stop	○
				01	Emergency stop	
				02	Foreced stop (Start/Stop by RC is restricted)	
		47	Error report target	00	All	○
				01	Display only for central remote control	
		49	FAN Setting when cooling thermostat OFF *2	00	Follow the setting on the remote controller	○
				01	Foreced stop	

*1: Auto restart is an emergency function such as for power failure etc.

Do not start and stop the indoor unit by this function in normal operation.

Be sure to operate by the control unit, converter or external input device.

*2: Fan Setting when cooling thermostat OFF, Connection of the wired remote controller (2-wire type or 3-wire type) and switching its thermistor are necessary.

1-8 Field Setting / Function Setting for Outdoor air unit

	Classification	ITEM CODE No.	Setting Mode	ITEM CODE No.	Setting Function	Default
Indoor unit field setting setting by remote controller	Address	01	Indoor unit address	00~63	00~63	00
		02	Refrigerant circuit address	00~99	00~99	00
	Filter	11	Filter indicator Interval	00	Default	○
				01	Longer	
				02	Shorter	
		13	Filter sign display	00	Enable	
				01	Disable	○
				02	Display only on central remote control	
	Airflow	26	Static Pressure setting - Outdoor air unit Only - The Range of static pressure is different from one model to other.	05	SP mode 05	
				06	SP mode 06	
				07	SP mode 07	
				08	SP mode 08	
				09	SP mode 09	
				10	SP mode 10	
				11	SP mode 11	
				12	SP mode 12	
				13	SP mode 13	
				14	SP mode 14	
				15	SP mode 15	
				16	SP mode 16	
				17	SP mode 17	
				18	SP mode 18	
				19	SP mode 19	
				20	SP mode 20	
				21	SP mode 21	
				22	SP mode 22	
				31	Normal SP	○
	Change of Function 1	40	Auto restart *1	00	Enable	
				01	Disable	○
		43	Cool air prevention	00	Super low	
				01	Follow the setting on the remote controller	○
		46	External control	00	Start / Stop	○
				01	Emergency stop	
				02	Foreced stop (Start/Stop by RC is restricted)	
		47	Error report target	00	All	○
				01	Display only for central remote control	
		63	Humidifier control *2	00	mode 00	○
				01	mode 01	
				02	mode 02	

*1: Auto restart is an emergency function such as for power failure etc.

Do not start and stop the indoor unit by this function in normal operation.

Be sure to operate by the control unit, converter or external input device.

*2: Select control conditions of external output.


"Mode 00" is output when heating thermostat is ON, "Mode 01" is output in heating operation, "Mode 02" is output in heating operation and in fan operation.



2. OUTDOOR UNIT OPERATION CONTROL



2. OUTDOOR UNIT

2-1 REFRIGERANT CIRCUIT



No.	Part name	Function	No.	Part name	Function
1	Compressor temp. Sensor 1	Detects the compressor temperature	26	Outdoor unit EEV1	Controls the flow of ref. based on target pressure
2	Discharge temp. Sensor 1	Detects the discharge temperature	27	Outdoor unit EEV2	Controls the flow of ref. based on target pressure
3	High pressure Switch	Detects abnormal high pressure (4.20 MPa)	29	Liquid pipe temp. Sensor 1	Detects the temperature of liquid refrigerant
4	Check valve	Comp. pressure equalization	30	Outdoor unit EEV3	Controls ref. subcooling /Operates in protection
5	Oil Separator	Separates oil and refrigerant	31	Sub-Cool Heat exchanger	Subcool of liquid refrigerant
6	Compressor (Inverter)	Operation range (20 rps - 90 rps)	32	Sub-Cool HEX gas outlet temp Sensor	Detects the temperature of refrigerant
7	Bypass / Oil return Valve	HP-LP bypass in protection, Returns the oil to COMP	33	Liquid pipe temp. Sensor 2	Detects the temperature of liquid refrigerant
8	Oil return Valve	Returns the oil to Compressor	36	3way-valve (Liquid)	Open / Close for Liquid line
9	High pressure Sensor	Detects the High pressure	37	3way-valve (Gas)	Open / Close for Gas line
10	Bypass Valve	HP-LP bypass in protection / Comp. pressure equalization	38	Service port	Measure Low pressure for Service
11	Suction gas temp. Sensor	Detects the temp of refrigerant	39	I.U HEX outlet temp. Sensor	Detects the temperature of refrigerant
12	Low pressure Sensor	Detects Low pressure	40	Room temp. Sensor	Detects the temperature of room
13	Accumulator	Collects refrigerant and the returned oil	41	Indoor unit FAN (Motor)	Controlled by setting / protection / Thermo OFF
14	4-Way-Valve 1	Changes operation mode of HEX 1	42	I.U Heat Exchanger	Operates as Condenser / Evaporator
15	4-Way-Valve 2	Changes operation mode of HEX 2	43	I.U HEX inlet temp. Sensor	Detects the temperature of refrigerant
16	Service port	Measure High pressure for Service	44	Indoor unit EEV	Controlled by setting / protection / Thermo OFF
17	Heat-Ex 1 gas temp. Sensor	Detects the temperature of refrigerant	45	4-Way-Valve 3	Changes operation mode
18	Heat Exchanger 1	Operates as Condenser / Evaporator	46	Check valve	Prevents the liquid refrigerant return at cooling
19	Heat-Ex 2 gas temp. Sensor	Detects the temperature of refrigerant			
20	Heat Exchanger 2	Operates as Condenser / Evaporator			
21	Outdoor unit FAN (Motor)	Control FAN speed for heat exchange of HEX			
22	Outdoor temp. Sensor	Detects the ambient temperature			
23	Heat-Ex 1 liquid temp. Sensor	Detects the temperature of refrigerant			
24	Heat-Ex 2 liquid temp. Sensor	Detects the temperature of refrigerant			
25	Pressure regulation valve	Operates in regulated pressure (4.00MPa)			

2-1-1 REFRIGERANT CIRCUIT for Outdoor air unit



—W— : Capillary □ : Strainer

No.	Part name	Function
51	Heat exchanger outlet thermistor	Detects the temperature of refrigerant
52	Suction airflow temp. thermistor	Detects the temperature of suction airflow
53	Heat exchanger	Operates as Condensor / Evapulator
54	Fan motor	Controlled by setting / protection / Thermo OFF
55	Fan motor	Controlled by setting / protection / Thermo OFF
56	Heat exchanger inlet thermistor	Detects the temperature of refrigerant
57	Electric expansion valve	Controlled by setting / protection / Thermo OFF
58	Solenoid valve (Bypass)	Opens at Thermo OFF in Heating mode
59	Discharge airflow temp. thermistor	Detects the temperature of discharge airflow

2-2 INPUT / OUTPUT LIST

		Input / output or kind of detail	Control range
I N P U T	High pressure sensor Low pressure sensor Discharge temperature sensor 1 Outdoor temperature sensor Suction gas temperature sensor Liquid pipe temperature sensor 1 Liquid pipe temperature sensor 2 Sub-cool heat exchanger gas outlet temp.sensor Heat exchanger 1 gas temp. sensor Heat exchanger 2 gas temp sensor Heat exchanger 1 liquid temp. sensor Heat exchanger 2 liquid temp. sensor Compressor temperature sensor 1 Operation current sensor High pressure switch 1	Pressure sensor Pressure sensor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Themistor Current transformer Pressure switch	Measure range 0.0 to 5.0MPa Measure range 0.0 to 1.7MPa Measure range 10 to 130°C Measure range -25 to 58°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range -35 to 70°C Measure range 10 to 130°C Open 4.2MPa Short 3.2MPa
	Rotary SW & DIP-SW & Push SW	Address and function setting	
O U T P U T	Compressor 1 (Inverter) Electric expansion valve 1 (HEX1) Electric expansion valve 2 (HEX2) Electric expansion valve 3 (SC - HEX) Fan motor 4-way valve 1 (HEX1) 4-way valve 2 (HEX2) 4-way valve 3 Solenoid valve 1 Solenoid valve 2 Solenoid valve 3 Crank case heater 1 Crank case heater 2 Base heater	Magnetic relay EEV coil EEV coil EEV coil DC Brushless motor 4-way valve coil 4-way valve coil 4-way valve coil Hot gas bypass Comp. pressure equalization valve ACM oil return valve1 For Compressor (Lower) For Compressor (Upper) Field supply	Operation coil AC220-240V, 50Hz Operating voltage DC12V Operating voltage DC12V Operating voltage DC12V AC220-240V, 50/60Hz 6/5 W AC220-240V, 50/60Hz 6/5 W AC220-240V, 50/60Hz 6/5 W AC220-240V, 50Hz, 8W AC220-240V, 50Hz, 6W AC220-240V, 50Hz, 6W AC240V, 35W AC240V, 35W AC240V(For rated 415V Power supply) The allowable current is 1A or less
Communication Input / Output	LON WORKS Inverter communication Outdoor unit communication	Indoor unit ↔ Outdoor unit Outdoor unit ↔ Outdoor unit	
External Input / Output	External input 1 (CN131) (Low noise mode operation) External input 2 (CN132) (Cooling / Heating priority) External input 3 (CN133) (Outdoor unit operation peak control) External input 4 (CN134) (Emergency stop operation) Electricity meter pulse input (CN135)	Non-voltage contact input	
	External output 1 (CN136) (Error display) External output 2 (CN137) (Operation display)	ON (Error) / OFF (Normal) ON (Operation) / OFF (Stop)	Control output: DC 0/12-24V, Max.30mA Control output: DC 0/12-24V, Max.30mA
LED display	Single LED 101 Single LED 102 7 Segment LED	Display the information on operation, error and setting with single LED and 7 segment LED.	

2-3 COMPRESSOR OPERATION

2-3-1 Operation / Stop Condition

When cooling requirement capacity or heating requirement capacity from either of the indoor units in the same refrigerant circuit is input, the compressor operates.

When all the indoor units in no "cooling requirement capacity" or "heating requirement capacity", the compressor is stopped.


But in the following case, the compressor operates in accordance with operation of each mode.

- During 3 minute restart prevention operation
- Icing protection
- Failure (Refer to chapter 4, TROUBLE SHOOTING)
- Oil recovery
- Under expansion valve initialization
- At protective operation
- Emergency stop
- Defrost operation
- Peak cut stop operation


2-3-2 Compressor speed control

(1) Speed range and controlling

- On operation range: 20 - 115 rps*
- Changing interval: 60 sec.
- When the multi connection outdoor unit has the same type of compressor, all of compressors rotational speed are controlled with the same speed at the normal operating condition.
- All of the outdoor unit compressors must start at the start-up process.
- The Normal start process (Except the condition of Cold start)
The first target speed is decided by indoor unit capacity demand.
The upper limit speed at starting is made 60 rps and is raised in 30 rps to 90 rps after 60 seconds.
(The upper speed limit depends on the operating high pressure value)




- The lower limit speed at start-up changes depending on the outdoor temperature



- Cold Start start process

Condition: Outdoor temperature below 21 °C and the system stopped for more than 1 hour]


Control HP*: Change the rps so that high pressure does not reach to protection condition



2-3-3 Capacity Control


(1) Capacity of compressor operation

The inverter compressor is able to control the amount of required refrigerant circulation in details.



By combining the operation of inverter compressors, the amount of required refrigerant circulation according to cooling and heating load can be supplied from compressor efficiently.

Ex) Combination of 65cc compressor / Heating (Heating main)



(2) Target low-pressure and high-pressure control

<Cooling>

In order to make the evaporation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by low-pressure sensor.

<Heating>

In order to make the condensation pressure of the indoor unit at the proper pressure on a variety of operations, capacity of the compressor will be controlled by high-pressure sensor.

2-3-4 Compressor Sequence Operation

Make starting sequence and start and stop of the compressors in accordance with the below sequence.

Starting sequence condition

Example)



Starting sequence ① : Compressor started first, compressor stopped last

Starting sequence ② : Compressor started 2nd, compressor stopped 2nd from the end

Starting sequence ③ : Compressor started 3rd, compressor stopped 3rd from the end

Rotate the stating sequence under the following conditions:

- (1) Defrosting
- (2) Oil recovery
- (3) When cooling discharge temperature is high
- (4) After stopping from Heating operation



2-4 FAN CONTROL

2-4-1 Cooling Operation

The outdoor fan speed at start up is 300 rpm

Fan step	Fan speed (rpm)					
	AJ* 072LALBH AJ* 072LATBH	AJ* 090LALBH AJ* 090LATBH	AJ* 108LALBH AJ* 108LATBH	AJ* 126LALBH AJ* 126LATBH	AJ* 144LALBH AJ* 144LATBH	AJ* 162LALBH AJ* 162LATBH
16	880		920	920	970	970
15	860		870	870	870	870
14	810		820	820	820	820
13	720		720	720	720	720
12	620		620	620	620	620
11	500		500	500	500	500
10	420		420	420	420	420
9	360		360	360	360	360
8	320		320	320	320	320
7	300		300	300	300	300
6	intermittent 6		intermittent 6	intermittent 6	intermittent 6	intermittent 6
5	intermittent 5		intermittent 5	intermittent 5	intermittent 5	intermittent 5
4	intermittent 4		intermittent 4	intermittent 4	intermittent 4	intermittent 4
3	intermittent 3		intermittent 3	intermittent 3	intermittent 3	intermittent 3
2	intermittent 2		intermittent 2	intermittent 2	intermittent 2	intermittent 2
1	intermittent 1		intermittent 1	intermittent 1	intermittent 1	intermittent 1
0	0		0	0	0	0

<< Ex. Cooling operation >>

The fan speed is controlled to keep high pressure saturation temperature within the target range as follows
The high-pressure is monitoring at a set time interval and the fan speed is changed by the following conditions.


(Conditions which raise the fan speed)

High-pressure saturation > upper limit of target high-pressure saturation or heat sink temperature $\geq 80^{\circ}\text{C}$

(Conditions which lower the fan speed)

High-pressure saturation < low limit of target high-pressure saturation range and heat sink temperature $\leq 75^{\circ}\text{C}$


High-pressure saturation temp.



Intermittent fan mode

When switched from normal fan step to intermittent fan step, always start from 300rpm/7sec.
When there was a change during intermittent step 1-6, switching is performed at the time the current speed duration time reaches time-up.


Fan step	Fan mode	Fan speed 0 rpm duration time T (sec)	Fan speed 300 rpm duration time (sec)
6	intermittent 6	40	7
5	intermittent 5	33	
4	intermittent 4	26	
3	intermittent 3	19	
2	intermittent 2	12	
1	intermittent 1	6	



2-4-2 Heating Operation

(1) Heating Operation

The fan speed during all heating is constant with **Fan step 16*** regardless of the outdoor air temperature.




Fan step	Fan speed (rpm)		
	AJ* 072/ 090L	AJ* 108/ 126L	AJ* 144/ 162L
16*	880	920	970
15	860	870	870
14	810	820	820
13	720	720	720
12	620	620	620
11	500	500	500

2-5 EXPANSION VALVE CONTROL

The EEV controls the flow of refrigerant

	Operation mode	Contrl and detection	Control range	
			operation range	stop
EEV 1	Cooling	_____	480 pulses	0 pulse
EEV 2	Heating	- SH control (TH7,TH8 - LPS) "Target SH: 4 °C " - Protection (TH1) (LPS)	11 - 480 pulses	0 pulse
EEV 3	Cooling	- SH control (TH6, - LPS) "Target SH: 4 °C " - Protection (TH1)	0- 500 pulses	0 pulse
	Heating			

Initialization conditions: - When power turned On. - When operation stopped.



2-6 SPECIAL OPERATION

2-6-1 Oil Recovery Operation

(1) Purpose of the operation

The amount of refrigerant lubricant oil which has been transported to the indoor units and the connection pipe with the refrigerant will become large as the operation time of compressor increases. It is necessary to recover the oil back into the outdoor unit for a certain time interval in order to prevent compressors from damaging due to lack of lubrication oil.

① Cooling oil recovery operation

< Start condition >

Compressor accumulated operation time since last cooling oil recovery operation exceeds 3 hours
(first time : 1hour)

< End condition >

30 seconds have elapsed since the start and "suction temperature - low pressure saturation temperature $\leq 5\text{deg}$ " at all outdoor units or 6 minutes have elapsed since the start.

< Operation >

COMPRESSOR: Performed by all INV compressors operating up until now

INV speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit): Controlled pulse (as normal operation mode).

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode).

② Heating oil recovery operation

< Start condition >

Compressor accumulated operation time since the last heating oil recovery exceeds 8 hours
(first time : 1hour)

< End condition >

After 4 minutes have elapsed

< Operation >



COMPRESSOR: Performed by all INV compressors operating up until now

INV speed varies depending on the operation state.

EEV Opening (Indoor/Outdoor unit) : Controlled pulse (as normal operation mode)

FAN speed (Indoor/Outdoor unit) : Controlled fan speed (as normal operation mode)

Others

During the oil recovery operation,  appears on the display of wired and central remote controller, and  appears on the simple remote controller.
The operation indicators (LED) of the indoor units flash slowly.

2-6-2 Pre-heat Operation

This pre-heat operation protects the start up failure by preventing the refrigerant from soaking into the oil in compressor.


2 pcs of belt heater installed on the compressor

The crankcase heaters are controlled by the outdoor temperature

< Control condition >

Crankcase heater ON: 30 minutes elapsed since installed compressors stopped
(However, ON when power turned on)

OFF: Installed compressors operation



2-6-3 Defrost Operation Control

< Defrosting start condition >

Accumulated heating operation time is 40 minutes or longer

(Accumulated heating operation time is reset at the end of cooling operation or defrosting operation.)

And

One of Heat-Ex satisfies condition ① or ② or ③ below

Condition ① : Accumulated operating time is 150 minutes* or longer:

"Heat exchange liquid temperature (TH9 and TH10) \leq -2°C"

*75 minutes: when indoor unit connection capacity \leq 90% at 1 outdoor unit connection.

Condition ② : Accumulated time 10 minutes:

"Heat exchange liquid temperature (TH9 and TH10) \leq Defrosting Start Judgment Temperature*

And

"During heat exchange liquid temperature keeps dropping "

*Defrosting Start Judgment Temperature(°C) = $0.8 \times \text{Outdoor temperature (°C)} - 11.6$

-However, -27.6°C to -6°C

If the calculated result is lower than -27.6°C, the judgment temperature is defined as -27.6°C

If the calculated result is higher than -6°C, the judgment temperature is defined as -6°C

(Defrosting start judgment temperature are determined by the outdoor temperature.)

Condition ③ : Less than 10 minutes operation at outdoor temperature below 2°C occurred 20 times.

< Defrosting end condition >

① At all outdoor units, heat exchange liquid temperature \geq Defrosting End Judgment Temp.* and 180sec elapsed,
and all of outdoor unit's Suction temperature - Low pressure saturation temperature \leq 5°C
or

② When 15 minutes have elapsed from the start

*Defrosting End Judgment Temperature(°C) = $0.39 \times \text{outdoor temperature(°C)} + 12.7$

-However, 5°C to 12°C range

If the calculated result is lower than 5°C, the judgment temperature is defined as 5°C.


If the calculated result is higher than 12°C, the judgment temperature is defined as 12°C

< Operating state of each part during defrosting operation >

Actuator	Preparation process	On Defrost operation	Finishing process
Compressor	All compressor operaiotn Stop	All compressor start	All compressor operaiotn Stop
Heat Ex(4WV)	Change Condensor (OFF)	Condensor (OFF)	Keeps the operation mode
FAN	Stops	Stops	Stops
EEV1 EEV2	0 pls	EEV1: 300 pls EEV2: 480 pls	0 pls
EEV3	0 pls	100 - 500 pls	0 pls
SV1,SV2	Open (Balancing)	Close	Open


[STEP 1]

All compressors operates and it defrosting.




[STEP 2]

Outdoor units which satisfied the defrosting end judgment temperature are operated at the lowest speed (20rps) for inverter compressor.



[STEP 3]

When the defrosting of all outdoor units ends, all outdoor unit stop.
The start rotation execution is done, and restarts.



2-6-4 Low noise mode

When the low noise mode setting ON from Push SW or External input or System controller Input, the outdoor unit operates in the low noise mode as follows.

« Setting and corresponding operations »

External Input (CN131) on Master O.U. or Low noise mode setting (Push SW)	Capacity priority setting (Push SW)	Low noise level setting (Push SW)	Operation mode
ON	OFF	LEVEL 1	LOW NOISE MODE ①
		LEVEL 2	LOW NOISE MODE ②
	ON	LEVEL 1	* Automatic switching ①
		LEVEL 2	* Automatic switching ②

« Low noise mode and operation contents »


			AJ* 072L	AJ* 090L	AJ* 108L	AJ* 126L	AJ* 144L	AJ* 162L
LOW NOISE MODE ①	COOL	Fan upper limit speed	620rpm	620rpm	620rpm	620rpm	620rpm	620rpm
		Upper limit compressor capacity	50rps	54rps	56rps	62rps	62rps	62rps
	HEAT	Fan upper limit speed	620rpm	620rpm	620rpm	620rpm	620rpm	620rpm
		Upper limit compressor capacity	50rps	62rps	56rps	71rps	71rps	71rps
LOW NOISE MODE ②	COOL	Fan upper limit speed	500rpm	500rpm	500rpm	500rpm	500rpm	500rpm
		Upper limit compressor capacity	50rps	50rps	47rps	53rps	53rps	53rps
	HEAT	Fan upper limit speed	500rpm	500rpm	500rpm	500rpm	500rpm	500rpm
		Upper limit compressor capacity	50rps	52rps	53rps	53rps	53rps	53rps

The operating noise is reduced by limiting the rotational speed of compressor and fan motor


LOW NOISE MODE ① . . . The operating sound lowers from about 3 to 5 dB more than the rated value

LOW NOISE MODE ② . . . The operating sound lowers from about 3 to 5 dB more than the LOW NOISE MODE ①

* Automatic switching ①



* Automatic switching ②



* Capacity shortage condition

- When the compressor capacity is not enough
(Compressor operates with upper limit capacity for long time.)
- When condensing capacity is not enough in cooling operation
(When the following condition keeps for 5 minutes,
All of HEX in use and FAN speed can not increase and High pressure saturation temperature $\geq 58^{\circ}\text{C}$ (3.57MPa))
- When evaporating capacity is not enough in heating operation
(When the following condition keeps for 5 minutes,
All of HEX in use and FAN speed can not increase and low pressure saturation temperature $\leq 0^{\circ}\text{C}$)


2-6-5 Snow Falling Protection Fan Mode -Default Setting -

The fan rotates compulsorily at the maximum speed when the outdoor temperature becomes 5 °C or less.
The fan is rotated for 1 minute at the fan step upper limit at the interval set by PUSH SW.
This mode ends when the outdoor temperature becomes 7 °C or more or operation starts.

When the Snow Falling protection is not necessary, change the Function setting F2 -22 "Invalid"

(Operation contents)

Interval setting	PUSH SW setting (F2 - 23)	Interval time Int (min)
setting ④ (standard)	00	30
setting ①	01	5
setting ②	02	10
setting ③	03	20




2-7 PROTECTIVE FUNCTION

2-7-1 Discharge temperature protection

Protective function	Detect device	Cool	Heat	Display	Starting conditions	Release conditions	Operation
Discharge temperature protection 1	Discharge temp. sensor <TH1>	○	○	—	Cooling : Discharge temperature above 95°C Heating : Discharge temperature above 102°C	Below 90°C Below 97°C	EEV3 + 30pls/30 sec.
Discharge temperature protection 2	Discharge temp. sensor <TH1>	○		—	Cooling : Discharge temperature Above 107°C	Below 105°C	Outdoor unit rotation execution * After rotation has been executed once; it is executed every 15 minutes.
Discharge temperature protection 3	Discharge temp. sensor <TH1>	○	○	—	Discharge temperature Above 105°C	Below 100°C	Compressor speed decrease - 6rps every 30 sec. until it becomes the cancelation condition.
Discharge temperature protection 4	Discharge temp. sensor <TH1>		○	—	Discharge temperature Above 90°C (Heating/ Heating main)	Below 85°C	EEV's of operating indoor unit in heating mode (incl. the Thermo OFF indoor units) gradually opens. (Thermo OFF indoor unit; max. 200 pls)
Discharge temperature protection 5	Discharge temp. sensor <TH1>		○	—	Discharge temperature Above 95°C	Below 90°C	EEV1 and EEV2 operating outdoor unit +10pls / 30sec
Discharge temperature protection stop	Discharge temp. sensor <TH1>	○	○	P1	Pattern 1: Discharge temperature above 115°C	3 minutes have elapsed and Discharge temperature below 80°C	Corresponding outdoor unit stops
				EA11	Pattern 2 Condition 1 generated 2 times within 40 minutes	Error reset (push button SW) executed after power reset	Corresponding outdoor unit stops (Permanent stop) & Error display


Discharge temperature protection -Summary-

Protection controlling range in Cooling mode



Note: In cooling mode, there are 4 kind of discharge temp. protections are existing and,
The protection operation by EEV exists only on the Outdoor unit.
Target pressure controlling will be cancelled when the temperature is in the range color orange.

Protection controlling range in Heating mode



Note: In heating mode, there are 5 kind of discharge temp. protections are existing.
and protection operation by EEV exists IU and O.U
Target pressure controlling will be cancelled when the temperature is in the range of orange.


2-7-2 High pressure protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
High pressure protection 1	High pressure sensor	○		—	Above 3.94MPa	60 sec. elapsed and Below 3.70MPa	SV2 =>ON
High pressure protection 2	High pressure sensor		○	—	Pattern 1 Above 3.40 (3.70)* MPa	60 sec. elapsed and Below 3.24 (3.54)* MPa	SV2 =>ON
					Pattern 2 Above 3.50 (3.80)* MPa	180 sec. elapsed and Below 3.34 (3.64)* Mpa	SV1, SV2 =>ON
Abnormal high pressure protection control	High pressure sensor	○	○	—	Pattern 1 Cooling : Above 3.78MPa	25 sec. elapsed and Below 3.70Mpa	Compressor rotation speed rise up prohibit
					Heating : Above 3.24 (3.54)* MPa	25 sec. elapsed and Below 3.19(3.49)* Mpa	
					Pattern 2 Cooling : Above 3.90MPa	25 sec. elapsed and Below 3.78MPa	Compressor rotation speed decrease - 18.5 rps (-15.0 rps) every30 sec. until cancel condition. (): AJ* 108/ 126/ 144/ 162L
					Heating : Above 3.30(3.60)* Mpa	25 sec. elapsed and below 3.24(3.54)* MPa	
High Pressure Protection Stop 1	High pressure <u>sensor</u>	○	○	P2	Pattern 1 Above 4.00MPa	5 minutes elapsed and Below 3.50MPa	Corresponding outdoor unit stops
				EA41	Pattern 2 Pattern 1 generated 3 times within 60 minutes	10minutes elapsed and below 3.50MPa	Corresponding outdoor unit stops & Error display
					Pattern 3 Pattern 1 generated 3 times within 30 minutes	Error reset (F3-40) executed after power turned on again	Compressor stopped (permanent stop) & Error display
High pressure protection stop 2	High pressure <u>switch</u>	○	○	P2	Pattern 1 Pressure SW operate (More than 4.20MPa detects)	5 minutes elapsed and pressure SW reset (3.2MPa)	Corresponding outdoor unit stops
				EA42	Pattern 2 Pattern 1 generated 3 times within 60 minutes	10 minutes elapsed and pressure SW reset (3.2MPa)	Corresponding outdoor unit stops & Error display

*The value in () , when the compressor is operating more than 30Hz.


High pressure protection -Summary-

Protection controlling range in cooling operating mode



Note: In cooling mode, there are 5 kind of high pressure protections are existing.
Target pressure controlling will be cancelled when the operating pressure is in the range of orange.

Protection controlling range in heating operating mode




Note: In heating mode, there are 6 kind of high pressure protections are existing.
Target pressure controlling will be cancelled when the operating pressure is in the range of orange.

2-7-3 Low pressure protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Low pressure protection 1	Low pressure sensor	○	○	—	Below 0.10MPa	3minutes elapsed and Above 0.17MPa	SV1 =>ON
Low pressure protection 2	Low pressure sensor		○	—	After compressor started and 3 minutes elapsed and Below 0.18MPa	3minutes elapsed and above 0.22MPa	Operating Indoor unit EEV forced controlling -Thermo-OFF indoor unit: 450pls. -Thermo-ON indoor unit: gradually opens.
Low pressure protection 3	Low pressure sensor		○	—	Below 0.13MPa and SH* above 10°C and EEV1 (EEV2) is operating with less than 52pls. *SH = Heat-Ex1(2) Gas temp - Low pressure saturation temp.	Except the start condition	EEV1 (EEV2) set 52 plus
Abnormal low pressure protection control	Low pressure sensor	○	○	—	Below 0.16MPa	3minutes elapsed and above 0.18MPa	Compressor rotation speed lessen in the limited time until above 0.17Mpa (Compressor rotation speed rise up prohibit)
Low pressure protection stop	Low pressure sensor	○	○	P3	Pattern 1 Below 0.05MPa or 0.10MPa for 10minutes.	3minutes elapsed and Above 0.17Mpa	Corresponding outdoor unit stops
				EA51	Pattern 2 Pattern 1 generated 5 times within 180 minutes	Error reset (push button SW) executed after power turned on	Corresponding outdoor unit stops (Permanent stop) & Error display

Low pressure protection - Summary -

Protection controlling range in cooling / heating operating mode



Note: Target pressure controlling will be cancelled when the operating pressure is in the range of orange.

2-7-4 Heatsink temperature protection

() : AJ* 108/ 126/ 144/ 162L

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Heat sink temperature protection 1	Heatsink temp sensor	○	○	—	Above 75℃ (75℃)	Below 75℃ (75℃)	Cancel Fan speed step down.
Heat sink temperature protection 2	Heatsink temp sensor	○	○	—	Above 84℃ (83℃)	Below 84℃ (83℃)	Fan speed up 1 step every 2 minutes.
Heat sink temperature protection 3	Heatsink temp sensor	○	○	—	Above 88℃ (87℃)	Below 75℃ (75℃)	Compressor rotation speed lessens- 10 rps/ 120sec.
Heatsink temperature protection stop	Heatsink temp sensor	○	○	—	(Pattern 1 Above 92℃ (91℃)	3 minutes elapsed, and below 75℃ (75℃)	Compressor stops
				EAC4	Pattern 2 Pattern 1 generated 3 times within 60 minutes	10 minutes elapsed, and below 75℃ (75℃)	Compressor stop and Error indication.

2-7-5 Compressor temperature protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Compressor temperature protection stop	Compressor temp. sensor <TH11>	○	○	P4	Pattern 1 Compressor temperature above 115℃	3 minutes have elapsed and Discharge temp. below 80℃	Corresponding outdoor unit stops
				EA31	Pattern 2 Pattern 1 generated 2 times within 40 minutes	Error reset (push button SW) executed after power reset.	Corresponding outdoor unit stops (Permanent stop) & Error display

2-7-6 O.U Heat - Ex.1(2) Gas Temp. abnormal stop

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
O.U Heat - Ex. 1(2) Gas Temp. abnormal stop	Heat-Ex 1(2) Gas temp. Sensor <TH7,TH8>	○		EA63 (Heat Ex1) EA64 (Heat Ex2)	Heat Ex.1(2) gas temp. sensor TH7 (TH8) for use as condenser (4Way valve: Off, EEV: Open) is detected abnormally-low to High pressure saturated temp. for 4 minutes or more.	Error reset (push button SW) executed after power turned on	System Stop and Error indication

2-7-7 Over current protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Overcurrent protection stop	Inverter PCB Embedded	○	○	E941 (permanent stop)	Over current protection circuit detects (Abnormal current) in 5 times during compressor operating.	Error reset (push button SW) executed after power turned on	Compressor stop and Error indication "Trip Detection"
				E931 (permanent stop)	Over current protection circuit detects (Abnormal current) at the compressor start-up.		Compressor stop and Error indication "Inverter Compressor Start up Error"

2-7-8 Compressor Frequency Maximum setting protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Compressor Frequency Maximum setting protection	Filter PCB Current transformer	○	○	—	Pattern 1 Current value more than : 16.0A (AJ* 072L) 20.2A (AJ* 090/ 108L) 33.0A (AJ* 126/ 144/ 162L)	Current value less than the start condition	Compressor speed rise up prohibited
				—	Pattern 2 Current value more than: 17.0A (AJ* 072L) 21.2A (AJ* 090/ 108L) 34.0A (AJ* 126/ 144/ 162L)	Current value less than the start condition	Compressor speed lowered

2-7-9 Compressor compress ratio protection

() : AJ* 108/ 126/ 144/ 162L

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Compressor compression ratio protection	High pressure sensor and Low pressure sensor	○	○	—	Compression ratio* above 9 (8)	3 minutes elapsed, and below 8 (7.5)	SV1 => ON

*1 Compress ratio:
$$\frac{\text{HPS} + 0.1}{\text{LPS} + 0.1}$$

2-7-10 Fan Motor, Motor Driver abnormal stop protection

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Fan Motor lock protection stop	Embedded device	○	○	E97. 1	1. When the outdoor fan rotation speed is less than 100rpm in 20seconds after fan motor starts. 2. After the fan motor restarts, and when the condition 1 is repeated consecutively 4 times.	Error reset (push button SW) executed after power turned on	Fan Motor and Compressor Stop Error indication
Fan Motor temperature protection stop	Embedded device	○	○	E97. 5	1. When the FAN motor failed the operation more than 470rpm. 2. After the fan motor restarts, and if the fan motor cannot operate at 470rpm or more, or the condition 1 is repeated consecutively 3 times within 60 minutes.		
Fan Motor driver protection stop	Embedded device	○	○	E97. 9	When the Driver PCB detects the following abnormalities, Driver PCB defective, Fan motor defective (short circuit), Main PCB defective (DC output abnormal), lose connection, or Disconnecting wire.		

2-7-11 EEV Coil abnormal Stop

Protective function	Detect device	Cool	Heat	Display	Start condition	Release condition	Operation
Indoor unit EEV coil abnormal Stop	Indoor unit Controller PCB EEV drive Circuit	○	○	Error on IU. LED blinks Operation 5 times Timer 2 times	When the EEV coil drive circuit is open circuit	Drive circuit detects normal condition and Power reset	System Stop Error indication "I.U Coil 1 Error"
Outdoot unit EEV coil 1,2,3 abnormal Stop	Outdoor unit Controller PCB EEV drive Circuit	○	○	Error on OU. 7-Seg display E9A"X" Coil No, "X"			System Stop Error indication "CoiX1 Error" Coil No, "X"



3. INDOOR UNIT OPERATION

3. INDOOR UNIT OPERATION

3-1 FAN CONTROL

3-1-1 Fan Speed Setting

Fan speed setting



Press the FAN CONTROL button to set the fan speed.




3-1-2 "AUTO" Position

1. COOLING OPERATION


The fan speed is determined automatically in accordance with the condition " T_R (corrected room temperature) - T_s (corrected set temperature)" as shown on the right. However, the fan speed zone is determined in the manner as the room temperature increases for the following cases.

- (1) When the T_s is changed.
- (2) When the operation mode is changed from other mode to "COOL".
- (3) When the fan control is changed from other position to "AUTO".



2. HEAT OPERATION

Same as Cooling operation, fan speed is decided by the difference between the room temperature and the set temperature.



3. DRY OPERATION

The indoor fan always rotates at "Lo" speed.



- (1) The indoor fan starts operation 5 seconds after the electric expansion valve opens. However, when the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is not stopped, the fan will rotate immediately without a delay time of 5 seconds.
- (2) The indoor fan will stop in 30 seconds when the refrigerant circulation stops.
- (3) The indoor fan will stop immediately when the indoor unit is stopped by pushing the stop button or by a setting of ON timer.
- (4) When the refrigerant circulation is stopped due to a lower room temperature for more than 3 minutes, the fan will rotate 2 minutes at intervals of 3 minutes.
- (5) When the indoor unit just starts its operation or the operation mode is changed from other to "DRY" and the refrigerant circulation is stopped, the fan will rotate for 1 minute and then it will operate according to the statement (4).

3-2 MASTER CONTROL

3-2-1 Operation Mode Control

Each operation mode is controlled as below.

(1) Stop mode

Indoor fan motor	: OFF
Electric expansion valve	: Stop pulse
Drain pump	: Turns ON-OFF by the drain pump control function

(2) Cool, Dry and Heat Mode

	Cool	Dry	Heat
Indoor fan motor	Operates according to the AIR FLOW-MODE setting.	See the fan control page.	Operates according to the AIR FLOW-MODE setting, and besides cold air prevention operation
Drain pump	Turns ON-OFF by the drain pump control function		
Electrical expansion valve	Pulse controlled by the temperature difference calculation and frost prevent fuction	Pulse controlled by the temperature difference calculation and frost prevent function	Pulse controlled by the temperature difference.

(3) Priority mode


The purpose of the priority mode is to restrict operation commands (heating, cooling, dry) from the connected indoor units. There are 3 priority modes of Neutral, Cooling Priority, and Heating Priority. The operation modes restricted by each of these modes are as follows:

Priority mode	Restricted operation mode
Neutral	No restrictions
Cooling priority	Heating
Heating priority	Cooling, dry

1. Priority mode decision methods

Method 1. (Default value)


The initial priority mode is made Neutral and is shifted to Cooling Priority when cooling and to Heating Priority when heating depending on which operation mode (cooling, heating) was input first. After shifting to Cooling Priority or Heating Priority, the priority mode shifts to Neutral only when there was a Stop input from all the indoor units.



Method 2. (Management by outdoor unit)

Operation mode management is made "Management by outdoor unit" by outdoor unit PUSH-SW (field setting).

The priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the outdoor unit regardless of the current mode.



Method 3. (Management by indoor unit)


Operation mode management is made "Management by indoor unit" by outdoor unit PUSH-SW (field setting).

Then the master indoor unit is set by wired remote controller.

Thereupon the priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the master indoor unit regardless of the current priority mode.

The priority mode is fixed at either cooling or heating even if the master indoor unit stops

Cooling/heating switching can be performed by the master indoor unit only.



(4) Opposite operation mode

When the operation mode commanded from an indoor unit (remote controller) and the operation mode allowed by the system (cooling and dry operation for cooling only type and operation mode allowed by priority mode for heat pump type) do not match, it is indicated by blinking of an LED.

Timer lamp: 3 secs ON/1 sec OFF repeated

3-2-2 Operation Mode Control for Outdoor air unit

Each operation mode is controlled as below.

(1) Stop mode

Outdoor air unit fan motor : OFF
Electric expansion valve : Stop pulse
Drain pump : Turns ON-OFF by the drain pump control function
Solenoid valve : Closed

(2) Cool and Heat Mode

Each operation mode is controlled as below.

	Cool	Heat	Fan
Outdoor air unit fan motor	Operates according to the HIGH MODE setting.	Operates according to the HIGH MODE setting.	Operates according to the HIGH MODE setting.
Drain pump	Turns ON-OFF by the drain pump control function		
Electrical expansion valve	Pulse controlled by the temperature difference calculation and freeze prevention control	Pulse controlled by the temperature difference.	Stop pulse
Solenoid valve	Closed at all times	Opened at thermostat off and compressor on. Closed at other operation.	Closed at all times

(3) Priority mode


The purpose of the priority mode is to restrict operation commands (heating, cooling) from the connected outdoor air units. There are 3 priority modes of Neutral, Cooling Priority, and Heating Priority. The operation modes restricted by each of these modes are as follows:

Priority mode	Restricted operation mode
Neutral	No restrictions
Cooling priority	Heating
Heating priority	Cooling

1. Priority mode decision methods

Method 1. (Default value)


The initial priority mode is made Neutral and is shifted to Cooling Priority when cooling and to Heating Priority when heating depending on which operation mode (cooling, heating) was input first. After shifting to Cooling Priority or Heating Priority, the priority mode shifts to Neutral only when there was a Stop input from all the indoor units.



Method 2. (Management by Outdoor unit)

Operation mode management is made "Management by Outdoor unit" by Outdoor unit PUSH-SW (field setting).

The priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the Outdoor unit regardless of the current mode.




Method 3. (Management by indoor unit)

Operation mode management is made "Management by indoor unit" by Outdoor unit PUSH-SW (field setting).

Then the master indoor unit is set by wired remote controller.

Thereupon the priority mode shifts to Cooling Priority or Heating Priority in accordance with input from the master indoor unit regardless of the current priority mode.

The priority mode is fixed at either cooling or heating even if the master indoor unit stops Cooling/Heating switching can be performed by the master indoor unit only.



(4) Opposite operation mode

When the operation mode commanded from an indoor unit (remote controller) and the operation mode allowed by the system (cooling and dry operation for cooling only type and operation mode allowed by priority mode for heat pump type) do not match, it is indicated by blinking of an LED.

Timer lamp: 3 secs ON/1 sec OFF repeated


3-2-3 Auto Changeover

[Method]

1. Switch operation mode management to "Management by indoor unit" by outdoor unit DIP-SW.
2. Set the master indoor unit by wired remote controller.
3. Judge cooling/ heating by the difference between the master indoor unit's setting temperature and the room temperature.

■ AUTO CHANGEOVER operation

Operation flow chart



3-2-4 Auto Changeover Heating / Cooling Operation for Outdoor air unit


Function is available when an outdoor air unit set as the administrative indoor unit
(Management Outdoor air unit).
Refer to the setting Method

Setting Method

1. Switch operation mode management to "Management by outdoor air unit" by Outdoor unit PUSH-SW.
2. Set the master outdoor air unit by wired remote controller.
3. Judge cooling/heating by the difference between the master outdoor air unit's setting temperature and the suction airflow temperature

■ AUTO CHANGEOVER operation


Operation flow chart



3-2-5 "COOL" Position

When using the cooling mode, set the temperature to a value lower than the current room temperature, otherwise the indoor unit will not start the cooling operation and only the fan will rotate.


An example for COOLING TEMPERATURE CONTROL time chart (Manual setting)



3-2-6 "HEAT" Position

- (1) When using the heating mode, set the temperature to a value higher than the current room temperature, otherwise the indoor unit will not start the heating operation.
- (2) After the start of heating operation, the fan of indoor unit will not rotate until the heater exchange is warmed up to blow out warm air.
- (3) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.


An example for HEATING TEMPERATURE CONTROL time chart (Manual setting)



3-2-7 "COOL" Position for Outdoor air unit

When using the cooling mode, set the temperature to a value lower than the discharge airflow temperature, otherwise the outdoor air unit will not start the cooling operation and only the fan will rotate.


An example for COOLING TEMPERATURE CONTROL time chart (Manual setting)



3-2-8 "HEAT" Position for Outdoor air unit

- (1) When using the heating mode, set the temperature to a value higher than the discharge airflow temperature, otherwise the outdoor air unit will not start the heating operation.
- (2) During defrosting, the OPERATION indicator lamp flashes 6 sec. ON and 2 sec. OFF, and repeat. The heating operation will be temporarily interrupted.

An example for HEATING TEMPERATURE CONTROL time chart (Manual setting)



3-3 LOUVER CONTROL


(1) ADJUSTING THE DIRECTION OF AIR CIRCULATION

Instructions relating to heating (*) are applicable only to heat pump type outdoor unit.

Begin air conditioner operation before performing this procedure.

Vertical Air Direction Adjustment

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".



Example : When set to vertical air direction.


Press the VERTICAL AIR FLOW DIRECTION SET button.

- Press the VERTICAL AIRFLOW DIRECTION button.
The temperature display will change to the vertical airflow direction setting display.
- Press the VERTICAL AIRFLOW DIRECTION button to change the vertical louvre position.
The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④

Heating : ①, ②, ③, ④


■ LARGE CEILING TYPE




■ UNIVERSAL FLOOR/CEILING TYPE




■ CASSETTE TYPE



■ COMPACT WALL MOUNTED TYPE



■ WALL MOUNTED TYPE



Adjustable Position (All Mode) ①, ②, ③, ④, ⑤
Position ② setting is available by only wireless remote controller

- Use the air direction adjustments within the ranges shown above.
- The vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.
During Cooling mode : Horizontal flow ①
During Heating mode : Downward flow ④ (Large Wall mounted type: ⑤)
- During AUTO mode operation, for the first minute after beginning operation, airflow will be horizontal ①, the air direction cannot be adjusted during this period.

Horizontal Air Direction Adjustment


This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE" and "WALL MOUNTED TYPE".

Press the HORIZONTAL AIR FLOW DIRECTION SET button.

- Press the HORIZONTAL AIRFLOW DIRECTION button. The temperature display will change to the horizontal airflow direction setting display.
- Press the HORIZONTAL AIRFLOW DIRECTION button to change the horizontal louvre position. The position number will appear on the display.


Cooling & Dry : ①, ②, ③, ④, ⑤

Heating : ①, ②, ③, ④, ⑤




Example : When set to horizontal air direction.


■ LARGE CEILING TYPE



■ WALL MOUNTED TYPE



■ UNIVERSAL FLOOR/CEILING TYPE



(2) SWING OPERATION

Instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".


Begin air conditioner operation before performing this procedure.

To select Vertical airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE", "UNIVERSAL FLOOR/CEILING TYPE", "CASSETTE TYPE", "WALL MOUNTED TYPE" and "COMPACT WALL MOUNTED TYPE".

Press the VERTICAL SWING button for more than two seconds.

The remote controller's Vertical Swing Display will light up.
In this mode, the UP/DOWN air direction flaps will swing automatically to direct the air flow both up and down.



Example : When set to vertical swing.

To Stop Vertical airflow SWING Operation

Press the VERTICAL SWING button for more than two seconds once and again.

The remote controller's Vertical Swing Display will go out.
Airflow direction will return to the setting before swing was begun.

Instructions are applicable to "LARGE CEILING TYPE",
 "UNIVERSAL FLOOR / CEILING TYPE", "CASSETTE TYPE",
 "WALL MOUNTED TYPE", and "COMPACT WALL MOUNTED TYPE".

About Vertical Airflow SWING Operation

- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Air swing range


Air flow direction set	Range of swing
①	① to ④ (All range) *Large Wall Mounted type ① to ⑤
②	
③	
④	

To select Horizontal Airflow SWING Operation

This instructions are applicable to "LARGE CEILING TYPE",
 "UNIVERSAL FLOOR / CEILING TYPE", "WALL MOUNTED TYPE"
 and "CEILING WALL TYPE".

Press the HORIZONTAL SWING button for more than two seconds.

The remote controller's Horizontal Swing Display will light up.
 In this mode, the RIGHT/LEFT air direction louvers will swing
 automatically to direct the airflow both right and left.



Example : When set to horizontal swing.

To stop Horizontal airflow SWING Operation

**Press the HORIZONTAL SWING button for more than two seconds
 once and again.**

The remote controller's Horizontal Swing Display will go out.
 Airflow direction will return to the setting before swing was begun.

About Horizontal Airflow Swing Operation

- Left and right swing range can be changed in 3 steps by field setting.
- The SWING operation may stop temporarily when the air conditioner's fan is not operating, or when operating at very low speeds.
- The swing operation is not available depending on the model. Please refer to the operating manual for the indoor unit.

Left and right swing range (◆ ... Factory setting)

Range of swing	Function Number	Setting Value
◆ ① to ⑤ (All range)	24	00
① to ③		01
③ to ⑤		02

3-4-1 ELECTRONIC EXPANSION VALVE CONTROL

1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

2. Operation Control

- When indoor unit stopping

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Slightly open

- When starting up
(Cooling) Move to the cooling control base pulse in steps.
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Room temperature control
The room temperature is controlled so that it reaches to the set-up temperature based on the difference between the room temperature and the set-up temperature, and the change of indoor unit temperature. if the room temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.

3. Special Control

- Oil recovery operation : Controlled pulse.
- Test run operation : Controlled pulse.
- Icing protection control : Fully closed.
- Pump down operation : Fully open.
- Defrost operation : Controlled pulse

3-4-2 ELECTRONIC EXPANSION VALVE CONTROL for Outdoor air unit

1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

2. Operation Control

- When indoor unit stopping by Thermo-OFF condition.

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Fully closed

- When starting up
(Cooling) Move to the cooling control base pulse in steps.
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Discharge airflow temperature control
The discharge airflow temperature is controlled so that it reaches to the set-up temperature based on the difference between the discharge airflow temperature and the set-up temperature.
Cooling operation: 1) If the discharge airflow temperature becomes 5°C lower than the set-up temperature, EEV is fully closed.
2) If the suction airflow temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.
Heating operation: 1) If the discharge airflow temperature becomes 5°C higher than the set-up temperature for 5 minutes or more, EEV is fully closed.
2) If the suction airflow temperature becomes 0.5°C higher than the set-up temperature, EEV is fully closed.

3. Special Control

- Oil recovery operation : Controlled pulse(Maximum 1400 puls)
- Test run operation : Controlled pulse.
- Freeze prevention control : Fully closed.
- Vacuuming operation : Fully open.
- Defrost operation : Controlled pulse(Maximum 1400 puls)

3-5-1 DRAIN PUMP OPERATION

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigerant circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
 - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
 - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

3-5-2 DRAIN PUMP OPERATION for Outdoor air unit

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigerant circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
 - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
 - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

3-6 FUNCTION

3-6-1 Auto Restart

The air conditioner restarts with the previous setting operation.

3-6-2 Icing Protection Control

The icing of the indoor heat exchanger is prevented during the cooling and dry mode operation.

(1) Starting Condition

- Compressor is operation more than 3 minutes.
When "Heat exchanger inlet temperature $\leq T_A$ " continues *4 minutes or more.
- Compressor is operation more than 3 minutes.
When "Heat exchanger outlet temperature $\leq T_A$ " continues 4 minutes or more.

(2) Operation

EEV is closed.
Fan is at the setting amount.

(3) Completing Condition

Heat exchanger inlet and middle temperature $\geq T_B$
After more than 5 minutes


* Drain pump turns off at 60 minutes past the completion of the icing protection operation.

T_A	T_B
1°C	7°C

3-6-3 Oil Recovery Operation

[Oil recovery operation] : It periodically returns the residual refrigerant ion oil in the indoor unit and the connection piping back to the outdoor unit , and prevents the compressor oil level from decreasing.

Indoor unit LED : Operation LED



Indoor fan : Same operation before oil recovery operation.

Indoor EEV : Control pulse


* During the above operation, a refrigerant noise may be from the indoor unit.

3-6-4 Outdoor temperature protected operation for Outdoor air unit


1. COOL OPERATION

The contents of operation is controlled as following based on the suction airflow temperature.

- a) Operation mode management is made
"Management by indoor unit", and
outdoor air unit is master indoor unit.




- b) Cases Other than (a)



2. HEAT OPERATION


The contents of operation is controlled as following based on the suction airflow temperature.




3. FAN OPERATION

The contents of operation is controlled as following based on the suction airflow temperature.

- a) Operation mode management is made
"Management by indoor unit", and
outdoor air unit is master indoor unit.



- b) Cases Other than (a)




3-7 DX-KIT

3-7-1 SYSTEM CONFIGURATION

1. FGL remote/controller connection


The DX kit is controlled by a VRF operation device and use the external output of the DX kit to perform the AHU operation indirectly.
Control devices can be unified with FGL devices.



Interface	Contents
External input	Fan ON/OFF
External output	Thermostat ON/OFF FAN abnormal input

2. External controller connection

Air conditioning control (thermostat-control) can be designed on-site.
(Air conditioning control by DX is also possible.)
Control equipment suited to the application can be connected.



Interface	Contents	Remarks
External input	Operation ON / OFF	
	Operation mode Cool / Heat	Typical indoor unit is required for mode changing.
	Set temperature or capacity request (Analog input)	Temperature setting : When thermo-control is performed by DX kit. Capacityrequest : When the thermo-control is performed by external controller.
	Error	Information on error occurred at external controller
External output	Operation ON/OFF	
	Error	Information on error occurred at VRF system
	Special operation (defrost)	The Fan operation can be stopped with the communication signal of special operation

3-7-2 FUNDAMENTAL FUNCTIONS

1. FGL remote/controller connection

Air conditioning control system (SET3-3)	Intake temperature control	Discharge temperature control
Set temperature objective	Intake temperature (Room temperature) Cooling: 18 to 30°C Heating: 10 to 30°C	Discharge temperature Cooling: 14 to 25°C Heating: 17 to 28°C
Thermostat OFF conditions	Cooling Intake temperature < Setting temperature -0.5°C Heating Intake temperature > Setting temperature +0.5°C	Cooling Discharge temperature < Setting temperature -5.0°C Heating Discharge temperature > Setting temperature +5.0°C for 5 minutes
Operation (ON/OFF/Mode/ Set temperature)	FGL controller	
Fan control	Fan control commands are output from the DX kit external output terminal	

2. External controller connection


Air conditioning control system (SET3-3)		Intake temperature control	Outlet temperature control
Analog input system (SET3-2)		Set temperature input / Capacity input Selection	Set temperature input / Capacity input Selection
Temperature setting	Temperature Setting range	Intake temperature (Room temperature) Cooling: 18 to 30°C Heating: 10 to 30°C	Discharge temperature Cooling: 14 to 25°C Heating: 17 to 28°C
	Thermostat OFF conditions	Cooling Intake temperature < Setting temperature -0.5°C Heating Intake temperature > Setting temperature +0.5°C	Cooling Discharge temperature < Setting temperature -5.0°C Heating Discharge temperature > Setting temperature +5.0°C for 5 minutes
Capacity input	Capacity input range	0%, 5% to 100%	
	Thermostat OFF conditions	Controlled by external controller and EEV closed by making the capacity input 0% in cooling mode. EEV slightly opened when the Compressor operating in heating mode.	
Operation (ON/OFFMode/ Set temperature		Controlled by external controller, input to DX Kit external input terminal *Operation from FGL controller is disabled. (Only monitoring is possible)	
When error generated at external equipment		When fanmotor locked or another error was generated at the external equipment, the refrigerant cycle is stopped by inputting an error signal to the DX Kit external input terminal. (EEV is Closed)	
Fan control		Control is performed by external equipment, but when you want to stop the fan during defrosting, use the defrost signal that is output from the DX Kit external output terminal.	

3-7-3 FUNDAMENTAL FUNCTIONS

Cooling operation

When using the cooling mode, set the temperature to a value lower than the target controlling temperature, otherwise the External refrigeration cycle equipment will not start the cooling operation.

An example for COOLING TEMPERATURE CONTROL time chart



T_R : Target controlling temperature (Air intake temperature or Air discharge temperature)

T_s : Corrected Setting temperature

Air intake temp controlling

$T_s + 0.5^\circ\text{C}$: The threshold temperature of start of refrigerant flow

$T_s - 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

Air discharge temp controlling


$T_s + 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

$T_s - 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

Heating operation

- (1) When using the heating mode, set the temperature to a value higher than the current room temperature, otherwise the indoor unit will not start the heating operation.
- (2) After the start of heating operation, the fan of indoor unit will not rotate until the heater exchange is warmed up to blow out warm air.
- (3) During defrosting, the OPERATION indicator lamp flashes 6sec. ON and 2sec. OFF, and repeat. The heating operation will be temporarily interrupted.

An example for HEATING TEMPERATURE CONTROL time chart



T_s : Corrected Setting temperature

*: Duration of cold air prevention

T_R : Target controlling temperature (Air intake temperature or Air discharge temperature)

Air intake temp controlling

$T_s - 0.5^\circ\text{C}$: The threshold temperature of start of refrigerant flow

$T_s + 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

Air discharge temp controlling

$T_s - 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

$T_s + 0.5^\circ\text{C}$: The threshold temperature of stop of refrigerant flow

*When the EEV operates with the minimum pulse, and it keeps for 5 minutes.

3-7-4 ELECTRONIC EXPANSION VALVE CONTROL for DX-KIT

1. Initialization

- When the power is turned ON.
- When it has passed the limited time since the last initialization.

2. Operation Control

- When indoor unit stopping by Thermo-OFF condition.

Outdoor unit Condition	EEV Condition
OFF	Fully closed
Cooling	Fully closed
Heating	Fully closed

- When starting up
(Cooling) Move to the cooling control base pulse in steps.
(Heating) Move to the heating control base pulse in steps.
- Automatic operatic control
Automatic PI control is performed based on the indoor unit heat exchanger outlet temp and inlet temp.
- Discharge airflow temperature control
The discharge airflow temperature is controlled so that it reaches to the set-up temperature based on the difference between the discharge airflow temperature and the set-up temperature.
Cooling operation: 1) If the discharge airflow temperature becomes 5°C lower than the set-up temperature, EEV is fully closed.
2) If the suction airflow temperature becomes 0.5°C lower than the set-up temperature, EEV is fully closed.
Heating operation: If the suction airflow temperature becomes 0.5°C higher than the set-up temperature, EEV is fully closed.

3. Special Control

- Oil recovery operation : Controlled pulse(Maximum 1400 puls)
- Test run operation : Controlled pulse.
- Freeze prevention control : Fully closed.
- Vacuuming operation : Fully open.
- Defrost operation : Controlled pulse(Maximum 1400 puls)

3-7-5 DRAIN PUMP OPERATION for DX-KIT

- (1) When cooling and refrigerant circulation starts, the drain pump starts simultaneously.
- (2) The drain pump operates continuously for 3 minutes after the refrigerant circulation stopped.
- (3) When the refrigent circulation is stopped by a start of indoor heat exchanger frost prevention operation, the drain pump will turn off in 1 hour after the end of indoor heat exchanger frost prevention operation.
- (4) When the water level in the drain pan rises up and then the float switch functions:
 - ① Microcomputer stops the refrigerant circulation and indoor fan motor operation.
 - ② Drain pump operates continuously for 3 minutes after the float switch is turned off.
(Almost condensing water may be drained)
- (5) When the float switch turns ON continuously for 3 minutes, 'FAILURE INDICATION' operates.
- (6) When the float switch turns OFF within 3 minutes, the unit starts cooling operation.

3-7-6 FUNCTION

Auto Restart

The air conditioner restarts with the previous setting operation.

Freeze Prevention Control

The icing of the indoor heat exchanger is prevented during the cooling and dry mode operation.

(1) Starting Condition

- Compressor is operation more than 3 minutes.
When "Heat exchanger inlet temperature $\leq T_A$ " continues *4 minutes or more.
- Compressor is operation more than 3 minutes.
When "Heat exchanger outlet temperature $\leq T_A$ " continues 4 minutes or more.

(2) Operation

EEV is closed.
Fan is at the setting amount.

(3) Completing Condition

Heat exchanger inlet and middle temperature $\geq T_B$
After more than 5 minutes

* Drain pump turns off at 60 minutes past the completion of the icing protection operation.


T_A	T_B
1°C	7°C

Oil Recovery Operation / Defrost Operation

[Oil recovery operation / Defrost operation] :

It periodically returns the residual refrigerant ion oil in the indoor unit and the connection piping back to the outdoor unit , and prevents the compressor oil level from decreasing.

IR Receiver Unit LED: Operation LED



FAN output : Same operation before oil recovery operation in cooling operation or dry operation.(Heating operation: Stop)

DX-KIT EEV : Control pulse

* During the above operation, a refrigerant noise might hear from the EEV Kit.











4. TROUBLE SHOOTING

4. TROUBLESHOOTING
















4-1 NORMAL OPERATION



4-1-1 Indoor Unit Display

Indication type	Indication Lamp	Flashing Pattern
Operation	Operation LED	Continuous lighting
Anti Freeze		Continuous lighting(lowered light)
Timer	Timer LED	Continuous lighting(lowered light)
Filter	Filter LED	Continuous lighting
Power Failure	Operation LED	ON  OFF
	Timer LED	ON  OFF
Test Operation	Operation LED	ON  OFF
	Timer LED	ON  OFF
Defrosting	Operation LED	ON  OFF
Oil Recovery		
Opposite Operation Mode	Timer LED	ON  OFF
Maintenance Mode	Operation LED	ON  OFF
	Timer LED	
	Filter LED	
Location Notification	Operation LED	ON  OFF
	Timer LED	
	Filter LED	

This function is only available on the 2 wires remote controller.
Please refer to the installation manual of UTY-RNR*

4-1-2 OUTDOOR UNIT DISPLAY

Indication type	7 Segment LED Pattern	Description
Idling(stop)	 Blank	
Cooling Mode	 "C" OO "L"	
Heating Mode	 "H" EA "T"	
Oil Recovery Operation	 "O" IL "R" ECOVERY	Refer to Chapter 02. (Outdoor unit operation control)
Defrost Operation	 "D" E "F" ROST	Refer to Chapter 02. (Outdoor unit operation control)
Discharge Temp. Protection is stopped	 "P" ROTECT "1"	<Starting condition> Discharge temp \geq fixed value 239°F(115°C) <Release condition> 3 minutes have elapsed and discharge temperature \leq 176°F(80°C)
High Pressure Protection is stopped	 "P" ROTECT "2"	<Starting condition> High pressure \geq 580psi(4.00MPa) or Pressure SW in operation <Release condition> 5 minutes have elapsed and high pressure \leq 509psi (3.50MPa) and Pressure SW release
Low Pressure Protection is stopped	 "P" ROTECT "3"	<Starting condition> Low pressure \leq 7psi (0.05MPa) or low pressure \leq 15psi (0.10MPa) continues for 10 mins <Release condition> 3 minutes have elapsed and low pressure \geq 25psi (0.17MPa)
Compressor Temperature Protection is stopped	 "P" ROTECT "4"	<Starting condition> Compressor temp \geq fixed value 239°F(115°C) <Release condition> 3 minutes have elapsed and discharge temperature \leq 176°F(80°C)
Peak Cut Mode	 "P" eak "C" ut	
Low Noise Mode	 "L" OW "N" OISE	Refer to Chapter 02. (Outdoor unit operation control)
Snow Falling Protection Fan mode	 "SN" OW	Refer to Chapter 02. (Outdoor unit operation control)
Inverter Compressor Operation Indication	 Blinking	ON  OFF 



4-2 ABNORMAL OPERATION

4-2-1 Error code Display

An Error code is represented by 3 digit characters.

The first 2 digit means the subsection Error code, and the last 1 digit means the specifics Error code.

Ex.) Indoor unit Network communication Error

1 4 . 3

Subsection Error Code

Specifics Error Code

14 : Network communication Error

3 : Indoor unit Network Communication Error

Each Error code section is shown by the following target

Subsection Error Code target	Subsection and Specifics Error code target
<ul style="list-style-type: none">- Indoor unit (Operation / Timer / Filter) LED- 2 / 3 Wires Remote controller- Simple Remote controller- Group Remote controller- Central Remote controller- Touch - Panel Controller	<ul style="list-style-type: none">- Outdoor unit 7 segment Display- Service Tool

When an Error occurs, each devices indicate own abnormal detecting condtion.

In order to confirm the actual error condition, the following procedure are required.

1) Confirm the Specific Error code on the Outdoor unit 7 segment display or the Service tool.


Ex.1.) When the wired remote controller shows " 9 U (Outdoor unit Error)".

Ex.2*) When the wired remote controller shows " 4 2 (Indoor unit Heat-Ex Sensor Error)"


*The Specific Error code can be indicated by service tool.

2) Confirm each Error code on each devices in case of Network communication Error.

Ex.) When the Network cable of indoor unit 00 disconnected during operating.




4-2-2 Indoor Unit Display




4-2-3 Outdoor Unit Display


LED display



POWER MODE LED : on
ERROR LED : blink




Operation button



ERROR transition

Short press : less than 3 seconds
Long press : more than 3 seconds



If some error is newly occurred or resolved during transition, it is reflected after going back to "Annunciation".


* Only in the case of "indoor unit abnormal (E.5U.1)", indoor unit address is shown by ENTER long press.

4-2-4 Remote Controller Display

<< SIMPLE REMOTE CONTROLLER >> UTY-RSKYT

ERROR CODE DISPLAY

If an error occurs, the following display will be shown.
 ("Er" will appear in the set room temperature display.)
 If "Er" is displayed, immediately contact authorized service personnel.




Faulty unit No.
 (Remote controller address)
 Ex. Error code display

<< WIRED REMOTE CONTROLLER 3 wire type >> UTY-RNKYT

ERROR CODE DISPLAY

If an error occurs, the following display will be shown.
 ("Er" will appear in the set room temperature display.)
 If "Er" is displayed, immediately contact authorized service personnel.


Unit number (usually 0) Error code




Ex. Error code display

<< WIRED REMOTE CONTROLLER 2 wire type >> UTY-RNRY


If an error occurred, an error icon appears on the Monitor mode screen.



1. Touch the [Status] on the Monitor mode screen.



2. Touch the [Error Information] on the Status screen.




2-digit numbers are corresponding to the error code

<< WIRED REMOTE CONTROLLER 2 wire type >> UTY-RLRY

This appears automatically on the display if an error occurs.

If an error occurs, the following display will be shown. ("⚠" will appear in the "Monitor Mode Screen")



Error code
 2-wire remote controller address


Ex. Error code display

<< GROUP REMOTE CONTROLLER >> UTY-CGGY

ERROR CODE DISPLAY

The air conditioning system must be inspected if "E" (error code) appears on the timer and Clock Display, or the operation lamp is flashing.

*1 ; Model code
 O : Outdoor unit
 I : Indoor unit
 G : Group remote controller
 R : Converter



Ex. Error code display

4-2-5 Trouble shooting index - Error code List 1/2 -

Display Target A	Display Target B	Display Target C	Display Target D
Simple Wired remote controller 2 / 3 wires Wired remote controller Indoor unit LED blinking times, " 1st figure: Operation LED, 2nd figure: Timer LED"	Group Remote controller Central Remote controller Touch- Panel controller	7 seg. Display on Outdoor unit Controller PCB	Service Tool

★: No Display A: LED 10 times Blinks J: LED 13 times Blinks U: LED 15 times Blinks

Display Target A	Display Target B	Error Contents < Subsection >	Display Target C	Display Target D	Error Contents < Supcifics >	Trouble shooting No.
1 2		Remote controller Communication Error	5 U.1	1 2 . 1	Wired Remote Controller communication Error	1
				1 2 . 2	Wired Remote Controller signal error (3 wires RC)	2
				1 2 . 3	Number Excess of device in Wired RC. System (2 Wires RC)	3
9 U	1 3	Communication Error between Outdoor unit	1 3 . 1		Communication Error Between Outdoor unit	4
1 4 ★	1 4 1 6	Network Communication Error	1 4 . 1	1 4 . 1 1 4 . 3	Outdoor unit Network communication 1 Error	5
1 4 9 U	1 4 1 6		1 4 . 2	1 4 . 2 1 4 . 1 1 4 . 3	Outdoor unit Network communication 2 Error	6
1 4 9 U ★	1 4 1 6		1 4 . 1 1 4 . 2	1 4 . 3 1 4 . 1 1 4 . 2	Indoor unit Network communication Error	7
9 U ★	1 4 1 6		1 4 . 5	1 4 . 5 1 4 . 3	The number of indoor unit shortage Error	8
1 6 ★		Peripheral device communication Error	1 4 . 1 1 4 . 2	1 4 . 3	Transmission PCB connection Error	9
					Communication Error between Controller and Indoor unit	10
2 6		Address settingError	5 U.1	2 6 . 4 2 6 . 5	Address duplication in Wired remote controller system Address setting Error in Wired remote controller system	11 12
★		Other setting Error	2 8 . 1 2 8 . 4	★ ★	Auto address setting Error Signal amplifier auto address Error	13 14
2 9 2 9	★	Connection unit number error in wired remote controller system	5 U. 1 ★	2 9 . 1 ★	Connection unit number Error (Indoor unit in WRC control system) Connection unit number Error (Remote controller)	15 16
3 1		Indoor unit Power supply Abnormal	5 U. 1	3 1 . 3	Indoor unit power frequency Abnormal	17
3 2		Indoor unit Main PCB Error		3 2 . 1 3 2 . 3 3 2 . 7	Indoor unit PCB Model informaiton Error Indoor unit EEPROM access Error Indoor unit microcomputer self-check error	18 19 19-1
3 A		Indoor unit communication circuit (WRC) error	5 U.1	3 A . 1	Indoor unit communication circuit (WRC) microcomputers communication error	20
4 1		Indoor unit Room temp. Sensor Error		4 1 . 1	Indoor unit Inlet air temp. Sensor Error	21
4 2		Indoor unit Heat-Ex. Sensor Error		4 2 . 1 4 2 . 3	Indoor unit Heat-Ex. Inlet temp. Sensor Error Indoor unit Heat-Ex. Outlet temp. Sensor Error	22 23
5 1		Indoor unit FAN Motor 1 Error		5 1 . 2	Indoor unit FAN Motor 1 rotation speed Error	24
5 2		Indoor unit Coil (EEV) Error		5 2 . 1	Indoor unit Coil 1 (EEV) Error	25
5 3		Indoor unit water drain Abnormal		5 3 . 1	Indoor unit Drain pump Error	26
★		Indoor unit Error		★	Indoor unit Error	Refer to I.U Error
9 U	6 1	Outdoor unit Power supply Abnormal	6 1 . 2 6 1 . 5		Outdoor unit under voltage Error Outdoor unit reverse phase, missing phase wire Error	27 27-1
	6 2	Outdoor unit PCB Error	6 2 . 3 6 2 . 6 6 2 . 8 6 2 . 9		Outdoor unit EEPROM access Error Inverters communication Error EEPROM data corrupted Error Outdoor unit microcomputer self-check error	28 29 30 30-1
	6 3	Outdoor unit Inverter PCB Error	6 3 . 1		Inverter Error	31
★	★	OU. short interruption detection protected operation	6 7 . 2		Inverter PCB short interruption Error	32
9 U	6 8	Outdoor unit Magnetic relay Error	6 8 . 2		Rush Current limiting resistor temp. rise protection	33
9 U	6 9	Outdoor unit Transmission PCB Error	6 9 . 1		Outdoor unit transmission PCB Parallel communication Error	34
1 4	1 4		6 9 . 1	1 4 . 1 1 4 . 3		
9 U	7 1	Outdoor unit Discharge temp. Sensor Error	7 1 . 1		Discharge temp.Sensor 1 Error	35
	7 2	Outdoor unit Compressor temp. Sensor Error	7 2 . 1		Compressor temp. Sensor 1 Error	36
	7 3	Outdoor unit Heat-Ex. temp. Sensor Error	7 3 . 4 7 3 . 5 7 3 . 6 7 3 . 7		Heat-Ex 1 gas temp. Sensor Error Heat-Ex 1 liquid temp. Sensor Error Heat-Ex 2 gas temp. Sensor Error Heat-Ex 2 liquid temp. Sensor Error	37 38 39 40
	7 4	Outdoor temp. Sensor Error	7 4 . 1		Outdoor temp. Sensor Error	41
	7 5	Suction gas temp. Sensor Error	7 5 . 1		Suction gas temp. Sensor Error	42
	7 7	Heat sink temp. Sensor Error	7 7 . 1		Heat sink temp. Sensor Error	43
	8 2	Sub cool HEX temp. Sensor Error	8 2 . 2		Sub cool HEX gas outlet temp. Sensor Error	44
	8 3	Liquid pipe temp. Sensor Error	8 3 . 1 8 3 . 2		Liquid pipe temp. Sensor 1 Error Liquid pipe temp. Sensor 2 Error	45 46
	8 4	Current Sensor Error	8 4 . 1		Current sensor 1 Error	47

4-2-5 Trouble shooting index - Error code List 2/2 -

Display Target A	Display Target B	Display Target C	Display Target D
Simple Wired remote controller 2 / 3 wires Wired remote controller Indoor unit LED blinking times, " 1st figure: Operation LED, 2nd figure: Timer LED"	Group Remote controller Central Remote controller Touch- Panel controller	7 seg. Display on Outdoor unit Controller PCB	Service Tool

★ : No Display A: LED 10 times Blinks J: LED 13 times Blinks U: LED 15 times Blinks

Display Target A	Display Target B	Error Contents < Subsection >	Display Target C	Display Target D	Error Contents < Supecifics >	Trouble shooting No.
9 U	8 6	Pressure Sensor Error	8 6 . 1		Discharge pressure sensor Error	48
			8 6 . 3		Suction pressure sensor Error	49
			8 6 . 4		High pressure SW 1 Error	50
	9 3	Compressor start up Error	9 3 . 1		Inverter compressor Start up Error	51
	9 4	Trip Detection	9 4 . 1		Trip detection	52
	9 5	Compressor motor control Error	9 5 . 5		Compressor motor loss of synchronization	53
	9 7	Outdoor unit FAN Motor 1 Error	9 7 . 1		Outdoor unit FAN Motor Lock Error	54
			9 7 . 5		Outdoor unit FAN Motor temp. Abnormal	55
			9 7 . 9		Outdoor unit FAN Motor Driver Abnormal	56
	9 A	Outdoor unit coil (EEV) Error	9 A . 1		Coil 1 (EEV) Error	57
			9 A . 2		Coil 2 (EEV) Error	58
			9 A . 3		Coil 3 (EEV) Error	59
	*1	Outdoor unit Abnormal	*1		Slave outdoor unit Error	60
	A 1	Discharge temp. Abnormal	A 1 . 1		Discharge temp. 1 Abnormal	61
	A 3	Compressor temp. Abnormal	A 3 . 1		Compressor 1 Temperature Abnormal	62
	A 4	Pressure abnormal 1	A 4 . 1		High pressure Abnormal	63
			A 4 . 2		High pressure protection 1	64
	A 5	Pressure abnormal 2	A 5 . 1		Low pressure Abnormal	65
	A 6	Heat-Ex temp. Abnormal	A 6 . 3		Outdoor unit Heat-Ex 1 Gas temp. Abnormal	66
			A 6 . 4		Outdoor unit Heat-Ex 2 Gas temp. Abnormal	67
	A C	Ambient temp Abnormal	A C . 4		Outdoor unit Heat Sink temp. Abnormal	68
★		Initial Setting Error	- - - -		* Initial Setting Error	71

*1: Master Outdoor unit : 9 U. 2 / Slave Outdoor unit and Service Tool indicate applicable Error code

Other Error code for Outdoor Air unit / DX-Kit

3 9	Indoor unit power supply circuit error	5 U.1	39.1	Indoor unit power supply error for fan motor 1	81
			39.2	Indoor unit power supply error for fan motor 2	
4 A	Indoor unit air temp. thermistor error		4A.1	Indoor unit suction air temp. thermistor error	82
			4A.2	Indoor unit discharge air temp. thermistor error	83
5 9	Indoor unit fan motor 2 error		59.2	Indoor unit fan motor 2 rotation speed error	84

Other Error code for DX-Kit

5 2	Indoor unit Coil (EEV) Error	5 U.1	52.2	Indoor unit Coil 2 (EEV) Error	85
J 6	Peripheral device Error		J6.1	Peripheral device Error	86

Wired remote controller "Internal Error" * These error codes will be shown only on the remote controller.

CC.1 C2.1 15.4	★	Sensor Error Transmission PCB Error Data acquisition Error	★	★	Replace the remote controller, If the error appears on the remote controller.
----------------------	---	--	---	---	---

4-2-6 Trouble shooting index - No Error code -

	Error condition	Error Contents	Trouble shooting
No Error Code System Abnormal	Indoor Unit - No Power (Except Wall Mounted)	Indoor Unit - No Power (Except Wall Mounted)	72
	Indoor unit - No Power (Wall Mounted)	Indoor Unit - No Power (Wall Mounted)	73
	Outdoor unit - No Power	Outdoor unit - No Power	74
	No operation (Power is ON)	No operation (Power is ON)	76
	No Cooling	No Cooling / No Heating	77
	Abnormal Noise	Abnormal Noise	78
	Water leaking	Water leaking	79
	Indoor Unit - No Power(Outdoor air unit)	Indoor Unit - No Power (Outdoor air unit)	80
	Peripheral device - No Power	Peripheral device - No Power	87
	Peripheral device - FAN not operates	Peripheral device - FAN not operates	88
	Peripheral device No Cooling / No Heating	Peripheral device No Cooling / No Heating	89
	DX-Kit - No Power	DX-Kit - No Power	90

4-2-7 TROUBLE LEVEL OF SYSTEM

<< System Condition when Outdoor Unit Error is occurred >>

System Condition	Outdoor unit Condition	Trouble Level	
		1	2
		Not indicated on Indoor Unit and Peripheral unit. Indicated on Service Tool.	Indicated on Indoor Unit (*1) and Peripheral unit. Indicated on Service Tool.
① System is not stopped compulsorily Operation continues	Abnormal LED indication Outdoor unit does not stop	- 14.1 Outdoor unit network communication 1 error	- 62.3 Outdoorunit EEPROM access error - 62.8 EEPROM data corrupted error - 73.5 Heat Ex.1 liquid temp. sensor error - 73.7 Heat Ex.2 liquid temp. sensor error - 75.1 Suction gas temp sensor error - 82.2 Sub-cool Heat Ex. gas outlet temp. sensor error - 83.1 Liquid pipe temp. sensor 1 error - 83.2 Liquid pipe temp. sensor 2 error
② System is compulsorily stopped (*4)	Abnormal LED indication Outdoor unit stop	- 67.2 Inverter PCB short interruption detection	- 62.6 Inverter communication error - 63.1 Inverter error - 68.2 Rush current limiting resister temp. rise protection (*3) - 71.1 Discharge Temp sensor 1 error - 72.1 Compressor Temp sensor 1 error - 73.4 Heat Ex. 1 gas temp sensor error - 73.6 Heat Ex. 2 gas temp sensor error - 74.1 Outdoor Temp sensor error - 77.1 Heat sink Temp sensor error - 84.1 Current sensor 1 error (*3) - 86.1 Discharge pressure sensor error - 86.3 Suction pressure sensor error - 86.4 High pressure switch 1 error - 93.1 Inverter compressor start up error (*3) - 94.1 Trip detection (*3) - 95.5 Comp. motor loss of synchronization (*3) - 97.1 Outdoor unit fan motor lock error (*3) - 97.5 Fan motor temperature abnormal (*3) - 97.9 Fan motor driver abnormal (*3) - A1.1 Discharge temperature 1 abnormal (*3) - A3.1 Compressor1 temperature abnormal (*3) - A4.1 High pressure abnormal - A4.2 High pressure protection1 - A6.3 Outdoor Heat Ex. 1 gas temp. abnormal (*3) - A6.4 Outdoor Heat Ex. 2 gas temp. abnormal (*3) - AC.4 Heat sink temperature abnormal
③ System is compulsorily stopped	Abnormal LED indication Outdoor unit stop		- 13.1 Communication error between outdoor unit - 14.2 Outdoor unit network communication 2 error - 14.5 The number of indoor unit shortage (*2) - 61.5 Outdoor unit reverse phase, missing phase wire error - 69.1 Outdoor unit transmission PCB parallel communication error - 9A.1 Coil1 (Expansion valve1) error - 9A.2 Coil2 (Expansion valve2) error - 9A.3 Coil3 (Expansion valve3) error - A5.1 Low pressure abnormal (*3)

(*1) This will not be displayed on indoor unit which Error Report Target (function setting 47 of indoor unit) is set "for administrator".

(*2) The System condition can change to ① (Trouble Level 1) by changing DIP SW (SET 4-1:OFF)

(*3) Even if power is reset, this Error cannot release. In Error release, you need to solving the problem and operate the push switch and a and apply "Error reset" (F3-40) after power restart.

(*4) When one of outdoor unit on the multi connection detects these Error, the backup operation can activate by using of remaining outdoorunit(s)
Please check each trouble shooting, and read the caution before using the backup operation.

<< Error code which manual error release will be required >>

- A5.1 Low pressure abnormal
- 84.1 Current sensor 1 error
- 93.1 Inverter compressor start up error
- 94.1 Trip detection
- A1.1 Discharge temperature 1 abnormal
- A3.1 Compressor 1 temperature abnormal
- 97.1 Outdoor unit fan motor lock error
- 97.5 Fan motor temperature abnormal
- 97.9 Fan motor driver abnormal
- 68.2 Rush current limiting resister temp rise protection
- 95.5 Compressor motor loss of synchronization
- A6.3 Outdoor heat exchanger 1 gas temperature abnormal
- A6.4 Outdoor heat exchanger 2 gas temperature abnormal

4-2-7 TROUBLE LEVEL OF SYSTEM

<< System Condition when Outdoor Unit Error is occurred >>

System Condition	Outdoor unit Condition	Trouble Level	
		1	2
		Not indicated on Indoor Unit and Peripheral unit. Indicated on Service Tool.	Indicated on Indoor Unit (*1) and Peripheral unit. Indicated on Service Tool.
① System is not stopped compulsorily Operation continues	Abnormal LED indication Outdoor unit does not stop	- 14.1 Outdoor unit network communication 1 error	- 62.3 Outdoorunit EEPROM access error - 62.8 EEPROM data corrupted error - 73.5 Heat Ex.1 liquid temp. sensor error - 73.7 Heat Ex.2 liquid temp. sensor error - 75.1 Suction gas temp sensor error - 82.2 Sub-cool Heat Ex. gas outlet temp. sensor error - 83.1 Liquid pipe temp. sensor 1 error - 83.2 Liquid pipe temp. sensor 2 error
② System is compulsorily stopped (*4)	Abnormal LED indication Outdoor unit stop	- 67.2 Inverter PCB short interruption detection	- 62.6 Inverter communication error - 63.1 Inverter error - 68.2 Rush current limiting resister temp. rise protection (*3) - 71.1 Discharge Temp sensor 1 error - 72.1 Compressor Temp sensor 1 error - 73.4 Heat Ex. 1 gas temp sensor error - 73.6 Heat Ex. 2 gas temp sensor error - 74.1 Outdoor Temp sensor error - 77.1 Heat sink Temp sensor error - 84.1 Current sensor 1 error (*3) - 86.1 Discharge pressure sensor error - 86.3 Suction pressure sensor error - 86.4 High pressure switch 1 error - 93.1 Inverter compressor start up error (*3) - 94.1 Trip detection (*3) - 95.5 Comp. motor loss of synchronization (*3) - 97.1 Outdoor unit fan motor lock error (*3) - 97.5 Fan motor temperature abnormal (*3) - 97.9 Fan motor driver abnormal (*3) - A1.1 Discharge temperature 1 abnormal (*3) - A3.1 Compressor1 temperature abnormal (*3) - A4.1 High pressure abnormal - A4.2 High pressure protection1 - A6.3 Outdoor Heat Ex. 1 gas temp. abnormal (*3) - A6.4 Outdoor Heat Ex. 2 gas temp. abnormal (*3) - AC.4 Heat sink temperature abnormal
③ System is compulsorily stopped	Abnormal LED indication Outdoor unit stop		- 13.1 Communication error between outdoor unit - 14.2 Outdoor unit network communication 2 error - 14.5 The number of indoor unit shortage (*2) - 61.5 Outdoor unit reverse phase, missing phase wire error - 69.1 Outdoor unit transmission PCB parallel communication error - 9A.1 Coil1 (Expansion valve1) error - 9A.2 Coil2 (Expansion valve2) error - 9A.3 Coil3 (Expansion valve3) error - A5.1 Low pressure abnormal (*3)

(*1) This will not be displayed on indoor unit which Error Report Target (function setting 47 of indoor unit) is set "for administrator".

(*2) The System condition can change to ① (Trouble Level 1) by changing DIP SW (SET 4-1:OFF)

(*3) Even if power is reset, this Error cannot release. In Error release, you need to solving the problem and operate the push switch and a and apply "Error reset" (F3-40) after power restart.

(*4) When one of outdoor unit on the multi connection detects these Error, the backup operation can activate by using of remaining outdoorunit(s)
Please check each trouble shooting, and read the caution before using the backup operation.

<< Error code which manual error release will be required >>

A5.1 Low pressure abnormal
84.1 Current sensor 1 error
93.1 Inverter compressor start up error
94.1 Trip detection
A1.1 Discharge temperature 1 abnormal
A3.1 Compressor 1 temperature abnormal
97.1 Outdoor unit fan motor lock error
97.5 Fan motor temperature abnormal
97.9 Fan motor driver abnormal
68.2 Rush current limiting resister temp rise protection
95.5 Compressor motor loss of synchronization
A6.3 Outdoor heat exchanger 1 gas temperature abnormal
A6.4 Outdoor heat exchanger 2 gas temperature abnormal
A4.1 High pressure Abnormal
86.4 High pressure SW 1 Error


4-2-8 ERROR HISTORY MODE

When the abnormality occurred, the Outdoor unit memorizes the history of error codes up to 10 and it can be displayed on 7 segments LED.


It is an effective means to examine abnormality that occurred in the past.

*The error history can be cleared by setting to F3-30.


Refer to the following for the procedure.




① Change to the Error History Mode from the Mode Selection Display




② Select the Error History Number



③ Check the detail of the Error History



④ End of the Error History mode



4-2-9 TROUBLE SHOOTING WITH ERROR CODE

Trouble shooting 1 INDOOR UNIT Error Method: Wired Remote Controller Communication Error	E12.1	Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. < 1 2 > Error Code : 1 2
---	--------------	--

Detective Actuators: Indoor unit controller PCB circuit Wired Remote Control (3 wire / 2 Wire type)	Detective details: Upon receiving the signal more than 1 time from Wired Remote or other Indoor unit, but the same signal has not been received more than 1 minute (3 Wire type). 2.5 minute (2 Wire type)
--	--

Forecast of Cause :

1. Terminal connection abnormal 2. Wired Remote Control failure 3. Controller PCB failure

Check Point 1 : Check the connection of terminal

After turning off the power, check & correct the followings.

- ☐ Indoor Unit - Check the connection of terminal between remote control and Indoor unit, or between Indoor units, and check if there is a disconnection or short of the cable.



Check Point 2 : Check Remote and Controller PCB

- ☐ Check terminal voltage of controller PCB Connector CNC01. (Power supply for Remote)

If DC12V, Remote Control failure (Controller PCB is OK) >>> Replace Remote controller

If DC0V, Controller PCB failure (Remote is OK) >>> Replace Controller PCB

- In case of re-installation is done due to removed connector or incorrect wiring,
turn on the power again.



Trouble shooting 2 E12.2 INDOOR UNIT Error Method: Wired Remote Controller signal Error	Indicate or Display: Outdoor Unit : E.5 U.1, Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Remote Controller : 1 2
--	--

Detective Actuators: Indoor unit Controller PCB circuit Wired Remote Control (3 wire type)	Detective details: More than 1 time of Token (Communication between wired remote controllers) is received, but it was not received more than 1 minute.
---	--

Forecast of Cause : 1. Terminal connection abnormal 2. Mis-setting 3. Wired Remote Control failure 4. Controller PCB failure

Check Point 1 : Check the connection of terminal
<u>After turning off the power, check & correct the followings.</u> <input type="checkbox"/> Indoor Unit - Check the connection of terminal between remote control and Indoor unit, or between Indoor units, and check if there is a disconnection or short of the cable.



Check Point 2 : Check Remote and Controller PCB
<input type="checkbox"/> Check terminal voltage of Controller PCB Connector CNC01. (Power supply for Remote) If DC12V, Remote Control failure (Controller PCB is OK) >>> Replace Remote If DC0V, Controller PCB failure (Remote is OK) >>> Replace Controller PCB ► In case of re-installation is done due to removed connector or incorrect wiring, turn on the power again.



Trouble shooting 3 E12.3 <u>INDOOR UNIT Error Method:</u> Number excess of device in Wired remote controller system (2 Wires RC)	<u>Indicate or Display:</u> Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 1 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 1 2
--	---

<u>Detective Actuators:</u> Wired remote controller (2-Wire) Indoor unit Controller PCB circuit	<u>Detective details:</u> When the number of connecting Indoor unit and Remote controller in one RCgroup exceeds more than 32 units.
--	--

Forecast of Cause : 1. Wrong wiring of RCgroup 2. Indoor unit controller PCB failure

Check Point 1 : Wire installation Wrong RCgroup setting
<input type="checkbox"/> Wrong wire connection in RCgroup (Please refer to the installation manual) <input type="checkbox"/> The number of connecting indoor unit and Remote controller in one RCgroup were less than 32 units.




Check Point 2 : Check Indoor unit controller PCB
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

Trouble shooting 5 <u>OUTDOOR UNIT Error Method:</u> Outdoor Unit Network Communication 1 Error	E14.1 <u>Indicate or Display:</u> Outdoor Unit : E. 1 4. 1 Indoor Unit : No display / Operation LED 1 times Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. Error Code : 1 4 / 1 6 / 1 4. 1 / 1 4. 3 *
--	--

* Indoor unit indicates No display or 1 4
Peripheral device indicates 1 4 or 16.

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> •DIP-SW SET4-1 is OFF. •No communication for 180 seconds or more from an indoor unit which received communication once and no Outdoor unit network communication 2 error.
---	--

<u>Forecast of Cause :</u>	1. Noise, momentary open, voltage drop 2. Indoor unit power off 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Controller PCB defective
-----------------------------------	---




Trouble shooting 6 OUTDOOR UNIT Error Method : Outdoor Unit Network Communication 2 Error	E14. 2 Indicate or Display: Outdoor Unit : E. 1 4. 2 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. / Operation LED 1 times Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. * Error Code : 9 U / 1 4 / 1 6 / 1 4. 1 / 1 4. 2 / 1 4. 3 *
--	--

* Indoor unit indicates 9 U or 1 4
Peripheral device indicates 1 4 or 1 6

Detective Actuators: Outdoor unit Main PCB	Detective details: [DIP-SW SET4-1 : ON] (Factory setting) •No communication for 180 seconds or more from an indoor unit which received communication once. [DIP-SW SET4-1 : OFF] •No communication for 180 seconds or more from all indoor units that once received communication.
--	---

Forecast of Cause :	1. Noise, momentary open, voltage drop 2. Indoor unit power off 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Control PCB defective
----------------------------	--



Trouble shooting 7 E14. 3 INDOOR UNIT Error Method: Indoor unit Network communication Error	Indicate or Display: Outdoor Unit : E.1 4. 1 / 1 4. 2 * Indoor Unit : Operation LED 1 times Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. Error Code : 1 4 / 1 6 / 9 U / 14.1 / 14.2 / 14.3 *
---	---

* Outdoor unit indicates 1 4.1 or 1 4.2 (No communication from 14.3 Error Indoor unit)
Peripheral device indicates 1 4 or 1 6

Detective Actuators: Indoor unit Controller PCB circuit Indoor unit Communication PCB	Detective details: When the cut-off of network communication is detected (more than 90 seconds passed since the last receipt of Outdoor unit signal).
--	---

Forecast of Cause :

1. Outside cause 2.Connection failure 3. Communication PCB failure 4. Controller PCB failure

Check Point 1 : Check if any outside cause such as voltage drop or noise

- ⚙ Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit.
- ⚙ Momentary power failure ----- Check contact failure or leak current in power supply circuit
>>Check power supply for Outdoor Unit as well.
- ⚙ Check if there is any equipment that causes harmonic wave near the power cable
(Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.
>>If the same symptom does not reappear after resetting the power, possibility of noise is high.



Check Point 2 : Check the connection

After turning off the power, check and correct followings.

- ☐ Is Indoor Communication PCB loose?
- ☐ Check loose or removed connection of communication line Indoor unit => Outdoor unit.
Refer to SERVICE INFORMATION Network communication Abnormal
- ☐ When the signal amplifier is connected , Check the error indication of signal amplifier. (Refer to the installation manual)



Check Point 3 : Check Communication PCB

- ☐ Replace Communication PCB of the Indoor units that have the error.



Check Point 4 : Check Controller PCB

- ☐ Replace controller PCB of the Indoor units that have the error.

Trouble shooting 8 E14. 5 OUTDOOR UNIT Error Method: The number of Indoor unit shortage Error	Indicate or Display: Outdoor Unit : E.1 4. 5 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. / No display (When DIP-SW4-1 is OFF.) Error Code : 9 U / 1 4 / 1 6 / 1 4. 5 / 1 4. 3 *
---	--

***Peripheral device indicates 14,16**

Detective Actuators: Outdoor unit Main PCB	Detective details: When the indoor unit number decreases for 180 seconds from the memorized maximum indoor units number after power(Breaker) ON.
--	--

Forecast of Cause :	1. Indoor unit power off 2. Noise, momentary open, voltage drop 3. Communication line connection defective 4. Terminal resistor setting mistake 5. Communication PCB mounting defective, Communication PCB defective 6. Controller PCB defective
----------------------------	---

Check Point 1 : Find the indoor unit that the communication is lost.
<input type="checkbox"/> Check system drawing and service tool.



Check Point 2 : Check the indoor unit power supply
<input type="checkbox"/> Main power ON check <input type="checkbox"/> Power cable connection and open check



Check Point 2 : Noise, momentary open, voltage drop
<input type="checkbox"/> Check if temporary voltage drop was not generated. <input type="checkbox"/> Check if momentary open was not generated. <input type="checkbox"/> Check if ground is connection correctly or there are no related cables near the power line.



Check Point 3 : Check the communication line connection
<input type="checkbox"/> Communication line connection, open check Refer to SERVICE INFORMATION Network communication Abnormal



Check Point 4 : Check the Terminal resistor setting
<input type="checkbox"/> Terminal resistor setting check



Check Point 5 : Check the communication PCB (indoor unit/ outdoor unit)
<input type="checkbox"/> Communication PCB connection check <input type="checkbox"/> Communication PCB check



Check Point 6 : Replace Main PCB and Communication PCB (indoor unit/ outdoor unit)
<input type="checkbox"/> Change Main PCB and Communication PCB, and set up the original address.

Attention!!

In case of DIP-SW SET4-1 is ON(factory setting), If this error occurs, system stops. In case of DIP-SW SET4-1 is OFF, If this error occurs, system does not stop.

If the failure indoor unit is pinpointed and it needs to erase the error indication, it can be reset by function setting (F3-41: Maximum memorized indoor unit number reset).

Caution!!

Even if normal, this error occurs temporarily by the timing of the power ON of outdoor unit, indoor unit, and signal amplifier.


In this case, please wait for 5 minutes after turning on all the equipments.

Trouble shooting 9 E16. 1 <u>INDOOR UNIT Error Method:</u> Transmission PCB Connection Error	<u>Indicate or Display:</u> Outdoor Unit : E.1 4.1, 1 4.2 * Indoor Unit : Operation LED 1 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash. Error Code : 1 6 *
--	--


* Outdoor unit indicates 1 4.1 or 14.2 (No communication from Indoor unit)
Peripheral device indicates 1 6 (1 6.4 Error)
Service Tool indicates 14.3 (Missing Error Indoor unit)

<u>Detective Actuators:</u> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<u>Detective details:</u> When Parallel communication error (Communication reset occurs continuously more than specified times) is detected.
---	--


<u>Forecast of Cause :</u> 1. Connection failure 2. Outside cause 3. Communication PCB failure 4. Controller PCB failure



Trouble shooting 10 E16. 4 INDOOR UNIT Error Method: Communication Error Between Controller and Indoor unit	Indicate or Display: Outdoor Unit : No Display Indoor Unit : No Display Error Code : 1 6 (Peripheral Unit)
<u>Detective Actuators:</u> Indoor unit Controller PCB circuit Indoor unit Communication PCB	<u>Detective details:</u> When the cut-off of network communication is detected (more than 90 seconds passed since the last receipt of Outdoor unit signal).
<u>Forecast of Cause :</u> 1. Outside cause 2. Connection failure 3. Communication PCB failure 4. Controller PCB failure	



Trouble shooting 11 E26. 4 INDOOR UNIT Error Method: Address Duplication in Wired remote contorller system	Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 2 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash. Error Code : 2 6
Detective Actuators: Wired remote controller (2-Wire) Indoor unit Controller PCB circuit	Detective details: When the duplicated address number exists in one RCgroup
Forecast of Cause : 1. Wrong wiring of RCgroup 2. Wrong remote address setting 3. Indoor unit controller PCB failure 4. Remote controller failure	



Trouble shooting 12 INDOOR UNIT Error Method: Address setting Error in Wired remote controller system	E26. 5 Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 2 times Flash, Timer LED 6 Times Flash, Filter LED Continuous Flash. Error Code : 2 6
--	---

Detective Actuators: Wired remote controller (2-Wire) Indoor unit Controller PCB circuit	Detective details: When the address number set by auto setting and manual setting are mixed in one RC group
---	---

Forecast of Cause : 1. Wrong wiring of RCgroup 2. Wrong remote address setting 3. Indoor unit controller PCB failure 4. Remote controller failure

Check Point 1 : Wire installation
<input type="checkbox"/> Wrong wire connection in RCgroup (Please refer to the installation manual)



Check Point 2 : Wrong RCgroup setting
<input type="checkbox"/> The given address number by auto setting (00) and the manual set number (Except 00) were not existing in one RCG. <input type="checkbox"/> The remote controller address setting by U.I. were not existing same address.



Check Point 3 : Check Indoor unit controller PCB
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

Trouble shooting 13 OUTDOOR UNIT Error Method: Auto Address Setting Error	E28. 1 Indicate or Display: Outdoor Unit : E. 28. 1 Indoor Unit : No Display Error Code : No Display * Service tool does not indicate the Error code
--	---

<< After Indoor unit Auto Address setting >>

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> ▪ When none of the connected indoor units answers during auto address And when abnormal answer signal is input.
---	--

<u>Forecast of Cause :</u>	1. Indoor unit power supply defective 2. Indoor unit overconnected 3.Communication line incorrect connection 4. Noise, momentary open
-----------------------------------	--

Check Point 1 : Check the indoor unit power supply
<input type="checkbox"/> Check the indoor unit power supply



Check Point 2 : Check the indoor unit number connection
<input type="checkbox"/> Check if more than 64 indoor units are connected in a refrigerant circuit



Check Point 3 : Check the communication line connection
Check if communication line is correctly connected
<input type="checkbox"/> Is it uncoupled or cut halfway ? <input type="checkbox"/> Connecting terminal position is correct as the installation manual shows ?




Check Point 4 : Check noise, momentary open, voltage drop
<input type="checkbox"/> Check if power supply temporarily stops by outages or if strong noise is generated from surrounding environment during auto address

Trouble shooting 14 E28. 4 OUTDOOR UNIT Error Method: Signal Amplifier Auto Address Error	Indicate or Display: Outdoor Unit : E. 2 8. 4 Indoor Unit : No Display Error Code : No Display *Service tool does not indicate the Error
---	--

Detective Actuators: Outdoor unit Main PCB	Detective details: ▪ When abnormal answer signal is input during signal amplifier auto address
--	--

Forecast of Cause :	1. Signal amplifier power supply defective 2. Signal amplifier overconnected 3. Signal amplifier auto address wrong setting 4. Noise, momentary open.
----------------------------	--



Trouble shooting 15 E29. 1 <u>INDOOR UNIT Error Method:</u> Connection unit number error (Indoor unit in Wired remote controller system)	Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 2 times Flash, Timer LED 9 Times Flash, Filter LED Continuous Flash. Error Code : 2 9
--	--

Detective Actuators: Wired remote controller (2-Wire) Indoor unit Controller PCB circuit	Detective details: When the number of connecting indoor units are out of specified rule.
---	--

Forecast of Cause : 1. Wrong wiring/ Number of I.U, RC in RCgroup 2. Indoor unit controller PCB defective
--

Check Point 1 : Wire installation
<input type="checkbox"/> Wrong number of connecting indoor unit



Check Point 2 : Check Indoor unit controller PCB
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address

Trouble shooting 16 INDOOR UNIT Error Method: Connection unit number error (Remote controller)	E29. 2 Indicate or Display: Outdoor Unit : No Display Indoor Unit : No Display Error Code : 2 9
---	--

Detective Actuators: Wired remote controller (2-Wire)	Detective details: When the number of connecting remote controller are out of specified rule.
---	---


Forecast of Cause : 1. Wrong wiring / Wrong number of connecting RC in RCgroup 2. Remote controller PCB defective
--

Check Point 1 : Wire installation
<input type="checkbox"/> Wrong number of connecting remote controller



Check Point 2 : Check Indoor unit controller PCB
<input type="checkbox"/> Check if controller PCB damage <input type="checkbox"/> Change controller PCB and check the Error after setting remote controller address


Trouble shooting 18 E32. 1 <u>INDOOR UNIT Error Method:</u> Indoor unit PCB Model Information Error	<u>Indicate or Display:</u> Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 3 2
<u>Detective Actuators:</u> Indoor Unit Controller PCB Circuit	<u>Detective details:</u> 3 continuous failure of lead test of EEPROM at Power ON, or Apparent Model information error from EEPROM. Also, Error on Model information upon model information test of EEPROM, or Model information of EEPROM not possible to recover.
<u>Forecast of Cause :</u> 1. Outside cause 2. Connection failure of electric components 3. Controller PCB defective	




Note : EEPROM

EEPROM(Electronically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it can not change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.

Trouble shooting 19 E32. 3 INDOOR UNIT Error Method: Indoor unit EEPROM Access Error	Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 3 2
Detective Actuators: Indoor Unit Controller PCB Circuit	Detective details: When 3 continuous failure occurred on lead test of EEPROM.
Forecast of Cause : 1. Outside cause 2. Defective connection of electric component 3. Controller PCB defective	



Trouble shooting 19-1 INDOOR UNIT Error Method: Indoor unit microcomputer self-check error	E32. 7 Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 3 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 3 2
Detective Actuators: Indoor Unit Controller PCB Circuit	Detective details: When the error is detected by the self-diagnosis of a microcomputer
Forecast of Cause : 1. Outside cause 2. Defective connection of electric component 3. Controller PCB defective	



Trouble shooting 20 INDOOR UNIT Error Method: Indoor unit communication circuit (WRC) microcomputers communication Error	E3A. 1 Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 3 times Flash, Timer LED 10 Times Flash, Filter LED Continuous Flash. Error Code : 3 A
---	--

Detective Actuators: Wired remote controller (2-Wire) Indoor unit Controller PCB circuit	Detective details: When the indoor unit(s) detects the configuration of RCG abnormal or the indoor unit detects lack of primary -remote controller.
---	---

Forecast of Cause : 1. Terminal connection abnormal 3. Indoor unit controller PCB defective	2. Wired remote controller failure
---	------------------------------------

Check Point 1 : Check the connection of terminal
After turning off the power supply, check & correct the followings <input type="checkbox"/> Indoor unit - Check the connection of terminal between remote control and indoor unit, or between Indoor units and check if there is a disconnection or short of the cable.





Check Point 2 , 3: Check Indoor unit controller PCB
<input type="checkbox"/> Check terminal voltage of controller PCB connector CNC01 (Power supply for remote) If DC12V, Remote control failure (Controller PCB is OK) >>> Replace Remote controller If DC0V, Controller PCB failure (Remote is OK) >>> Replace Controller PCB In case of re-installation is done due to removed connector or incorrect wiring, turn on the power again.

Trouble shooting 24 E51. 2 INDOOR UNIT Error Method: Indoor Unit Fan Motor 1 rotation speed Error	Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 5 times Flash, Timer LED 1 Times Flash, Filter LED Continuous Flash. Error Code : 5 1
---	--

Detective Actuators: Indoor Unit Controller PCB Circuit Indoor Fan Motor	Detective details: When the FAN motor feed back rotation value which is detecting on the controller PCB becomes 0 and lasts for more than 1 minute at motor operation condition. Or, when the feed back rotation value continues at 1/ 3 of target value for more than 1 minute.
---	---

Forecast of Cause :	1. Fan rotation failure 2. Fan motor winding open 3. Motor protection by ambient temp. increase 4. Capacitor failure 5. Controller PCB failure
----------------------------	--




* Applicable indoor unit:
 - ARXA, ARXB, ARXC type

Trouble shooting 25 E52. 1 INDOOR UNIT Error Method: Coil 1 (Expansion valve) Error	Indicate or Display: Outdoor Unit : E.5U.1 Indoor Unit : Operation LED 5 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 5 2
--	---

Detective Actuators: Indoor unit controller PCB	Detective details: When the EEV1 drive circuit is open circuit
---	--

Forecast of Cause : 1. EEV1 coil lose connection 2. EEV1 wire(s) cut or pinched 3. Defective EEV1 coil 4. Controller PCB (DC 12V) output abnormal 5. Noise momentary open, voltage drop
--



Trouble shooting 26 INDOOR UNIT Error Method: Indoor unit Drain pump Error	E53. 1 Indicate or Display: Outdoor Unit : E.5 U.1 Indoor Unit : Operation LED 5 times Flash, Timer LED 3 Times Flash, Filter LED Continuous Flash. Error Code : 5 3
---	---

<u>Detective Actuators:</u> Indoor Unit Controller PCB Circuit Float Switch	<u>Detective details:</u> When Float switch is ON for more than 3 minutes.
--	--


<u>Forecast of Cause :</u> <div style="display: flex; justify-content: space-between; padding: 0 10px;"> <div>1. Drain Installation</div> <div>2. Drain pipe line blockage</div> <div>3. Float switch defective</div> </div> <div style="display: flex; justify-content: space-between; padding: 0 10px;"> <div>4. Shorted connector/wire</div> <div>5. Controller PCB defective / Drain pump defective</div> </div>

Check Point 1 : Check Drain pipe installation
<input type="checkbox"/> Check Drain pipe installation (Refer to the installaion manual) The Height limit for Drain pump, The angle of drain pipe, The angle of indoor unit



Check Point 2 : Check Drain pipe blockage
<input type="checkbox"/> Check Drain pipe line blockage The drain pump inlet and outlet, The connecting pipe, The drain pipe outlet



Check Point 3, 4 : Check Float Switch operation, connecting wire shorted.
<input type="checkbox"/> Check operation of float switch. Remove Float switch and check ON/OFF switching operationby using a meter. >>If Float switch is defective, replace it. <div style="display: flex; align-items: center; justify-content: center; margin-top: 20px;">  </div>




Check Point 5 : Check controller PCB defective / Drain pump defective
<input type="checkbox"/> Measure power supply (AC198 - 264V) for the drain pump on the Power supply PCB (CN106) at the Float SW ON states. >>If No voltage on the connector, replace the power supply PCB >>If AC198- 264V on the connector, replace the Drain pump

Trouble shooting 27 E61. 2 OUTDOOR UNIT Error Method: Outdoor Unit under voltage Error	Indicate or Display: Outdoor Unit : E. 6 1. 2 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 1
--	---

Detective Actuators: Outdoor unit Filter PCB (MAIN) Outdoor unit Main PCB	Detective details: ▪ When Main PCB input voltage has detected lower than AC 174.1V.
--	---


Forecast of Cause :	1. Noise, momentary open, voltage drop 2. Power supply defective 3. Filter PCB (Main) defective 4. Main PCB defective
----------------------------	--



Trouble shooting 27-1 E61. 5 <u>OUTDOOR UNIT Error Method:</u> Outdoor Unit Reverse Phase, Missing Phase Wire Error	<u>Indicate or Display:</u> Outdoor Unit : E. 6 1. 5 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 1
---	--

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> <ul style="list-style-type: none"> ▪ Reverse phase prevention circuit detected reversed phase input or input was not normal at the time of power ON. ▪ Reverse phase prevention circuit detected open-phase after power ON.
---	--


<u>Forecast of Cause :</u>	1. Noise, momentary open, voltage drop 2. Power supply defective 3. Filter PCB (Main) defective 4. Main PCB defective
-----------------------------------	--



Trouble shooting 28 E62. 3 OUTDOOR UNIT Error Method: Outdoor Unit EEPROM Access Error	Indicate or Display: Outdoor Unit : E. 6 2. 3 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 2
--	---

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> •Access to EEPROM failed due to some cause after outdoor unit started.
---	--


<u>Forecast of Cause :</u> 1. Noise, momentary open, voltage drop 2. Main PCB defective
--



Trouble shooting 29 OUTDOOR UNIT Error Method: Inverters Communication Error	E62. 6 Indicate or Display: Outdoor Unit : E. 6 2. 6 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 2
---	--

Detective Actuators: Outdoor unit Main PCB	Detective details: •Communication not received from Inverter PCB for 10 seconds or more
--	---

Forecast of Cause :	1. Noise 2. Main PCB to Inverter PCB wiring connection defective 3. Main PCB defective 4. Inverter PCB defective
----------------------------	---



Caution

By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)

The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)


- The operating compressor life time becomes shorter.
- The operating performance may drop due to the limited active compressor(s).
- The compressor may stop frequently by protection controlling.

*In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 30 OUTDOOR UNIT Error Method: EEPROM data corrupted error	E62. 8 Indicate or Display: Outdoor Unit : E. 6 2. 8 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 2
---	--

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> <ul style="list-style-type: none"> ▪ Set contents sum value memorized in EEPROM and sum value calculated based on the set contents read from EEPROM do not match * Regarding the sum value, only the contents set in the push button SW setting mode (F2) shall be the objective.
---	---


<u>Forecast of Cause :</u> 1. Noise, momentary open, voltage drop 2. Main PCB defective
--



Trouble shooting 30-1 E62. 9 <u>OUTDOOR UNIT Error Method:</u> Outdoor unit microcomputer self-check error	<u>Indicate or Display:</u> Outdoor Unit : E. 6 2. 9 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 2
--	--

<u>Detective Actuators:</u> Outdoor unit Main PCB	<u>Detective details:</u> When the error is detected by the self-diagnosis of a microcomputer
---	---


<u>Forecast of Cause :</u> 1. Noise, momentary open, voltage drop 2. Defective connection of electric component 3. Main PCB defective



Trouble shooting 31 E63. 1 OUTDOOR UNIT Error Method: Inverter Error	Indicate or Display: Outdoor Unit : E. 6 3. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 3
--	---

Detective Actuators: Inverter PCB	Detective details: <ul style="list-style-type: none"> ▪ Error information received from Inverter PCB. ▪ When "Inverter PCB short interruption detection" or "Rush current limiting resistor temp. rise protection" occurs, Inverter error also occurs.
---	---

Forecast of Cause :	1. Noise, momentary open, voltage drop. 2. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 3. Main PCB to Inverter PCB wiring disconnection, open 4. Magnetic Relay (for inverter) coil side wiring disconnection, open 5. Magnetic Relay activation circuit defective 6. Main PCB or Filter PCB (INV) or Inverter PCB defective 7. Cement Resistor Open circuit
----------------------------	--




Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 32 E67. 2 OUTDOOR UNIT Error Method: Inverter PCB short interruption Error	Indicate or Display: Outdoor Unit : E. 6 7. 2 Indoor Unit : No Display Error Code : No display
---	---

<u>Detective Actuators:</u> Inverter PCB	<u>Detective details:</u> <ul style="list-style-type: none"> • "Short interruption" received from Inverter PCB
--	---


<u>Forecast of Cause :</u>	1. Noise, momentary power failure, voltage drop 2. Magnetic Relay (for Inverter) coil side wiring disconnection, open 3. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 4. Main PCB defective 5. Inverter PCB defective
-----------------------------------	--



Trouble shooting 33 OUTDOOR UNIT Error Method: Rush Current Limiting Resistor Temp Rise Protection	E68. 2 Indicate or Display: Outdoor Unit : E. 6 8. 2 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 8
---	--

<u>Detective Actuators:</u> Inverter PCB	<u>Detective details:</u> ▪ "Protection stop by "Rush current limiting resistor temperature rise detection" of inverter PCB" was generated 2 times.
--	---

<u>Forecast of Cause :</u>	1. Magnetic relay (for INV) coil side wiring disconnection, open 2. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 3. Magnetic relay activation circuit defective 4. Main PCB to Inverter PCB wiring disconnection, open 5. Main PCB output AC198 - 242V on CN130 defective Main PCB defective (output AC198 - 242V on CN130 for Magnetic relay (INV) defective)
-----------------------------------	--




After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset
Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 34 E69. 1 OUTDOOR UNIT Error Method: Outdoor Unit Transmission PCB Parallel Communication Error	Indicate or Display: Outdoor Unit : E. 6 9. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. / Operation LED 1 time Flash, Timer LED 4 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 6 9 / 1 4 / 14.1 / 14.3*
--	--

*When this error occurs on the Slave outdoor unit, Error code 69.1 is transferred to each device on the network.
When this error occurs on the Master outdoor unit, the indoor unit on the network indicates 14 (14.3 No communication from Outdoor unit), and Service tool indicates 14.1 (Outdoor unit Network communication Error).

Detective Actuators: Outdoor unit Main PCB	Detective details: ▪When Parallel communication error (Communication reset occurs continuously more than specified times) is detected.
--	--

Forecast of Cause :	1. Noise 2. Communication PCB connection defective 3. Communication PCB defective 4. Main PCB defective
----------------------------	--



Trouble shooting 35 E71. 1 OUTDOOR UNIT Error Method: Discharge Temp. Sensor 1 Error	Indicate or Display: Outdoor Unit : E. 7 1. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 1
--	---

Detective Actuators: Discharge temp. sensor 1	Detective details: <ul style="list-style-type: none"> • Discharge temp. sensor 1 short detected • Discharge temp. sensor 1 open detected after compressor 1 operated continuously for 5 minutes or more
---	--



Forecast of Cause : <ul style="list-style-type: none"> 1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
--

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN162: 1-2) voltage value = 5V Remove the sensor from Main PCB, check the voltage.
<div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 0.5; text-align: center;">  </div> </div>
Discharge temp. sensor 1 (CN162: 1-2) ► If the voltage does not appear, replace Main PCB and set up original address.

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) <ul style="list-style-type: none"> - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 36 E72. 1 OUTDOOR UNIT Error Method: Compressor Temp Sensor 1 Error	Indicate or Display: Outdoor Unit : E. 7 2. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 2
--	---

Detective Actuators: Compressor temp. sensor 1	Detective details: <ul style="list-style-type: none"> Compressor temp. sensor 1 short detected Compressor temp. sensor 1 open detected after compressor 1 operated continuously for 5 minutes or more
--	---

Forecast of Cause :	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Thermistor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN162: 3-4) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> </div> <div style="flex: 0.5; text-align: center;"> </div> </div> <p>Compressor temp. sensor 1 (CN162: 3-4)</p> <p>► <u>If the voltage does not appear, replace Main PCB and set up original address.</u></p>

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 37 E73.4 OUTDOOR UNIT Error Method: Heat Ex.1 Gas Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 3. 4 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 3
--	---

<u>Detective Actuators:</u> Heat ex.1 gas temp. sensor	<u>Detective details:</u> • Heat ex.1 gas temp. sensor short or open detected
--	---

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN163: 3-4) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> </div> <div> </div> </div> <p>Heat ex.1 gas temp. sensor (CN163: 3-4)</p> <p>► <u>If the voltage does not appear, replace Main PCB and set up original address.</u></p>

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 38 E 73. 5 OUTDOOR UNIT Error Method: Heat Ex.1 Liquid Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 3. 5 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 3
---	---

<u>Detective Actuators:</u> Heat ex.1 liquid temp. sensor	<u>Detective details:</u> • Heat ex.1 liquid temp. sensor short or open detected
---	--

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)

- ❑ Main PCB (CN163: 1-2) voltage value = 5V
Remove the sensor from Main PCB, check the voltage.

CN163	1	1	BLACK		THERMISTOR (HEX. LIQ.1)
	2	2	BLACK		
	3	3	BLACK		THERMISTOR (HEX. GAS.1)
	4	4	BLACK		
	5	5			
	6	6			

Heat ex.1 liquid temp. sensor (CN163: 1-2)

- ▶ If the voltage does not appear, replace Main PCB and set up original address.

Trouble shooting 39 E73. 6 OUTDOOR UNIT Error Method: Heat Ex.2 Gas Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 3. 6 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 3
--	---

<u>Detective Actuators:</u> Heat ex.2 gas temp. sensor	<u>Detective details:</u> • Heat ex.2 gas temp. sensor short or open detected
--	---

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)

- Main PCB (CN164: 3-4) voltage value = 5V
Remove the sensor from Main PCB, check the voltage.

The diagram shows a 7-pin connector labeled CN164. The pins are numbered 1 through 7. Pins 1 and 2 are labeled 'BLACK'. Pins 3 and 4 are labeled 'BLACK'. Pins 5, 6, and 7 are labeled 'THERMISTOR (HEX. GAS.2)'. The diagram also shows two thermistors connected to pins 3 and 4. One thermistor is labeled 'THERMISTOR (HEX. LIQ.2)' and the other is labeled 'THERMISTOR (HEX. GAS.2)'. The thermistors are represented by a rectangle with a diagonal line and a small circle at the end.

A symbol for DC voltage, consisting of a rectangle with 'DC' inside, and a circle with a diagonal line and two small circles below it.

Heat ex.2 gas temp. sensor (CN164: 3-4)

- If the voltage does not appear, replace Main PCB and set up original address.**

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 40 E73. 7 <u>OUTDOOR UNIT Error Method:</u> Heat Ex.2 Liquid Temp Sensor Error	<u>Indicate or Display:</u> Outdoor Unit : E. 7 3. 7 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 3
--	--

<u>Detective Actuators:</u> Heat ex.2 liquid temp. sensor	<u>Detective details:</u> • Heat ex.2 liquid temp. sensor short or open detected
---	--

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN164: 1-2) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <div style="display: flex; align-items: center;"> <div style="border-right: 1px solid black; padding-right: 5px; text-align: center;"> 1 2 3 4 5 6 7 </div> <div style="padding-left: 5px;"> 1 2 3 4 5 6 7 </div> </div> <div style="margin-top: 5px;"> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> BLACK </div> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> BLACK </div> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> BLACK </div> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> BLACK </div> </div> <div style="margin-top: 5px;"> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> THERMISTOR (HEX. LIQ.2) </div> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> THERMISTOR (HEX. GAS.2) </div> </div> </div> </div> <div style="margin-left: 20px;"> <div style="border: 1px solid black; padding: 5px; text-align: center; width: 50px;"> DC </div> </div>

Heat ex.2 liquid temp. sensor (CN164: 1-2)
► If the voltage does not appear, replace Main PCB and set up original address.

Trouble shooting 41 E74. 1 OUTDOOR UNIT Error Method: Outdoor Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 4. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 4
---	---

<u>Detective Actuators:</u> Outdoor temp. sensor	<u>Detective details:</u> • Outdoor temp. sensor short or open detected
--	---

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2: Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN144:1-3) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <div style="display: flex; align-items: center;"> <div style="text-align: center;"> 1 1 2 2 3 3 </div> <div style="margin-left: 10px;"> THERMISTOR (OUT TEMP.) </div> </div> </div> <div style="text-align: center;"> </div> </div>
Outdoor temp. sensor (CN144:1-3)
► <u>If the voltage does not appear, replace Main PCB and set up original address.</u>

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 42 E75. 1 OUTDOOR UNIT Error Method: Suction Gas Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 5. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 5
---	---

<u>Detective Actuators:</u> Suction gas temp. sensor	<u>Detective details:</u> • Suction gas temp. sensor short or open detected
--	---



<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN165:1-3) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <div style="display: flex; align-items: center;"> <div style="text-align: center;"> 1 1 2 2 3 3 </div> <div style="margin-left: 5px;"> BLACK THERMISTOR (SUC. TEMP.) BLACK </div> </div>  </div> <div style="text-align: center;">  </div> </div> <p>Suction gas temp. sensor (CN165:1-3)</p> <p>► <u>If the voltage does not appear, replace Main PCB and set up original address.</u></p>

Trouble shooting 43 E77. 1 OUTDOOR UNIT Error Method: Heat Sink Temp Sensor Error	Indicate or Display: Outdoor Unit : E. 7 7. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 7 7
---	---

<u>Detective Actuators:</u> Heat sink temp. sensor	<u>Detective details:</u> • Heat sink temp. sensor open/short detected
--	--

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Inverter PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Inverter PCB (DC5.0V)

- ❑ Inverter PCB (CN360: 1-2) voltage value = 5V

Remove the sensor from Inverter PCB, check the voltage.

The diagram shows a 2-pin connector labeled CN360. The pins are numbered 1 and 2. Pin 1 is connected to a wire labeled 'BLACK'. Pin 2 is connected to a wire labeled 'BLACK'. A thermistor sensor, labeled 'THERMISTOR (HEATSINK)', is shown connected to the 'BLACK' wire from pin 2. The sensor is depicted as a small rectangular component with a diagonal line and a 'u' symbol, indicating it is a thermistor.

A square icon containing the letters 'DC' in a bold, sans-serif font. Below the 'DC' text is a circle with a diagonal line through it, and two small circles to the right, representing a standard DC voltage symbol.

Heat sink temp. sensor (CN360: 1-2)

- If the voltage does not appear, replace Inverter PCB.

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 44 OUTDOOR UNIT Error Method: Sub-cool Heat EX. Gas outlet Temp Sensor Error	E82. 2 Indicate or Display: Outdoor Unit : E. 8 2. 2 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 2
--	--

<u>Detective Actuators:</u> Sub-cooling heat ex. gas outlet temp. sensor	<u>Detective details:</u> • Sub-cooling heat ex. gas outlet temp. sensor short or open detected.
--	--

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN142: 7-8) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> </div> <div> </div> </div>
Sub-cooling heat ex. gas outlet temp. sensor (CN142: 7-8) ► If the voltage does not appear, replace Main PCB and set up original address.

Trouble shooting 45 OUTDOOR UNIT Error Method: Liquid Pipe Temp. Sensor 1 Error	E83. 1 Indicate or Display: Outdoor Unit : E. 8 3. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 3
--	--

<u>Detective Actuators:</u> Liquid pipe temp. sensor 1	<u>Detective details:</u> • Liquid pipe temp. sensor 1 short or open detected
--	---

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN142: 1-2) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> </div> <div> </div> </div>
Liquid pipe temp. sensor 1 (CN142: 1-2) ► If the voltage does not appear, replace Main PCB and set up original address.

Trouble shooting 46 OUTDOOR UNIT Error Method: Liquid Pipe Temp. Sensor 2 Error	E83. 2 Indicate or Display: Outdoor Unit : E. 8 3. 2 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 3
--	--

<u>Detective Actuators:</u> Liquid pipe temp. sensor 2	<u>Detective details:</u> • Liquid pipe temp. sensor 2 short or open detected
--	---

<u>Forecast of Cause :</u>	1. Connector connection defective, open 2. Sensor defective 3. Main PCB defective
-----------------------------------	---

Check Point 1 : Check the connector connection and cable open
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the sensor
<input type="checkbox"/> Sensor characteristics check (Disconnect the sensor from the PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".




Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN142: 3-4) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> </div> <div> </div> </div>
Liquid pipe temp. sensor 2 (CN142: 3-4) ► If the voltage does not appear, replace Main PCB and set up original address.

Trouble shooting 47 E84. 1 OUTDOOR UNIT Error Method: Current Sensor 1 abnormal	Indicate or Display: Outdoor Unit : E. 8 4. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 4
---	---

<u>Detective Actuators:</u> Judgment from value sensed by current sensor 1 (current sensor for inverter) * Current sensor 1 is mounted on Filter PCB(INV)	<u>Detective details:</u> <ul style="list-style-type: none"> • "Protection stop by "inverter speed ≥ 20rps and sensor value 0A continued for 1 min"" was generated 2 times • Sensor value while inverter stopped = maximum was detected
--	---

<u>Forecast of Cause :</u>	1. Power supply defective 2. Power cable disconnection , open 3. Filter PCB (INV) to Inverter PCB CT system wiring connector disconnection, open 4. Power supply to Filter PCB (INV) to Inverter PCB wiring disconnection, open 5. Filter PCB(INV) defective (Power supply section, current sensor section) 6. Inverter PCB defective
-----------------------------------	--



After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution
By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)
The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)

- The operating compressor life time becomes shorter.
- The operating performance may drop due to the limited active compressor(s).
- The compressor may stop frequently by protection controlling.

*In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 48 OUTDOOR UNIT Error Method: Discharge Pressure Sensor Error	E86. 1 Indicate or Display: Outdoor Unit : E. 8 6. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 6
---	--

Detective Actuators: Discharge pressure sensor	Detective details: <ul style="list-style-type: none"> When any of the following conditions is satisfied, a discharge pressure sensor error is generated. <ol style="list-style-type: none"> 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value < 0.3V continued for 30 seconds or more 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value \geq 5.0V was detected.
--	---

Forecast of Cause : <ol style="list-style-type: none"> Discharge pressure sensor connector disconnection, open Discharge pressure sensor defective Main PCB defective

Check Point 1 : Check the discharge pressure sensor connection state <input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the discharge pressure sensor <input type="checkbox"/> Sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to the "Service Parts Information 22".



Check Point 3 : Check voltage of Main PCB (DC5.0V) <input type="checkbox"/> Main PCB (CN118:1-3) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u> <div data-bbox="165 1368 761 1805" data-label="Diagram"> </div> <p>Discharge pressure sensor (CN118:1-3)</p> <p>► If the voltage does not appear, replace Main PCB and set up original address.</p>	
---	--

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) <ul style="list-style-type: none"> - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 49 OUTDOOR UNIT Error Method: Suction Pressure Sensor Error	E86. 3 Indicate or Display: Outdoor Unit : E. 8 6. 3 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 6
---	--

Detective Actuators: Suction pressure sensor	Detective details: <ul style="list-style-type: none"> When any of the following conditions is satisfied, a suction pressure sensor error is generated. <ol style="list-style-type: none"> 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value < 0.06V continued for 30 seconds or more. 30 seconds or more have elapsed since the outdoor unit power was turned on and pressure sensor detected value \geq 5.0V was detected.
--	--



Forecast of Cause :	1. Suction pressure sensor connector disconnection, open 2. Suction pressure sensor defective 3. Main PCB defective
----------------------------	---

Check Point 1 : Check the suction pressure sensor connection state
<input type="checkbox"/> Connector connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the suction pressure sensor
<input type="checkbox"/> Sensor characteristics check * For the characteristics of the suction pressure sensor, refer to the "Service Parts Information 22".




Check Point 3 : Check voltage of Main PCB (DC5.0V)
<input type="checkbox"/> Main PCB (CN119:1-3) voltage value = 5V <u>Remove the sensor from Main PCB, check the voltage.</u>
<div style="display: flex; align-items: center;"> <div style="flex: 1;">  <p style="text-align: center;">CN119</p> </div> <div style="flex: 0.5; text-align: center;">  </div> </div> <p style="text-align: center;">Suction pressure sensor (CN119:1-3)</p> <p>► If the voltage does not appear, replace Main PCB and set up original address.</p>

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) <ul style="list-style-type: none"> - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 50 OUTDOOR UNIT Error Method: High Pressure Switch 1 Error	E86. 4 Indicate or Display: Outdoor Unit : E. 8 6. 4 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 8 6
--	--

<u>Detective Actuators:</u> High pressure switch 1	<u>Detective details:</u> • When the power was turned on, "high pressure switch 1: open" was detected.
--	--

<u>Forecast of Cause :</u>	1. High pressure switch 1 connector disconnection, open 2. High pressure switch 1 characteristics defective 3. Main PCB defective
-----------------------------------	---



Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 51 E93. 1 OUTDOOR UNIT Error Method: Inverter Compressor Start UP Error	Indicate or Display: Outdoor Unit : E. 9 3. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 3
--	---

<u>Detective Actuators:</u> Inverter PCB	<u>Detective details:</u> <ul style="list-style-type: none"> ▪ "Protection stop by "overcurrent generation at inverter compressor starting" ⇒ restart" generated consecutively 60 times x 2 sets (total 120 times) * The shortest time up to error generation is about 130 minutes * Restart is not performed if an indoor unit in the same refrigerant system is not turned ON by thermostat. * After the end of the 1st set, the 2nd set is not started if all the compressors in the same refrigerant system are not temporarily stopped.
--	---

<u>Forecast of Cause :</u>	1. Inverter PCB to inverter compressor wiring disconnection, open 2. Inverter PCB defective 3. Inverter compressor defective (lock, winding short)
-----------------------------------	--

Check Point 1 : Check the Inverter PCB to inverter compressor connection state
<input type="checkbox"/> Wiring connection state check <input type="checkbox"/> Cable open check



Check Point 2 : Check the Inverter PCB
<input type="checkbox"/> Inverter PCB check (Refer to Service Parts Information 4)



Check Point 3 : Replace the Inverter compressor
<input type="checkbox"/> Inverter compressor replacement


After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 52 OUTDOOR UNIT Error Method: Trip Detection	E94. 1 Indicate or Display: Outdoor Unit : E. 9 4. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 4
--	--

<u>Detective Actuators:</u> Inverter PCB	<u>Detective details:</u> <ul style="list-style-type: none"> ▪ "Protection stop by "overcurrent generation after inverter compressor start processing completed"" generated consecutively 5 times. * The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.
--	---

<u>Forecast of Cause :</u>	1. Outdoor unit fan operation defective, foreign matter on hear exchanger, excessive rise of ambient temperature 2. Inverter PCB defective 3. Inverter compressor defective (lock, winding short)
-----------------------------------	---




After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset
--

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 53 OUTDOOR UNIT Error Method: Compressor Motor Loss of Synchronization	E95. 5 Indicate or Display: Outdoor Unit : E. 9 5. 5 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 5
--	--

<u>Detective Actuators:</u> Inverter PCB	<u>Detective details:</u> <ul style="list-style-type: none"> ▪ "Protection stop by "loss of synchronization detection"" generated consecutively 5 times * The number of generations is reset if protection stop is not generated again within 40 seconds after restarting.
--	--

<u>Forecast of Cause :</u>	1. Inverter PCB defective 2. Inverter compressor defective (lock)
-----------------------------------	--



After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 54 E97. 1 OUTDOOR UNIT Error Method: Outdoor Unit Fan Motor Lock Error	Indicate or Display: Outdoor Unit : E. 9 7. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 7
---	---

Detective Actuators: Outdoor unit fan motor	Detective details: 1. When outdoor fan rotation speed is less than 100rpm in 20 seconds after fan motor starts, fan motor and compressor stops. 2. After fan motor restarts, if the same operation is repeated consecutively 4 times, fan motor and compressor stops permanently.
---	--

Forecast of Cause :	1. Rotation obstruction by foreign matter 2. Main PCB to Driver PCB to Fan motor wiring, disconnection, open 3. Fan motor defective (winding open, lock) 4. Driver PCB defective 5. Main PCB defective
----------------------------	--

Check Point 1 : Fan rotation state check
<input type="checkbox"/> Check for the absence of foreign matter around the fan.



Check Point 2 : Main PCB to Driver PCB to Fan motor wiring connection state
<input type="checkbox"/> Connector and wiring connection state check. <input type="checkbox"/> Check blown fuse of DC FAN motor (5A FUSE) <input type="checkbox"/> Cable open check. (Refer to the service parts information 5)



Check Point 3 : Fan motor defective
<input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor winding resistance check <input type="checkbox"/> Motor operation check. (Refer to the service parts information 21)



Check Point 4 : Replace Driver PCB
<input type="checkbox"/> Check the appearance of Driver PCB. <input type="checkbox"/> Change Driver PCB and release the error. Check if the error reoccurs on a test run.



Check Point 5 : Replace Main PCB
<input type="checkbox"/> Change Main PCB and release the error. Check if the error reoccurs on a test run. >> If it is abnormal, replace Main PCB. (When Main PCB is replaced, set up the original setting by Rotary, Dip, and Push SW)


After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset
--

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 55 E97. 5 OUTDOOR UNIT Error Method: Outdoor Unit Fan Motor Temp. Abnormal	Indicate or Display: Outdoor Unit : E. 9 7. 5 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 7
--	---

<u>Detective Actuators:</u> Driver PCB	<u>Detective details:</u> 1. When outdoor fan motor cannot operate more than 470rpm, fan motor and compressor stops. 2. After fan motor restarts, if fan motor cannot operate at 470rpm or more, or the same operation is repeated consecutively 3 times within 60 minutes, fan motor and compressor stops permanently.
--	--

<u>Forecast of Cause :</u> <ol style="list-style-type: none"> 1. Rotation obstructed by foreign matter 2. Ventilation obstructed by heat exchange foreign matter 3. Excessive ambient temperature rise 4. Static pressure setting incorrect, specified static pressure value exceeded 5. Driver PCB defective



After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution
By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)
The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)
- The operating compressor life time becomes shorter.
- The operating performance may drop due to the limited active compressor(s).
- The compressor may stop frequently by protection controlling.
*In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 56 OUTDOOR UNIT Error Method: Outdoor Unit Fan Motor Driver Abnormal	E97. 9	Indicate or Display: Outdoor Unit : E. 9 7. 9 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 7
--	---------------	---

<u>Detective Actuators:</u> Driver PCB Fan motor Main PCB	<u>Detective details:</u> When Driver PCB detects the following abnormalities, the error signal is output. ▪ Driver PCB defective ▪ Fan motor defective (Layer short) ▪ Main PCB defective (DC output abnormal) ▪ Lose connection or disconnecting wire
---	---

<u>Forecast of Cause :</u>	1. Driver PCB defective 2. Fan motor defective 3. Main PCB defective 4. Lose connection or disconnecting wire
-----------------------------------	--

Check Point 1 : Check the wiring connection
<input type="checkbox"/> Check Fan motor to Driver PCB wiring connector disconnection, open <input type="checkbox"/> Check blown fuse of DC FAN motor (5A FUSE) <input type="checkbox"/> Check Driver PCB to Capacitor wiring connector disconnection, open <input type="checkbox"/> Check Main PCB to Driver PCB wiring connector disconnection, open



Check Point 2 : Check DC input power of Driver PCB
<input type="checkbox"/> Check the DC voltage of CN759 is within 15V± 10%. Refer to the service parts info 5 >> If it is abnormal, replace Main PCB. (When Main PCB is replaced, set up the original setting by Rotary, Dip, and Push SW)



Check Point 3 : Replace Driver PCB
<input type="checkbox"/> Check the appearance and condition of mounting of Driver PCB. <input type="checkbox"/> Change Driver PCB and release the error. Check if the error reoccurs on a test run.



Check Point 4 : Replace Fan motor
<input type="checkbox"/> Check the winding resistance of Fan motor. <input type="checkbox"/> Change Fan motor and check if the error reoccurs on a test run.


After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 57 E9A.1 OUTDOOR UNIT Error Method: Coil 1 (EEV) Error	Indicate or Display: Outdoor Unit : E. 9 A. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 A
---	---

<u>Detective Actuators:</u> Main PCB	<u>Detective details:</u> Coil 1(Expansion valve 1) driver circuit open detected.
--	---


<u>Forecast of Cause :</u> 1. EEV1 coil loose connection 2. EEV1 wires cut or pinched. 3. Defective EEV1 coil 4. Main PCB (DC12V) output abnormal



Trouble shooting 59 OUTDOOR UNIT Error Method: Coil 3 (EEV) Error	E9A.3 Indicate or Display: Outdoor Unit : E. 9 A. 3 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / 9 A
--	---

<u>Detective Actuators:</u> Main PCB	<u>Detective details:</u> Coil 3(Expansion valve 3) driver circuit open detected.
--	---

<u>Forecast of Cause :</u> 1. EEV3 coil loose connection 2. EEV3 wires cut or pinched. 3. Defective EEV3 coil 4. Main PCB (DC12V) output abnormal



Trouble shooting 61 EA1. 1 OUTDOOR UNIT Error Method: Discharge Temperature 1 Abnormal	Indicate or Display: Outdoor Unit : E. A 1. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A 1
---	---

Detective Actuators: Discharge temp. sensor 1	Detective details: ▪ "Protection stop by "discharge temp. 1 $\geq 115^{\circ}\text{C}$ (239°F) during compressor 1 operation"" generated 2 times within 40 minutes.
---	---

Forecast of Cause : <ol style="list-style-type: none"> 1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Discharge temp. sensor 1 defective 5. Insufficient refrigerant

<Cooling operation>

Check Point 1 : Check if 3-way valve is open. <input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV (EEV1, EEV2, EEV3, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 15, 16".



Check Point 3 : Check the outdoor unit fan, heat exchanger <input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check



Check Point 4 : Check the discharge temp. sensor 1 <input type="checkbox"/> Discharge temp. sensor 1 characteristics check (Check by disconnecting sensor from PCB.) * For the characteristics of the sensor, refer to the "Service Parts Information 24".



Check Point 5 : Check the refrigerant amount <input type="checkbox"/> Leak check
--

<Heating operation>

Check Point 1 : Check if 3-way valve is open. <input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.



Check Point 2 : Check the EEV, strainer <input type="checkbox"/> EEV (EEV1, EEV2, EEV3) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 15, 16".
--



After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution
 By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)
 The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)
 - The operating compressor life time becomes shorter.
 - The operating performance may drop due to the limited active compressor(s).
 - The compressor may stop frequently by protection controlling.
 *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 62 EA3. 1 OUTDOOR UNIT Error Method: Compressor 1 Temperature Abnormal	Indicate or Display: Outdoor Unit : E. A 3. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A 3
---	---

Detective Actuators: Compressor temp. sensor 1	Detective details: ▪ "Protection stop by "compressor 1 temp. $\geq 115^{\circ}\text{C}$ (239°F)during compressor 1 operation"" generated 2 times within 40 minutes.
--	---

Forecast of Cause :	1. 3-way valve not opened 2. EEV defective, strainer clogged 3. Outdoor unit operation defective, foreign matter on heat exchanger 4. Compressor 1 temp. sensor defective 5. Insufficient refrigerant
----------------------------	---

<Cooling operation>

Check Point 1 : Check if 3-way valve is open.
<input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.

↓
OK

Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2, EEV3, indoor unit EEV) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 15, 16".

↓
OK

Check Point 3 : Check the outdoor unit fan,heat exchanger
<input type="checkbox"/> Check for foreign matter at heat exchanger <input type="checkbox"/> Check if fan can be rotated by hand. <input type="checkbox"/> Motor check

↓
OK

Check Point 4 : Check the compressor 1 temp. sensor
<input type="checkbox"/> Compressor 1 temp. sensor characteristics check (Check by disconnecting sensor from PCB.) * For the characteristics of the sensor, refer to the "Service Parts Information 24".

↓
OK

Check Point 5 : Check the refrigerant amount
<input type="checkbox"/> Leak check

<Heating operation>

Check Point 1 : Check if 3-way valve is open.
<input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.

↓
OK

Check Point 2 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2, EEV3) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM oil return) Refer to "Service Parts Information 14, 15, 16".

↙
OK

After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution
By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)
The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)
- The operating compressor life time becomes shorter.
- The operating performance may drop due to the limited active compressor(s).
- The compressor may stop frequently by protection controlling.
*In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 63 EA4. 1 OUTDOOR UNIT Error Method: High Pressure Abnormal	Indicate or Display: Outdoor Unit : E. A 4. 1 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A 4
---	---

Detective Actuators: Judgment from value sensed by discharge pressure sensor	Detective details: ▪ "Protection stop by "discharge pressure \geq 580psi(4.00MPa)during operation of any compressor"" generated 3 times within 60 minutes. If the same operation (High pressure protection stop) generated 3 times within 30 minutes, compressor stops permanently.
--	--

Forecast of Cause :	1. 3-way valve not opened 2. Outdoor unit fan operation defective, foreign matter at heat exchanger, excessive ambient temperature rise 3. EEV defective, strainer clogged 4. Solenoid valve defective 5. 4-way valve (including a coil) defective 6. Discharge pressure sensor defective 7. Refrigerant overcharged
----------------------------	--

<Cooling operation>

Check Point 1 : Check if 3-way valve is open.
<input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.



Check Point 2 : Check the outdoor unit fan operation, heat exchanger, ambient temperature
<input type="checkbox"/> No foreign matter in air passage? <input type="checkbox"/> Heat exchange fins clogged <input type="checkbox"/> Outdoor unit fan motor check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?



Check Point 3 : Check the EEV, strainer
<input type="checkbox"/> EEV (EEV1, EEV2) open? <input type="checkbox"/> Strainer clogging check (before and after EEV, ACM, oil return) Refer to "Service Parts Information 14, 15".



Check Point 4 : Check the 4-way valve (4WV1, 4WV2, 4WV3)
<input type="checkbox"/> 4-way valve operation check. Refer to "Service Parts Information 18".



Check Point 5 : Check the solenoid valve (SV1, SV2)
<input type="checkbox"/> Solenoid valve operation check. Refer to "Service Parts Information 17".



Check Point 6 : Check the discharge pressure sensor
<input type="checkbox"/> Discharge pressure sensor characteristics check * For the characteristics of the discharge pressure sensor, refer to "Service Parts Information 22".



Check Point 7 : Check the refrigerant amount
<input type="checkbox"/> Refrigerant charged amount check

<Heating operation>

Check Point 1 : Check if 3-way valve is open.
<input type="checkbox"/> If the 3-way valve was closed, open the 3-way valve and check operation.



Check Point 3 : Check the EEV, strainer (indoor unit)
<input type="checkbox"/> EEV operation check <input type="checkbox"/> Check of strainers before and after EEV Refer to "Service Parts Information 13".




Caution

By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible)
 The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)

- The operating compressor life time becomes shorter.
- The operating performance may drop due to the limited active compressor(s).
- The compressor may stop frequently by protection controlling.

*In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.



Trouble shooting 65
OUTDOOR UNIT Error Method:
Low Pressure Abnormal

EA5. 1

Indicate or Display:

Outdoor Unit : E. A 5. 1

Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash,
 Filter LED Continuous Flash.

Error Code : 9 U / A 6

Detective Actuators:

Suction pressure sensor

Detective details:

- "Protection stop by "suction pressure \leq 15psi (0.10MPa) continued for 10 minutes" or "suction pressure \leq 7.25psi (0.05MPa)" during operation of any compressor"" was generated 5 times within 3 hours

Forecast of Cause :

1. 3-way valve not opened
2. Outdoor unit ambient temperature too low
3. Outdoor unit fan operation defective, foreign matter at heat exchanger
4. EEV defective, strainer clogged
5. Solenoid valve defective
6. 4-way valve defective
7. Low pressure sensor characteristics defective
8. Insufficient refrigerant

<Cooling operation>

Check Point 1 : Check if 3-way valve is open.

- ☐ If the 3-way valve was closed, open the 3-way valve and check operation.

OK

Check Point 4 : Check the indoor unit EEV, strainer clogging

- ☐ Indoor unit EEV operation check
- ☐ Strainer not clogged?

OK

Check Point 6 : Check the solenoid valve (SV1)

- ☐ Solenoid valve operation check
Refer to "Service Parts Information 17".

OK

Check Point 7 : Check the suction pressure sensor

- ☐ Suction pressure sensor characteristics check
* For the characteristics of the suction pressure sensor, refer to "Service Parts Information 22".

OK

Check Point 8 : Check the refrigerant amount

- ☐ Leak check

<Heating operation>

Check Point 1 : Check if 3-way valve is open.

- ☐ If the 3-way valve was closed, open the 3-way valve and check operation.

OK

Check Point 2 : Check the outdoor unit ambient temperature

- ☐ Outdoor ambient temperature lower than operating range?

OK

Check Point 3 :
Check the outdoor unit fan operation, heat exchanger

- ☐ No foreign matter in air passage?
- ☐ Heat exchange fins clogged
- ☐ Fan rotates?
- ☐ Outdoor unit fan motor check

OK

Check Point 4 : Check the outdoor unit EEV, strainer clogging

- ☐ Outdoor unit EEV1, EEV2 operation check
- ☐ Strainer not clogged?
Refer to "Service Parts Information 14,15".

OK

Check Point 5 : Check the 4-way valve (4WV1, 4WV2, 4WV3)

- ☐ 4-way valve operation check.
Refer to "Service Parts Information 18".



After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Trouble shooting 66 EA6. 3 OUTDOOR UNIT Error Method: Heat Ex.1 gas temp. Error	Indicate or Display: Outdoor Unit : E. A 6. 3 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A 6
--	---

Detective Actuators: Heat Ex.1 gas temp. sensor (TH7)	Detective details: ▪ Heat Ex.1 gas temp. sensor (TH7) for use as condenser (4way valve1:Off, EEV1:Open) is detected abnormally-low to High pressure saturated temp. for 4 minutes or more.
---	--

Forecast of Cause : <ol style="list-style-type: none"> 1. Heat Ex.1 gas temp. sensor (TH7) not installed correct position. 2. Heat Ex.1 gas temp. sensor (TH7) defective 3. 4-way valve1 (including a coil) defective 4. EEV1 (including a coil) defective 5. Main PCB defective
--

Check Point 1 : Check the condition of Heat Ex.1 gas temp. sensor (TH7)
<input type="checkbox"/> Check the condition of mounting of Heat Ex.1 gas temp. sensor (TH7).



Check Point 2 : Check the Heat Ex.1 gas temp. sensor (TH7)
<input type="checkbox"/> Check characteristics check. (Disconnect the Heat Ex.1 gas temp. sensor from PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check the condition of 4-way valve1 coil
<input type="checkbox"/> Check the condition of mounting of 4-way valve1 coil and 4-way valve2 coil.



Check Point 4 : Check the EEV
<input type="checkbox"/> Check the condition of mounting of EEV1 coil. <input type="checkbox"/> Check the connector connection state of EEV1, EEV2, EEV3 coil.



Check Point 5 : Replace Main PCB
<input type="checkbox"/> Check the appearance and condition of mounting of Main PCB. >> If it is abnormal, replace Main PCB. (When Main PCB is replaced, set up the original setting by Rotary, Dip, and Push SW.)



Check Point 6 : Replace 4-way valve1
<input type="checkbox"/> 1. Fully close the 3-way valve, and the refrigerant is recovered. 2. 4-way valve1 is replaced. 3. Perform vacuuming of repaired outdoor unit thoroughly , and add the refrigerant with the recovered amount. 4. Check if the error reoccurs on a test run.

After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution
 By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection.
 (Stand alone outdoor unit is impossible)
 The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.)
 - The operating compressor life time becomes shorter.
 - The operating performance may drop due to the limited active compressor(s).
 - The compressor may stop frequently by protection controlling.
 *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.

Trouble shooting 67 EA6. 4 OUTDOOR UNIT Error Method: Heat Ex.2 gas temp. Error	Indicate or Display: Outdoor Unit : E. A 6. 4 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A 6
--	---

Detective Actuators: Heat Ex.2 gas temp. sensor (TH8)	Detective details: <ul style="list-style-type: none"> Heat Ex.2 gas temp. sensor (TH8) for use as condenser (4way valve2:Off, EEV2:Open) is detected abnormally-low to High pressure saturated temp. for 4 minutes or more.
---	---

Forecast of Cause :	1. Heat Ex.2 gas temp. sensor (TH8) not installed correct position 2. Heat Ex.2 gas temp. sensor (TH8) defective 3. 4-way valve2 (including a coil) defective 4. EEV2 (including a coil) defective 5. Main PCB defective
----------------------------	--

Check Point 1 : Check the condition of Heat Ex.2 gas temp. sensor (TH8)
<input type="checkbox"/> Check the condition of mounting of Heat Ex.2 gas temp. sensor (TH8).



Check Point 2 : Check the Heat Ex.2 gas temp. sensor (TH8)
<input type="checkbox"/> Check characteristics check. (Disconnect the Heat Ex.2 gas temp. sensor from PCB and check.) * For the sensor characteristics, refer to the "Service Parts Information 24".



Check Point 3 : Check the condition of 4-way valve2 coil
<input type="checkbox"/> Check the condition of mounting of 4-way valve1 coil and 4-way valve2 coil.



Check Point 4 : Check the EEV2
<input type="checkbox"/> Check the condition of mounting of EEV2 coil. <input type="checkbox"/> Check the connector connection state of EEV1, EEV2, EEV3 coil.



Check Point 5 : Replace Main PCB
<input type="checkbox"/> Check the appearance and condition of mounting of Main PCB. >> If it is abnormal, replace Main PCB. (When Main PCB is replaced, set up the original setting by Rotary, Dip, and Push SW.)



Check Point 6 : Replace 4-way valve2
<input type="checkbox"/> 1. Fully close the 3-way valve, and the refrigerant is recovered. 2. 4-way valve2 is replaced. 3. Perform vacuuming of repaired outdoor unit thoroughly , and add the refrigerant with the recovered amount. 4. Check if the error reoccurs on a test run.

After fixing the problem and for canceling the Error, Error Reset (F3-40) will be required after power reset

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 68 EAC. 4 OUTDOOR UNIT Error Method: Outdoor unit Heat Sink Temperature Abnormal	Indicate or Display: Outdoor Unit : E. A C. 4 Indoor Unit : Operation LED 9 times Flash, Timer LED 15 Times Flash, Filter LED Continuous Flash. Error Code : 9 U / A C
---	---

Detective Actuators: Heat sink temp. sensor	Detective details: ▪ "Protection stop by "heat sink temp. $\geq 91^{\circ}\text{C}$ (195.8°F) " occurred 3 times within 60 minutes.
---	--

Forecast of Cause :	1. Foreign matter on heat sink, heat sink dirty 2. Foreign matter on heat exchanger, excessive ambient temperature rise 3. Heat sink temp. sensor defective
----------------------------	---

Check Point 1 : Check the heat sink state
<input type="checkbox"/> Heat sink foreign matter, soiling check



Check Point 2 : Check the foreign matter and ambient temperature of heat exchanger
<input type="checkbox"/> Heat exchange foreign matter check <input type="checkbox"/> Ambient temperature not raised by effect of other heat sources? <input type="checkbox"/> Discharged air not sucked in?




Check Point 3 : Check the heat sink temp. sensor
<input type="checkbox"/> Heat sink temp. sensor characteristics check (Check by disconnecting sensor from PCB.) * For the characteristics of the thermistor, refer to "Service Parts Information 24".

Caution By changing of DIP SW 4-2 to ON, the Back-up operation can start when the active outdoor unit exists on the multi outdoor unit connection. (Stand alone outdoor unit is impossible) The following conditions will be concerned in use of back-up operation. (Please do not use the system with back-up operation for long time.) - The operating compressor life time becomes shorter. - The operating performance may drop due to the limited active compressor(s). - The compressor may stop frequently by protection controlling. *In order to keep the operating capacity, the release of the Low noise mode setting might be necessary.
--

Trouble shooting 71 OUTDOOR UNIT Error Method: Initial Setting Error	Indicate or Display: Outdoor Unit : - - - - Indoor Unit : No Display Error Code : No Display * Service tool does not indicate the Error code
---	---

Detective Actuators: Outdoor unit main PCB	Detective details: <ul style="list-style-type: none"> ▪ When no communication data can be received from the Inverter PCB at the time of power ON. (In this case, "Inverters communication error" also occurs.) ▪ When no communication data can be received from the Transmission PCB at the time of power ON. (In this case, "Outdoor unit transmission PCB parallel communication error" also occurs.) Master unit: When the power is turned on, the number of connected slave units set at the master unit and the number of slave units received by communication do not match. Slave unit: When the power is turned on, not even one master unit communication data can be received.
--	---

Forecast of Cause : <ol style="list-style-type: none"> 1. Power supply defective 2. Outdoor unit address/number of connected slave units setting mistake 3. The number setting mistake of outdoor unit 4. Connection of communication line between outdoor units defective 5. Noise 6. Main PCB defective 7. Inverter PCB defective 8. Transmission PCB defective
--



4-2-10 TROUBLE SHOOTING NO ERROR CODE

Trouble shooting 72

Indoor Unit - No Power (Except wall mounted type)

Forecast of Cause :

1. Power Supply failure
2. Outside cause
3. Electrical Component defective

Check Point 1 : Power supply

- Is not the breaker down?
 - Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
 - Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
 - Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).
Check the complete insulation of grounding.

OK

Check Point 2 : Fuse of Indoor unit

- Is not open circuit ?
If the fuse was open state, check the cause of short circuit on the AC circuit before replacing the spare parts.

OK

NG (Short circuit on AC circuit)

Check Point 3 : Short circuit check on AC circuit

- Check on short circuit state step by step
1. Disconnect AC input wire on the terminal board.
 2. Disconnect Drain pump AC input connector
 3. Disconnect FAN motor AC input connector

NG (Short circuit on AC circuit)

Replace power supply PCB

NG (Short circuit)

Check Point 4 : Resistor R101

- Check Resistor R101, Open / Short circuit check

NG
(Open circuit on R101)

Replace power supply PCB

OK (Not Open)
3.3 Ohm \pm 5%

Check Point 5 : Short circuit check on DC supply circuit

- Disconnect CN102 and check short circuit step by step.
1. Check short circuit between the pin No. 1 and the pin No.6
 2. Check short circuit between the pin No. 2 and the pin No.6

OK (Open circuit)

Check Point 6 : Short circuit check on DC13.5V circuit

- Disconnect CN 4 (DC power supply) , and check short circuit between the pin No. 1 and the pin No.6 step by step
1. Disconnect EEV connector
 2. Disconnect SP motor
 3. Disconnect Wired Remote Controller
 4. Disconnect Transmission PCB

OK (Open circuit)

Check Point 7 : Short circuit check on DC5.0V circuit

- Disconnect CN 4 (DC power supply) , and check short circuit between the pin No. 2 and the pin No.6 step by step
1. Disconnect Indicator PCB
 2. Disconnect SW PCB
 3. Disconnect Transmission PCB

NG (Short circuit)

Replace Main PCB

NG (Short circuit)

Trouble shooting 73

Indoor Unit - No Power (Wall mounted type)

Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Component defective

Check Point 1 : Power supply

- ☐ Is not the breaker down?
 - Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
 - Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
 - Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).
- Check the complete insulation of grounding.

↓ **OK**

Check Point 2 : Fuse or Thermal fuse of Indoor unit

- ☐ Is not open circuit ?
If the fuse was open state, check the cause of short circuit on the AC circuit before replacing the spare parts.

↓ **NG (Short circuit on AC circuit)**

Check Point 3 : Short circuit check on AC circuit

- ☐ Disconnect AC power input wires and check short circuit

↓ **NG (Short circuit on AC circuit)**

Check Point 4 : Power supply circuit of FAN Motor

- ☐ Disconnect FAN motor and Check short circuit

↓ **NG (Short circuit)**

Replace Main PCB

NG (Short circuit)

Check Point 5 : Resistor R101

- ☐ Check Resistor R101, Open / Short circuit check

↓ **NG
(Open circuit on R101)**

↓ **OK (Not Open)
2.2 Ohm ± 5%**

Check Point 6 : Short circuit check on DC13.5V circuit

- Check short circuit between Pin No.1 and Pin No. 6 of CNB01 (DC 13.5V circuit)
1. Disconnect EEV connector
 2. Disconnect SP motor
 3. Disconnect Wired Remote Controller
 4. Disconnect Transmission PCB

↓ **OK (Open circuit)**

Check Point 7 : Short circuit check on DC5.0V circuit

- Check short circuit between Pin No.5 and Pin No. 7 of CN3 (TEST) (DC 5.0V circuit)
or
Pin No.1 and Pin No.7 of CN18
1. Disconnect Indicator PCB
 2. Disconnect SW PCB
 3. Disconnect Transmission PCB

NG (Short circuit)

Trouble shooting 74

Outdoor Unit - No Power

Forecast of Cause :

1. Power Supply failure 2. Outside cause 3. Electrical Components defective

Check Point 1 : Check Installation Condition

- ☐ Isnt the breaker down?
- ☐ Check loose or removed connection cable.
- >>If abnormal condition is found, correct it by referring to Installation Manual or Design ta & Technical Manual.**

OK

Check Point 2 : Check Outside Cause such as Voltage drop or Noise

- Instant drop ----- Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).
Check the complete insulation of grounding.

OK

Check Point 3 : Check Electrical Components

- ☐ Check the voltage of power supply.
- >> Check if AC342 - 456V appears at Outdoor Unit Terminal L1-L2, L2-L3, L3-L1.**

OK

- ☐ Check the fuse on the Filter PCB(Main).

OK

NG

- ☐ Replace the fuse.
- ☐ Recheck if the power supply terminals section is shorted.
- (Note) Always check in the power off state.

OK

NG

- ☐ Disconnect connecting cable of the Filter PCB(Main) and Main PCB and recheck. if the power supply terminals section is not shorted.
- (Note) Always check in the power off state.

OK

NG

- ☐ Disconnect the connector for the AC power input devices and check short circuit on power input cable one by one.
- Solenoid valve, 4 way valve, Heater, Mg-Relay -

☐ Replace the Filter PCB

NG

- ☐ Replace the defective device

OK

- ☐ Check short circuit on EEV's internal circuit
- Disconnect EEV from Main PCB, and check the short circuit of EEV internal circuit.
- Check Short circuit (0 Ohm) between pin No.1 and other pin No..

NG

OK

- ☐ Replace the defective device

NG (No DC5.0V)

- ☐ Check DC (5.0V) circuit on CN118
- Check DC voltage 5.0 V between pin No.1 and pin No.3

OK


- ☐ Replace Main PCB

- ☐ Check Pressure Sensor open / short after remove Transmission PCB from the Main PCB

- ☐ Replace the Pressure sensor

OK (No Short Circuit 0 Ohm)

NG (Open Circuit)



NO



Trouble shooting 76

No Operation (Power is ON)

Forecast of Cause :

1. Setting/Connection failure
2. Outside cause
3. Electrical Component defective

Check Point 1 : Check indoor and outdoor installation condition

- ❑ Indoor Unit - Check incorrect wiring between Indoor Unit- Remote Control, or terminals between Indoor Units.
Or, check if there is an open cable connection.
 - ❑ Check address setting (Are all the address of Indoor unit, Outdoor unit correct?)
 - ❑ Are these Indoor Unit, Outdoor Unit, and Remote Control suitable model numbers to connect?
- >> If there is some abnormal condition, correct it by referring to Installation manual and Design & Technical Manual.**



OK

Turn off Power and check/correct followings.

- ❑ Isn't Communication PCB of Indoor Unit removed?
- ❑ Is there loose or removed communication line of Indoor Unit and Outdoor Unit?
- ❑ Check Terminator (DIP-SW SET 5) is installed on Outdoor Main PCB.
- ❑ Check loose or removed communication line between each Outdoor Unit.
- ❑ Check loose Communication PCB of each Outdoor Unit.
- ❑ Check network cable connection between Indoor unit - Outdoor unit.



OK

Check Point 2 : Check outside cause at Indoor unit and Outdoor unit (Voltage drop or Noise)

- ⚙ Instant drop -----Check if there is a large load electric apparatus in the same circuit.
- ⚙ Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
- ⚙ Noise ----- Check if there is any equipment causing harmonic wave near electric line
(Neon bulb or electric equipment that may cause harmonic wave).
Check the complete insulation of grounding.



OK

Check Point 3 : Check Electrical Components at Indoor unit, Outdoor unit

- ❑ Indoor Unit - Check the voltage between pins 1-3 of the connector (on the control PCB) for connection with the remote controller.
In case of 2 wires WRC, Check the voltage between pins 1-2.
>> If it is DC12V, Remote Control is defective (Controller PCB is normal) >> Replace Remote Control
>> If it is DC 0V, Controller PCB is defective (Check Remote Control once again) >> Replace Controller PCB
- ❑ If some of Indoor unit does not operate, replace the Communication PCB of the non-operative Indoor Unit.
>> If the symptom does not change, replace Controller PCB of Indoor Unit.
- ❑ If all of Indoor Units do not operate, check the connection between Main PCB and Communication PCB of Outdoor Unit (Main Unit).
>> If the symptom does not change, replace Communication PCB of Outdoor Unit (Main Unit).
(If it did not work, replace Main PCB.)

Trouble shooting 77

No Cooling / No Heating

Forecast of Cause :

1. Indoor Unit error
2. Outdoor Unit error
3. Effect by Surrounding environment
4. Connection Pipe / Connection Wire failure
5. Refrigeration cycle failure

Check Point 1 : Check Indoor Unit

- ☐ Does Indoor Unit FAN run on HIGH FAN?
- ☐ Is Air Filter dirty?
- ☐ Is Heat Exchanger clogged?



Check Point 2 : Check Outdoor Unit Operation

- ☐ Check if Outdoor Unit is operating
- ☐ Check any objects that obstruct the air flow route.
- ☐ Check clogged Heat Exchanger.
- ☐ Is the pipe length setting (Push Switch "MODE/EXIT", "SELECT", "ENTER") suitable?
- ☐ Is the Valve open?



Check Point 3 : Check Site Condition

- ☐ Is capacity of Indoor Unit fitted to Room size?
- ☐ Any windows open? Or direct sunlight ?




Check Point 4 : Check Indoor/Outdoor Installation Condition

- ☐ Check connection pipe (specified pipe length & Pipe diameter?)
- ☐ Check any loose or removed communication line.
- >> If there is an abnormal condition, correct it by referring to Installation Manual or Design & Technical Manual.**





Check Point 5 : Check Refrigeration Cycle

- ☐ Check if Strainer is clogged (Refer to the figure at right).
- ☐ Measure Gas Pressure and if there is a leakage, correct it.
- >> When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.**
- ▶ Check EEV (Refer to the Service Parts Information)
- ▶ Check Solenoid Valve (Refer to the See Service Parts Information)
- ▶ Check Compressor (Refer to the See Service Parts Information)
- ▶ Check 4 way valve (Refer to the See Service Parts Information)



Attention!!

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference like shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.



Trouble shooting 78

Abnormal Noise

Forecast of Cause :

1. Abnormal installation (Indoor / Outdoor)
2. Fan failure(Indoor/Outdoor)
3. EEV failure (Indoor)
4. Compressor failure (Outdoor)

Diagnosis method when Abnormal Noise is occurred

Abnormal noise is coming from Indoor Unit
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is the installation of Air suction grille and front panel normal?
- ☐ In case of Duct type : Is Static Pressure range normal?
(Refer to Data & Technical Manual)

↓ OK

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

Attention!!

If Refrigerant Noise is occurring, Check if the Indoor and Outdoor Thermistor is wrongly installed. Check and correct the thermistor.

Abnormal noise is coming from Outdoor Unit
(Check and correct followings)

- ☐ Is Main Unit installed in stable condition?
- ☐ Is Bell Mouth installed normally?

↓ OK

- ☐ Is Fan broken or deformed?
- ☐ Is the screw of Fan loose?
- ☐ Is there any object which obstruct the Fan rotation?

↓ OK

- ☐ Check if vibration noise by loose bolt or contact noise of piping is happening.

↓ OK

- ☐ Is Compressor locked?
>> Check Compressor (Service Parts Information 2,3)

Trouble shooting 79

Water Leaking

Forecast of Cause :

1. Erroneous installation
2. Drain hose failure
3. Float Switch failure

Diagnosis method when water leak occurs

- ☐ Is Main Unit installed in stable condition?
- ☐ Is Main Unit broken or deformed at the time of transportation or maintenance?

OK

- ☐ Is Drain Hose connection loose?
- ☐ Is there a trap in Drain Hose?
- ☐ Is Drain Hose clogged?

OK

- ☐ Is Fan rotating?
>> Check Fan Motor (Service Parts Information 19, 20)

OK


- ☐ Is Float Switch defective?
>> Check Float Switch (Refer to Trouble Shooting 26)

Diagnosis method when water is spitting out

- ☐ Is the filter clogged?

OK

- ☐ Check Gas Pressure and correct it if there was a gas leak.



Attention!!

If water is leaking from the Indoor Unit that is not in operation, there is a possibility of Indoor EEV is not closed.

=> Check EEV (Service Parts Information)

Trouble shooting 80

Outdoor air unit- No Power

Forecast of Cause :

1. Power Supply failure
2. Outside cause
3. Electrical Component defective

Check Point 1 : Power supply

- ❑ Is not the breaker down?
 - Instant drop -----Check if there is a large load electric apparatus in the same circuit.
 - Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.
 - Noise ----- Check if there is any equipment causing harmonic wave near electric line (Neon bulb or electric equipment that may cause harmonic wave).
Check the complete insulation of grounding.

↓ **OK**

Check Point 2 : Check Protector (20A)

- ❑ Check protector open / short
If the protector is open circuit, replace it.

↓ **OK (No short circuit)**

Check Point 3 : Check AC line

- ❑ Check AC line (L-N) open / short

↓ **NG (Short circuit)**

Check Point 4 : Check short circuit Filter PCB

- ❑ Disconnect the wire between Filter PCB and reactor, check short circuit of AC line.
If there is short circuit, replace the Filter PCB.

↓ **OK (No short circuit)**

Check Point 5 : Check short circuit Diode bridge

- ❑ Connect the disconnected wire(s) on the check point 4, disconnect the wire between Diode bridge and Capacitor, check short circuit of AC line.
If there is short circuit, replace the Diode bridge.

↓ **OK (No short circuit)**

Check Point 6 : Check short circuit Capacitor

- ❑ Connect the disconnected wire(s) on the check point 5, disconnect the wire between Capacitor and Filter PCB, check short circuit of AC line.
If there is short circuit, replace the Capacitor.

↓ **OK (No short circuit)**

Check Point 7 : Check short circuit Power supply PCB

- ❑ Connect the disconnected wire(s) on the check point 6, disconnect the wire of Fan motor, check short circuit of AC line.
If there is short circuit, replace the Power supply PCB.

↓ **OK (No short circuit)**

Check Point 8 : Check Fan Motor

- ❑ Check open / short of FAN motor
Refer to the Service Parts Information 20.
If there is short circuit, replace FAN motor.

↓ **OK (No short circuit)**

Check Point 9 : Short circuit check on DC circuit

- Disconnect the connector (CN200) on the Power supply PCB and check the short circuit
1. DC12V line (CN200 Pin 1 - 5)
 2. DC 5V Line (CN200 Pin 1 - 3)
 3. DC 15V-1 Line (CN500 Pin 3 - 4)
 4. DC 15V-2 Line (CN530 Pin 3 - 4)
- If one of them is short circuit, replace the Power supply PCB

↓ **OK (No short circuit)**

Check Point 10 : Check short circuit of actuators (for DC12V)

- ❑ Disconnect the CN10 (EEV1) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.
If the short circuit disappears, replace the EEV coil.
- ❑ Disconnect the CNC01 (WRC) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.
If the short circuit disappears, check the WRC wire, WRC.
- ❑ Disconnect the CNB01 (Ext.Out) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.
If the short circuit disappears, check the Ext. device or wiring.
- ❑ Disconnect the CN2 (TransmissionPCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.
If the short circuit disappears, replace the Transmission PCB.
- ❑ Disconnect the CN22 (Interconnecting wire) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 5.
If the short circuit disappears, replace the Filter PCB.
- ❑ If the short circuit appears after disconnecting actuators, replace the Main PCB.

↓ **OK (No short circuit)**

Check Point 11 : Check short circuit of actuators (for DC5V)

- ❑ Disconnect the CN14 (SW PCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.
If the short circuit disappears, replace the SW PCB.
- ❑ Disconnect the CN18 (Receiver unit *Option) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.
If the short circuit disappears, check the wire, Receiver unit.
- ❑ Disconnect the CN2 (Transmission PCB) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.
If the short circuit disappears, replace the Transmission PCB.
- ❑ Disconnect the CN21 (Interconnecting wire) on the Main PCB, and check short circuit on Main PCB CN 4 Pin 1 - 3.
If the short circuit disappears, replace the Power supply PCB.
- ❑ If the short circuit appears after disconnecting actuators, replace the Main PCB.

Trouble shooting 81 INDOOR UNIT Error Method: Indoor Unit power supply error for FAN motor 1 (2)	E39. 1 (E39. 2)	Indicate or Display: Outdoor Unit :E.5 U.1 Error Code :39, 39.1(2)
---	----------------------------------	---

Detective Actuators: Indoor Unit Controller PCB Circuit Indoor Unit Power supply PCB Circuit	Detective details: When the DC power input for Fan motor < W500 - W501 (W530 - W531) on the Power supply PCB > becomes lower voltage than the specified voltage.
---	--

Forecast of Cause :	1. Noise momentary open, voltage drop 2. Wire connection 3. Fan motor 4. Peripheral electric devices 5. Power supply PCB 6. Controller PCB
----------------------------	---

Check Point 1 : Check if any outside cause such as voltage drop or noise

- ⚙ Instant voltage drop ----- Check if there is any electric equipment with a large load within the same circuit
- ⚙ Momentary power failure ---- Check contact failure or leak current in power supply circuit
- ⚙ Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave). And check the complete insulation of grounding.
 >>If the same symptom does not reappear after resetting the power, possibility of noise is high.

↓
OK

Check Point 2 : Check wire connection

- ❑ Wire lose connection / damage between the CN21 on the Controller PCB and CN250 on the Power supply PCB.
 In case of Model 72, between W530 (W531) on the Power supply PCB and Capacitor.
 >>If there is abnormal on the wire, replace it

↓
OK

Check Point 3 : Check rotation of Fan / wire resistance

- ❑ Rotate the applicable fan by hand when operation is off.
- ❑ Disconnect the connector from the Power supply PCB and Check resistance value of Motor connector.
 (Refer to the service parts information 20)

↓
OK

Check Point 4 : Check peripheral devices, Posistor, Capacitor, Diode bridge

- ❑ Check resistance value, short circuit, visible damage
 >>If there is abnormal, replace it

↓
OK

Check Point 5 : Replace Power supply PCB

- ❑ Change Power supply PCB

↓
NG

Check Point 6 : Replace Controller PCB

- ❑ Change Controller PCB and set up the original address.

Trouble shooting 82 INDOOR UNIT Error Method: Indoor unit suction air temp. thermistor error	E 4A.1 Indicate or Display: Outdoor Unit : E.5 U.1 Error Code : 4 A, 4 A. 1
---	--

<u>Detective Actuators:</u> Indoor Unit Controller PCB Circuit Suction air temp. thermistor	<u>Detective details:</u> When Indoor unit suction air temp. thermistor open or shortage is detected.
--	---

<u>Forecast of Cause :</u> 1. Connector defective connection 2. Thermistor defective 3. Controller PCB defective
--

Check Point 1 : Check connection of Connector
<input type="checkbox"/> Check if connector is loose or removed <input type="checkbox"/> Check erroneous connection <input type="checkbox"/> Check if thermistor cable is open >>Reset Power when reinstalling due to removed connector or incorrect wiring.



Check Point 2 : Remove connector and check sensor resistance value									
Sensor Characteristics (Rough value)									
Temperature (°F)	32	41	50	59	68	77	86	95	
Temperature (°C)	0	5	10	15	20	25	30	35	
Resistance Value (kΩ)	33.6	25.2	20.1	15.8	12.5	10.0	8.0	6.5	
Temperature (°F)	104	113	122						
Temperature (°C)	40	45	50						
Resistance Value (kΩ)	5.3	4.3	3.5						
► If Thermistor is either open or shorted, replace it and reset the power.									



Check Point 3 : Check voltage CN9 of Controller PCB (DC5.0V)
► If the voltage does not appear, replace Controller PCB and set up the original address.



Trouble shooting 83 E 4A.2 INDOOR UNIT Error Method: Indoor unit discharge air temp. thermistor error	Indicate or Display: Outdoor Unit : E.5 U.1 Error Code : 4 A, 4 A. 2
---	---

<u>Detective Actuators:</u> Indoor Unit Controller PCB Circuit Discharge air temp. thermistor	<u>Detective details:</u> When Indoor unit discharge air temp. thermistor open or shortage is detected.
--	---

<u>Forecast of Cause :</u> 1. Connector defective connection 2. Thermistor defective 3. Controller PCB defective
--

Check Point 1 : Check connection of Connector
<input type="checkbox"/> Check if connector is loose or removed <input type="checkbox"/> Check erroneous connection <input type="checkbox"/> Check if thermistor cable is open >>Reset Power when reinstalling due to removed connector or incorrect wiring.



Check Point 2 : Remove connector and check sensor resistance value									
Sensor Characteristics (Rough value)									
Temperature (°F)	32	41	50	59	68	77	86	95	
Temperature (°C)	0	5	10	15	20	25	30	35	
Resistance Value (kΩ)	33.6	25.2	20.1	15.8	12.5	10.0	8.0	6.5	
Temperature (°F)	104	113	122						
Temperature (°C)	40	45	50						
Resistance Value (kΩ)	5.3	4.3	3.5						
► If Thermistor is either open or shorted, replace it and reset the power.									




Check Point 3 : Check voltage CN9 of Controller PCB (DC5.0V)
► If the voltage does not appear, replace Controller PCB and set up the original address.




Trouble shooting 84 E59. 2 <u>INDOOR UNIT Error Method:</u> Indoor Unit Fan Motor 2 rotation speed Error	<u>Indicate or Display:</u> Outdoor Unit : E.5 U.1 Error Code : 5 9, 5 9. 2
---	--

<u>Detective Actuators:</u> Indoor Unit Controller PCB Circuit Indoor Fan Motor 2	<u>Detective details:</u> When the FAN motor feed back rotation value which is detecting on the controller PCB becomes 0 and lasts for more than 1 minute at motor operation condition. Or, when the feed back rotation value continues at 1/ 3 of target value for more than 1 minute.
--	--

<u>Forecast of Cause :</u>	1. Fan rotation failure 4. Capacitor failure	2. Fan motor winding open 5. Controller PCB failure	3. Motor protection by ambient temp. increase
-----------------------------------	---	--	---



Trouble shooting 85 E52. 2 INDOOR UNIT Error Method: Coil 2 (Expansion valve) Error	Indicate or Display: Outdoor Unit : E.5U.1 Indoor Unit : Operation LED 5 times Flash, Timer LED 2 Times Flash, Filter LED Continuous Flash. Error Code : 5 2
Detective Actuators: Indoor unit controller PCB	Detective details: When the EEV2 drive circuit is open circuit
Forecast of Cause : 1. Wrong capacity setting 2. EEV2 coil lose connection 3. EEV2 wire(s) cut or pinched 4. Defective EEV2 coil 5. Controller PCB (DC 12V) output abnormal 6. Noise momentary open, voltage drop	



Trouble shooting 86 OUTDOOR UNIT Error Method: Compressor Motor Loss of Synchronization	EJ6. 1 Indicate or Display: Outdoor Unit : E. 5U. 1 Indoor Unit : Operation LED 13 times Flash, Timer LED 6 times Flash, Filter LED Continuous Flash. Error Code : J 6
--	---

<u>Detective Actuators:</u> Peripheral device Error	<u>Detective details:</u> When the DX-KIT control unit received the Error input from Peripheral device Error
---	--

<u>Forecast of Cause :</u>	1. Error input connecting wire (When the External input Error input in use.) damage 2. Peripheral device Error
-----------------------------------	---

Check Point 1 : Check the wire connection of External input (Error input)
<input type="checkbox"/> Check wire between the terminal "Error input signal" of DX-KIT and the peripheral device, if it is not short circuit. If the connecting wire has the short circuit, replace the wire.

Check Point 2 : Check the Error status of peripheral device
<input type="checkbox"/> Refer to the Maintenance manual for the peripheral device.

* The type of error cannot be checked at the DX-KIT control unit.

Trouble shooting 87

Peripheral device doesn't operate

Forecast of Cause :

1. Power supply failure
2. Trouble on peripheral device
3. DX-Kit Electrical component defective
4. Field setting mismatch

General check procedure

1. Check Error code on the VRF system. (Remote controller, Service tool, etc)
2. Check LED brinks on the controller PCB of DX-KIT
3. Check Error code on the peripheral device.
4. Check non of wrong filed settings or wrong installation.

Check Point 1 : Power supply

❑ Is not the breaker down?

Instant drop ----- Check if there is a large load electric apparatus in the same circuit.

Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.

Noise ----- Check if there is any equipment causing harmonic wave near electric line
(Neon bulb or electric equipment that may cause harmonic wave).

Check the complete insulation of grounding.

↓ **OK**

Check Point 2 : LED indication on the controller PCB

LED Blinking

Check Error code indication on the remote controller or Service tool

↓ **LED ON**

Check Point 3 : Operation signal output

Short circuit

Refer to the service manual for the peripheral device and check the trouble shooting tips.

❑ Check circuit on the terminal ON /OFF SIGNAL(OUTPUT)

↓ **Open circuit**

Check Point 4 : Relay PCB power input DC12V

OK (DC12V)

Make sure that the operation command (ON signal) is transferring from the controller to the DX-Kit controller.
If the ON signal was OK, Replace the Relay PCB.

❑ Check power input CN800 Pin1 - Pin2

↓ **NG**

Make sure that the operation command (ON signal) is transferring from the Controller to the DX-Kit controller.
If the ON signal was OK, Replace the Main PCB.

Other tips

Check Field function setting, (External input signal setting)
The Prohibit setting conditions
The operating mode mismatch

Trouble shooting 88

Peripheral device FAN not operate

Forecast of Cause :

1. Power supply failure
2. Trouble on peripheral device
3. DX-Kit Electrical component defective
4. Field setting mismatch

General check procedure

1. Check Error code on the VRF system. (Remote controller, Service tool, etc)
2. Check LED brinks on the controller PCB of DX-KIT
3. Check Error code on the peripheral device.
4. Check non of wrong filed settings or wrong installation.
5. Check if FAN operation stopped by the freeze prevention or the defrosting operation.

Check Point 1 : Power supply

❑ Is not the breaker down?

Instant drop ----- Check if there is a large load electric apparatus in the same circuit.

Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.

Noise ----- Check if there is any equipment causing harmonic wave near electric line
(Neon bulb or electric equipment that may cause harmonic wave).

Check the complete insulation of grounding.

↓ **OK**

Check Point 2 : LED indication on the controller PCB

LED Blinking

Check Error code indication on the remote controller or Service tool

↓ **LED ON**

Check Point 3 : Operation signal output

❑ Check circuit on the terminal ON /OFF SIGNAL(OUTPUT)

Open circuit

Short circuit

Check Point 4 : FAN SIGNAL output

Short circuit

Refer to the service manual for the peripheral device and check the trouble shooting tips.

❑ Check circuit on the terminal FAN SIGNAL (OUTPUT)

Open circuit

Check Point 5 : Relay PCB power input DC12V

OK (DC12V)

Make sure that the operation command (ON signal) is transferring from the controller to the DX-Kit controller.
If the ON signal was OK, Replace the Relay PCB.

❑ Check power input CN800 Pin1 - Pin2

↓ **NG**

Make sure that the operation command (ON signal) is transferring from the Controller to the DX-Kit controller.
If the ON signal was OK, Replace the Main PCB.

Other tips

Check Field function setting, (External input signal setting)
The Prohibit setting conditions
The operating mode mismatch

Trouble shooting 89

Peripheral device No Cooling/ Heating

Forecast of Cause :

1. Temperature controlling
2. EEV controlling
3. External Factor

General check procedure

1. Check Error code on the VRF system. (Remote controller, Service tool, etc)
2. Check LED brinks on the controller PCB of DX-KIT
3. Check Error code on the peripheral device.
4. Check none of protection function is operating on the system.
Protection functions (For the description of protective conditions, see the service manual.)
 - Abnormal Temperature: Compressor temperature, Discharge temperature, Heat-sink temperature, IDU HEX temp.
 - Abnormal pressure: High pressure, Low pressure,
 - Abnormal on devices: EEV coil, FAN motor, Compressor Frq,

Check Point 1: Temperature sensors

Sensor position / Wire connection / Temperature detection

- Measure the resistance of sensor at the terminal board, and compare the temperature (transformed with resistance value) with the actual detecting temperature by using the Service tool.

Gas / Liquid Sensor Characteristics (Rough value)

Temperature (°F)	32	41	50	59	68	77	86	95	104	113	122
Temperature (°C)	0	5	10	15	20	25	30	35	40	45	50
Resistance Value (kOhm)	33.6	25.2	20.1	15.8	12.5	10.0	8.0	6.5	5.3	4.3	3.5

Inlet / Outlet Air Sensor Characteristics (Rough value)

Temperature (°F)	32	41	50	59	68	77	86	95	104	113	122
Temperature (°C)	0	5	10	15	20	25	30	35	40	45	50
Resistance Value (kOhm)	168.6	129.8	100.9	79.1	62.5	49.8	40.0	32.4	26.3	21.2	17.8

If the sensor position was incorrect, install the sensor to the correct position


If the temperature detection was wrong, replace the sensor.

Check Point 2: EEV

Wire connection / EEV movment

- Measure the resistance of EEV coil and measure the DC12V power input at the terminal board.
EEV1: CN10_Pin No.1 - Pin No.6, Pin No.1 - Pin No.4, Pin No.2 - Pin No.3, Pin No.2 - Pin No.5
EEV2: CN11_Pin No.1 - Pin No.6, Pin No.1 - Pin No.4, Pin No.2 - Pin No.3, Pin No.2 - Pin No.5
- Check EEV initialisation movment by the power reset of DX-Kit.
- Check refrigerant flowing by measuring the temperature of pipe inlet and pipe outlet.

Read wire	Resistance value (20°C)
White - Red	200 Ω ±10%
Yellow - Brown	
Orange - Red	
Blue - Brown	



If the resistance of EEV coil was not correct, replace the EEV unit.

If the DC12V did not appear on the terminal, check DCV power supply on CN102.

No Voltage : Replace the power supply PCB,

DC12V appears: Replace the controller PCB.

If the EEV did not react after power reset, or no refrigerant flowing, replace the EEV unit.

Check Point 3: External factor

Air circulation obstruction

Design mismatch (Capacity, FAN speed mismatch, Field setting (Analog signal input) etc,)

Peripheral device abnormal (See the Service manual for the peripheral device)

Trouble shooting 90

DX-KIT Controller No Power (LED on the Main PCB is OFF)

Forecast of Cause :

1. Power supply failure
2. DX-Kit Electrical component defective

Check Point 1 : Power supply

❑ Is not the breaker down?

Instant drop ----- Check if there is a large load electric apparatus in the same circuit.

Momentary power failure ----- Check if there is a defective contact or leak current in the power supply circuit.

Noise ----- Check if there is any equipment causing harmonic wave near electric line
(Neon bulb or electric equipment that may cause harmonic wave).

Check the complete insulation of grounding.

OK

Check Point 2 : FUSE F101 on the Power supply PCB

OPEN

Before replacing the burnt FUSE,
make sure that the terminal between
L - N - E are not short-circuit.

OK

Check Point 3 : Output voltage on the power supply PCB

NG

Replace the Power supply PCB

❑ Disconnect the CN 102 on the Power supply PCB.

Check voltage CN102 output voltage

Pin No.1 - Pin No.6 : DC12V

Pin No.2 - Pin No.6 : DC 5V

OK

Check Point 4 : Output voltage on the main PCB

NG

Replace the Main PCB

❑ Disconnect the CN 801, and the power input connectors for actuators (EEV, Sensor, Relay PCB.)

Check voltage CN801 output voltage

Pin No.1 - Pin No.2 : DC12V

OK

Check Point 5 : Check the condition of short-circuit

NG

Replace the actuators which has the
Short-circuit conditions

❑ Disconnect the power input connectors for actuators (EEV, Sensor, Relay PCB.) And check the short circuit of each actuators.

4-3 SERVICE INFORMATION

SERVICE INFORMATION


Network communication Abnormal

- Basic trouble shooting procedure -

1. Check Error code in one network segment separately, and check the Error code of (OU, IU, RC, ST)
< If the system has more than 2 Net work segments, disconnect the other Network segment.>
2. Connect Service tool to the Outdoor unit, and try out **"Address checker"** Function by the Service tool.
< Check missing indoor unit or outdoor unit by using Address checker function of Service tool>
3. Check terminal resistance value $53 \text{ Ohm} \pm 5\%$ + Line Resistance on the terminal board one by one.
< Terminal Resistance is located on the Outdoor unit PCB(activated SET 5-4 ON) >
*Refer to the wiring diagram of Network cable

Example

Terminal Resistance (A) is located on the controller PCB of Outdoor unit as the Network for Indoor unit.



4-4 SERVICE INFORMATION

SERVICE INFORMATION

Backup Operation

Details :

- Backup operation is the operating method of replacing compressor while the system is running. Compressor can be replaced without stopping the system.
- In backup operation, cooling and heating capacity is decreased by the capacity of the separated outdoor unit.
- The work procedure is as follows.


4-4-1 Backup operation

1. Method of backup operation

1-1. Backup operation when compressor of the master unit is defective.

[Procedure]


(Example: Three outdoor units are connected.)



1-2. Backup operation when compressor of the slave unit #1 is broken.

[Procedure]

(Example: Three outdoor units are connected. the slave unit #1 is broken.)



4-4-2 Work procedure after the backup operation

1. Refrigerant shortage at the backup operation

When excessive refrigerant accumulates in the defective outdoor unit during the backup operation, it becomes capacity shortage by refrigerant shortage.

The meaning of the sign

- LPS : Low pressure sensor detection value
- EEV1 : Expansion valve #1
- EEV2 : Expansion valve #2
- TH2 : Outdoor temperature sensor detection value
- TH3 : Suction temperature sensor detection value
- TH7 : Heat -Ex.1 gas temparture sensor detection value
- TH8 : Heat -Ex.2 gas temparture sensor detection value
- TH9 : Heat -Ex.1 liquid temparture sensor detection value
- TH10 : Heat -Ex.2 liquid temparture sensor detection value

<How to judge, when refrigerant is deficient>

Refrigerant shortage is judged by the information from "Service tool" during backup operation.
The outdoor unit shall enter the Cooling Main mode or Heating Main mode.

1. On Cooling operation


- ① It often creates "Low pressure protection stop".
>>> When LPS < 14.5psi(0.1MPa) for 10 minutes or When LPS < 7.25psi(0.05Mpa)
If one of this condition happens 5 times within 180 minutes, the system stops permanently.
- ② Running indoor unit's EEV is fully open condition.
>>> It displays corresponding indoor unit's EEV on the chart at the bottom of the monitor.
If there is no sign of closing the EEV from fully opened condition.

2. On Heating operation

- ① It often creates "Low pressure protection stop".
>>> When LPS < 14.5psi(0.1MPa) for 10 minutes or When LPS < 7.25psi(0.05Mpa)
If one of this condition happens 5 times within 180 minutes, the system stops permanently.
- ② EEV1 opens at 480 pulse. (fully open)
EEV2 opens at 480 pulse. (fully open)
- ③ Suction superheat is too high, when the condition is following
TH9 < Th7, TH10 < TH8, TH2 ≧ TH3
Note: The suctin SH can be larger temprary at the start up, oil recovery, defrosting.
Even if the lowpressure protection does not occur, keep watching the operating condition for a while.

<How to respond, when refrigerant is deficient>

- ① Reuse the refrigerant of the broken master unit.



Connect the high pressure service port of the broken master unit and the low pressure pipe of the broken master unit by pressure gauge.

>>> Refrigerant release from the heat exchanger of the broken master unit.
(Refrigerant is removed until refrigerant shortage is resolved)

When new refrigerant is added to the operating system, check the weight of additional refrigerant, and adjust the total refrigerant amount after repairing.

- ② Recover the remaining refrigerant in the broken master unit from the service port(s).

2. Refrigerant charging after the compressor replacement.

- ① If the amount of recovered refrigerant is available that was pulled out of outdoor unit which compressor was replaced.

(When the refrigerant is recovered by refrigerant recovery machine, and its weight is measured.)

>>> Perform vacuuming of repaired outdoor unit thoroughly, and add the refrigerant with the recovered amount.

- ② If the amount of recovered refrigerant from outdoor unit that compressor was replaced is not sure.
(When the refrigerant leakage was the case.)

>>> Once recover all units' refrigerant, and recharge the calculated amount of refrigerant
(Original amount and additional amount) again after vacuuming.


Note: To use the recovered refrigerant is not recommended in case of refrigerant leakage.
Always charge fresh refrigerant with correct amount for the system after repairing.

4-5 SERVICE PARTS INFORMATION

SERVICE PARTS INFORMATION 1

Compressor

Diagnosis method of Compressor (If Outdoor Unit 7 segment LED displays Error, refer to Trouble shooting)



Note


If it is suspected of lack of oil, we recommend also replacing OIL RETURN VALVE A ASSY(P/N 9378745056) together with Compressor.

SERVICE PARTS INFORMATION 2

Inverter Compressor


Check Point 1 : Check Connection

- ❑ Check terminal connection of Compressor (loose or incorrect wiring)
- ❑ Check connection of magnet relay (Loose or incorrect wiring)



Check Point 2 : Check Winding Resistance

- ❑ Check winding resistance of each terminal
- ▶ **If the resistance value is 0Ω or infinite, replace Compressor.**



Attention!!

If Check 1, 2 are normal, make sure the following points.

- (1) Check AC voltage among each terminals from filter PCB(INV) to Diode Bridge.
(AC208 - 230V , voltage among L1, L2 and L3).

▶ **If it does not appear, check the power supply terminal.**

- (2) Check Voltage from Main PCB to Inverter PCB.
(DC16.0 - 20.0V between terminals of CN126 (1-2) connector of Main PCB).

▶ **If it does not appear, replace Main PCB.**


- ◆ **If both of above voltages appear, it is considered to be Inverter PCB circuit failure. Replace Inverter PCB and check operation.**



SERVICE PARTS INFORMATION 3


Main PCB

Filter PCB (Main)




SERVICE PARTS INFORMATION 4

Inverter PCB Filter PCB (INV)



SERVICE PARTS INFORMATION 5

Fan Driver PCB



SERVICE PARTS INFORMATION 6


Filter PCB(INV)

Check Point 1

- Measure the resistance of Filter PCB(INV) by following procedure.
 1. Turn OFF the Outdoor unit(s) power supply
 2. Disconnect the connection wires between the Filter PCB(INV) - Inverter PCB.
 3. Measure the resistance value

Good : 300 Ohm \pm 20% (240 ~ 360 Ohm)

Filter PCB(INV) [K11CE-1100HUE-FL0]



SERVICE PARTS INFORMATION 7

IPM

(Mounted on Inverter PCB)

Check Point 1



- ① Disconnect the connection wires between the Inverter PCB - electrolytic capacitor and Inverter PCB - Inverter Compressor.

- ② Set the tester to the "Resistance" mode, and measure the resistance between the following terminals.


Red wire (P) - screw terminals U / V / W

White wire (N) - screw terminals U / V / W


- ③ Judge the result of ② as follows:

All 6 points several MΩ or greater	: Normal
1 or more points several kΩ to short	: Defective

Inverter PCB



Check Point 2



- ④ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

Tester +side (red)	Tester - side (black)	Tester display [V]
Terminal U	Red wire (P)	
Terminal V		
Terminal W		
White wire (N)	Terminal U	
	Terminal V	
	Terminal W	

- ⑤ Judge the result of ④ as follows:

All 6 points several 0.3V to 0.7V	: Normal
1 or more points under 0.1V or over load	: Defective

SERVICE PARTS INFORMATION 8

3-Phase Diode Bridge


Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at body and terminal section?
- ☐ Is the rear of the body coated with silicone grease?
- ☐ Are there no abnormalities at threaded parts (stripped threads, deformation, damage, etc.) ?

Check Point 2 : Electric check


- ① In the 3-phase diode bridge single part state, set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

Tester + side (red)	Tester - side (black)
Pin 1	Pin 4
Pin 2	
Pin 3	
Pin 5	Pin 1
	Pin 2
	Pin 3



- ② Judge the result of ① as follows:

All 6 points several 0.3V to 0.7V	Normal
1 or more points under 0.1V or over load	Defective



- ③ Set the tester to the "Diode" mode, and measure the voltage value between the following terminals.

Tester + side (red)	Tester - side (black)
Pin 4	Pin 1
	Pin 2
	Pin 3
Pin 1	Pin 5
Pin 2	
Pin 3	

- ④ Judge the result of ③ as follows:

All 6 points over load	Normal
1 or more points except over load	Defective


SERVICE PARTS INFORMATION 9

Reactor

Check Point 1 : Appearance check

- No fissures, breaks, damage, etc. at the body and winding section, terminals section?

Check Point 2 : Electric check



- ① Set the tester to the "Resistance" mode, and check for open/short between both ends of the reactor wire (or connector).

- ② Judge the result of ① as follows:

Short	: Normal
Open	: Abnormal (open)

SERVICE PARTS INFORMATION 10

Resistor, Cement

Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?

Check Point 2 : Electric check

1. Surge prevention resistor (connected to magnetic contactor)

- ① Set the tester to the "Resistance" mode, and measure the resistance value between the terminals.
(No polarity)

- ② Judge the result of ① as follows:


$5.6\ \Omega \pm 5\%$	Normal
Other than the above	Deteriorated, defective

2. Discharge resistor (connected to electrolytic capacitor)

- ① Set the tester to the "Resistance" mode, and measure the resistance value between the terminals. (No polarity)

- ② Judge the result of ① as follows:

$33\ \text{k}\Omega \pm 5\%$	Normal
Other than the above	Deteriorated, defective



SERVICE PARTS INFORMATION 11


Terminal

Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?
- ☐ Not clogged with foreign matter?
- ☐ Are there no abnormalities at threaded parts (Stripped threads, deformation, damage, etc.) ?

Check Point 2 : Electric check

- ☐ No short between adjacent terminals?
- ☐ Conducts before and after same terminal?



SERVICE PARTS INFORMATION 12

Magnetic Relay

Check Point 1 : Appearance check

- ☐ No fissures, breaks, damage, etc. at the body and terminals section?
- ☐ Are there no abnormalities at threaded parts (Stripped threads, deformation, damage, etc.) ?



Check Point 2 : Electric check

① Set the tester to the "Resistance" mode, and check for open/short between the following terminals. (No polarity)

- Between R to U
- Between S to V
- Between T to W

② Judge the result of ① as follows:

Open	: Normal
Short	: Abnormal (contacts fused)




SERVICE PARTS INFORMATION 13

Indoor Unit Electronic Expansion Valve (EEV)


Check Point 1 : Check Connections

❑ Check Connectors (Loose connector or open cable.)

Duct, Cassette, Wall mount



Floor/ Ceiling, Ceiling, Small Wall mount



Check Point 2 : Check Coil of EEV

❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value 68°F(20°C)
White - Red	200 ± 10% Ω
Yellow - Brown	
Orange - Red	
Blue - Brown	

▶ **If Resistance value is abnormal, replace EEV.**

Check Point 3 : Check Noise at start up

Turn on Power and check operation noise.

>> **If an abnormal noise does not show, replace Controller PCB.**

Check Point 4 : Check Voltage from Controller PCB


❑ Remove Connector and check Voltage (DC12V).

>> **If it does not appear, replace Controller PCB.**

Check Point 5 : Check Opening and Closing Operation of Valve


When Valve is closed,
it has a temp. difference between Inlet and Outlet.

CLOSE Example : Hot Gas





If it is open,
it has no temp. difference between Inlet and Outlet.

OPEN Example : Hot Gas



Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




SERVICE PARTS INFORMATION 14

Outdoor Unit Electronic Expansion Valve (EEV1)


Check Point 1 : Check Connections

- ❑ Check connection of connector (CN116)
(Loose connector or open cable)



Check Point 2 : Check Coil of EEV1

- ❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value 68°F(20°C)
White - Red	$46 \pm 4 \% \Omega$ 
Yellow - Red	
Orange - Red	
Blue - Red	


► **If Resistance value is abnormal, replace EEV1.**

Check Point 3 : Check Noise at start up

- ❑ Turn on Power and check operation noise.
>> If an abnormal noise does not show, replace Controller PCB.

Check Point 4 : Check Voltage from Controller PCB


- ❑ Remove Connector and check Voltage (DC12V).
>> If it does not appear, replace Controller PCB.




Check Point 5 : Check Opening and Closing Operation of Valve

Note : Check the EEV1 in the state of 4-way1 valve is ON.

When EEV1 is closed,
it has no temp. difference between Inlet and Outlet.



If it is open, it has a temp. difference between Inlet and Outlet.
Outlet temp. is near Low-pressure saturated temp.



In the following cases, even if EEV1 is closed, there may be a difference in temp.



- On comp. start-up
- Just after switching the 4-way valve1
- Just after switching the EEV1 (Open --> Close)

Note

If valve opening is 12~51pls,
the check of temp. cannot be performed.
Check temp. at the other valve opening.

Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




SERVICE PARTS INFORMATION 15

Outdoor Unit Electronic Expansion Valve (EEV2)


Check Point 1 : Check Connections

- ❑ Check connection of connector (CN117)
(Loose connector or open cable)



Check Point 2 : Check Coil of EEV2

- ❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value 68°F(20°C)
White - Red	$46 \pm 4 \% \Omega$ 
Yellow - Red	
Orange - Red	
Blue - Red	


► **If Resistance value is abnormal, replace EEV2.**

Check Point 3 : Check Noise at start up

- ❑ Turn on Power and check operation noise.
>> If an abnormal noise does not show, replace Controller PCB.

Check Point 4 : Check Voltage from Controller PCB


- ❑ Remove Connector and check Voltage (DC12V).
>> If it does not appear, replace Controller PCB.



Check Point 5 : Check Opening and Closing Operation of Valve

Note : Check the EEV2 in the state of 4-way valve2 is ON.


When EEV2 is closed,
it has no temp. difference between Inlet and Outlet.



In the following cases, even if EEV2 is closed, there may be a difference in temp.

- On comp. start-up
- Just after switching the 4-way valve2
- Just after switching the EEV2 (Open --> Close)

If it is open, it has a temp. difference between Inlet and Outlet.
Outlet temp. is near Low-pressure saturated temp.





Note

If valve opening is 12~51pls,
the check of temp. cannot be performed.
Check temp. at the other valve opening.

Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




SERVICE PARTS INFORMATION 16

Outdoor Unit Electronic Expansion Valve (EEV3)


Check Point 1 : Check Connections

- ❑ Check connection of connector (CN160)
(Loose connector or open cable)



Check Point 2 : Check Coil of EEV3

- ❑ Remove connector, check each winding resistance of Coil.

Read wire	Resistance value 68°F(20°C)
White - Red	$46 \pm 4 \% \Omega$ 
Yellow - Red	
Orange - Red	
Blue - Red	


► **If Resistance value is abnormal, replace EEV3.**

Check Point 3 : Check Noise at start up

- ❑ Turn on Power and check operation noise.
>> If an abnormal noise does not show, replace Controller PCB.


Check Point 4 : Check Voltage from Controller PCB

- ❑ Remove Connector and check Voltage (DC12V).
>> If it does not appear, replace Controller PCB.




Check Point 5 : Check Opening and Closing Operation of Valve

When EEV3 is closed,
it has no temp. difference between Inlet and Outlet.



If it is open, it has a temp. difference between Inlet and Outlet.
Outlet temp. is near Low-pressure saturated temp.





In the following cases, even if EEV3 is closed, there may be a difference in temp.
 - On comp. start-up
 - Just after switching the EEV3 (Open --> Close)

Note
 If valve opening is 12~51pls,
 the check of temp. cannot be performed.
 Check temp. at the other valve opening.

Check Point 6 : Check Strainer

Strainer normally does not have temperature difference between inlet and outlet as shown in (1), but if there is a difference as shown in (2), there is a possibility of inside clogged. In this case, replace Strainer.




SERVICE PARTS INFORMATION 17

Outdoor Unit Solenoid Valve (SV1, SV2, SV3)

Check Point 1 : Check connections

- ❑ Check connection of connector.
(Loose connector or open cable)



Check Point 2 : Check Solenoid Coil

- ❑ Remove connector and check if coil is open.

Solenoid Coil	Resistance value
SV1	1324Ω ±7%
SV2, SV3	1495Ω ±7%

Resistance value 68°F(20°C)

>> **If Resistance value is abnormal, replace Solenoid Coil.**

Check Point 3 : Check Voltage from Main PCB


- ❑ Remove connector and check the voltage (AC208- 230V).

>> **If the voltage does not appear, replace Main PCB.**


Check Point 4-1 : Check opening & closing operation of SV1, SV2

- ❑ Depending on either during operation or protection control, check if Valve is operating normally.
(When Valve opens, Inlet and Outlet temperature is raised.)


Normal Operation
Pipe (In) TEMP. Normal,
Pipe (Out) TEMP.Normal



**Protection Function (Refer to 2-6-1),
Special Operation (Defrost, Oil recovery, Start-up)**
Pipe (In) TEMP. Hi,
Pipe (Out) TEMP. Hi



- ❑ If the valve closes by removing the connector of the valve which does not close, it is considered to be Main PCB failure. Replace Main PCB.
- ❑ If it does not close by removing connector, there is a possibility of (1) clogging by dirt, or (2) deformation by the heat at the time of Solenoid Valve installation. In this case, replace Solenoid Valve.



Check Point 4-2 : Check operation of SV3

□ Check the operation noise when the connector of SV3 is removed.

- When SV3 is open

The sound of operation noise is heard ---> Normal

The sound of operation noise is not heard. ---> Replace SV3

- When SV3 is closed


The sound of operation noise is heard ---> Replace Main PCB

The sound of operation noise is not heard. ---> Normal

Comp. OFF

or Discharge temp. $\leq 50^{\circ}\text{F}(10^{\circ}\text{C})$


or Discharge temp. - High pressure saturated temp. $< 41^{\circ}\text{F}(5^{\circ}\text{C})$



Comp. ON

and Discharge temp. $> 50^{\circ}\text{F}(10^{\circ}\text{C})$

and Discharge temp. - High pressure saturated temp. $\geq 46.4^{\circ}\text{F}(8^{\circ}\text{C})$




SERVICE PARTS INFORMATION 18

4-WAY VALVE 1 (2) (3)


Check Point 1 : Check Circuit connection

- Check the connection of connector CN105 (CN156,158)



Check Point 2 : Check Solenoid Coil

- Remove CN105 (CN156,158) from PCB and check the resistance value of coil




Resistance Value
 $2.085k\Omega \pm 10\%$
 (4WV1, 4WV2)
 $1.725k\Omega \pm 10\%$
 (4WV3)

☆ If it is Open or abnormal resistance value, replace Solenoid Coil

Check Point 3: Check Operation of 4 Way Valve

- Check each piping temperature, and confirm the location of the valve by the temperature difference.



☆ If the valve location is not proper, replace 4 way valve.

Check Point 4: Check Voltage of Solenoid Coil

- If CN105 (CN156,158) of Control PCB dose not Show (AC208- 230V) during Heating operation (Compressor is in operation), replace Main PCB.


SERVICE PARTS INFORMATION 19

Indoor Unit AC Fan Motor

Check Point : ARXC36GATH (High Static Pressure Duct Type)

□ Check each winding resistance of the motor

► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	13.4 $\Omega \pm 8\%$
Red – Black	16.9 $\Omega \pm 8\%$
Red – Violet	11.5 $\Omega \pm 8\%$
Violet – Blue	13.3 $\Omega \pm 8\%$

at 20°C

Check Point : ARXC45/ 60GATH (High Static Pressure Duct Type)

□ Check each winding resistance of the motor

► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	6.84 $\Omega \pm 7\%$
Red – Black	9.78 $\Omega \pm 7\%$
Red – Violet	6.1 $\Omega \pm 7\%$
Violet – Blue	6.1 $\Omega \pm 7\%$

at 20°C

Check Point : ARXC72GATH (High Static Pressure Duct Type)

□ Check each winding resistance of the motor

► **If Resistance value is abnormal, replace motor.**




Lead wire	Resistance value
White – Red	5.25 $\Omega \pm 7\%$
Red – Black	5.02 $\Omega \pm 7\%$
Red – Pink	1.86 $\Omega \pm 7\%$
Pink – Violet	0.94 $\Omega \pm 7\%$
Violet – Blue	0.94 $\Omega \pm 7\%$

at 20°C

Check Point : ARXC90GATH (High Static Pressure Duct Type)

□ Check each winding resistance of the motor

► **If Resistance value is abnormal, replace motor.**



Lead wire	Resistance value
White – Red	4.24 $\Omega \pm 7\%$
Red – Black	4.16 $\Omega \pm 7\%$
Red – Pink	0.46 $\Omega \pm 7\%$
Pink – Violet	0.91 $\Omega \pm 7\%$
Violet – Blue	0.46 $\Omega \pm 7\%$

at 20°C

SERVICE PARTS INFORMATION 20

Indoor unit fan motor < DC motor >

⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.


Check Point 1 : Check rotation of Fan

- Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

Check Point 2 : Check resistance of Indoor Fan Motor

- Refer to below. Circuit-test "Vm" and "GND" terminal.
(Vm: DC voltage, GND: Earth terminal)
- >>If they are short-circuited (below 300 k Ω), replace Indoor fan motor**

Pin number (wire color)	Terminal function (symbol)
1 (Brown or Blue)	Feed back (FG)
2 (Yellow)	Speed command (Vsp)
3 (White)	Control voltage (Vcc)
4 (Black)	Earth terminal (GND)
5	No function
6 (Red)	DC voltage (Vm)



SERVICE PARTS INFORMATION 21

Outdoor unit fan motor


⚠ When you approach this part, please cut off the power supply and wait for a while until DC voltage has been discharged.

Check Point 1 : Check rotation of Fan


- Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
- >>If Fan or Bearing is abnormal, replace it.**

Check Point 2 : Check resistance of Outdoor Fan Motor

- Refer to below. Circuit-test " Winding coil resistance U, V, W." and the Location sensor Circuit test
- >>If they are other resistance value, replace Outdoor fan motor.**



Pin number (wire color)	Terminal function (symbol)
U (Red) - W (Black)	2.8 Ω
V (white) - U (Red)	
W (Black) - V (White)	
1 (Yellow) - 4 (Pink)	9.3 K Ω
2 (Blue) - 4 (Pink)	
3 (Orange) - 4 (Pink)	
4 (Pink) - 5 (Gray)	More than 1.2 K Ω
1 or 2 or 3 - 5 (Gray)	More than 10 K Ω



SERVICE PARTS INFORMATION 22



Discharge Pressure Sensor Suction Pressure Sensor

1. Discharge Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN118:2-3 of the Main PCB.

- Characteristics of pressure sensor



psi	0.0	14.5	29.0	43.5	58.0	72.5	101.5	116.0	130.5	145.0	174.0	203.0	232.0	261.0	290.0
MPa	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.20	1.40	1.60	1.80	2.00
Output (V)	0.50	0.58	0.66	0.74	0.82	0.90	1.06	1.14	1.22	1.30	1.46	1.62	1.78	1.94	2.10



psi	319.0	348.0	377.0	406.0	435.0	464.0	493.0	522.0	551.0	580.0	609.0	638.0	667.0	696.0	725.0
MPa	2.20	2.40	2.60	2.80	3.00	3.20	3.40	3.60	3.80	4.00	4.20	4.40	4.60	4.80	5.00
Output (V)	2.26	2.42	2.58	2.74	2.90	3.06	3.22	3.38	3.54	3.70	3.86	4.02	4.18	4.34	4.50

2. Suction Pressure Sensor

Check Point : Check Voltage from Main PCB

- With the connector connected to the PCB, measure the voltage between CN119:2-3 of the Main PCB.

- Characteristics of pressure sensor




psi	0.0	14.5	29.0	43.5	58.0	72.5	101.5	116.0	130.5	145.0	159.5	174.0	188.5	203.0	217.5
MPa	0.00	0.10	0.20	0.30	0.40	0.50	0.70	0.80	0.90	1.00	1.10	1.20	1.30	1.40	1.50
Output (V)	0.50	0.68	0.85	1.03	1.21	1.38	1.74	1.91	2.09	2.27	2.44	2.62	2.79	2.97	3.15

psi	232.0	246.5
Mpa	1.60	1.70
Output (V)	3.32	3.50

SERVICE PARTS INFORMATION 23

Pressure Switch

• Type of contact



• Characteristics of pressure switch

Contact : Short ⇒ Open	4.2±0.1MPa (609±14.5 psi)
Contact : Open ⇒ Short	3.2±0.15MPa (464±21.8 psi)


SERVICE PARTS INFORMATION 24

Thermistor

Check Point : Check Thermistor resistance value

□ Remove connector and check Thermistor resistance value.

Temperature [°F]	Temperature [°C]	Resistance Value [kΩ] / Voltage Value [V]			
		Thermistor A	Thermistor B	Thermistor C	Thermistor D
- 4	- 20	--- / ---	--- / ---	105.4 / 1.33	--- / ---
14	- 10	--- / ---	27.8 / 1.67	58.2 / 1.98	27.4 / 0.26
23	- 5	--- / ---	21.0 / 2.00	44.0 / 2.33	20.7 / 0.34
32	0	168.6 / 0.19	16.1 / 2.33	33.6 / 2.66	15.8 / 0.43
41	5	129.8 / 0.24	12.4 / 2.65	25.9 / 2.98	12.2 / 0.55
50	10	100.9 / 0.31	9.6 / 2.96	20.2 / 3.27	9.5 / 0.68
59	15	79.1 / 0.39	7.6 / 3.25	15.8 / 3.54	7.5 / 0.84
68	20	62.5 / 0.48	6.0 / 3.50	12.5 / 3.77	5.9 / 1.01
77	25	49.8 / 0.59	4.8 / 3.73	10.0 / 3.96	4.7 / 1.21
86	30	40.0 / 0.71	3.8 / 3.92	8.0 / 4.13	3.8 / 1.42
104	40	26.3 / 1.01	2.5 / 4.23	5.3 / 4.39	2.5 / 1.88
122	50	17.8 / 1.36	1.7 / 4.45	3.6 / 4.57	1.7 / 2.35
140	60	12.3 / 1.75	1.2 / 4.61	--- / ---	1.2 / 2.81
158	70	8.7 / 2.17	--- / ---	--- / ---	0.8 / 3.22
176	80	6.3 / 2.57	--- / ---	--- / ---	0.6 / 3.57
194	90	4.6 / 2.96	--- / ---	--- / ---	0.4 / 3.87
212	100	3.4 / 3.30	--- / ---	--- / ---	0.3 / 4.10
230	110	2.6 / 3.60	--- / ---	--- / ---	--- / ---
248	120	2.0 / 3.85	--- / ---	--- / ---	--- / ---
Applicable Thermistors		Discharge temp. TH1 Comp.1 temp. TH	Suction temp. TH Liquid temp. TH 1 Liquid temp. TH 2 Sub-cool heat- ex (outlet) TH Heat- ex 1 gas TH Heat- ex 2 gas TH Heat- ex 1 liquid TH Heat- ex 2 liquid TH	Outdoor temp. TH	Heat sink temp. TH






5. APPENDING DATA (UNIT)

5-1 REFRIGERANT CIRCUIT

MODELS : AJ* 072/ 090/ 108/ 126/ 144/ 162LALBH
AJ* 072/ 090/ 108/ 126/ 144/ 162LATBH



SYMBOL DESCRIPTION

● Outdoor unit

MARK	DESCRIPTION
CMP1	Compressor 1 (Inverter type)
HEX1	Heat exchanger 1
HEX2	Heat exchanger 2
FAN1	Fan 1
ACM	Accumulator
OS	Oil separator
SCHEX	Sub-cool heat exchanger
HPS	High pressure sensor
LPS	Low pressure sensor
HPSW1	High pressure sensor switch 1
4WV1	4-way valve 1
4WV2	4-way valve 2
4WV3	4-way valve 3
EEV1	Electric expansion valve 1
EEV2	Electric expansion valve 2
EEV3	Electric expansion valve 3
SV1	Solenoid valve 1
SV2	Solenoid valve 2
SV3	Solenoid valve 3
TH1	Discharge temperature thermistor 1
TH2	Outdoor temperature thermistor
TH3	Suction temperature thermistor
TH4	Liquid temperature thermistor 1
TH5	Liquid temperature thermistor 2
TH6	Sub-cool heat exchanger (outlet) thermistor
TH7	Heat exchanger 1 gas thermistor
TH8	Heat exchanger 2 gas thermistor
TH9	Heat exchanger 1 liquid thermistor
TH10	Heat exchanger 2 liquid thermistor
TH11	Compressor 1 temperature thermistor 1

Marking color
BLUE
—
RED
WHITE
BROWN
GREEN
BLACK
YELLOW
PINK
GRAY
ORANGE

● Indoor unit


MARK	DESCRIPTION
HEX21	Heat exchanger
FAN21	Fan
EEV21	Electric expansion valve
TH21	Room temperature thermistor
TH22	Heat exchanger (inlet) thermistor
TH24	Heat exchanger (outlet) thermistor

5-2 WIRING DIAGRAM

5-2-1 Indoor Unit


COMPACT CASSETTE TYPE

**MODELS : AUXB04GALH, AUXB07GA* H, AUXB09GA* H, AUXB12GA* H,
AUXB14GA* H, AUXB18GA* H, AUXB24GA* H**




CASSETTE TYPE

MODELS : AUXD18GA* H, AUXD24GA* H, AUXA18GALH, AUXA24GALH, AUXA30GA* H, AUXA36GA* H, AUXA45GA* H, AUXA54GA* H




LOW STATIC PRESSURE DUCT/ CONCEALED FLOOR TYPE

MODEL : ARXB07GALH, ARXB09GALH, ARXB12GALH
ARXB14GALH, ARXB18GALH




SLIM DUCT / SLIM CONCEALED FLOOR TYPE

MODELS : ARXD04GALH, ARXD07GA* H, ARXD09GA* H, ARXD12GA* H, ARXD14GA* H, ARXD18GA* H, ARXD24GA* H




LOW STATIC PRESSURE DUCT TYPE

MODEL : ARXB24GALH, ARXB30GALH, ARXB36GALH




MODEL : ARXB45GALH




MEDIUM STATIC PRESSURE DUCT TYPE

MODELS : ARXA24GALH, ARXA30GALH, ARXA36GALH, ARXA45GALH




MODELS : ARXA24GB* H, ARXA30GB* H, ARXA36GB* H, ARXA45GB* H




HIGH STATIC PRESSURE DUCT TYPE


MODELS : ARXC36GATH, ARXC45GATH, ARXC60GATH,




MODELS : ARXC72GATH, ARXC90GATH



MODEL : ARXC36GBTH




MODELS : ARXC72GBTH, ARXC90GBTH




FLOOR / CEILING TYPE

**MODELS : AB* A12GATH, AB* A14GATH, AB* A18GATH,
AB* A24GATH**




CEILING TYPE

**MODELS : AB* A30GATH, AB* A36GATH, AB* A45GATH,
AB* A54GATH**




WALL MOUNTED TYPE (EEV external model)

MODELS : AS* E04GACH, AS* E07GACH, AS* E09GACH,
AS* E12GACH, AS* E14GACH




WALL MOUNTED TYPE


MODELS : AS* A04GACH, AS* A07GA* H, AS* A09GA* H,
AS* A12GA* H, AS* A14GA* H




MODELS : AS* A18GA* H, AS* A24GA* H, AS* A30GA* H




MODEL : ARXH054GTAH



MODEL : ARXH072GTAH




MODEL : ARXH096GTAH




5-2-2 Outdoor Unit

**MODELS : AJ* 072LALBH, AJ* 090LALBH
AJ* 072LATBH, AJ* 090LATBH**



**MODELS : AJ* 108LALBH, AJ* 126LALBH, AJ* 144LALBH, AJ* 162LALBH
AJ* 108LATBH, AJ* 126LATBH, AJ* 144LATBH, AJ* 162LATBH**



5-3 SATURATION TABLE (R410A)

5-3-1 Saturation temperature and saturation pressure tables (°C / Mpa)


(Pressure: Gauge pressure)

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
-30	0.1722	0.1717
-29	0.1836	0.1830
-28	0.1953	0.1947
-27	0.2074	0.2067
-26	0.2199	0.2192
-25	0.2328	0.2320
-24	0.2460	0.2452
-23	0.2597	0.2588
-22	0.2737	0.2728
-21	0.2882	0.2872
-20	0.3031	0.3021
-19	0.3185	0.3174
-18	0.3343	0.3331
-17	0.3505	0.3493
-16	0.3672	0.3659
-15	0.3844	0.3830
-14	0.4021	0.4006
-13	0.4202	0.4187
-12	0.4389	0.4373
-11	0.4580	0.4563
-10	0.4776	0.4759
- 9	0.4978	0.4960
- 8	0.5185	0.5166
- 7	0.5398	0.5377
- 6	0.5616	0.5594
- 5	0.5839	0.5817
- 4	0.6069	0.6045
- 3	0.6304	0.6279
- 2	0.6545	0.6519
- 1	0.6791	0.6765
0	0.7044	0.7017
1	0.7303	0.7274
2	0.7569	0.7539
3	0.7840	0.7809
4	0.8119	0.8086
5	0.8403	0.8369
6	0.8695	0.8659
7	0.9000	0.8956
8	0.930	0.926
9	0.961	0.957
10	0.993	0.989
11	1.026	1.022
12	1.059	1.055
13	1.093	1.089
14	1.128	1.123
15	1.164	1.159
16	1.200	1.195
17	1.237	1.232

Temp. (°C)	Saturation pressure (Mpa)	
	Saturated liquid	Saturated gas
18	1.275	1.270
19	1.314	1.308
20	1.353	1.348
21	1.394	1.388
22	1.435	1.429
23	1.477	1.471
24	1.520	1.513
25	1.563	1.557
26	1.608	1.601
27	1.654	1.647
28	1.700	1.693
29	1.747	1.740
30	1.796	1.788
31	1.845	1.837
32	1.895	1.887
33	1.946	1.938
34	1.998	1.990
35	2.051	2.043
36	2.105	2.097
37	2.160	2.152
38	2.216	2.208
39	2.273	2.265
40	2.332	2.323
41	2.391	2.382
42	2.451	2.442
43	2.513	2.503
44	2.575	2.565
45	2.639	2.629
46	2.703	2.693
47	2.769	2.759
48	2.836	2.826
49	2.904	2.894
50	2.974	2.963
51	3.044	3.034
52	3.116	3.106
53	3.189	3.178
54	3.263	3.253
55	3.338	3.328
56	3.415	3.405
57	3.493	3.483
58	3.572	3.562
59	3.653	3.643
60	3.735	3.725
61	3.818	3.808
62	3.902	3.893
63	3.988	3.979
64	4.075	4.066
65	4.164	4.155

Saturation pressure (Mpa)	Saturation temperature (°C)	
	Saturated liquid	Saturated gas
0.0	-51.85	-51.83
0.1	-37.25	-37.21
0.2	-27.61	-27.55
0.3	-20.21	-20.14
0.4	-14.12	-14.04
0.5	- 8.89	- 8.80
0.6	- 4.30	- 4.20
0.7	- 0.17	- 0.06
0.8	3.58	3.69
0.9	7.02	7.15
1.0	10.22	10.35
1.1	13.21	13.34
1.2	16.01	16.15
1.3	18.66	18.80
1.4	21.17	21.31
1.5	23.55	23.70
1.6	25.83	25.98
1.7	28.01	28.16
1.8	30.10	30.25
1.9	32.11	32.26
2.0	34.04	34.20
2.1	35.91	36.06
2.2	37.72	37.87
2.3	39.46	39.62
2.4	41.16	41.31
2.5	42.80	42.95
2.6	44.40	44.55
2.7	45.95	46.10
2.8	47.47	47.62
2.9	48.94	49.09
3.0	50.38	50.53
3.1	51.78	51.93
3.2	53.16	53.30
3.3	54.50	54.63
3.4	55.81	55.94
3.5	57.09	57.22
3.6	58.35	58.48
3.7	59.58	59.70
3.8	60.79	60.91
3.9	61.98	62.09
4.0	63.14	63.25
4.1	63.99	64.38

5-3-3 Temperature and pressure of refrigerant (Graph)





6. DISASSEMBLY PROCESS


6. DISASSEMBLY / ASSEMBLY PROCESS

6.1 Indoor Unit

⚠ CAUTION

Before servicing the unit, turn the power supply switch OFF,
When you approach PWB, be sure to equip with the electrostatic removal band.
(PWB may be broken by static electricity.)

1. Indoor unit Transmisson PCB removal




 : Touchable area

1. Disconnect the connector of transmisson wire form the **Terminal - board side**.
2. Hold the PCB's both end of touchable area mentioned on the left figure.
3. Pull up the PCB one side and another side step by step.
(Do not deform the pins on the controller PCB)




2. Indoor unit Transmisson PCB install





1. Before installing transmission PCB on to the Main PCB, confirm the connector of transmisson wire was connected on the Transmission PCB.
2. Hold the PCB's both end of touchable area and adjust the position of transmission PCB based on the position of spacers on the Main PCB. (Do not attach the transmission PCB wrong position.)
*When the connection of transmission PCB and the Main PCB was wrong, the both of PCB might be broken after power supply on.
3. After adjusting the position of PCB, attach the PCB to the Main PCB.

Correct position



Incorrect position



SET1-1	SET1-2	SET1-3	SET1-4	SET2-1	Indoor unit capacity
OFF	OFF	OFF	OFF	OFF	2.2kW
ON	OFF	OFF	OFF	OFF	2.8kW
OFF	ON	OFF	OFF	OFF	3.6kW
ON	ON	OFF	OFF	OFF	4.0kW
OFF	OFF	ON	OFF	OFF	4.5kW
ON	OFF	ON	OFF	OFF	5.6kW
OFF	ON	ON	OFF	OFF	7.1kW
ON	ON	ON	OFF	OFF	8.0kW
OFF	OFF	OFF	ON	OFF	9.0kW
ON	OFF	OFF	ON	OFF	11.2kW
OFF	ON	OFF	ON	OFF	12.5kW
ON	ON	OFF	ON	OFF	14.0kW
OFF	OFF	ON	ON	OFF	18.0kW
ON	OFF	ON	ON	OFF	22.4kW
OFF	ON	ON	ON	OFF	25.0kW
ON	ON	ON	ON	OFF	28.0kW

When you need to replace the transmission PCB to new one, set the DIP-SW setting as same as the previous PCB'S setting.

6.2 Outdoor Unit

⚠ WARNING

Before servicing the unit, turn the power supply switch OFF,
Then, do not touch electric parts for 10 minutes due to the risk of electric shock.

1. Appearance




Model : AJY072/ 090LALBH


2. PANEL TOP removal



Remove the 4 mounting screws.



Remove the PANEL TOP
by sliding toward.




Hook (3 places)

3. CONTROL BOX COVER removal




Remove the 4 mounting screws.




Remove the CONTROL BOX COVER
by sliding toward.




4. Layout plan in CONTROL BOX



[Reference Data]
Model : AJY108/ 126/ 144/ 162LALBH




5. Screw tightening torque




[Reference Data]

Model : AJY108/ 126/ 144/ 162LALBH



6. Main PCB removal



⚠ CAUTION

The model name is written in Main PCB of the outdoor unit and indoor unit, and when the factory of the product is shipped, it is written. However, the model name is not written in the Main PCB supplied for the repair. When the following function is made to work, the written model name is needed.

1. Display of system list display in service tool or system controller
2. Display of refrigerant circuit diagram in service tool.
3. When you use the electricity charge calculation function as system controller or touch panel controller.




If the model name is not written, the trouble such as the refrigerant circuit diagram is not displayed or the electricity charge calculation is not done accurately might occur.

Therefore, please register the model name to each controller who uses it when you exchange Main PCB by the repair.

1. Model name registration to service tool
Please register the model name with the system list template files.
(Please see the operation manual of the service tool for details)
2. Model name registration to system controller
Please register the model name by the electricity charge calculation setting.
(Please see the operation manual of the system controller for details)

7. Inverter PCB removal




AJ*072/ 090LALBH, AJ*072/ 090LATBH



Compound

Parts Name	Service Parts No.
HEAT SINKER(20g)	0000036795


Spread the heat dissipation compound on the other side of IPM when you exchange Inverter PCB by the repair.




Compound	
Parts Name	Service Parts No.
HEAT SINKER(20g)	0000036795

Spread the heat dissipation compound on the other side of IPM when you exchange Inverter PCB by the repair.

8. Fan driver PCB removal




Remove the connectors.



Remove the 2 mounting screws and the spacers.

Note the tightening torque at the installation.
Tightening torque is as follows.

- Temporary tightening : 0.3 ± 0.1 N.m
- Final tightening : 1.3 ± 0.1 N.m



Heat sink M (AJY072/ 090)
Heat sink L (AJY108/ 126/ 144/ 162)

Heat sink K


IPM

- Spread the heat dissipation compound on the other side of IPM when you exchange Fan driver PCB by the repair.
- Spread the heat dissipation compound without a gap between the Heat sink K and Heat sink M or L.


Compound

Parts Name	Service Parts No.
HEAT SINKER(20g)	0000036795


9. PANEL BTM removal




Remove the 7 mounting screws.




Remove the PANEL BTM by sliding toward.




10. Control Box open



Remove the 2 mounting screws.



Loose or remove the cable ties.
(3 places)




Remove the locking stopper
of edging saddle.(3 places)




Remove the wires from edging saddle.
(3 places)



Remove the Wire plate
by sliding rightward.



Remove the 6 mounting screws.




Open the Control Box with handle.


11. THERMISTORS removal



Cut the cable tie.



Remove the heat insulation.



Remove the thermo spring and thermistor.

12. SOLENOID COILS (4way valve and Solenoid valves) removal



Remove the mounting screw.




Remove the SOLENOID COIL.

13. EEV COILS removal





Remove the EEV coil by hand.
There are two coils.

14. PRESSURE SENSORS removal



Remove the PRESSURE SENSOR
with wrench.
There are two sensors.
(High and Low pressure)
Note the tightening torque at the installation.
Tightening torque is $15 \pm 1.5 \text{ N}\cdot\text{m}$.

15. Fan motor removal




Remove the Fan Guard.



Remove the nut.

Note the tightening torque at the installation.
Tightening torque is from 15 to 20N·m.




Remove the Propeller fan.

Note at the installation.
Insert propeller fan and motor shaft reference
D cutting position.




Cut the cable tie.




Remove the 4 mounting screws.
Remove the Fan motor.

16. Comp box cover removal



Loose the 2 mounting screws.
Remove the 2 mounting screws.



Remove the Comp box cover
by sliding leftward and toward.




17. Compressor removal

Precautions for exchange of Compressor.


Do not allow moisture or debris to get inside refrigerant pipes during work.

Procedure for compressor removal.


- (1) Turn off power.
 - (2) Remove the Panel top and Panel btm.
 - (3) Remove the Control Box.
 - (4) Fully close the 3-way valve (Gas) and (Liquid).
 - (5) Collect the refrigerant from the service port.
- Start the following work after completely collecting the refrigerant.
Do not reuse the refrigerant that has been collected.




Remove the 4 mounting screws.
Remove the Center beam.




Loose or remove the cable ties.
(4 places)




Remove the 7 mounting screws.




Remove the Comp Box(Top)
by sliding toward.




Remove the 4 mounting screws.



Remove the Comp Box(L)
by sliding toward.




Remove the 4 mounting screws.



Remove the Comp Box(R)
by sliding toward.





Comp.cover
(Top)
Color: White&
Green

Comp. cover
(Body)
Color: White



Comp. cover
(Accumulator)
Color: white

Comp. cover
(Outside)
Color: Green


Remove the Compressor cover (Top).

Note :
Compressor cover (Top) consists of 2 parts.
The inside of the Comp.cover is white, and
the outside of Comp.cover is green.

Remove the Compressor cover (Outside),
Compressor cover (Accumulator), and
Compressor cover (Body).



Remove the Terminal Cover.



Remove the 3 mounting screws of Terminal.

[U: Red, V: White, W: Black]

Note the tightening torque at the installation.
Tightening torque is 2.0 ~2.5N·m.



Discharge temp. thermistor
(TH1)

Compressor shell temp. thermistor
(TH11)

Remove the Discharge temp. thermistor
and Compressor shell temp. thermistor.



Remove the Comp Bolts.
(4 places)




Hook (2 places)


Crank Case Heater
(2 places)

Remove the Crank Case Heaters.

Note the tightening torque at the installation.
Crank Case Heater should not overlap each other.



Cut the Discharge pipe in this range.



Cut the Suction pipe in this range.
Remove the Compressor.

Caution

- Keep their shape better.
- There is a possibility of catching fire to oil when removing by the welding without cutting it.

Procedure for compressor installation.

Reverse procedure to removing the compressor.

Precautions for installation of Compressor.

- (1) When brazing, do not apply the flame to the terminal.
- (2) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

18. Precautions for when replacing refrigerant-cycle-parts

- (1) During replacement of the following parts shall be protected by wet rag and not make the allowable temperature or more.
- (2) Remove the heat insulation when there is the heat insulation near the welding place.
Move and cool it when its detaching is difficult.
- (3) Cool the parts when there are parts where heat might be transmitted besides the replacement part.
- (4) Interrupt the flame with the fire-retardant board when the flame seems to hit the following parts directly.
- (5) Do not allow moisture or debris to get inside refrigerant pipes during work.
- (6) When brazing, be sure to replace the air in the pipe with nitrogen gas to prevent forming oxidization scale.

Part name	Allowable temperature	Precautions in work
Solenoid Valve 1 /2 /3	200°C	Remove the coil before brazing. And install the coil after brazing.
Expansion Valve 1 /2 /3	120°C	Remove the coil before brazing. And install the coil after brazing.
4-way Valve 1 /2 /3		Remove the suction temp. sensor before brazing. And install the suction temp. sensor after brazing.
Check Valve		
3-way Valve (Gas)	100°C	
3-way Valve (Liquid)		
Union Joint		Remove the pressure sensor before brazing. And install the pressure sensor after brazing.
High pressure sensor		Tighten the flare part gripping it. (Tightening torque :15±1.5N·m)
Low pressure sensor		Do the static electricity measures.
Pressure switch		



FUJITSU GENERAL LIMITED

3-3-17, Suenaga, Takatsu-ku, Kawasaki 213-8502, Japan

Product specifications are subject to change without notice.

"**AIRSTAGE**" is a worldwide trademark of FUJITSU GENERAL LIMITED.

Copyright© 2004 Fujitsu General Limited. All rights reserved.