



DISASSEMBLY ILLUSTRATION


Model: AOY90RPBMF


AOY90APBMF



Model: AOY90RPBMF
AOY90APBMF





Model: ACT 50101 DMH

PARTS LIST

Models : AOY90APBMF

OUTDOOR UNIT

Ref No.	Description	Part No. AOY90APBMF	Ord Q'ty	Ref No.	Description	Part No. AOY90APBMF	Ord Q'ty
2	FAN COVER	9366142010		330-3	JOINT PIPE C (OIL SEPA)	9369897009	
4	EMBLEM (FUJITSU)	9359836018		331	JNT PP A AS (OIL SEPA)	9369927003	
4	EMBLEM (GENERAL)	313791088308		331-1	SUCTION PIPE B ASSY	9369852008	
9	REAR PANEL PAINTED	9361712027		331-2	SUCTION PIPE A ASSY	9369925009	
12	BASE ASSY	9361684003		333	ACCUMULATOR ASSY	9369948008	
13	3-WAY VALVE ASSY	9368997007		343-1	SOLENOID SV5	9970007057	
16-1	CONDENSER ASSY 3X30	9370134018		343-2	SOLENOID SV4	9970007040	
16-2	CONDENSER ASSY 2X30	9370133028		343-3	SOLENOID SV1	9970007019	
26	COMPRESSOR COVER-A	9361935006		343-4	SOLENOID SV2	9970007026	
32	CONTROL BOX	9361713000		343-5	SOLENOID SV3	9970007033	
39	PROPELLER FAN	9361726000		347	NOISE INSULATION-D	313712304109	
41	FAN MOTOR ASSY-OUTER	9601271017		355	BRACKET(CONDENSER)-L	9361698000	
42	BRACKET PANEL(MOTOR)	9361703001		356	BRACKET(CONDENSER)-R	9361699007	
45	BRACKET(MOTOR)	9361701007		361	BUSHING	9361725003	
46-1	COMPRESSOR A ASSY	9370065008		376	BRACKET(CONTROL BOX)	9361727007	
46-2	COMPRESSOR B ASSY	9370066005		450	DISCHARGE PIPE A ASSY	9369842009	
46-3	COMPRESSOR C ASSY	9370067002		453	RECEIVER TANK ASSY	9366371007	
64	CAPACITOR(FAN MOTOR)	9703306037		477	BELL MOUTH	9361721005	
82	JNT PP (CHECK JOINT) A AS	9369889004		527	CONDENSER GUARD	9366143017	
82-1	JNT PP (CHECK JOINT) B AS	9369891007		560	FLANGE ASSY E895	9363035001	
82-2	JOINT PIPE(RECEIVER TANK)	9370832037		564	BYPASS A ASSY	9369878008	
86	GASKET	9363272000		564-1	BYPASS B ASSY	9369886003	
87	BRACKET(COMPRESSOR)	9361694002		599	SIGNAL PCB ASSY	9704424013	
100	BASE FOOT PAINTED	9361688025		620	INLET PIPE A(CONDENSER)	9369899003	
117-3	SPECIAL WASHER M6	313306391007		620-1	INLET PIPE B(CONDENSER)	9369913006	
121-3	BALL VALVE JOINT PIPE B AS	9371153018		646	COMPRESSOR COVER-B	9361936003	
132	FRONT PROTECTION NET	9366144014		678	BRACKET(THERMISTOR)	313557406106	
133	FRONT PANEL-L	9361709027		735-1	DISTRIBUTOR A ASSY	9369903007	
134	FRONT PANEL-R	9361710047		735-2	DISTRIBUTOR B ASSY	9369917004	
160	DRAIN PAN	9361700000		761	SIDE PANEL-R PAINTED	9361706026	
164	SEPARATE WALL-UPPER	9361693005		762	SIDE PANEL-L PAINTED	9361705029	
166	SEPARATE WALL-L	9361695009		791	MAGNETIC RELAY	9363277005	
167	SEPARATE WALL-R	9361696006		810	BALL VALVE-B (R22)	9361938007	
175	BRKT PNL(S VLV)	9364230009		815-1	TERMINAL 5P	9363275018	
176	BRACKET(VALVE)-A	9368955007		815-2	TERMINAL 3P	9358660027	
185	RUBBER BUSHING	313005066051		846	RELAY G2R-1A-T DC12V	9304375005	
226	REINFORCEMENT	9361697003		880-1	NETWORK (C-R)	9700987017	
236	CONTROLLER PCB ASSY	9704723017		890	BRKT PNL(COMP)ASSY	9364208008	
253	THERMISTOR ASSY	9900098018		914	OIL SEPARATOR ASSY	9369947001	
267	INSULATION(PIPE) C	9363828009		915-1	PRESSURE SENSOR	9900097011	
289	REINFORCEMENT	9361704008		942	CONTROL BOX COVER	9361716001	
310	COMPRESSOR COVER	9366132004		982-1	CORD CLAMP	9356857009	
330-2	JOINT PIPE F (OIL SEPA)	9371086002		982-2	CORD CLAMP B	9356858006	

PARTS LIST

Models : AOY90RPBMF

OUTDOOR UNIT

Ref No.	Description	Part No. AOY90RPBMF	Ord Q'ty	Ref No.	Description	Part No. AOY90RPBMF	Ord Q'ty
2	FAN COVER	9366142010		333	ACCUMULATOR ASSY	9369948008	
4	EMBLEM (FUJITSU)	9359836018		343-1	SOLENOID SV5	9970007057	
4	EMBLEM (GENERAL)	313791088308		343-2	SOLENOID SV4	9970007040	
9	REAR PANEL PAINTED	9361712027		343-3	SOLENOID SV1	9970007019	
12	BASE ASSY	9361684003		343-4	SOLENOID SV2	9970007026	
13	3-WAY VALVE ASSY	9368997007		343-5	SOLENOID SV3	9970007033	
16-1	CONDENSER ASSY 3X30	9370134018		343-6	SOLENOID 4WV1	9970008016	
16-2	CONDENSER ASSY 2X30	9370133028		343-7	SOLENOID 4WV2	9970008023	
26	COMPRESSOR COVER-A	9361935006		344-2	4-WAY VALVE 2	9353532008	
32	CONTROL BOX	9361713000		344-3	4-WAY VALVE 1	9703884009	
39	PROPELLER FAN	9361726000		347	NOISE INSULATION-D	313712304109	
41	FAN MOTOR ASSY-OUTER	9601271017		355	BRACKET(CONDENSER)-L	9361698000	
42	BRACKET PANEL(MOTOR)	9361703001		356	BRACKET(CONDENSER)-R	9361699007	
45	BRACKET(MOTOR)	9361701007		361	BUSHING	9361725003	
46-1	COMPRESSOR A ASSY	9370065008		376	BRACKET(CONTROL BOX)	9361727007	
46-2	COMPRESSOR B ASSY	9370066005		450	DISCHARGE PIPE A ASSY	9369842009	
46-3	COMPRESSOR C ASSY	9370067002		453	RECEIVER TANK ASSY	9366371007	
64	CAPACITOR(FAN MOTOR)	9703306037		477	BELL MOUTH	9361721005	
82	JNT PP (CHECK JOINT) A AS	9369889004		527	CONDENSER GUARD	9366143017	
82-1	JNT PP (CHECK JOINT) B AS	9369891007		560	FLANGE ASSY E895	9363035001	
86	GASKET	9363272000		564	BYPASS A ASSY	9369878008	
87	BRACKET(COMPRESSOR)	9361694002		564-1	BYPASS B ASSY	9369886003	
100	BASE FOOT PAINTED	9361688025		599	SIGNAL PCB ASSY	9704424013	
117-3	SPECIAL WASHER M6	313306391007		620	INLET PIPE A(CONDENSER)	9369899003	
121-1	BALL VALVE JOINT A D28.58	9369893001		620-1	INLET PIPE B(CONDENSER)	9369913006	
121-2	BALL VALVE JOINT B D12.78	9369894008		646	COMPRESSOR COVER-B	9361936003	
132	FRONT PROTECTION NET	9366144014		678	BRACKET(THERMISTOR)	313557406106	
133	FRONT PANEL-L	9361709027		735-1	DISTRIBUTOR A ASSY	9369903007	
134	FRONT PANEL-R	9361710047		735-2	DISTRIBUTOR B ASSY	9369917004	
160	DRAIN PAN	9361700000		761	SIDE PANEL-R PAINTED	9361706026	
164	SEPARATE WALL-UPPER	9361693005		762	SIDE PANEL-L PAINTED	9361705029	
166	SEPARATE WALL-L	9361695009		765	DRAIN PIPE (L-TYPE)	9301102000	
167	SEPARATE WALL-R	9361696006		790-1	BELT HEATER A 240V 35W	9361140097	
175	BRKT PNL(S VLV)	9364230009		790-2	BELT HEATER B 240V 35W	9361140080	
176	BRACKET(VALVE)-A	9368955007		790-3	BELT HEATER C 240V 25W	9361140073	
185	RUBBER BUSHING	313005066051		791	MAGNETIC RELAY	9363277005	
226	REINFORCEMENT	9361697003		810	BALL VALVE-B (R22)	9361938007	
236	CONTROLLER PCB ASSY	9704723017		815-1	TERMINAL 5P	9363275018	
253	THERMISTOR ASSY	9900098018		815-2	TERMINAL 3P	9358660027	
253-1	THERMISTOR (H.E.1)	9900099015		825	EXPANSION VALVE	9370365009	
253-2	THERMISTOR (H.E.2)	9900099022		829-1	JOINT PIPE A ASSY	9369859007	
267	INSULATION(PIPE) C	9363828009		829-2	JOINT PIPE B ASSY	9369862007	
289	REINFORCEMENT	9361704008		829-4	JOINT PIPE C	9370743005	
300	SUCTION PIPE C	9369895005		846	RELAY G2R-1A-T DC12V	9304375005	
310	COMPRESSOR COVER	9366132004		880-1	NETWORK (C-R)	9700987017	
330	JNT PP A ASSY(OIL SEPA)	9369864001		890	BRKT PNL(COMP)ASSY	9364208008	
330-1	JOINT PIPE B (OIL SEPA)	9369896002		914	OIL SEPARATOR ASSY	9369947001	
330-2	JOINT PIPE F (OIL SEPA)	9371086002		915-1	PRESSURE SENSOR	9900097011	
330-3	JOINT PIPE C (OIL SEPA)	9369897009		919-2	COIL(EXPANSION VALVE)	9370435009	
330-4	JOINT PIPE D (OIL SEPA)	9369898006		919-3	COIL(EXPANSION VALVE)	9370436006	
330-5	JOINT PIPE E ASSY(OIL SEPA)	9370730005		942	CONTROL BOX COVER	9361716001	
331	SUCTION PIPE A ASSY	9369848001		982-1	CORD CLAMP	9356857009	
331-1	SUCTION PIPE B ASSY	9369852008		982-2	CORD CLAMP B	9356858006	