


DISASSEMBLY ILLUSTRATION & PARTS LIST

OUTDOOR UNIT


Models : AJ* 126LELAH

AJ* 144LELAH




Ref No.	Description	Parts No.		
		AJ* 126LELAH	AJ* 144LELAH	
1	SERVICE PANEL SUB ASSY	9380571070	9380571070	
2	FAN GUARD	9382654009	9382654009	
3	FRONT PANEL SUB ASSY	9380569060	9380569060	
4	TOP PANEL SUB ASSY	9379416078	9379416078	
5	CABINET RIGHT SUB ASSY	9380570073	9380570073	
6	PIPE COVER FRONT	9382428006	9382428006	
7	VALVE PLATE	9382430009	9382430009	
8	PROTECTIVE NET ASSY	9378926073	9378926073	
9	THERMO HOLDER	9383182006	9383182006	
10	PROPELLER FAN	9382350000	9382350000	
11	MOTOR,DC BRUSHLESS	9603611019	9603611019	
12	MOTOR BRACKET SUB ASSY	9380566090	9380566090	
13	CONDENSER TOTAL ASSY	9382681029	9382681029	
14	SEPARATE WALL SUB ASSY	9380567066	9380567066	
15	GRIP FRONT	9382349004	9382349004	
16	NUT	0700103063	0700103063	
17	WASHER	0700132476	0700132476	

Models : AJ* 126LELAH
AJ* 144LELAH



Ref No.	Description	Parts No.	
		AJ* 126LELAH	AJ* 144LELAH
21	COMMUNICATION PCB	9707774023	9707774023
22	MAIN PCB (service unit)	9710851094	9710851094
23	FILTER PCB	9710972003	9710972003
24	INVERTER PCB (service unit)	9709682432	9709682432
25	POWER PCB	9710979002	9710979002
26	FAN DRIVER 1 (service unit)	9709682449	9709682449
27	FAN DRIVER 2 (service unit)	9709682456	9709682456
28	CT PCB	9708938004	9708938004
29	DIODE	0001113013	0001113013
30	REACTOR ASSY(INV)	9900744021	9900744021
31	REACTOR ASSY(MAIN)	9900584016	9900584016
32	TERMINAL	9900428129	9900428129
33	HEAT SINK (INV)	9383102004	9383102004
34	HEAT SINK (DB FAN)	9382540012	9382540012
35	HEAT SINK (FAN)	9382539016	9382539016
36	CONTROL BOX (MAIN PART) ASSY	9382847005	9382847005
37	CONTROL BOX (INV PART) ASSY	9382835002	9382835002

Models : AJ* 126LELAH
AJ* 144LELAH



Models : AJ* 126LELAH
AJ* 144LELAH

Ref No.	Description	Parts No.		
		AJ* 126LELAH	AJ* 144LELAH	
51	BASE SUB ASSY	9379425179	9379425179	
52	COMPRESSOR SUB ASSY	9379228060	9379228060	
53	BELT HEATER (UP)	9361140288	9361140288	
54	BELT HEATER (LO)	9361140332	9361140332	
55	RUBBER MOUNT (COMP)	9379229012	9379229012	
56	ACCUMULATOR SUB ASSY	9379221122	9379221122	
57	SUB COOL HEX ASSY	9378749290	9378749290	
58	EXPANSION VALVE ASSY	9378750227	9378750227	
59	EXPANSION VALVE (EEV 1)	9970104053	9970104053	
60	EXPANSION VALVE (EEV 2)	9900056049	9900056049	
61	COIL(EXPANSION VALVE) (EEV 1)	9970105067	9970105067	
62	COIL(EXPANSION VALVE) (EEV 2)	9970101076	9970101076	
63	DISCHARGE PIPE ASSY	9378888067	9378888067	
64	OIL SEPARATOR SUB ASSY	9383215001	9383215001	
65	PRESSURE SWITCH	9900186029	9900186029	
66	SENSOR (HP)	9970178009	9970178009	
67	SENSOR (LP)	9970178016	9970178016	
68	4-WAY VALVE SUB ASSY	9381449057	9381449057	
69	SOLENOID (4-WAY VALVE)	9970110092	9970110092	
70	3-WAY VALVE B ASSY	9379039086	9379039086	
71	3-WAY VALVE ASSY	9379039062	9379039062	
72	BYPASS VALVE ASSY	9378744141	9378744141	
73	SOLENOID (SV)	9970044052	9970044052	
74	SUCTION PIPE ASSY	9378741096	9378741096	
75	STRAINER ASSY	9371191157	9371191157	
76	COMPRESSOR COVER A	9379647120	9379647120	
77	COMPRESSOR COVER B	9379647137	9379647137	
78	COMPRESSOR COVER TOP	9379647144	9379647144	
79	COMPRESSOR WIRE	9378456068	9378456068	
--	THERMISTOR ASSY (Discharge temp.+Comp. temp.)	9900922023	9900922023	
--	THERMISTOR ASSY (Sub cool hex. temp. Liquid/ Gas.)	9900953010	9900953010	
--	THERMISTOR ASSY (Suction temp.+Heat ex. temp.)	9900956011	9900956011	
--	THERMISTOR ASSY (Outdoor temp.)	9900957018	9900957018	
--	HEAT SINK THERMISTOR	9900518004	9900518004	