




Model: AOY90TPBMF
AOY90EPBMF




Model: AOY90TPBMF
AOY90EPBMF





Model : AOY90EPBMF



MODEL : AO90TPBMF
AO90EPBMF

Ref No.	Description	Parts No. AO90TPBMF	Parts No. AO90EPBMF	Ord Q'ty	Ref No.	Description	Parts No. AO90TPBMF	Parts No. AO90EPBMF	Ord Q'ty
2	FAN COVER	9366142010	9366142010		267	INSULATION(PIPE)-C	9363828009	9363828009	
4	EMBLEM-REAR(FUJITSU)	9359836018	9359836018		285	INSU(ACCUMULATOR)	9366131007	9366131007	
4	EMBLEM-REAR(FUJITSU)	313791088308	313791088308		289	REINFORCEMENT	9361704008	9361704008	
9	REAR PANEL,PAINTED	9361712027	9361712027		300	SUCTIONPIPE C	9369895005	—	
12	BASE ASSY	9361684003	9361684003		310	COMPRESSOR COVER	9366132004	9366132004	
13	3-WAY VALVE ASSY	9374762019	9374762019		320-1	WIRE CLAMP METAL	313483219905	313483219905	
15	DRYER	9369978012	9369978012		330-1	JOINT PIPE B(OIL SEPA)	9369896002	—	
16-1	CONDENSER A ASSY	9370134049	9370134049		330-2	JOINT PIPE F(OILSEPA)	9371086002	9371086002	
16-2	CONDENSER B ASSY	9370134056	9370134056		330-3	JOINT PIPE C(OILSEPA)	9369897009	9369897009	
26-1	COMPRESSOR COVER	9370774016	9370774016		330-4	JOINT PIPE D(OILSEPA)	9369898006	9369898006	
26	COMPRESSOR COVER-A	9361935006	9361935006		330-5	JOINT PIPE E ASSY(OIL SEP	9370730005	9370730005	
32	CONTROL BOX	9361713000	9361713000		330	JOINT PIPE A ASSY(OIL SEP	9369864001	9369864001	
39	PROPELLER FAN	9361726000	9361726000		331	SUCTION PIPE A ASSY	9369848001	—	
41	FAN MOTOR ASSY-OUTER	9601271017	9601271017		331	SUCTION PIPE A ASSY	—	9370777017	
42	BRACKET PANEL(MOTOR)	9361703001	9361703001		331-1	SUCTION PIPE B ASSY	9370771015	9370771015	
45	BRACKET(MOTOR)	9361701007	9361701007		333	ACCUMULATOR ASSY	9369948008	9369948008	
46	COMPRESSOR ASSY	9367377008	9367377008		343-3	SOLENOID SV1	9970007019	9970007019	
46-1	COMPRESSOR A ASSY	9367379002	9367379002		343-4	SOLENOID SV2	9970007026	9970007026	
46-2	COMPRESSOR B ASSY	9370772012	9370772012		343-5	SOLENOID SV3	9970007033	9970007033	
64/34	CAPACITOR(FANMOTOR)	9703306037	9703306037		343-2	SOLENOID SV4	9970007040	9970007040	
69-3	BOLT,HEX.SOCKET	301210060360	301210060360		343-1	SOLENOID SV5	9970007057	9970007057	
82	JOINT,PIPE(CHECKJOINT)	9369889004	9369889004		343-6	SOLENOID 4WV1	9970008016	—	
82-1	JOINT.PIPE(CHECKJOINT)	9369891007	9369891007		343-7	SOLENOID 4WV2	9970008023	9970008023	
85	VALVEPLATE	9363063004	9363063004		344-2	4-WAYVALVE 2	9353532008	9353532008	
86	GASKET	9363272000	9363272000		344-3	4-WAYVALVE 1	9703884009	—	
87	BRACKET(COMPRESSOR)	9361694002	9361694002		347	NOISEINSULATION-D	313712304109	313712304109	
100	BASE FOOT PAINTED	9361688025	9361688025		355	BRACKET(CONDENSER)-L	9361698000	9361698000	
107	RUBBERSEAT-A	9364084008	9364084008		356	BRACKET(CONDENSER)-R	9361699007	9361699007	
108	SLEEVE-A	9364085005	9364085005		361	BUSHING	9361725003	9361725003	
109	TERMINAL COVER	9364087009	9364087009		376	BRACKET(CONTROLBOX)	9361727007	9361727007	
109-1	TERMINAL COVER	9366265009	9366265009		408/55	SPECIAL NUTM8	313252257701	313252257701	
111	TERMINAL PACKING	9364086002	9364086002		450	DICHARGPIPEAASSY	9370769012	9370769012	
111-1	TERMINAL PACKING	9366264002	9366264002		453	RECEIVER TANK ASSY	9366371007	9366371007	
117/3	SPECIAL WASHERM6	313306391007	313306391007		457-1	SOLENOID VALVE	9703889028	9703889028	
121-1	BALL VALVE JOINT A	9369893001	—		477	BELLMOUTH	9361721005	9361721005	
121-2	BALL VALVE JOINT B	9369894008	9369894008		527	CONDENSER GUARD	9366143017	9366143017	
132	FRONT PROTECTION NET	9366144014	9366144014		564	BYPASS AASSY	9369878008	9369878008	
133	FRONT PANEL-L	9361709027	9361709027		564-1	BYPASS B ASSY	9369886003	9369886003	
134	FRONT PANEL-R	9361710047	9361710047		560	FLANGE ASSY E895	9363035001	9363035001	
143-3	CLAMP NK-6N	9305657001	9305657001		599	SIGNAL PCB ASSY	9704424013	9704424013	
155	INSULATION(PIPE)B	9364739007	9364739007		620	INLET,PIPE(CONDENSER)	9369899003	9369899003	
160	DRAINPAN	9361700000	9361700000		620-1	INLET,PIPE(CONDENSER)	9369913006	9369913006	
164	SEPARATE WALL-UPPER	9361693005	9361693005		629	EMIFILTER	0400056119	0400056119	
166	SEPARATE WALL-L	9361695009	9361695009		629	EMIFILTER	0400056188	0400056188	
167	SEPARATE WALL-R	9361696006	9361696006		646	COMPRESSOR COVER-B	9361936003	9361936003	
172	PIPE COVER	9363470000	9363470000		652-1	THERM.HOLDERPIPE	313714262805	313714262805	
175	BRKT PNL(SVLV)	9364230009	9364230009		653	BOLT,FORFANMOTOR	0700145087	0700145087	
176	BRACKET(VALVE)-A	9368955007	9368955007		678	BRACKET(THERMISTOR)	313557406106	313557406106	
182	CLAMP NO.249	313361271505	313361271505		735-1	DISTORIBUTOR-A,ASSY	9369903007	9369903007	
184-1	THERMO.SPRING-A	313728262708	313728262708		735-2	DISTORIBUTOR-B,ASSY	9369917004	9369917004	
185	RUBBER BUSHING	313005066051	313005066051		760-1	INSULATION(PIPE)G	9365851005	9365851005	
193	CUSHION RUBBER	313376149201	313376149201		760-3	INSULATION(PIPE)I	9367069002	9367069002	
226	REIN FORCEMENT	9361697003	9361697003		761	SIDE PANEL-R,PAINTED	9361706026	9361706026	
236	CONTROLLER PCB ASSY	9704723017	9704723017		762	SIDE PANEL-L,PAINTED	9361705029	9361705029	
253	WIRE WITH CONNECTOR	9703878015	9703878015		765	DRAINPIPE,(L-TYPE)	9301102000	—	
253	TERMISTOR ASSY	9900098018	9900098018		790-2	BELT HEATER B	9361140158	9361140158	
253-1	TERMISTOR(H.E.1)	9900099015	—		790-1	BELT HEATER A	9361140097	9361140097	
253-2	TERMISTOR(H.E.2)	9900099022	—		790-3	BELT HEATER C	9361140073	9361140073	

**MODEL : AO90TPBMF
AO90EPBMF**

Ref No.	Description	Parts No.	Parts No.	Ord Q'ty	Ref No.	Description	Parts No.	Parts No.	Ord Q'ty
		AO90TPBMF	AO90EPBMF				AO90TPBMF	AO90EPBMF	
791	MAGNETIC RELAY	9363277005	9363277005		942	CONTROLBOXCOVER	9361716001	9361716001	
810	BALL VALVE-B	9361938007	9361938007		982-1	CORD CLAMP	9356857009	9356857009	
815-2	TERMINAL 3P	9358660027	9358660027		982-2	CORD CLAMP B	9356858006	9356858006	
815-1	TERMINAL 5P	9363275018	9363275018		994	ALLENWRENCH	9351228019	9351228019	
825	EXPANSIONVALVE ASSY	9370765014	9370765014			ACWIREG633	9367880003	9367880003	
825	EXPANSION,VALVE	9370365009	9370365009			CHECK JOINT ASSY	9366486008	9366486008	
829-1	JOINT PIPE A ASSY	9369859007	9369859007			INS(OILSEPARATOR)B	9367757008	9367757008	
829-2	JOINT PIPE B ASSY	9369862007	-----			INSTALLATION MANUAL	9370848014	9370848014	
829-2	JOINTPIPEBASSY	-----	9370775013			INSULATION(PRESSURE	9367034000	9367034000	
829-4	JOINT PIPE C	9370743005	-----			PACKING BOTTOM PAPER	9363888003	9363888003	
846	RELAY	9304375005	9304375005			PACKING WOOD-BOTTOM	9362978019	9362978019	
880-1	NETWORK(C-R)	9700987017	9700987017			PACKING WOOD-FRONT	9362979016	9362979016	
890	BRKTPNL(COMP)ASSY	9364208008	9364208008			PACKING WOOD-PROTECT	9363301014	9363301014	
914	OILSEPARATOR ASSY	9369947001	9369947001			PACKING WOOD-SIDE	9362980012	9362980012	
915-1	PRESSURE SENSOR	9900097011	9900097011			PACKING WOOD-TOP	9362981019	9362981019	
919-2	COIL(EXPANSIONVALVE	9370435009	9370435009			SWITCH,PUSH	9700450016	9700450016	
919-3	COIL(EXPANSIONVALVE	9370436006	9370436006						